


promass 83 **FOUNDATION Fieldbus** **Coriolis Mass Flow** **Measuring System**

Description of Device Functions



Operation Promass 83 FOUNDATION Fieldbus

- with local operation: see Page 5
- with FOUNDATION Fieldbus: see Page 73

Registered trademarks

HART®

Registered trademark of HART Communication Foundation, Austin, USA

S-DAT™, T-DAT™, F-CHIP™

Registered trademarks of Endress+Hauser Flowtec AG

Table of contents for local operation

1	Notes on using this manual	7
1.1	Using the table of contents to locate a function description	7
1.2	Using the graphic of the function matrix to locate a function description	7
1.3	Using the index of the function matrix to locate a function description	7
2	Function matrix	8
2.1	General layout of the function matrix	8
2.1.1	Blocks (A, B, C, etc.)	8
2.1.2	Groups (AAA, AEA, CAA, etc.)	8
2.1.3	Function groups (000, 020, 060, etc.)	8
2.1.4	Functions (0000, 0001, 0002, etc.)	8
2.1.5	Codes identifying cells	9
2.2	Function matrix PROline Promass 83	10
3	Block MEASURED VARIABLES	11
3.1	Group MEASURING VALUES	12
3.1.1	Function group MAIN VALUES	12
3.2	Group SYSTEM UNITS	13
3.2.1	Function group CONFIGURATION	13
3.2.2	Function group ADDITIONAL CONFIGURATION	16
4	Block USER INTERFACE	18
4.1	Group CONTROL	19
4.1.1	Function group BASIC CONFIGURATION	19
4.1.2	Function group UN-/LOCKING	20
4.1.3	Function group OPERATION	21
4.2	Group MAIN LINE	22
4.2.1	Function group CONFIGURATION	22
4.2.2	Function group MULTIPLEX	24
4.3	Group ADDITION LINE	26
4.3.1	Function group CONFIGURATION	26
4.3.2	Function group MULTIPLEX	29
4.4	Group INFORMATION LINE	32
4.4.1	Function group CONFIGURATION	32
4.4.2	Function group MULTIPLEX	35
5	Block TOTALIZER	38
5.1	Group TOTALIZERS (1...3)	39
5.1.1	Function group CONFIGURATION	39
5.1.2	Function group OPERATION	41
5.2	Group INVENTORY	42
5.3	Group HANDLING TOTALIZER	43

6	Block BASIC FUNCTION	44
6.1	Group FOUNDATION FIELDBUS	45
6.1.1	Function group CONFIGURATION	45
6.1.2	Function group FUNCTION BLOCKS	46
6.1.3	Function group INFORMATION	47
6.2	Group PROCESS PARAMETER	48
6.2.1	Function group CONFIGURATION	48
6.2.2	Function group EPD PARAMETER	50
6.2.3	Function group REFERENCE PARAMETER	51
6.2.4	Function group ADJUSTMENT	53
6.3	Group SYSTEM PARAMETER	55
6.3.1	Function group CONFIGURATION	55
6.4	Group SENSOR DATA	56
6.4.1	Function group CONFIGURATION	56
6.4.2	Function group FLOW COEFFICIENT	57
6.4.3	Function group DENSITY COEFFICIENT	58
6.4.4	Function group ADDITIONAL COEFFICIENT	60
7	Block SUPERVISION	61
7.1	Group SYSTEM	62
7.1.1	Function group OPERATION	62
7.2	Group VERSION-INFO	64
7.2.1	Function group SENSOR	64
7.2.2	Function group AMPLIFIER	65
7.2.3	Function group I/O MODULE	66
8	Index key words for function matrix	67
9	Index key words for local operation	69

1 Notes on using this manual

There are various ways of locating the description of a function of your choice in the manual:

1.1 Using the table of contents to locate a function description

The designations of all the cells in the function matrix are listed in the table of contents. You can use these unambiguous designations (such as MEASURED VARIABLES, USER INTERFACE, TOTALIZER, etc.) to choose whichever functions are applicable to a particular set of conditions. The page references show you exactly where to find the detailed descriptions of the functions in question. The table of contents is on Page 3.

1.2 Using the graphic of the function matrix to locate a function description


This step-by-step, top-down approach starts with the blocks, the highest level, and works down through the matrix to the description of the function you need:

- 1. All available blocks and their corresponding subgroups are shown on Page 10. Select the block (or the group within the block) which you need for your application and use the page reference to locate the information corresponding to the next level.
- 2. The page in question contains a graphic showing of the block with all its subordinate groups, function groups and functions. Select the function which you need for your application and use the page reference to locate the detailed function description.

1.3 Using the index of the function matrix to locate a function description

Each "cell" in the function matrix (blocks, groups, function groups, functions) has a unique identifier in the form of a code consisting of one or three letters or a three- or four-digit number. The code identifying a selected "cell" appears at the top right on the local display.

Example:




The function-matrix index lists the codes for all the available "cells" in alphabetic and consecutive order, complete with the page references for the corresponding functions. The index to the function matrix is on Page 67.

2 Function matrix

2.1 General layout of the function matrix

The function matrix consists of four levels:

Blocks -> Groups -> Function groups -> Functions



2.1.1 Blocks (A, B, C, etc.)

The blocks are the highest-level grouping of the operation options for the device. The blocks include, for example: MEASURED VARIABLES, QUICK SETUP, USER INTERFACE, TOTALIZER, etc.

2.1.2 Groups (AAA, AEA, CAA, etc.)

A block consists of one or more groups. Each group represents a more detailed selection of the operation options in the higher-order block. The groups in the "USER INTERFACE" block, for example, include: CONTROL, MAIN LINE, ADDITION LINE, etc.

2.1.3 Function groups (000, 020, 060, etc.)

A group consists of one or more function groups. Each function group represents a more detailed selection of the operation options in the higher-order group. The function groups in the "CONTROL" group, for example, include: BASIC CONFIGURATION, UN/LOCKING, OPERATION, etc.

2.1.4 Functions (0000, 0001, 0002, etc.)

Each function group consists of one or more functions. The functions are used to operate and parameterize the device. Numerical values can be entered resp. parameters selected and saved.

The functions in the "BASIC CONFIGURATION" function group include LANGUAGE, DISPLAY DAMPING, CONTRAST LCD, etc. The procedure for changing the language of the user interface, for example, is as follows:

1. Select the "USER INTERFACE" block
2. Select the "CONTROL" group
3. Select the "BASIC CONFIGURATION" function group
4. Select the "LANGUAGE" function (this is where the language can be selected).

2.1.5 Codes identifying cells

Each cell (block, group, function group and function) in the function matrix has an individual, unique code.

Blocks:

The code is a letter (A, B, C, etc.)

Groups:

The code consists of three letters (AAA, ABA, BAA, etc.).

The first letter matches the block code (i.e. each group in block A has a code starting with an "A", in other words A _ _; the codes of the groups in block B start with a "B", in other words B _ _ , and so on). The other two letters are for identifying the group within the respective block.

Function groups:


The code consists of three digits (000, 001, 100, etc.)

Functions:

The code consists of four digits (0000, 0001, 0201, etc.).

The first three digits are the same as the code for the function group.


The last digit in the code is a counter for the functions in the function group, incrementing from 0 to 9 (e.g. function 0005 is the sixth function in group 000).



2.2 Function matrix PROline Promass 83

BLOCKS		GROUPS		FUNCTION GROUPS								
MEASURED VARIABLES A (see Page 11)	→	<table><tr><td>MEASURING VALUES</td><td>AAA</td></tr><tr><td>SYSTEM UNITS</td><td>ACA</td></tr></table>	MEASURING VALUES	AAA	SYSTEM UNITS	ACA	→	see Page 12 see Page 13				
MEASURING VALUES	AAA											
SYSTEM UNITS	ACA											
↓												
USER INTERFACE C (see Page 18)	→	<table><tr><td>CONTROL</td><td>CAA</td></tr><tr><td>MAIN LINE</td><td>CCA</td></tr><tr><td>ADDITION LINE</td><td>CEA</td></tr><tr><td>INFORMATION LINE</td><td>CGA</td></tr></table>	CONTROL	CAA	MAIN LINE	CCA	ADDITION LINE	CEA	INFORMATION LINE	CGA	→	see Page 19 see Page 22 see Page 26 see Page 32
CONTROL	CAA											
MAIN LINE	CCA											
ADDITION LINE	CEA											
INFORMATION LINE	CGA											
↓												
TOTALIZER D (see Page 38)	→	<table><tr><td>TOTALIZER (1...3)</td><td>DAA, -B, -C</td></tr><tr><td>INVENTORY</td><td>DGA</td></tr><tr><td>HANDLING TOTALIZER</td><td>DJA</td></tr></table>	TOTALIZER (1...3)	DAA, -B, -C	INVENTORY	DGA	HANDLING TOTALIZER	DJA	→	see Page 39 see Page 42 see Page 43		
TOTALIZER (1...3)	DAA, -B, -C											
INVENTORY	DGA											
HANDLING TOTALIZER	DJA											
↓												
BASIC FUNCTION G (see Page 44)	→	<table><tr><td>FOUND. FIELDBUS</td><td>GGA</td></tr><tr><td>PROCESS PARAMETER</td><td>GIA</td></tr><tr><td>SYSTEM PARAMETER</td><td>GLA</td></tr><tr><td>SENSOR DATA</td><td>GNA</td></tr></table>	FOUND. FIELDBUS	GGA	PROCESS PARAMETER	GIA	SYSTEM PARAMETER	GLA	SENSOR DATA	GNA	→	see Page 45 see Page 48 see Page 55 see Page 56
FOUND. FIELDBUS	GGA											
PROCESS PARAMETER	GIA											
SYSTEM PARAMETER	GLA											
SENSOR DATA	GNA											
↓												
SUPERVISION J (see Page 61)	→	<table><tr><td>SYSTEM</td><td>JAA</td></tr><tr><td>VERSION-INFO</td><td>JCA</td></tr></table>	SYSTEM	JAA	VERSION-INFO	JCA	→	see Page 62 see Page 64				
SYSTEM	JAA											
VERSION-INFO	JCA											

3 Block MEASURED VARIABLES



3.1 Group MEASURING VALUES


3.1.1 Function group MAIN VALUES

MEASURED VARIABLES A ⇒ MEASURING VALUES AAA ⇒ MAIN VALUES 000

Function description MEASURED VARIABLES → MEASURING VALUES → MAIN VALUES	
 Note! - The units of measure of all the measured variables shown here can be set in the "SYSTEM UNITS" group. - If the fluid in the pipe flows backwards, a negative sign prefixes the flow reading on the display.	
MASS FLOW (0000)	The currently measured mass flow appears on the display. Display shows: 5-digit floating-point number, including unit and sign (e.g. 462.87 kg/h; -731.63 lb/min; etc.)
VOLUME FLOW (0001)	The volume flow appears on the display. The volume flow is derived from the measured mass flow and the measured density of the fluid. Display shows: 5-digit floating-point number, including unit and sign (e.g. 5.5445 dm³/min; 1.4359 m³/h; -731.63 gal/d; etc.)
CORRECTED VOLUME FLOW (0004)	The corrected volume flow appears on the display. The corrected volume flow is derived from the measured mass flow and the reference density (density at reference temperature, measured or fixed entry) of the fluid. Display shows: 5-digit floating-point number, including unit and sign (e.g. 1.3549 Nm³/h; 7.9846 scm/day; etc.)
DENSITY (0005)	The currently measured density or its specific gravity appears on the display. Display shows: 5-digit floating-point number, including unit corresponding to 0.100000...6.00000 kg/dm³ (e.g. 1.2345 kg/dm³; 993.5 kg/dm³; 1.0015 SG_20 °C; etc.)
REFERENCE DENSITY (0006)	The density of the fluid, at reference temperature, appears on the display. The reference density can either be measured or entered as a fixed value (see FIXED REFERENCE DENSITY (6461) function on Page 51). Display shows: 5-digit floating-point number, including unit corresponding to 0.100000...6.00000 kg/dm³ (e.g. 1.2345 kg/dm³; 993.5 kg/dm³; 1.0015 SG_20 °C; etc.)
TEMPERATURE (0008)	The currently measured temperature appears on the display. Display shows: max. 4-digit fixed-point number, including unit and sign (e.g. -23.4 °C; 160.0 °F; 295.4 K; etc.)

3.2 Group SYSTEM UNITS

3.2.1 Function group CONFIGURATION




Function description	
MEASURED VARIABLES → SYSTEM UNITS → CONFIGURATION	
You can select the units for measured variables in this function group.  Note! The units selected here have no effect on the Fieldbus. They are only used for the local display and for assigned instrument functions.	
UNIT MASS FLOW (0400)	Use this function to select the unit for displaying the mass flow (mass/time). The unit you select here is also valid for: • Switching points (limit value for mass flow, flow direction) • Low flow cut off Options: Metric: gram → g/s; g/min; g/h; g/day kilogram → kg/s; kg/min; kg/h; kg/day ton → t/s; t/min; t/h; t/day US: ounce → oz/s; oz/min; oz/h; oz/day pound → lb/s; lb/min; lb/h; lb/day ton → ton/s; ton/min; ton/h; ton/day Factory setting: kg/h
UNIT MASS (0401)	Use this function to select the unit for displaying the mass. The unit you select here is also valid for: • Pulse weighting (e.g. kg/p) Options: Metric → g; kg; t US → oz; lb; ton Factory setting: kg  Note! The unit of the totalizers is independent of your choice here. The unit for each totalizer is selected separately for the totalizer in question.

Function description MEASURED VARIABLES → SYSTEM UNITS → CONFIGURATION	
UNIT VOLUME FLOW (0402)	Use this function to select the unit for displaying the volume flow (volume/time). The unit you select here is also valid for: - Switching points (limit value for volume flow, flow direction) - Low flow cut off Options: Metric: Cubic centimeter → cm³/s; cm³/min; cm³/h; cm³/day Cubic decimeter → dm³/s; dm³/min; dm³/h; dm³/day Cubic meter → m³/s; m³/min; m³/h; m³/day Milliliter → ml/s; ml/min; ml/h; ml/day Liter → l/s; l/min; l/h; l/day Hectoliter → hl/s; hl/min; hl/h; hl/day Megaliter → Ml/s; Ml/min; Ml/h; Ml/day US: Cubic centimeter → cc/s; cc/min; cc/h; cc/day Acre foot → af/s; af/min; af/h; af/day Cubic foot → ft³/s; ft³/min; ft³/h; ft³/day Fluid ounce → oz f/s; oz f/min; oz f/h; oz f/day Gallon → gal/s; gal/min; gal/h; gal/day Million gallon → Mgal/s; Mgal/min; Mgal/h; Mgal/day Barrel (normal fluids: 31.5 gal/bbl) → bbl/s; bbl/min; bbl/h; bbl/day Barrel (beer: 31.0 gal/bbl) → bbl/s; bbl/min; bbl/h; bbl/day Barrel (petrochemicals: 42.0 gal/bbl) → bbl/s; bbl/min; bbl/h; bbl/day Barrel (filling tanks: 55.0 gal/bbl) → bbl/s; bbl/min; bbl/h; bbl/day Imperial: Gallon → gal/s; gal/min; gal/h; gal/day Mega gallon → Mgal/s; Mgal/min; Mgal/h; Mgal/day Barrel (beer: 36.0 gal/bbl) → bbl/s; bbl/min; bbl/h; bbl/day Barrel (petrochemicals: 42.0 gal/bbl) → bbl/s; bbl/min; bbl/h; bbl/day Factory setting: m³/h
UNIT VOLUME (0403)	Use this function to select the unit for displaying the volume. The unit you select here is also valid for: Pulse weighting (e.g. m³/p) Options: Metric → cm³; dm³; m³; ml; l; hl; Ml US → cc; af; ft³; oz f; gal; Mgal; bbl (normal fluids); bbl (beer); bbl (petrochemicals); bbl (filling tanks) Imperial → gal; Mgal; bbl (beer); bbl (petrochemicals) Factory setting: m³  Note! The unit of the totalizers is independent of your choice here. The unit for each totalizer is selected separately for the totalizer in question.

Function description	
MEASURED VARIABLES → SYSTEM UNITS → CONFIGURATION	
UNIT CORRECTED VOLUME FLOW (0404)	Use this function to select the unit for displaying the corrected volume flow (corrected volume/time). The unit you select here is also valid for: • Switching points (limit value for corrected volume flow, flow direction) • Low flow cut off Options: Metric: Nl/s Nl/min Nl/h Nl/day Nm³/s Nm³/min Nm³/h Nm³/day US: Sm³/s; Sm³/min; Sm³/h; Sm³/day Scf/s; Scf/min; Scf/h; Scf/day Factory setting: Nm³/h
UNIT CORRECTED VOLUME (0405)	Use this function to select the unit for displaying the corrected volume. The unit you select here is also valid for: • Pulse weighting (e.g. Nm³/p) Options: Metric: Nm³ Nl US: Sm³ Scf Factory setting: Nm³  Note! The unit of the totalizers is independent of your choice here. The unit for each totalizer is selected separately for the totalizer in question.


3.2.2 Function group ADDITIONAL CONFIGURATION



Function description	
MEASURED VARIABLES → SYSTEM UNITS → ADDITIONAL CONFIGURATION	
Note! The units selected here have no effect on the Fieldbus. They are only used for the local display and for assigned instrument functions.	
UNIT DENSITY (0420)	Use this function to select the unit for displaying the fluid density. The unit you select here is also valid for: - Switching points (limit value for density) - Density adjustment value - Density response value for EPD Options: Metric → g/cm³; g/cc; kg/dm³; kg/l; kg/m³; SD 4 °C, SD 15 °C, SD 20 °C; SG 4 °C, SG 15 °C, SG 20 °C US → lb/ft³; lb/gal; lb/bbl (normal fluids); lb/bbl (beer); lb/bbl (petrochemicals); lb/bbl (filling tanks) Imperial → lb/gal; lb/bbl (beer); lb/bbl (petrochemicals) Factory setting: kg/l SD = Specific Density, SG = Specific Gravity The specific density is the ratio of fluid density to water (at water temperature = 4, 15, 20 °C)
UNIT REFERENCE DENSITY (0421)	Use this function to select the unit for displaying the reference density. The unit you select here is also valid for: - Switching points (limit value for density) - Fixed reference density (for calculation of corrected volume flow) Options: Metric: kg/Nm³ kg/Nl US: g/Scg kg/Sm³ lb/Scf Factory setting: kg/Nl

Function description MEASURED VARIABLES → SYSTEM UNITS → ADDITIONAL CONFIGURATION	
UNIT TEMPERATURE (0422)	Use this function to select the unit for displaying the temperature. The unit you select here is also valid for: - Switching points (limit value for temperature) - Reference temperature (for corrected volume measurement with measured reference density) Options: °C (Celsius) K (Kelvin) °F (Fahrenheit) R (Rankine) Factory setting: °C
UNIT LENGTH (0424)	Use this function to select the unit for displaying the length for nominal diameter. The unit you select here is valid for: Nominal diameter of the sensor (see the NOMINAL DIAMETER (6804) function on Page 56). Options: MILLIMETER INCH Factory setting: MILLIMETER

4 Block USER INTERFACE



4.1 Group CONTROL

4.1.1 Function group BASIC CONFIGURATION

USER INTERFACE C

⇒


CONTROL CAA

⇒

BASIC CONFIGURATION 200


Function description	
USER INTERFACE → CONTROL → BASIC CONFIGURATION	
LANGUAGE (2000)	Use this function to select the language for all texts, parameters and messages shown on the local display. Options: ENGLISH DEUTSCH FRANCAIS ESPANOL ITALIANO NEDERLANDS DANSK NORSK SVENSKA SUOMI BAHASA INDONESIA JAPANESE (syllabary)  Note! If you press the  keys simultaneously during startup, the language defaults to "ENGLISH".
DISPLAY DAMPING (2002)	Use this function to enter a time constant defining how the display reacts to severely fluctuating flow variables, either very quickly (enter a low time constant) or with damping (enter a high time constant). User input: 0...100 seconds Factory setting: 1 s  Note! Setting the time constant to zero seconds switches off damping.
CONTRAST LCD (2003)	Use this function to optimize display contrast to suit local operating conditions. User input: 10...100% Factory setting: 50%

4.1.2 Function group UN-/LOCKING



Function description USER INTERFACE → CONTROL → UN-/LOCKING	
ACCESS CODE (2020)	All data of the measuring system are protected against inadvertent change. Programming is disabled and the settings cannot be changed until a code is entered in this function. If you press the  key in any function the measuring system automatically goes to this function and the prompt to enter the code appears on the display (programming disabled). You can enable programming by entering the personal code (Factory setting = 83, see the DEFINE PRIVATE CODE (2021) function). User input: max. 4-digit number: 0...9999  Note! • The programming levels are disabled if you do not press a key within 60 seconds following automatic return to the HOME position. • You can also disable programming in this function by entering any number (other than the defined private code). • The Endress+Hauser service organization can be of assistance if you mislay your personal code. • Certain functions are not accessible unless a special service code is entered. This code is known only to the Endress+Hauser service organization. Please contact your Endress+Hauser service center if you require clarification. • In this function, access to programming is only valid for local configuration. If functions or parameters are to be changed over Fieldbus, programming must be released separately in the parameter "Un/Locking - Access code" (see Page 115).
DEFINE PRIVATE CODE (2021)	Use this function to enter a personal code number for enabling programming. User input: 0...9999 (max. 4-digit number) Factory setting: 83  Note! • If you define the personal code number = 0, the programming is always enabled. • Programming has to be enabled before this code can be changed. When programming is disabled the function can't be changed, this precaution prevents others from changing your personal code without your knowledge and consent.
STATUS ACCESS (2022)	Use this function to check the access status for the function matrix. Display shows: ACCESS CUSTOMER (Parameterization enabled) ACCESS SERVICE (Parameterization enabled) LOCKED (Parameterization disabled)


4.1.3 Function group OPERATION



Function description	
USER INTERFACE → CONTROL → OPERATION	
TEST DISPLAY (2040)	Use this function to test the operability of the local display and its pixels. Options: OFF ON Factory setting: OFF Test sequence: 1. Start the test by selecting ON. 2. All pixels of the main line, additional line and information line are darkened for minimum 0.75 second. 3. Main line, additional line and information line show an "8" in each field for minimum 0.75 second. 4. Main line, additional line and information line show a "0" in each field for minimum 0.75 second. 5. Main line, additional line and information line show nothing (blank display) for minimum 0.75 second. When the test completes the local display returns to its initial state and the setting changes to OFF.

4.2 Group MAIN LINE


4.2.1 Function group CONFIGURATION



Function description	
USER INTERFACE → MAIN LINE → CONFIGURATION	
F-x3xxxx-07-05-x-x-xx-000 A B C	
ASSIGN (2200)	Use this function to define the display value assigned to the main line (the top line of the local display) during normal measuring operation. Options: OFF MASS FLOW MASS FLOW IN % VOLUME FLOW VOLUME FLOW IN % CORRECTED VOLUME FLOW CORRECTED VOLUME FLOW IN % DENSITY REFERENCE DENSITY TEMPERATURE TOTALIZER 1 TOTALIZER 2 TOTALIZER 3 AI 1 - OUT VALUE AI 2 - OUT VALUE AI 3 - OUT VALUE AI 4 - OUT VALUE AI 5 - OUT VALUE AI 6 - OUT VALUE AI 7 - OUT VALUE PID - IN VALUE (controlled variable) PID - CAS_IN VALUE (external set point) PID - OUT VALUE (manipulated variable) Factory setting: MASS FLOW

Function description	
USER INTERFACE → MAIN LINE → CONFIGURATION	
100% VALUE (2201)	 Note! This function is not available unless one of the following was selected in the ASSIGN function (2200): • MASS FLOW IN % • VOLUME FLOW IN % • CORRECTED VOLUME FLOW IN % Use this function to define the flow value to be shown on the display as the 100% value. User input: 5-digit floating-point number Factory setting: 10 kg/s, 10 l/s resp. 10 NI/s
FORMAT (2202)	Use this function to define the maximum number of places after the decimal point displayed for the reading in the main line. Options: XXXXX. - XXXX.X - XXX.XX - XX.XXX -X.XXXX Factory setting: X.XXXX  Note! • Note that this setting only affects the reading as it appears on the display, it has no influence on the accuracy of the system's calculations. • The places after the decimal point as computed by the measuring device cannot always be displayed, depending on this setting and the engineering unit. In these instances an arrow appears on the display between the measured value and the engineering unit (e.g. 1.2→ kg/h), indicating that the measuring system is computing with more decimal places than can be shown on the display.

4.2.2 Function group MULTIPLEX





Function description	
USER INTERFACE → MAIN LINE → MULTIPLEX	
ASSIGN (2220)	Use this function to define the second reading to be displayed in the main line alternately (every 10 seconds) with the value defined in the ASSIGN function (2200). Options: OFF MASS FLOW MASS FLOW IN % VOLUME FLOW VOLUME FLOW IN % CORRECTED VOLUME FLOW CORRECTED VOLUME FLOW IN % DENSITY REFERENCE DENSITY TEMPERATURE TOTALIZER 1 TOTALIZER 2 TOTALIZER 3 AI 1 - OUT VALUE AI 2 - OUT VALUE AI 3 - OUT VALUE AI 4 - OUT VALUE AI 5 - OUT VALUE AI 6 - OUT VALUE AI 7 - OUT VALUE PID - IN VALUE (controlled variable) PID - CAS_IN VALUE (external set point) PID - OUT VALUE (manipulated variable) Factory setting: OFF
100% VALUE (2221)	 Note! This function is not available unless one of the following was selected in the ASSIGN function (2220): • MASS FLOW IN % • VOLUME FLOW IN % • CORRECTED VOLUME FLOW IN % Use this function to define the flow value to be shown on the display as the 100% value. User input: 5-digit floating-point number Factory setting: 10 kg/s, 10 l/s resp. 10 NI/s

Function description	
USER INTERFACE → MAIN LINE → MULTIPLEX	
FORMAT (2222)	Use this function to define the maximum number of places after the decimal point for the second value displayed in the main line. Options: XXXXX. - XXXX.X - XXX.XX - XX.XXX -X.XXXX Factory setting: X.XXXX  Note! • Note that this setting only affects the reading as it appears on the display, it has no influence on the accuracy of the system's calculations. • The places after the decimal point as computed by the measuring device cannot always be displayed, depending on this setting and the engineering unit. In these instances an arrow appears on the display between the measured value and the engineering unit (e.g. 1.2 → kg/h), indicating that the measuring system is computing with more decimal places than can be shown on the display.

4.3 Group ADDITION LINE

4.3.1 Function group CONFIGURATION




Function description USER INTERFACE → ADDITION LINE → CONFIGURATION	
	
A = main line, B = additional line, C = information line	
ASSIGN (2400)	Use this function to define the display value assigned to the additional line (the middle line of the local display) during normal measuring operation. Options: OFF MASS FLOW MASS FLOW IN % VOLUME FLOW VOLUME FLOW IN % CORRECTED VOLUME FLOW CORRECTED VOLUME FLOW IN % DENSITY REFERENCE DENSITY TEMPERATURE MASS FLOW BARGRAPH IN % VOLUME FLOW BARGRAPH IN % CORRECTED VOLUME FLOW BARGRAPH IN % TOTALIZER 1 TOTALIZER 2 TOTALIZER 3 TAG NAME AI 1 - OUT VALUE AI 2 - OUT VALUE AI 3 - OUT VALUE AI 4 - OUT VALUE AI 5 - OUT VALUE AI 6 - OUT VALUE AI 7 - OUT VALUE PID - IN VALUE (controlled variable) PID - CAS_IN VALUE (external set point) PID - OUT VALUE (manipulated variable) DEVICE PD-TAG BLANK LINE Factory setting: TOTALIZER 1

Function description USER INTERFACE → ADDITION LINE → CONFIGURATION	
100% VALUE (2401)	 Note! This function is not available unless one of the following was selected in the ASSIGN function (2400): • MASS FLOW IN % • VOLUME FLOW IN % • CORRECTED VOLUME FLOW IN % • MASS FLOW BARGRAPH IN % • VOLUME FLOW BARGRAPH IN % • CORRECTED VOLUME FLOW BARGRAPH IN % Use this function to define the flow value to be shown on the display as the 100% value. User input: 5-digit floating-point number Factory setting: 10 kg/s, 10 l/s resp. 10 NI/s
FORMAT (2402)	 Note! This function is not available unless a number was selected in the ASSIGN function (2400). Use this function to define the maximum number of places after the decimal point displayed for the reading in the additional line. Options: XXXXX. - XXXX.X - XXX.XX - XX.XXX -X.XXXX Factory setting: X.XXXX  Note! • Note that this setting only affects the reading as it appears on the display, it has no influence on the accuracy of the system's calculations. • The places after the decimal point as computed by the measuring device cannot always be displayed, depending on this setting and the engineering unit. In these instances an arrow appears on the display between the measured value and the engineering unit (e.g. 1.2 → kg/h), indicating that the measuring system is computing with more decimal places than can be shown on the display.

Function description	
USER INTERFACE → ADDITION LINE → CONFIGURATION	
DISPLAY MODE (2403)	Note! This function is not available unless one of the following was selected in the ASSIGN function (2400): • MASS FLOW BARGRAPH IN % • VOLUME FLOW BARGRAPH IN % • CORRECTED VOLUME FLOW BARGRAPH IN % Use this function to define the format of the bar graph. Options: STANDARD Simple bar graph with 25 / 50 / 75% gradations and integrated sign. +25+50+75% F-x3xxxx-20-xx-xx-xx-000 SYMMETRY Symmetrical bar graph for positive and negative directions of flow, with -50 / 0 / +50% gradations and integrated sign. -50+50% F-x3xxxx-20-xx-xx-xx-001 Factory setting: STANDARD

4.3.2 Function group MULTIPLEX




Function description	
USER INTERFACE → ADDITION LINE → MULTIPLEX	
ASSIGN (2420)	Use this function to define the second reading to be displayed in the additional line alternately (every 10 seconds) with the value defined in the ASSIGN function (2400). Options: OFF MASS FLOW MASS FLOW IN % VOLUME FLOW VOLUME FLOW IN % CORRECTED VOLUME FLOW CORRECTED VOLUME FLOW IN % DENSITY REFERENCE DENSITY TEMPERATURE MASS FLOW BARGRAPH IN % VOLUME FLOW BARGRAPH IN % CORRECTED VOLUME FLOW BARGRAPH IN % NOMINAL CURRENT (1...3) NOMINAL FREQUENCY (1...2) TOTALIZER 1 TOTALIZER 2 TOTALIZER 3 TAG NAME AI 1 - OUT VALUE AI 2 - OUT VALUE AI 3 - OUT VALUE AI 4 - OUT VALUE AI 5 - OUT VALUE AI 6 - OUT VALUE AI 7 - OUT VALUE PID - IN VALUE (controlled variable) PID - CAS_IN VALUE (external set point) PID - OUT VALUE (manipulated variable) DEVICE PD-TAG BLANK LINE Factory setting: OFF  Note! Multiplex mode is suspended as soon as a fault/notice message is generated. The message in question appears on the display. - Fault message (identified by a lightning icon): Multiplex mode is resumed as soon as the fault message is no longer active. - Notice message (identified by an exclamation mark): Multiplex mode is resumed as soon as the notice message is no longer active.

Function description USER INTERFACE → ADDITION LINE → MULTIPLEX	
100% VALUE (2421)	 Note! This function is not available unless one of the following was selected in the ASSIGN function (2420): • MASS FLOW IN % • VOLUME FLOW IN % • CORRECTED VOLUME FLOW IN % • MASS FLOW BARGRAPH IN % • VOLUME FLOW BARGRAPH IN % • CORRECTED VOLUME FLOW BARGRAPH IN % Use this function to define the flow value to be shown on the display as the 100% value. User input: 5-digit floating-point number Factory setting: 10 kg/s, 10 l/s resp. 10 NI/s
FORMAT (2422)	 Note! This function is not available unless a number was selected in the ASSIGN function (2420). Use this function to define the maximum number of places after the decimal point for the second value displayed in the additional line. Options: XXXXX. - XXXX.X - XXX.XX - XX.XXX -X.XXXX Factory setting: X.XXXX  Note! • Note that this setting only affects the reading as it appears on the display, it has no influence on the accuracy of the system's calculations. • The places after the decimal point as computed by the measuring device cannot always be displayed, depending on this setting and the engineering unit. In these instances an arrow appears on the display between the measured value and the engineering unit (e.g. 1.2 → kg/h), indicating that the measuring system is computing with more decimal places than can be shown on the display.

Function description	
USER INTERFACE → ADDITION LINE → MULTIPLEX	
DISPLAY MODE (2423)	 Note! This function is not available unless one of the following was selected in the ASSIGN function (2420): • MASS FLOW BARGRAPH IN % • VOLUME FLOW BARGRAPH IN % • CORRECTED VOLUME FLOW BARGRAPH IN % Use this function to define the format of the bar graph. Options: STANDARD Simple bar graph with 25 / 50 / 75% gradations and integrated sign. +25+50+75% F-x3xxxxx-20-xx-xx-xx-000 SYMMETRY Symmetrical bar graph for positive and negative directions of flow, with -50 / 0 / +50% gradations and integrated sign. -50+50% F-x3xxxxx-20-xx-xx-xx-001 Factory setting: STANDARD


4.4 Group INFORMATION LINE

4.4.1 Function group CONFIGURATION



Function description

USER INTERFACE → INFORMATION LINE → CONFIGURATION



A = main line, B = additional line, C = information line

ASSIGN
(2600)

Use this function to define the display value assigned to the information line (the bottom line of the local display) during normal measuring operation.

Options:

OFF
 MASS FLOW
 MASS FLOW IN %
 VOLUME FLOW
 VOLUME FLOW IN %
 CORRECTED VOLUME FLOW
 CORRECTED VOLUME FLOW IN %
 DENSITY
 REFERENCE DENSITY
 TEMPERATURE
 MASS FLOW BARGRAPH IN %
 VOLUME FLOW BARGRAPH IN %
 CORRECTED VOLUME FLOW BARGRAPH IN %
 TOTALIZER 1
 TOTALIZER 2
 TOTALIZER 3
 TAG NAME
 OPERATING/SYSTEM CONDITIONS
 DISPLAY FLOW DIRECTION
 AI (1...7) - OUT VALUE
 PID - IN VALUE (controlled variable)
 PID - CAS_IN VALUE (external set point)
 PID - OUT VALUE (manipulated variable)
 DEVICE PD-TAG
 BLANK LINE


Factory setting:

OPERATING/SYSTEM CONDITIONS

Function description USER INTERFACE → INFORMATION LINE → CONFIGURATION	
100% VALUE (2601)	 Note! This function is not available unless one of the following was selected in the ASSIGN function (2600): • MASS FLOW IN % • VOLUME FLOW IN % • CORRECTED VOLUME FLOW IN % • MASS FLOW BARGRAPH IN % • VOLUME FLOW BARGRAPH IN % • CORRECTED VOLUME FLOW BARGRAPH IN % Use this function to define the flow value to be shown on the display as the 100% value. User input: 5-digit floating-point number Factory setting: 10 kg/s, 10 l/s resp. 10 NI/s
FORMAT (2602)	 Note! This function is not available unless a number was selected in the ASSIGN function (2600). Use this function to define the maximum number of places after the decimal point displayed for the reading in the information line. Options: XXXXX. - XXXX.X - XXX.XX - XX.XXX -X.XXXX Factory setting: X.XXXX  Note! • Note that this setting only affects the reading as it appears on the display, it has no influence on the accuracy of the system's calculations. • The places after the decimal point as computed by the measuring device cannot always be displayed, depending on this setting and the engineering unit. In these instances an arrow appears on the display between the measured value and the engineering unit (e.g. 1.2 → kg/h), indicating that the measuring system is computing with more decimal places than can be shown on the display.

Function description	
USER INTERFACE → INFORMATION LINE → CONFIGURATION	
DISPLAY MODE (2603)	Note! This function is not available unless one of the following was selected in the ASSIGN function (2600): • MASS FLOW BARGRAPH IN % • VOLUME FLOW BARGRAPH IN % • CORRECTED VOLUME FLOW BARGRAPH IN % Use this function to define the format of the bar graph. Options: STANDARD Simple bar graph with 25 / 50 / 75% gradations and integrated sign. +25+50+75% F-x3xxxx-20-xx-xx-xx-000 SYMMETRY Symmetrical bar graph for positive and negative directions of flow, with -50 / 0 / +50% gradations and integrated sign. -50+50% F-x3xxxx-20-xx-xx-xx-001 Factory setting: STANDARD

4.4.2 Function group MULTIPLEX




Function description	
USER INTERFACE → INFORMATION LINE → MULTIPLEX	
ASSIGN (2620)	Use this function to define the second reading to be displayed in the information line alternately (every 10 seconds) with the value defined in the ASSIGN function (2600). Options: OFF MASS FLOW MASS FLOW IN % VOLUME FLOW VOLUME FLOW IN % CORRECTED VOLUME FLOW CORRECTED VOLUME FLOW IN % DENSITY REFERENCE DENSITY TEMPERATURE MASS FLOW BARGRAPH IN % VOLUME FLOW BARGRAPH IN % CORRECTED VOLUME FLOW BARGRAPH IN % TOTALIZER 1 TOTALIZER 2 TOTALIZER 3 TAG NAME OPERATING/SYSTEM CONDITIONS DISPLAY FLOW DIRECTION AI 1 - OUT VALUE AI 2 - OUT VALUE AI 3 - OUT VALUE AI 4 - OUT VALUE AI 5 - OUT VALUE AI 6 - OUT VALUE AI 7 - OUT VALUE PID - IN VALUE (controlled variable) PID - CAS_IN VALUE (external set point) PID - OUT VALUE (manipulated variable) DEVICE PD-TAG BLANK LINE Factory setting: OFF  Note! Multiplex mode is suspended as soon as a fault/notice message is generated. The message in question appears on the display. - Fault message (identified by a lightning icon): Multiplex mode is resumed as soon as the fault message is no longer active. - Notice message (identified by an exclamation mark): Multiplex mode is resumed as soon as the notice message is no longer active.

Function description USER INTERFACE → INFORMATION LINE → MULTIPLEX	
100% VALUE (2621)	 Note! This function is not available unless one of the following was selected in the ASSIGN function (2620): • MASS FLOW IN % • VOLUME FLOW IN % • CORRECTED VOLUME FLOW IN % • MASS FLOW BARGRAPH IN % • VOLUME FLOW BARGRAPH IN % • CORRECTED VOLUME FLOW BARGRAPH IN % Use this function to define the flow value to be shown on the display as the 100% value. User input: 5-digit floating-point number Factory setting: 10 kg/s, 10 l/s resp. 10 NI/s
FORMAT (2622)	 Note! This function is not available unless a number was selected in the ASSIGN function (2620). Use this function to define the maximum number of places after the decimal point for the second value displayed in the information line. Options: XXXXX. - XXXX.X - XXX.XX - XX.XXX -X.XXXX Factory setting: X.XXXX  Note! • Note that this setting only affects the reading as it appears on the display, it has no influence on the accuracy of the system's calculations. • The places after the decimal point as computed by the measuring device cannot always be displayed, depending on this setting and the engineering unit. In these instances an arrow appears on the display between the measured value and the engineering unit (e.g. 1.2 → kg/h), indicating that the measuring system is computing with more decimal places than can be shown on the display.


Function description	
USER INTERFACE → INFORMATION LINE → MULTIPLEX	
DISPLAY MODE (2623)	Note! This function is not available unless one of the following was selected in the ASSIGN function (2620): • MASS FLOW BARGRAPH IN % • VOLUME FLOW BARGRAPH IN % • CORRECTED VOLUME FLOW BARGRAPH IN % Use this function to define the format of the bar graph. Options: STANDARD Simple bar graph with 25 / 50 / 75% gradations and integrated sign. +25+50+75% F-x3xxxxx-20-xx-xx-xx-000 SYMMETRY Symmetrical bar graph for positive and negative directions of flow, with -50 / 0 / +50% gradations and integrated sign. -50+50% F-x3xxxxx-20-xx-xx-xx-001 Factory setting: STANDARD

5 Block TOTALIZER



5.1 Group TOTALIZERS (1...3)


5.1.1 Function group CONFIGURATION



Function description TOTALIZER → TOTALIZERS (1...3) → CONFIGURATION	
The function descriptions below apply to totalizers 1...3; the totalizers are independently configurable.	
ASSIGN (3000)	Use this function to assign a measured variable to the totalizer. Options: OFF MASS FLOW VOLUME FLOW CORRECTED VOLUME FLOW Factory setting: MASS FLOW Note! - The totalizer is reset to "0" as soon as the selection is changed. - If you select OFF, the only function shown in this function group is this function (ASSIGN).
UNIT TOTALIZER (3001)	Use this function to define the unit for the totalizer's measured variable, as selected beforehand. Options (for the MASS FLOW assignment): Metric → g; kg; t US → oz; lb; ton Factory setting: kg Options (for the VOLUME FLOW assignment): Metric → cm³; dm³; m³; ml; l; hl; Ml US → cc; af; ft³; oz f; gal; Mgal; bbl (normal fluids); bbl (beer); bbl (petrochemicals); bbl (filling tanks) Imperial → gal; Mgal; bbl (beer); bbl (petrochemicals) Factory setting: m³ Options (for the CORRECTED VOLUME FLOW assignment): Metric → NI; Nm³ US → Sm³; Scf Factory setting: Nm³ Note! The unit selected here have no effect on the Fieldbus. It is only used for the local display and for assigned instrument functions.


Function description	
TOTALIZER → TOTALIZERS (1...3) → CONFIGURATION	
TOTALIZER MODE (3002)	Use this function to define how the flow components are to be totaled by the totalizer. Options: BALANCE (positive and negative flow components) The positive and negative flow components are balanced. In other words, net flow in the flow direction is registered. FORWARD Positive flow components only REVERSE Negative flow components only Factory setting: Totalizer 1 = BALANCE Totalizer 2 = FORWARD Totalizer 3 = REVERSE
RESET TOTALIZER (3003)	Use this function to reset the sum and the overflow of the totalizer to zero. Options: NO YES Factory setting: NO

5.1.2 Function group OPERATION




Function description TOTALIZER → TOTALIZERS (1...3) → OPERATION	
The function descriptions below apply to totalizers 1...3; the totalizers are independently configurable.	
SUM (3040)	Use this function to view the total for the totalizer's measured variable aggregated since measuring commenced. The value can be positive or negative, depending on the setting selected in the "TOTALIZER MODE" function (3002), and the direction of flow. Display shows: max. 7-digit floating-point number, including sign and unit (e.g. 15467.04 m³; -4925.631 kg) Note! - The effect of the setting in the "TOTALIZER MODE" function (see Page 40) is as follows: - If the setting is "BALANCE", the totalizer balances flow in the positive and negative directions. - If the setting is "POSITIVE", the totalizer registers only flow in the positive direction. - If the setting is "NEGATIVE", the totalizer registers only flow in the negative direction. - The totalizer's response to faults is defined in the "FAILSAFE ALL TOTALIZERS" function (3801) (see Page 43). - If the service code is used to call this function, this value is editable.
OVERFLOW (3041)	Use this function to view the overflow for the totalizer aggregated since measuring commenced. Total flow quantity is represented by a floating-point number consisting of max. 7 digits. You can use this function to view higher numerical values (>9,999,999) as overflows. The effective quantity is thus the total of OVERFLOW plus the value returned by the SUM function. Example: Reading for 2 overflows: 2 10⁷ kg (= 20,000,000 kg) The value returned by the SUM function = 196,845.7 kg Effective total quantity = 20,196,845.7 kg Display shows: integer with exponent, including sign and unit, e.g. 2 10⁷kg Note! If the service code is used to call this function, this value is editable.

5.2 Group INVENTORY




Function description	
TOTALIZER → INVENTORY → Inventory totalizer functions	
 Note! The group INVENTORY is only accessible when the programming is enabled by service code.	
SUM INVENTORY (3600)	Use this function to view the flow quantity for the inventory totalizer aggregated since commissioning (unit in kg). All flow components are totaled, irrespective of their direction of flow (positive / negative). Display shows: 7-digit floating-point number [kg]
OVERFLOW INVENTORY (3601)	Use this function to view the overflow for the inventory totalizer aggregated since commissioning (unit in kg). Display shows: 7-digit integer with exponential coefficient [kg]

5.3 Group HANDLING TOTALIZER



Function description	
TOTALIZER → HANDLING TOTALIZER → Totalizer administration functions	
RESET ALL TOTALIZERS (3800)	Use this function to reset the totals (including all overflows) of the totalizers (1...3) to "zero" (= RESET). Options: NO YES Factory setting: NO  Caution! Note that the inventory totalizer (see Page 42) is not reset.
FAILSAFE ALL TOTALIZERS (3801)	Use this function to define the common response of all totalizers (1...3) to error. Options: STOP The totalizer is paused until the fault is rectified. The totalizer stops at the last value prior to the occurrence of the error. ACTUAL VALUE The totalizer continues to count is based on the current flow measured value. The fault is ignored. HOLD VALUE The totalizer continues to count the flow is based on the last valid flow value (before the fault occurred). Factory setting: STOP  Caution! The inventory totalizer (called SUM INVENTORY, see Page 42) can't be assigned its own individual response to error. If an error occurs the inventory totalizer stops at the last value prior to the occurrence of the error (corresponds to STOP).

6 Block BASIC FUNCTION




6.1 Group FOUNDATION FIELDBUS

6.1.1 Function group CONFIGURATION


BASIC FUNCTION G ⇒ FOUND. FIELDBUS GGA ⇒ CONFIGURATION 620	
Function description BASIC FUNCTION → FOUNDATION FIELDBUS → CONFIGURATION	
WRITE PROTECT (6200)	Use this function to check whether the measuring device can be write accessed via Fieldbus. Display shows: OFF Access to device parameter via FF is possible ON Access to device parameter via FF is not possible Factory setting: ON  Note! Hardware write protection is activated and deactivated by means of a jumper on the I/O board (see Operating Instruction Promass 83 BA 065D/06/en/).
SIMULATION (6201)	Use this function to check whether a simulation in the Analog Input Function Block is possible. Display shows: OFF Simulation in the Analog Input and Discrete Output Function Block is not possible. ON Simulation in the Analog Input and Discrete Output Function Block is possible Factory setting: OFF  Note! - The Simulation mode is activated and deactivated by means of a jumper on the I/O board (see Operating Instruction Promass 83 BA 065D/06/en/). - The status of the simulation mode is also shown in the parameter "BLOCK_ERR" of the Resource Block (see Page 80).
BUS-ADDRESS (6202)	 Note! The service code has to be entered in order to access this function. If the service code is used to call this function, this value can be edited.
DEVICE PD-TAG (6203)	Use this function to enter a tag name for the measuring device. User input: max. 32-character text, permissible: A-Z, 0-9, +, -, punctuation marks Factory setting: E+H_PROMASS_83_XXXXXXXXXX

6.1.2 Function group FUNCTION BLOCKS



Function description	
BASIC FUNCTION → FOUND. FIELDBUS → OPERATION	
BLOCK SELECTION (6220)	In this function, a function block can be selected, whose value and status is shown in the following functions. Options: ANALOG INPUT 1 ANALOG INPUT 2 ANALOG INPUT 3 ANALOG INPUT 4 ANALOG INPUT 5 ANALOG INPUT 6 ANALOG INPUT 7 PID Factory setting: ANALOG INPUT 1
OUT VALUE (6221)	Display of the output value OUT, incl. unit and status of the selected Analog Input or PID function in the function BLOCK SELECTION (6220).
IN VALUE (6222)	 Note! This function is not available unless the PID selection was selected in the BLOCK SELECTION (6220) function. Display of the controlled variable IN, incl. unit and status of the selected Analog Input or PID function in the function BLOCK SELECTION (6220).
CASCADE IN VALUE (6223)	 Note! This function is not available unless the PID selection was selected in the BLOCK SELECTION (6220) function. Display of an analog set value, incl. units and status, taken over from an external function block.
SETPOINT VALUE (6224)	 Note! • This function is not available unless the PID selection was selected in the BLOCK SELECTION (6220) function. • If the service code is used to call this function, this value can be edited. Display of the set value, incl. units and status, for the PID function block.


6.1.3 Function group INFORMATION




Function description	
BASIC FUNCTION → FOUND. FIELDBUS → OPERATION	
MANUFACTURER ID (6240)	Use this function to view the manufacturer ID in decimal numerical format. Display shows: 452B48 (hex) for Endress+Hauser
DEVICE TYPE (6241)	Use this function to view the device ID in hexadecimal numerical format. Display shows: 1051 (dez) for Promass 83 FOUNDATION Fieldbus
SERIAL NUMBER (6242)	Use this function to view the serial number. Display shows: 11-digit number
DEVICE REVISION (6243)	Use this function to view the device Revision number. Display shows: 1
DD REVISION (6244)	Use this function to view the Revision number of the Device Description. Display shows: 1

6.2 Group PROCESS PARAMETER


6.2.1 Function group CONFIGURATION



Function description	
BASIC FUNCTION → PROCESS PARAMETER → CONFIGURATION	
ASSIGN LOW FLOW CUT OFF (6400)	Use this function to assign the switching point for Low flow cut off rate suppression. Options: OFF MASS FLOW VOLUME FLOW CORRECTED VOLUME FLOW Factory setting: MASS FLOW
ON-VALUE LOW FLOW CUT OFF (6402)	Use this function to assign a value to the switch-on point for Low flow cut off. Low flow cut off is active if the setting is a value not equal to 0. The sign of the flow value is highlighted on the display to indicate that Low flow cut off is active. User input: depends on nominal diameter Factory setting: 0.0000  Note! The appropriate unit is taken from the corresponding unit function in the group SYSTEM UNITS (see Page 13).
OFF-VALUE LOW FLOW CUT OFF (6403)	Use this function to assign a value to the switch-off point for Low flow cut off. Enter the OFF-VALUE as a positive hysteresis from the ON-VALUE. User input: 0...100% Factory setting: 50%


Function description	
BASIC FUNCTION → PROCESS PARAMETER → CONFIGURATION	
PRESSURE SHOCK SUPPRESSION (6404)	The closure of a valve can cause brief but severe movements of the fluid in the piping system, movements which the measuring system registers. The pulses totaled in this way result in a totalizer reading error, particularly in the case of filling processes. For this reason, the measuring device is equipped with Pressure shock suppression (= short-term signal suppression) which can eliminate system-related "disruptions".  Note! Note that Pressure shock suppression cannot be used unless the Low flow cut off is active (see ON-VALUE LOW FLOW CUT OFF function on Page 48). Use this function to define the time span for active pressure shock suppression. Activation of the Pressure shock suppression Pressure pulse suppression is activated after the flow falls below the ON_Value of the Low flow cut off (see point 1 in grafic). While Pressure shock suppression is active, the following conditions apply: • Flow reading on display → 0 • Totalizer reading → the totalizers are pegged at the last correct value. Deactivation of the Pressure shock suppression The Pressure shock suppression is deactivated after the time interval, set in this function, has passed (see point 2 in grafic).  Note! The actual flow value is displayed and output, when the time interval for the Pressure shock suppression has passed and the flow exceeds the OFF-VALUE of the Low flow cut off (see point 3 in grafic).  User input: max. 4-digit number, incl. unit: 0.00...100.00 s Factory setting: 0.00 s

6.2.2 Function group EPD PARAMETER



Function description BASIC FUNCTION → PROCESS PARAMETER → EPD PARAMETER	
EMPTY PIPE DETECTION (6420)	Use this function to activate the empty pipe detection (EPD). With empty measuring tubes the density of the fluid falls below a specified value (see EPD VALUE LOW function). Options: OFF - ON Factory setting: OFF  Caution! • Select a correspondingly low EPD response value in the EPD VALUE LOW function, so that the difference to the effective density of the fluid is sufficiently large enough. This ensures that totally empty measuring tubes and not partially filled ones are detected. • For gas measurement we strongly recommend to switch off empty pipe detection.
EPD VALUE LOW (6423)	 Note! This function is not available unless the ON selection was selected in the EMPTY PIPE DETECTION function. Use this function to set an lower threshold for the measured density value, in order to detect possible problems in the process indicated by too low density. User input: 5-digit floating-point number Factory setting: 0.2000 g/cc
EPD VALUE HIGH (6424)	 Note! This function is not available unless the ON selection was selected in the EMPTY PIPE DETECTION function. Use this function to set an upper threshold for the measured density value. User input: 5-digit floating-point number Factory setting: 6.0000 g/cc
EPD RESPONSE TIME (6425)	Use this function to enter the time span for which the criteria for an empty pipe have to be satisfied without interruption before a notice message or fault message is generated. User input: fixed-point number: 1.0...60.0 s Factory setting: 1.0 s


6.2.3 Function group REFERENCE PARAMETER



Function description BASIC FUNCTION → PROCESS PARAMETER → REFERENCE PARAMETER	
CORRECTED VOLUME CALCULATION (6460)	This function is used to set the reference density for calculating the corrected volume flow. Options: FIXED REFERENCE DENSITY CALCULATED REFERENCE DENSITY Factory setting: CALCULATED REFERENCE DENSITY
FIXED REFERENCE DENSITY (6461)	Note! This function is not available unless the FIXED REFERENCE DENSITY setting was selected in the COR. VOL. CALC. function (6460). In this function, a fixed value for the reference density can be entered, with which the corrected volume flow or corrected volume is calculated. User input: 5-digit floating-point number Factory setting: 1 kg/Nl
EXPANSION COEFFICIENT (6462)	Note! This function is not available unless the CALCULATED REFERENCE DENSITY setting was selected in the COR. VOL. CALC. function (6460). For temperature compensated calculations of the reference density an expansion coefficient specific to the fluid is required and can be entered in this function. User input: 5-digit floating-point number Factory setting: 0.5000 e-3 [1/K]
EXPANSION COEFFICIENT SQUARELY (6463)	Use this function to enter a squarely expansion coefficient, if the temperature compensation follows a non-linear behaviour. User input: 5-digit floating-point number Factory setting: 0 e-6 [1/K²]

Function description	
BASIC FUNCTION → PROCESS PARAMETER → REFERENCE PARAMETER	
REFERENCE TEMPERATURE (6464)	 Note! This function is not available unless the CALCULATED REFERENCE DENSITY setting was selected in the COR. VOL. CALC. function (6460). Input of the reference temperature for calculation corrected volume flow, corrected volume and reference density. User input: 5-digit floating-point number Factory setting: 20.000 °C The reference density is calculated as follows: $\rho_N = \rho \cdot (1 + \alpha \Delta t + \beta \Delta t^2)$; where $\Delta t = t - t_N$ ρ_N = Reference density ρ = Actual measured density of fluid (measured value Promass) t = Actual measured temperature of fluid (measured value Promass) t_N = Reference temperature for calculating reference density (e.g. 20 °C) α = Volumetric expansion coefficient of the fluid. Unit = [1/K]; K = Kelvin β = Square volumetric expansion coefficient of the fluid. Unit = [1/K²]

6.2.4 Function group ADJUSTMENT




Function description BASIC FUNCTION → PROCESS PARAMETER → ADJUSTMENT	
ZEROPOINT ADJUST (6480)	This function enables a zero point adjustment to be automatically carried out. The new zero point determined by the measuring system is adopted by the ZERO POINT function (see Page 56). Options: CANCEL START Factory setting: CANCEL  Caution! Before carrying out the calibration, please refer to BA059D/06/en "Promass 83 Operating Instructions" where a detailed description of the zero point adjustment is given.  Note! - Programming is locked during zero point adjustment and the display shows: "ZERO ADJUST RUNNING". - If the zero point adjustment is not possible, e.g. with a flow velocity > 0.1 m/s, or has been cancelled, then the alarm message "ZERO ADJUST NOT POSSIBLE" is shown on the display. This error is communicated to the subsequent function blocks via the status "UNCERTAIN" for the process variables.
DENSITY SET VALUE (6483)	In this function, enter the density set value of the fluid for which you want to carry out a field density adjustment. User input: 5-digit floating-point number, incl. units  Note! - The preset density entered here should not vary from the actual fluid density by a more than ±10%. - The appropriate unit is taken from the corresponding UNIT function in the group SYSTEM UNITS (see Page 13).
MEASURE FLUID (6484)	In this function the actual density of the fluid is measured for the density adjustment. Options: CANCEL START

Function description	
BASIC FUNCTION → PROCESS PARAMETER → ADJUSTMENT	
DENSITY ADJUST (6487)	With this function a density adjustment can be carried out on site. The density adjustment values will thus be recalculated and stored. This ensures that the values dependent on density calculations (e.g. volume flow) are as accurate as possible.  Note! Before carrying out a density adjustment, please refer to BA059D/06/en "Promass 83 Operating Instructions" where a detailed description of the density adjustment is given. 1-point density adjustment (with one fluid) This type of density adjustment is necessary under the following conditions: • The sensor does not accurately measure the density which the operator expects based on laboratory trials. • The characteristics of the fluid are outside the measuring points set at the factory or reference conditions under which the flowmeter has been calibrated. • The plant is used solely for measuring a fluid whose density is to be determined very accurately under constant conditions. User input: CANCEL DENSITY ADJUST Factory setting: CANCEL
RESTORE ORIGINAL (6488)	With this function the original density coefficient determined at the factory are restored. Options: NO YES Factory setting: NO

6.3 Group SYSTEM PARAMETER


6.3.1 Function group CONFIGURATION



Function description BASIC FUNCTION → SYSTEM PARAMETER → CONFIGURATION	
INSTALLATION DIRECTION SENSOR (6600)	Use this function to reverse the sign of the flow quantity, if necessary. Options: NORMAL (flow as indicated by the arrow) INVERSE (flow opposite to direction indicated by the arrow) Factory setting: NORMAL  Note! Ascertain the actual direction of fluid flow with reference to the direction indicated by the arrow on the sensor (nameplate).
DENSITY DAMPING (6602)	The density filter allows the sensitivity of the density measuring signal to be lowered with respect to variations in the density of the fluid, e.g. with inhomogeneous liquids. The damping acts on all functions of the measuring device. User input: max. 5-digit number, including unit: 0.00...100.00 s Factory setting: 0.00 s
FLOW DAMPING (6603)	Using the interference blanking (= time constant for exponential filter) the sensitivity of the flow measurement signal can be reduced with respect to transient flows and interference peaks; e.g. with fluid containing solids or gas bubbles, etc. The damping acts on all functions of the measuring device. User input: 0...100 s Factory setting: 0 s
POSITIVE ZERO RETURN (6605)	Use this function to interrupt evaluation of measured variables. This is necessary when a piping system is being cleaned, for example. This setting acts on all functions of the measuring device. Options: OFF ON (signal output is set to the zero flow value, temperature and density are output normally) Factory setting: OFF  Note! An active positive zero return is communicated to the subsequent function blocks via the status "UNCERTAIN" for the process variables.


6.4 Group SENSOR DATA

6.4.1 Function group CONFIGURATION




Function description	
BASIC FUNCTION → SENSOR DATA → CONFIGURATION	
All sensor data, including nominal diameter, calibration factor, and zero point are set at the factory. All the sensor's parameter settings are saved on the S-DAT memory chip. Caution! Under normal circumstances you should not change these parameter settings, because changes affect numerous functions of the entire measuring facility in general, and the accuracy of the measuring system in particular. Consequently, the functions described below can be accessed only by entering a special service code, which is not the same as your private code number. Contact the E+H service organization if you have any questions about these functions.	
K FACTOR (6800)	This function shows the current calibration factor for the sensor. Factory setting: depends on nominal diameter and calibration Note! If the service code is used to call this function, this value can be edited.
ZERO POINT (6803)	This function shows the current zero-point correction value for the sensor. User input: max. 5-digit number: -99999 ...+99999 Factory setting: depends on calibration
NOMINAL DIAMETER (6804)	This function shows the nominal diameter for the sensor. Factory setting: depends on the size of the sensor Note! If the service code is used to call this function, this value can be edited.

6.4.2 Function group FLOW COEFFICIENT



Function description	
BASIC FUNCTION → SENSOR DATA → FLOW COEFFICIENT	
All flow coefficient are set at the factory. All the sensor's parameter settings are saved on the S-DAT memory chip.  Caution! Under normal circumstances it is not necessary to change these default settings. Consequently, the functions described below can be accessed only by entering a special service code, which is not the same as your private code number. Contact the E+H service organization if you have any questions about these functions.	
TEMPERATURE COEFFICIENT KM (6840)	This function shows the temperatur coefficient KM.
TEMPERATURE COEFFICIENT KM 2 (6841)	This function shows the temperatur coefficient KM 2.
TEMPERATURE COEFFICIENT KT (6842)	This function shows the temperatur coefficient KT.
CALIBRATION COEFFICIENT KD 1 (6843)	This function shows the calibration coefficient KD 1.
CALIBRATION COEFFICIENT KD 2 (6844)	This function shows the calibration coefficient KD 2.


6.4.3 Function group DENSITY COEFFICIENT



Function description BASIC FUNCTION → SENSOR DATA → DENSITY COEFFICIENT	
All density coefficient are set at the factory. All the sensor's parameter settings are saved on the S-DAT memory chip.  Caution! Under normal circumstances it is not necessary to change these default settings. Consequently, the functions described below can be accessed only by entering a special service code, which is not the same as your private code number. Contact the E+H service organization if you have any questions about these functions.	
DENSITY COEFFICIENT C 0 (6850)	This function shows the actual density coefficient C 0.  Note! If the service code is used to call this function, this value can be edited.  Caution! A density adjustment can alter the calibration value of this coefficient.
DENSITY COEFFICIENT C 1 (6851)	This function shows the actual density coefficient C 1.  Note! If the service code is used to call this function, this value can be edited.  Caution! A density adjustment can alter the calibration value of this coefficient.
DENSITY COEFFICIENT C 2 (6852)	This function shows the actual density coefficient C 2.  Note! If the service code is used to call this function, this value can be edited.  Caution! A density adjustment can alter the calibration value of this coefficient.


Function description	
BASIC FUNCTION → SENSOR DATA → DENSITY COEFFICIENT	
DENSITY COEFFICIENT C 3 (6853)	This function shows the actual density coefficient C 3.  Note! If the service code is used to call this function, this value can be edited.  Caution! A density adjustment can alter the calibration value of this coefficient.
DENSITY COEFFICIENT C 4 (6854)	This function shows the actual density coefficient C 4.  Note! If the service code is used to call this function, this value can be edited.  Caution! A density adjustment can alter the calibration value of this coefficient.
DENSITY COEFFICIENT C 5 (6855)	This function shows the actual density coefficient C 5.  Note! If the service code is used to call this function, this value can be edited.  Caution! A density adjustment can alter the calibration value of this coefficient.

6.4.4 Function group ADDITIONAL COEFFICIENT



Function description	
BASIC FUNCTION → SENSOR DATA → ADDITIONAL COEFFICIENT	
All sensor data are set at the factory. All the sensor's parameter settings are saved on the S-DAT memory chip.  Caution! These functions are used for displaying device parameters only and consequently cannot be accessed. Contact the E+H service organization if you have any questions about these functions.	
MINIMAL TEMPERATURE MEASURED (6860)	Display of the lowest fluid temperature measured.
MAXIMAL TEMPERATURE MEASURED (6861)	Display of the highest fluid temperature measured.
MINIMAL TEMPERATURE CARRIER TUBE (6862)	Display of the lowest carrier tube temperature measured.
MAXIMAL TEMPERATURE CARRIER TUBE (6863)	Display of the highest carrier tube temperature measured.

7 Block SUPERVISION



7.1 Group SYSTEM

7.1.1 Function group OPERATION




Function description SUPERVISION → SYSTEM → OPERATION	
ACTUAL SYSTEM CONDITION (8040)	Use this function to check the present system status. Display shows: "SYSTEM OK" or the fault / notice message with the highest priority.
PREVIOUS SYSTEM CONDITION (8041)	Use this function to view the fifteen most recent error and notice messages since measuring last started. Display shows: The 15 most recent error or notice messages
SIMULATION FAILSAFE MODE (8042)	Use this function to set all totalizers to their defined error-response modes, in order to check whether they respond correctly. During this time, the words "SIMULATION FAILSAFE MODE" appear on the display. Options: ON OFF Factory setting: OFF  Note! An active simulation of the failsafe mode is communicated to the subsequent function blocks via the status "UNCERTAIN" for the process variables.
SIMULATION MEASURAND (8043)	In this function, the simulation of a process variable can be activated. The simulation value is set in the function VALUE SIMULATION MEASURAND (8044). During this time, the words "SIMULATION MEASURAND" appear on the display. Options: OFF MASS FLOW VOLUME FLOW CORRECTED VOLUME FLOW DENSITY REFERENCE DENSITY TEMPERATURE Factory setting: OFF  Caution! • The measuring device cannot be used for measuring while this simulation is in progress. • The setting is not saved if the power supply fails.  Note! • An active simulation of the measurand is communicated to the subsequent function blocks via the status "UNCERTAIN" for the process variables. • The simulation is independent of the position of the jumper for the simulation mode on the I/O board.

Function description SUPERVISION → SYSTEM → OPERATION	
VALUE SIMULATION MEASURAND (8044)	 Note! The function is not visible unless the SIMULATION MEASURAND function (8043) is active. Use this function to define a selectable value (e.g. 12 m³/s). This is used to test the associated functions in the flowmeter itself and downstream function blocks. User input: 5-digit floating-point number Factory setting: 0  Caution! The setting is not saved if the power supply fails.
SYSTEM RESET (8046)	Use this function to perform a reset of the measuring system. Options: NO RESTART SYSTEM (restart without interrupting power supply) Factory setting: NO
TROUBLESHOOTING (8047)	Use this function to rectify errors in the EEPROM (Error message AMP SW-EEPROM, # 012). The EEPROM is divided into a number of blocks. Only blocks which an error has occurred are shown. Select the block in question and press the [E]-key to clear the error.  Note! When you clear an error in a block, the parameters of the block you select are reset to their factory settings.
OPERATION HOURS (8048)	 Note! The service code has to be entered in order to access this function. Use this function to read the operating hours of the measuring device. Display shows: 00:00:00 = hr : min : sec 0000:00 = hr : min 000000 = hr


7.2 Group VERSION-INFO

7.2.1 Function group SENSOR




Function description	
SERVICE & ANALYSIS → APPLICATION → TESTPOINTS	
SERIAL NUMBER (8200)	Use this function to view the serial number of the sensor.
SENSOR TYPE (8201)	Use this function to view the sensor type (e.g. Promass F).
HARDWARE REVISION NUMBER SENSOR (8202)	Use this function to view the hardware revision number of the sensor.
HARDWARE ID NUMBER SENSOR (8203)	Note! The service code has to be entered in order to access this function. Use this function to view the hardware ID number of the sensor.
PRODUCTION NUMBER SENSOR (8204)	Note! The service code has to be entered in order to access this function. Use this function to view the production number of the sensor.
SOFTWARE REVISION NUMBER S-DAT™ (8205)	Use this function to view the software revision number of the software used to create the content of the S-DAT™.

7.2.2 Function group AMPLIFIER



Function description SUPERVISION → VERSION-INFO → AMPLIFIER	
HARDWARE REVISION NUMBER AMPLIFIER (8220)	Use this function to view the hardware revision number of the amplifier.
HARDWARE ID NUMBER AMPLIFIER (8221)	 Note! The service code has to be entered in order to access this function. Use this function to view the hardware ID number of the amplifier.
SOFTWARE REVISION NUMBER AMPLIFIER (8222)	Use this function to view the software revision number of the amplifier.
SOFTWARE ID NUMBER AMPLIFIER (8223)	 Note! The service code has to be entered in order to access this function. Use this function to view the software ID number of the amplifier.
PRODUCTION NUMBER AMPLIFIER (8224)	 Note! The service code has to be entered in order to access this function. Use this function to view the production number of the amplifier.
SOFTWARE REVISION NUMBER T-DAT™ (8225)	Use this function to view the software revision number of the software used to create the content of the T-DAT™.

7.2.3 Function group I/O MODULE



Function description	
SUPERVISION → VERSION-INFO → I/O MODULE	
I/O MODULE TYPE (8300)	Use this function to view the configuration of the I/O module complete with terminal numbers.
HARDWARE REVISION NUMBER I/O MODULE (8301)	Use this function to view the hardware revision number of the I/O module.
HARDWARE ID NUMBER I/O MODULE (8302)	 Note! The service code has to be entered in order to access this function. Use this function to view the hardware ID number of the I/O module.
SOFTWARE REVISION NUMBER I/O MODULE (8303)	Use this function to view the software revision number of the I/O module.
SOFTWARE ID NUMBER I/O MODULE (8304)	 Note! The service code has to be entered in order to access this function. Use this function to view the software ID number of the I/O module.
PRODUCTION NUMBER I/O MODULE (8305)	 Note! The service code has to be entered in order to access this function. Use this function to view the production number of the I/O module.

8 Index key words for function matrix

Blocks

A = MEASURED VARIABLES	11
C = USER INTERFACE	18
D = TOTALIZER	38
G = BASIC FUNCTION	44
J = SUPERVISION	61

Groups

AAA = MEASURING VALUES	12
ACA = SYSTEM UNITS	13
CAA = CONTROL	19
CCA = MAIN LINE	22
CEA = ADDITION LINE	26
CGA = INFORMATION LINE	32
DAA = TOTALIZER 1	39
DAB = TOTALIZER 2	39
DAC = TOTALIZER 3	39
DGA = INVENTORY	42
DJA = HANDLING TOTALIZER	43
GGA = FOUNDATION FIELDBUS	45
GIA = PROCESS PARAMETER	48
GLA = SYSTEM PARAMETER	55
GNA = SENSOR DATA	56
JAA = SYSTEM	62
JCA = VERSION-INFO	64

Function groups

000 = MAIN VALUES	12
040 = CONFIGURATION	13
042 = ADDITIONAL CONFIGURATION	16
200 = BASIC CONFIGURATION	19
202 = UNLOCKING/LOCKING	20
204 = OPERATION	21
220 = CONFIGURATION	22
222 = MULTIPLEX	24
240 = CONFIGURATION	26
242 = MULTIPLEX	29
260 = CONFIGURATION	32
262 = MULTIPLEX	35
300 = CONFIGURATION	39
304 = OPERATION	41
620 = CONFIGURATION	45
622 = FUNCTION BLOCKS	46
624 = INFORMATION	47
640 = CONFIGURATION	48
642 = EPD PARAMETER	50
646 = REFERENCE PARAMETER	51
648 = ADJUSTMENT	53
660 = CONFIGURATION	55
680 = CONFIGURATION	56
684 = FLOW COEFFICIENT	57
685 = DENSITY COEFFICIENT	58
686 = ADDITIONAL COEFFICIENT	60
804 = OPERATION	62
820 = SENSOR	64
822 = AMPLIFIER	65
830 = I/O MODULE	66

Functions 0...

0000 = MASS FLOW	12
0001 = VOLUME FLOW	12
0004 = CORRECTED VOLUME FLOW	12
0005 = DENSITY	12
0006 = REFERENCE DENSITY	12
0008 = TEMPERATURE	12
0400 = UNIT MASS FLOW	13
0401 = UNIT MASS	13
0402 = UNIT VOLUME FLOW	14
0403 = UNIT VOLUME	14
0404 = UNIT CORRECTED VOLUME FLOW	15
0405 = UNIT CORRECTED VOLUME	15
0420 = UNIT DENSITY	16
0421 = UNIT REFERENCE DENSITY	16
0422 = UNIT TEMPERATURE	17
0424 = UNIT LENGTH	17

2...

2000 = LANGUAGE	19
2002 = DISPLAY DAMPING	19
2003 = LCD CONTRAST	19
2020 = ACCESS CODE	20
2021 = DEFINE PRIVATE CODE	20
2022 = STATUS ACCESS	20
2040 = TEST DISPLAY	21
2200 = ASSIGN	22
2201 = 100% VALUE	23
2202 = FORMAT	23
2220 = ASSIGN	24
2221 = 100% VALUE	24
2222 = FORMAT	25
2400 = ASSIGN	26
2401 = 100% VALUE	27
2402 = FORMAT	27
2403 = DISPLAY MODE	28
2420 = ASSIGN	29
2421 = 100% VALUE	30
2422 = FORMAT	30
2423 = DISPLAY MODE	31
2600 = ASSIGN	32
2601 = 100% VALUE	33
2602 = FORMAT	33
2603 = DISPLAY MODE	34
2620 = ASSIGN	35
2621 = 100% VALUE	36
2622 = FORMAT	36
2623 = DISPLAY MODE	37

3...

3000 = ASSIGN	39
3001 = UNIT TOTALIZER	39
3002 = TOTALIZER MODE	40
3003 = RESET TOTALIZER	40
3040 = SUM	41
3041 = OVERFLOW	41
3600 = SUM INVENTORY	42

3601 = OVERFLOW INVENTORY	42
3800 = RESET ALL TOTALIZERS	43
3801 = FAILSAFE ALL TOTALIZERS	43

6...

6200 = WRITE PROTECT	45
6201 = SIMULATION	45
6202 = BUS ADDRESS	45
6203 = DEVICE PD-TAG	45
6220 = BLOCK SELECTION	46
6221 = OUT VALUE	46
6222 = IN VALUE	46
6223 = CASCADE IN VALUE	46
6224 = SETPOINT VALUE	46
6240 = MANUFACTURER ID	47
6241 = DEVICE TYPE	47
6242 = SERIAL NUMBER	47
6243 = DEVICE REVISION	47
6244 = DD REVISION	47
6400 = ASSIGN LOW FLOW CUT OFF	48
6402 = ON-VALUE LOW FLOW CUT OFF	48
6403 = OFF-VALUE LOW FLOW CUT OFF	48
6404 = PRESSURE SHOCK SUPPRESSION	49
6420 = EMPTY PIPE DETECTION	50
6423 = EPD VALUE LOW	50
6424 = EPD VALUE HIGH	50
6425 = EPD RESPONSE TIME	50
6460 = CORRECTED VOLUME CALCULATION	51
6461 = FIXED REFERENCE DENSITY	51
6462 = EXPANSION COEFFICIENT	51
6463 = EXPANSION COEFFICIENT SQUARELY	51
6464 = REFERENCE TEMPERATURE	52
6480 = ZEROPOINT ADJUST	53
6483 = DENSITY SET VALUE	53
6484 = MEASURE FLUID	53
6487 = DENSITY ADJUST	54
6488 = RESTORE ORIGINAL	54
6600 = INSTALLATION DIRECTION SENSOR	55
6602 = DENSITY DAMPING	55
6603 = FLOW DAMPING	55
6605 = POSITIVE ZERO RETURN	55
6800 = K FACTOR	56
6803 = ZERO POINT	56
6804 = NOMINAL DIAMETER	56
6840 = TEMPERATURE COEFFICIENT KM	57
6841 = TEMPERATURE COEFFICIENT KM 2	57
6842 = TEMPERATURE COEFFICIENT KT	57
6843 = CALIBRATION COEFFICIENT KD 1	57
6844 = CALIBRATION COEFFICIENT KD 2	57
6850 = DENSITY COEFFICIENT C 0	58
6851 = DENSITY COEFFICIENT C 1	58
6852 = DENSITY COEFFICIENT C 2	58
6853 = DENSITY COEFFICIENT C 3	59
6854 = DENSITY COEFFICIENT C 4	59
6855 = DENSITY COEFFICIENT C 5	59
6860 = MINIMAL TEMPERATURE MEASURED	60
6861 = MAXIMAL TEMPERATURE MEASURED	60
6862 = MINIMAL TEMPERATURE CARRIER TUBE	60
6863 = MAXIMAL TEMPERATURE CARRIER TUBE	60

8...

8040 = ACTUAL SYSTEM CONDITION	62
8041 = PREVIOUS SYSTEM CONDITION	62
8042 = SIMULATION FAILSAFE MODE	62
8043 = SIMULATION MEASURAND	62
8044 = VALUE SIMULATION MEASURAND	63
8046 = SYSTEM RESET	63
8047 = TROUBLESHOOTING	63
8048 = OPERATION HOURS	63
8200 = SERIAL NUMBER	64
8201 = SENSOR TYPE	64
8202 = HW REV.-NUMBER SENSOR	64
8203 = HW ID-NUMBER SENSOR	64
8204 = PROD.-NUMBER SENSOR	64
8205 = SW REV.-NUMBER S-DAT	64
8220 = HW REV.-NUMBER AMPLIFIER	65
8221 = HW ID-NUMBER AMPLIFIER	65
8222 = SW REV.-NUMBER AMPLIFIER	65
8223 = SW ID- NUMBER AMPLIFIER	65
8224 = PROD.-NUMBER AMPLIFIER	65
8225 = SW REV.-NUMBER T-DAT	65
8300 = I/O MODULE TYPE	66
8301 = HW REV.-NUMBER I/O MODULE	66
8302 = HW ID-NUMBER I/O MODULE	66
8303 = SW REV.-NUMBER I/O MODULE	66
8304 = SW ID-NUMBER I/O MODULE	66
8305 = PROD.-NUMBER I/O MODULE	66

9 Index key words for local operation

A

Access Code	20
Actual system condition	62
Addition line	
Configuration	26
Multiplex	29
Additional coefficient	60
Additional configuration (System units)	16
Adjustment	
Density	54
Zero point	53
Amplifier (Version-Info)	65
Assign	
Addition line	26
Addition line (Multiplex)	29
Information line	32
Information line (Multiplex)	35
Low flow cut off	48
Main line	22
Main line (Multiplex)	24
Totalizer	39

B

Basic configuration (User interface)	19
Basic function	44
Block	
Basic functions	44
Measured variables	11
Supervision	61
Totalizer	38
User interface	18
Block Selection	46
Bus-address	45

C

Calibration	
Coefficient KD 1	57
Coefficient KD 2	57
Cascade IN Value	46
Coefficient	
Calibration KD 1	57
Calibration KD 2	57
Density C 0	58
Density C1	58
Density C2	58
Density C3	59
Density C4	59
Density C5	59
Expansion	51
Expansion (squarely)	51
Temperature KM	57
Temperature KM 2	57
Temperature KT	57

Configuration	
Addition line	26
FOUNDATION Fieldbus	45
Information line	32
Main line	22
Process parameter	48
Sensor data	56
System parameter	55
System units	13
Totalizer	39
Contrast LCD	19
Control (User interface)	
Basic configuration	19
Operation	21
Un-/Locking	20
Corrected volume calculation	51
Corrected volume flow	12

D

Damping	
Density	55
Display	19
Flow	55
DD Revision	47
Define private code	20
Density	12
Adjustment	54
Coefficient C0	58
Coefficient C1	58
Coefficient C2	58
Coefficient C3	59
Coefficient C4	59
Coefficient C5	59
Damping	55
Fixed reference density	51
Set value	53
Device PD-Tag	45
Device Revision	47
Device type	47
Display	
Damping	19
Test	21
Display mode	
Addition line	28
Addition line (Multiplex)	31
Information line	34
Information line (Multiplex)	37

E

EPD (Empty pipe detection)	
EPD	50
Response time	50
Value high	50
Value low	50

Expansion

Coefficient	51
Coefficient squarely	51

F

Failsafe

All totalizers	43
----------------	----

Fixed reference density	51
-------------------------	----

Flow

Coefficient	57
Damping	55

Flow damping	55
--------------	----

Fluid (measure)	53
-----------------	----

Format

Addition line	27
Addition line (Multiplex)	30
Information line	33
Information line (Multiplex)	36
Main line	23
Main line (Multiplex)	25

FOUNDATION Fieldbus

Configuration	45
Function blocks	46
Information	47

Function blocks (FOUNDATION Fieldbus)	46
---------------------------------------	----

Function groups

Additional coefficient	60
Additional configuration	16
Adjustment	53
Amplifier	65
Basic configuration (User interface)	19

Configuration

Additional line	26
FOUNDATION Fieldbus	45
Information line	32
Main line	22
Process parameter	48
Sensor data	56
System parameter	55
System units	13
Totalizer	39

Density coefficient	58
---------------------	----

EPD parameter	50
---------------	----

Flow coefficient	57
------------------	----

Function blocks

FOUNDATION Fieldbus	46
Information (FOUNDATION Fieldbus)	47
I/O Module	66
Main values	12

Function groups (continuation)

Multiplex

Addition line	29
Information line	35
Main line	24

Operation

System	62
Totalizer	41
User interface	21

Reference parameter	51
---------------------	----

Sensor	64
--------	----

Un-/Locking	20
-------------	----

Function matrix

Codes identifying	9
General layout	8
Overview	10

G

Groups

Additional line	26
Control (User interface)	19
FOUNDATION Fieldbus	45
Handling Totalizer	43
Information line	32
Inventory	42
Main line	22
Measuring values	12
Process parameter	48
Sensor data	56
System	62
System parameter	55
System units	13
Totalizer (1...3)	39
Version-Info	64

H

Handling Totalizer	43
--------------------	----

Hardware ID number

Amplifier	65
I/O Module	66
Sensor	64

Hardware revision number

Amplifier	65
I/O Module	66
Sensor	64

I

IN Value	46
----------	----

Information line

Configuration	32
Multiplex	35

Information (FOUNDATION Fieldbus)	47
-----------------------------------	----

Installation direction sensor	55
-------------------------------	----

Inventory

Overflow	42
Sum	42

I/O Module	66
------------	----

K

K Factor56

L

Language19

LCD Contrast19

Low flow cut off

Assign48

Off-Value48

On-Value48

M

Main line

Configuration22

Multiplex24

Main values (Measuring values)12

Manufacturer ID47

Mass flow12

Maximal

Temperature carrier tube60

Temperature measured60

Measure fluid53

Measured variables11

Measuring values12

Minimal

Temperature carrier tube60

Temperature measured60

Mode

Totalizer40

Multiplex

Addition line29

Information line35

Main line24

N

Nominal diameter56

O

Off-value Low flow cut off48

On-value Low flow cut off48

Operation

Hours63

System62

Totalizer41

OUT Value46

Overflow

Inventory42

Totalizer41

P

Positive zero return55

Pressure shock suppression49

Previous system condition62

Process parameter

Adjustment53

Configuration48

EPD parameter50

Reference parameter51

Production number

Amplifier65

I/O Module66

Sensor64

R

Reference Density12

Reference temperature52

Reset

All Totalizers43

Totalizer40

Restore original54

S

Sensor data

Additional coefficient60

Configuration56

Density coefficient58

Flow coefficient57

Sensor Type64

Sensor (Version-info)64

Serial number47

Serial number sensor64

Setpoint value46

Simulation45

Failsafe mode62

Measurand62

Software ID number

Amplifier65

I/O Module66

Software revision number

Amplifier65

I/O Module66

S-DAT64

T-DAT65

Status Access20

Sum

Inventory42

Totalizer41

Supervision61

System

Operation62

Reset63

System condition

Actual62

Previous62

S (continuation)

System parameter	
Configuration	55
System units	
Additional configuration	16
Configuration	13

T

Temperature	12
Coefficient KM	57
Coefficient KM 2	57
Coefficient KT	57
Test display	21
Totalizer	38
Configuration	39
Mode	40
Operation	41
Overflow	41
Reset	40
Sum	41
Unit	39
Troubleshooting	63
Type I/O Module	66

U

Unit	
Corrected Volume	15
Corrected volume flow	15
Density	16
Length	17
Mass	13
Mass flow	13
Reference density	16
Temperature	17
Totalizer	39
Volume	14
Volume flow	14
Un-/Locking (User interface)	20
User interface	18

V

Value Simulation	
Measurand	63
Version-Info	
Amplifier	65
I/O Module	66
Sensor	64
Volume flow	12

W

Write protect	45
---------------	----

Z

Zero point	56
Adjustment	53

Numerics

100% Value	
Addition line	27
Addition line (Multiplex)	30
Information line	33
Information line (Multiplex)	36
Main line	23
Main line (Multiplex)	24

Table of contents for FOUNDATION Fieldbus

1	Operation via FOUNDATION Fieldbus	75
1.1	Block model	75
2	Resource Block	77
2.1	Selecting the operating mode	77
2.2	Block status	77
2.3	Write protection and simulation	78
2.4	Alarm detection and processing	78
2.5	Parameters Resource Block	79
3	Transducer Block	86
3.1	Signal processing	86
3.2	Block output values	87
3.3	Selecting the operating mode	88
3.4	Alarm detection and processing	88
3.5	Diagnosis	88
3.6	Accessing the device-specific parameters	88
3.7	Transducer block parameters	89
4	Function blocks – general	131
5	Analog Input Function Block	132
5.1	Signal processing	132
5.2	Selecting the operating mode	133
5.3	Selection of the process variable	134
5.4	Linearisation types	134
5.5	Selection of units	134
5.6	Status of the output value OUT	135
5.7	Simulation of input/output	135
5.8	Diagnosis	135
5.9	Rescaling the input value	136
5.10	Limit values	137
5.11	Alarm detection and processing	137
5.12	Parameters of the Analog Input Function Block	138
6	Discrete Output Function block	151
6.1	Signal processing	151
6.2	Selection of the process variable	152
6.3	Safety behavior	152
6.4	Assignment between the Discrete Output Function block and the Transducer block	152
6.5	Values for the parameters CAS_IN_D, RCAS_IN_D, OUT_D, and SP_D	153
6.6	Parameter Discrete Output Funktionsblock	154
7	PID Function Block (PID controller)	160
7.1	Signal processing in the PID Function Block	160
7.2	PID Function Block equation	161
7.3	Selecting the operating mode	162
7.4	Setpoint selection	162
7.5	Damping	162
7.6	Limit Values	163
7.7	Alarm detection and processing	163
7.8	Example: Basic PID control strategy	164
7.9	PID Function Block configuration	165
7.10	Parameters of the PID Function Block	166
8	Index key words FOUNDATION Fieldbus	185

1 Operation via FOUNDATION Fieldbus

1.1 Block model

In the FOUNDATION Fieldbus all the device parameters are categorised according to their functional properties and task and are generally assigned to three different blocks. A block may be regarded as a container in which parameters and the associated functionalities are contained. A FOUNDATION Fieldbus device has the following block types:


- A Resource Block
The Resource Block contains all the device-specific characteristics of the device.
- One or more Transducer blocks (transmission blocks)
The Transducer block contains all the measuring technology and device-specific parameters of the device. The measurement principles (e.g. flow, temperature) are depicted in the Transducer blocks in accordance with the FOUNDATION Fieldbus specification.
- One or more function blocks
Function blocks contain the automation functions of the device. We distinguish between different function blocks, e.g. Analog Input Function Block, Analog Output function block, PID function block (PID controller), etc. Each of these function blocks is used to process different application functions.

Different automation tasks can be realized depending on the arrangement and connection of the individual blocks. In addition to these blocks, a field device may have any number of further blocks, e.g. several Analog Input Function Blocks if more than one process variable is available to from the field device.

Blocks used by the Promass 83 FF

The Promass 83 FF has the following blocks:

- A Resource Block
- A Transducer block for the measuring principle flow
- Nine function blocks
 - Seven Analog Input function blocks for the process variables Mass Flow, Volume Flow, Corrected Volume Flow, Density, Reference Density, Temperature and Totalizer 1 to 3.
 - One Discrete Output function block
 - One PID function block



The sensor signal is first prepared specifically for the flow in the measuring block (the Transducer block). The process variables (Volume Flow and Totalizer) are then passed to the Analog Input Function Blocks for technical processing (e.g. scaling, limit value processing).

The process variables go through the complete function block algorithm and are available to other function blocks, e.g. the PID block, as a starting variable for connecting the desired application function.

Using the Discrete Output function block (DO), various actions and functions in the Promass 83 FF can be initiated and controlled via FOUNDATION Fieldbus.

2 Resource Block

A Resource Block contains all the data that uniquely identifies and characterises the field device. It is an electronic version of a nameplate on the field device. Parameters of the Resource Block include device type, device name, manufacturer ID, serial number, etc.

A further task of the Resource Blocks is the management of overall parameters and functions that have an influence on the execution of the remaining blocks in the field device. The Resource Block is thus the central unit that also checks the device status and thereby influences or controls the operability of the other blocks and thus also of the device. Since the Resource Block has no block input and block output data, it cannot be linked with other blocks.

The major functions and parameters of the Resource Block are listed below; you will find an overview of all the available parameters starting on Page 79.

2.1 Selecting the operating mode

The operating mode is set via the parameter group MODE_BLK (see Page 82). The Resource Block supports the following operating modes:

- AUTO
- OOS



Note!

The block status OOS is also shown via the parameter BLOCK_ERR (see Page 80). In operating mode OOS, if write protection is not enabled, you can access all the write parameters without restriction.

2.2 Block status

The current operating status of the Resource Block is shown in the parameter RS_STATE (see Page 83).

The Resource Block can take on the following states:

- | | |
|------------------|---|
| – STANDBY | The Resource Block is in operating mode OOS. The remaining blocks cannot be executed. |
| – ONLINE LINKING | The connections configured between the function blocks have not yet been linked. |
| – ONLINE | Normal operating status; the Resource Block is in operating mode AUTO. The connections configured between the function blocks have been linked. |

2.3 Write protection and simulation

Write protection of the device parameters and simulation in the Analog Input and Discrete Output Function Block can be locked or unlocked via a jumper setting on the FOUNDATION Fieldbus I/O board (see Operating Instructions Promass 83 FF, BA 065D/06/en).

The parameter WRITE_LOCK (see Page 83) shows the status of the hardware write protection. The following statuses are possible:

- LOCKED = device data cannot be modified
- NOT LOCKED = device data can be modified

The parameter BLOCK_ERR (see Page 80) indicates whether a simulation is possible in the Analog Input and Discrete Output Function Block.

- Simulation Active = Simulation is possible in the Analog Input and Discrete Output Function Block

2.4 Alarm detection and processing

Process alarms provide information on particular block statuses and block events. The status of the process alarms is communicated to the fieldbus host system via the parameter BLOCK_ALM (see Page 79). The parameter ACK_OPTION (see Page 79) specifies whether an alarm must be acknowledged via the fieldbus host system.

The following process alarms are generated by the Resource Block:

- **Block process alarms**

The following block process alarms of the Resource Block are shown via the parameter BLOCK_ALM (see Page 79):

- OUT OF SERVICE
- SIMULATE ACTIVE

- **Write protection process alarm**

If write protection is disabled on the FOUNDATION Fieldbus I/O board, then prior to communicating the change of status to the fieldbus host system the alarm priority specified in the parameter WRITE_PRI (see Page 85) is checked. The alarm priority specifies the action taken when the write protection alarm WRITE_ALM (see Page 85) is enabled.



Note!

- If the option of a process alarm has **not** been enabled in the parameter ACK_OPTION (see Page 79), this process alarm can only be acknowledged in the parameter BLOCK_ALM (see Page 79).
- The parameter ALARM_SUM (see Page 79) shows the current status of all the process alarms.

2.5 Parameters Resource Block

The following table shows all the available parameters of the Resource Block.

Resource Block		
Parameter	Write access with operating mode (MODE_BLK)	Description
ACK_OPTION	AUTO - OOS	This parameter is used to specify whether a process alarm must be acknowledged at the time of alarm recognition by the fieldbus host system. If this option is enabled the process alarm is acknowledged automatically. Options: DISC ALM Write protection no longer exists, and thus the data can be accessed. BLOCK ALM Block alarm Factory setting: The option is not enabled for any alarm, the alarms must be acknowledged.
ALARM_SUM	AUTO - OOS	Displays the current status of the process alarms in the Resource Block. Display: DISC ALM Write protection no longer exists, and thus the data can be accessed. BLOCK ALM Block alarm  Note! In addition the process alarms can also be disabled in this parameter group.
ALERT_KEY	AUTO - OOS	Entry of the identification number of the plant unit. This information can be used by the fieldbus host system for sorting alarms and events. User input: 1...255 Factory setting: 0
BLOCK_ALM	AUTO - OOS	Displays the current block status with information on pending configuration, hardware or system errors, including details of the alarm time (date, time) when the error occurred. The block alarm is triggered in the event of the following block errors: • SIMULATE ACTIVE • OUT OF SERVICE  Note! If the option of the alarm has not been enabled in the parameter ACK_OPTION, the alarm can only be acknowledged via this parameter.

Resource Block		
Parameter	Write access with operating mode (MODE_BLK)	Description
BLOCK_ERR	read only	Displays the active block error. Display: SIMULATION ACTIVE Simulation is possible in the Analog Input function block via the parameter SIMULATE and in the Discrete Output block via parameter SIMULATE_D (for simulation mode configuration see also Operating Instructions Promass 83 FF BA 065D/06/en/). OUT OF SERVICE The block has the status "Out Of Service".
CLR_FSTATE	AUTO - OOS	This parameter can be used to manually disable the security behaviour of the Discrete Output function block. Options: UNINITIALIZED OFF CLEAR (security behaviour disabled)  Note! The security behaviour of the Discrete Output Block can be manually activated in the parameter SET_FSTATE.
CONFIRM_TIME	AUTO - OOS	Specifies the confirmation time for the event report. If the device does not receive confirmation within this time then the event report is sent to the fieldbus host system again. Factory setting: 640000 $\frac{1}{32}$ ms
CYCLE_SEL	AUTO - OOS	Displays the block execution method used by the fieldbus host system.  Note! The block execution method is selected by the fieldbus host system.
CYCLE_TYPE	read only	Displays the block execution methods supported by the device. Display: SCHEDULED (timed block execution method) BLOCK EXECUTION (sequential block execution method)
DD_RESOURCE	read only	Displays the reference source for the device description in the device. Display: (NULL)  Note! If there is no device description in the device then the designation (NULL) is displayed.
DD_REV	read only	Displays the revision number of the device description.
DEV_REV	read only	Displays the revision number of the device.
DEV_TYPE	read only	Displays the device type in decimal numerical format. Display: 4177 ($\cong$ 0 x 1051 hex) for Promass 83 FF

Resource Block		
Parameter	Write access with operating mode (MODE_BLK)	Description
FAULT_STATE	read only	Current status display of the security behaviour of the Discrete Output function block. Display: UNINITIALIZED CLEAR (security behaviour not active) ACTIVE (security behaviour active)
FEATURES	read only	Displays the additional options supported by the device. Display: REPORTS Event report is sent. FAULTSTATE The security behaviour of the Discrete Output Block is supported (see parameter CLR_STATE and SET_STATE). HARD W LOCK Hardware write protection.
FEATURES_SEL	AUTO - OOS	Selects the additional options of the device. Options: UNICODE (is not supported). REPORTS Event report is sent. The fieldbus host system must acknowledge receipt of the event report. FAULTSTATE The security behaviour of the Discrete Output Block is supported (see parameter CLR_STATE and SET_STATE). SOFT W LOCK (is not supported). HARD W LOCK Hardware write protection (this option has no effect). OUT READ BACK (is not supported). DIRECT WRITE (is not supported).
FREE_TIME	read only	Displays the free system time (in percent) available for execution of further function blocks.  Note! Since the function blocks of the Promass 83 FF are permanently configured, this parameter always displays the value 0%.
FREE_SPACE	read only	Displays the free system memory (in percent) available for execution of further function blocks.  Note! Since the function blocks of the Promass 83 FF are permanently configured, this parameter always displays the value 0%.
GRANT_DENY	AUTO - OOS	Releases or restricts the access authorisation of a fieldbus host system on the field device.  Note! This parameter is not evaluated by the Promass 83 FF.

Resource Block		
Parameter	Write access with operating mode (MODE_BLK)	Description
HARD_TYPES	read only	Displays the input signal type for the Analog Input function block. Display: SCALAR INPUT (scalable analog input value) DISCRETE OUTPUT
ITK_VER	read only	Displays the revision state of the Interoperability Test Kits (ITK). Display: 4.0
LIM_NOTIFY	AUTO - OOS	This parameter is used to specify the number of event reports that can exist unconfirmed at the same time. User input: 0...24 Factory setting: 24
MANUFAC_ID	read only	Displays the manufacturer's ID number. Display: 0 x 452B48 = Endress + Hauser
MAX_NOTIFY	read only	Displays the maximum number of event reports supported by the device that can exist unconfirmed at the same time. Display: 24
MEMORY_SIZE	read only	Displays the available configuration memory in kilobytes.  Note! This parameter is not supported.
MIN_CYCLE_T	read only	Displays the execution time of all the function blocks present in the device (Promass 83 FF = 1 PID, 1 DO plus 7 AI function blocks). Display: 6400 $\frac{1}{32}$ ms ($\approx$ 200ms)
MODE_BLK	AUTO - OOS	Displays the current (Actual) and desired (Target) operating mode of the Resource Block, the permitted modes (Permitted) supported by the Resource Block and the normal operating mode (Normal). Display: AUTO - OOS The Resource Block supports the following operating modes: • AUTO (automatic operation) In this mode the execution of the remaining blocks (Transducer block, AI and PID function block) is permitted. • OOS (Out Of Service) The block has the status "Out Of Service". In this mode execution of the remaining blocks (Transducer block, AI and PID function block) is blocked. These blocks are forced into OOS and cannot be set to AUTO mode.  Note! The current operating status of the Resource Block is also shown via the parameter RS_STATE (see Page 83).

Resource Block		
Parameter	Write access with operating mode (MODE_BLK)	Description
NV_CYCLE_T	read only	Displays the time interval for which the dynamic device parameters are stored in the non-volatile memory. The time interval displayed relates to storage of the following dynamic device parameters: • OUT • PV • FIELD_VAL  Note! Since the Promass 83 FF does not store the dynamic device parameter in the non-volatile memory, this parameter always displays the value 0 1/32 ms.
RESTART	AUTO - OOS	This parameter is used to reset the device in various ways. Options: UNINITIALIZED RUN Normal operating status. RESOURCE (is not supported) DEFAULTS The device data and the connections of the function blocks are reset to the factory settings. PROCESSOR Warm start of device, processor restart.
RS_STATE	read only	Displays the current operating status of the Resource Block. Display: STANDBY The Resource Block is in operating mode OOS. The remaining blocks cannot be executed. ONLINE LINKING The configured connections between the function blocks have not yet been made. ONLINE Normal operating status, the Resource Block is in operating mode AUTO. The configured connections between the function blocks have been made.
SET_FSTATE	AUTO - OOS	This parameter can be used to manually enable the security behaviour of the Discrete Output function block. Options: UNINITIALIZED OFF SET (the security behaviour will be enabled)  Note! The security behaviour of the Discrete Output Block can be manually deactivated in the parameter CLR_FSTATE.

Resource Block		
Parameter	Write access with operating mode (MODE_BLK)	Description
SHED_RCAS	AUTO - OOS	Specifies the monitoring time for checking the connection between the fieldbus host system and the PID function block in operating mode RCAS. On expiry of the monitoring time the PID function block switches from operating mode RCAS to the operating mode selected in the parameter SHED_OPT (see Page 181). Factory setting: 640000 $\frac{1}{32}$ ms
SHED_ROUT	AUTO - OOS	Specifies the monitoring time for checking the connection between the fieldbus host system and the PID function block in operating mode ROUT. On expiry of the monitoring time the PID function block switches from operating mode ROUT to the operating mode selected in the parameter SHED_OPT (see Page 181). Factory setting: 640000 $\frac{1}{32}$ ms
STRATEGY	AUTO - OOS	Parameter for grouping and thus faster evaluation of blocks. Grouping is carried out by entering the same numerical value in the parameter STRATEGY for each individual block. Factory setting: 0  Note! This data is neither checked nor processed by the Resource block.
ST_REV	read only	Displays the revision status of the static data.  Note! The revision status is incremented on each modification of static data.
TAG_DESC	AUTO - OOS	Entry of a user-specific text of max. 32 characters for unique identification and assignment of the block. Factory setting: " _ _ _ _ _ " without text
TEST_RW	AUTO - OOS	 Note! This parameter is required only for interoperability tests and has no meaning in normal operation.
UPDATE_EVT	read only	Displays whether static block data has been modified, including date and time.


Resource Block		
Parameter	Write access with operating mode (MODE_BLK)	Description
WRITE_ALM	AUTO - OOS	Displays the status of the write protection alarm.  Note! - The alarm is triggered if the write protection is disabled. - If the option of the alarm has not been enabled in the parameter ACK_OPTION, the alarm can only be acknowledged via this parameter.
WRITE_LOCK	read only	Displays the status of the hardware write protection. Display: UNINITIALIZED LOCKED Device data cannot be modified via fieldbus NOT LOCKED Device data can be modified via fieldbus  Note! For hardware write protection configuration see also Operating Instruction Promass 83 FF, BA 065D/06/en/.
WRITE_PRI	AUTO - OOS	Specifies the behaviour of a write protection alarm (parameter "WRITE_ALM"). User input: 0 The write protection alarm is not evaluated. 1 No report to the fieldbus host system in the event of a write protection alarm. 2 Reserved for block alarms. 3-7 The write protection alarm is output with the appropriate priority (3 = low priority, 7 = high priority) to the fieldbus host system as a user notice. 8-15 The write protection alarm is output with the appropriate priority (8 = low priority, 15 = high priority) to the fieldbus host system as a critical alarm. Factory setting: 0

3 Transducer Block

The Transducer block of the Promass 83 FF contains all the measurement- and device-specific parameters of the flowmeter. All the settings directly connected with the flow measurement/application are made here. It forms the interface between the sensor-specific measured value preprocessing and the Analog Input Function Blocks required for automation.

A Transducer block allows you to influence the input and output values of a function block. The parameters of a Transducer block include information on the sensor type, sensor configuration, physical units, calibration, damping, diagnosis, etc. as well as the device-specific parameters.

The diagram shows the internal structure of the Transducer block:



3.1 Signal processing

The Transducer block receives several signals from the sensor as input values (mass, density, temperature). Other process variables (volume, standard volume) are derived from these signals. The input signals further processed via an amplifier.

The parameter "Simulation - Value Measurand" (see Page 100) allows you to specify a simulation value for the Transducer block in order to test assigned parameters in the device and subsequent function blocks.

A low flow cut off allows you to hide measurement inaccuracies in the low-flow sector. The parameter "Low Flow Cut Off - On-Value" (see Page 93) allows you to define a limit value. If the measured flow value is below this limit value then the output value of 0 is output.

In addition, the parameter "System - Positive Zero Return" (see Page 103) allows you to switch the measured value to "Zero Flow". This is necessary when a piping system is being cleaned, for example.

The process variables of the Transducer blocks are output via the parameters Mass Flow, Volume Flow, Corrected Volume Flow, Density, Reference Density, Temperature and Totalizer 1 to 3. A process variable, e.g. mass flow, volume flow, etc., can be assigned to the individual totalizers. Each totalizer can be manually reset using the parameter Totalizer (1 - 3) - Reset.

The major functions and parameters of the Transducer block are listed below, you will find an overview of all the available parameters starting on Page 89.

3.2 Block output values

The Transducer block has nine permanent process variables:

- Mass Flow
- Volume Flow
- Corrected volume Flow
- Density
- Reference density
- Temperature
- Totalizer 1
- Totalizer 2
- Totalizer 3

Assignment of which process variable is copied in the subsequent Analog Input Function Block is carried out using the CHANNEL parameter of the Analog Input Function Block (see Page 141):

- The mass flow process variable (parameter Mass Flow, Page 94) of the Transducer block is assigned to the subsequent Analog Input Function Block by selecting CHANNEL = 1 → Mass Flow in the CHANNEL parameter there.
- The volume flow process variable (parameter Volume Flow, Page 130) of the Transducer block is assigned to the subsequent Analog Input Function Block by selecting CHANNEL = 2 → Volume Flow in the CHANNEL parameter there.
- The corrected volume flow process variable (parameter Corrected Volume Flow, Page 90) of the Transducer block is assigned to the subsequent Analog Input Function Block by selecting CHANNEL = 3 → Corrected Volume Flow in the CHANNEL parameter there.
- The density process variable (parameter Density, Page 90) of the Transducer block is assigned to the subsequent Analog Input Function Block by selecting CHANNEL = 4 → Density in the CHANNEL parameter there.
- The reference density process variable (parameter Reference Density, Page 95) of the Transducer block is assigned to the subsequent Analog Input Function block by selecting CHANNEL = 5 → Reference Density in the CHANNEL parameter there.
- The temperature process variable (parameter Temperature, Page 108) of the Transducer block is assigned to the subsequent Analog Input Function Block by selecting CHANNEL = 6 → Temperature in the CHANNEL parameter there.
- The totalizer 1 process variable (parameter Totalizer 1, Page 108) of the Transducer block is assigned to the subsequent Analog Input Function Block by selecting CHANNEL = 7 → Totalizer 1 in the CHANNEL parameter there.
- The totalizer 2 process variable (parameter Totalizer 2, Page 110) of the Transducer block is assigned to the subsequent Analog Input Function Block by selecting CHANNEL = 8 → Totalizer 2 in the CHANNEL parameter there.
- The totalizer 3 process variable (parameter Totalizer 3, Page 112) of the Transducer block is assigned to the subsequent Analog Input Function Block by selecting CHANNEL = 9 → Totalizer 3 in the CHANNEL parameter there.

3.3 Selecting the operating mode

The operating mode is set via the parameter group MODE_BLK (see Page 94). The Resource Block supports the following operating modes:

- AUTO
- MAN
- OOS



Note!

The block status OOS is also shown via the parameter BLOCK_ERR (see Page 90). In operating mode OOS, if write protection is not enabled and the access code is entered, you can access all the write parameters without restriction.

3.4 Alarm detection and processing

The Transducer block does not generate any process alarms. The status of the process variables of the Transducer block is evaluated in the subsequent Analog Input Function Blocks. If the Analog Input Function Block receives no input value that can be evaluated from the Transducer block then a process alarm is generated. This process alarm is displayed in the parameter BLOCK_ERR of the Analog Input Function Block (see Page 141) (BLOCK_ERR = Input Failure / process variable has BAD status).

The parameter BLOCK_ERR of the Transducer block (see Page 90) displays the device error that produced the input value that could not be evaluated and thus triggered the process alarm in the Analog Input Function Block. Similarly, the active device error of the Transducer block is displayed in the parameter Transducer Error (see Page 115). More information on remedying errors can be found in the Operating Instructions Promass 83 FF BA 065D/06/en.

3.5 Diagnosis

The status of the device is displayed via the following parameters specified in the FOUNDATION Fieldbus specification:

- BLOCK_ERR (see Page 90)
- Transducer Error (see Page 115)

Detailed information on the current device status is shown in the device-specific parameter "Diagnosis - Actual System Condition" (see Page 91).

3.6 Accessing the device-specific parameters

To access the device-specific parameters the following requirements must be met:

1. Hardware write protection must be disabled.
2. The correct code must be entered in the parameter "Un/Locking - Access code" (see Page 115).

3.7 Transducer block parameters

The following table shows all the available parameters of the Transducer block. A gray  background marks the manufacturer-specific parameters. These parameters are not accessible until the Un-/Locking Access Code has been entered.


Transducer block		
Parameter	Write access with operating mode (MODE_BLK)	Description
ALERT_KEY	AUTO - MAN - OOS	For entry of the identification number of the plant unit. This information can be used by the fieldbus host system for sorting alarms and events. User input: 1...255 Factory setting: 0
Amplifier - HW-Revision	read only	Use this parameter to view the hardware revision number of the amplifier.
Amplifier - HW-Identification	read only	Use this parameter to view the hardware ID number of the amplifier.
Amplifier - SW-Revision	read only	Use this parameter to view the software revision number of the amplifier.
Amplifier - SW-Identification	read only	Use this parameter to view the software ID number of the amplifier.
Amplifier - Production-No.	read only	Use this parameter to view the production number of the amplifier.
Amplifier - SW-Rev. T-DAT	read only	Use this parameter to view the software revision number of the software used to create the content of the T-DAT.
BLOCK_ALM	AUTO - MAN - OOS	Displays the current block status with information on pending configuration, hardware or system errors, including details of the alarm time (date, time) when the error occurred.  Note! - In addition the active block alarm can be acknowledged in this parameter group. - The Promass 83 FF does not use this parameter to display a process alarm since these are generated in the parameter "BLOCK_ALM" of the Analog Input Function Block (see Seite 140).

Transducer block		
Parameter	Write access with operating mode (MODE_BLK)	Description
BLOCK_ERR	read only	Displays the active block error. Display: SIMULATE ACTIVE Simulation via the parameter "Simulation - Measurand" (see Page 100) in the Transducer block is enabled. OUT OF SERVICE The block has the status "Out Of Service". DEVICE NEEDS MAINTENANCE NOW The device needs to be checked since an active device error is pending. A detailed display of the cause of the device error can be called up via the parameter "Diagnosis - Actual System Condition" (see Page 91) in the Transducer block.
Corrected Volume	read only	Displays the current measured value and the status of the third process variable (Corrected Volume Flow) made available to the Analog Input Function Block as an input value.
Corrected Volume Unit	read only	Displays the unit of the corrected volume flow.  Note! The unit is set in the associated Analog Input Function Block via the parameter group "XD_SCALE" (see Seite 150).
Density	read only	Displays the current measured value and the status of the fourth process variable (Density) made available to the Analog Input Function Block as an input value.
Density Unit	read only	Displays the unit of the density.  Note! The unit is set in the associated Analog Input Function Block via the parameter group "XD_SCALE" (see Seite 150).
Density Adjustment - Set Value	AUTO - MAN - OOS	In this parameter, enter the density set value of the fluid for which you want to carry out a field density adjustment. User input: 5-digit floating-point number  Note! The preset density entered here should not vary from the actual fluid density by a more than $\pm 10\%$.
Density Adjustment - Unit	read only	Displays the unit of the density adjustment.  Note! The appropriate unit is taken from the corresponding parameter "System Unit - Density" (see Seite 106).
Density Adjustment - Measure Fluid	AUTO - MAN - OOS	In this parameter the actual density of the fluid is measured for the density adjustment. Options: CANCEL START

Transducer block		
Parameter	Write access with operating mode (MODE_BLK)	Description
Density Adjustment	AUTO - MAN - OOS	With this parameter a density adjustment can be carried out. The density adjustment values will thus be recalculated and stored. This ensures that the values dependent on density calculations (e.g. mass flow) are as accurate as possible.  Note! Before carrying out a density adjustment, please refer to BA059D/06/en "Promass 83 FF Operating Instructions" where a detailed description of the density adjustment is given. 1-point density adjustment (with one fluid) This type of density adjustment is necessary under the following conditions: • The sensor does not accurately measure the density which the operator expects based on laboratory trials. • The characteristics of the fluid are outside the measuring points set at the factory or reference conditions under which the flowmeter has been calibrated. • The plant is used solely for measuring a fluid whose density is to be determined very accurately under constant conditions. User input: CANCEL START Factory setting: CANCEL
Density Adjustment - Restore Original	AUTO - MAN - OOS	With this parameter the original density coefficient determined at the factory are restored. Options: NO YES Factory setting: NO
Diagnosis - Actual System Condition	read only	Displays the current system status.  Note! A precise error description as well as notes on remedying errors can be found in the Operating Instructions Promass 83 FF BA065D/06/en.
Diagnosis - Prev. System Condition	read only	Displays the last error message that occurred.  Note! The display can be reset manually using the parameter "Diagnosis - Prev. System Condition Reset".
Diagnosis - Reset Prev. System Condition	AUTO - MAN - OOS	Resets the stored error message in the parameter "Diagnosis - Prev. System Condition". Options: NO YES

Transducer block		
Parameter	Write access with operating mode (MODE_BLK)	Description
Diagnosis - Alarm Delay	AUTO - MAN - OOS	Use this parameter to define a time span for which the criteria for an error have to be satisfied without interruption, before an error or notice message is generated.  Note! Depending on the setting and the type of error, this suppression acts on the display. User input: 0...100 s (in steps of one second) Factory setting: 0 s  Caution! If this parameter is activated error and notice messages are delayed by the time corresponding to the setting before being forwarded to the higher-order controller (process controller, etc.). It is therefore imperative to check in advance in order to make sure whether a delay of this nature could affect the safety requirements of the process. If error and notice messages cannot be suppressed, a value of 0 seconds must be entered here.
EPD - Empty Pipe Detection	AUTO - MAN - OOS	Use this parameter to activate the empty pipe detection (EPD). With empty measuring tubes the density of the fluid falls below a specified value (see parameter "EPD - Low Value"). Options: OFF ON Factory setting: OFF  Caution! • Select a correspondingly low EPD response value in the EPD VALUE LOW parameter, so that the difference to the effective density of the fluid is sufficiently large enough. This ensures that totally empty measuring tubes and not partially filled ones are detected. • For gas measurement we strongly recommend to switch off empty pipe detection.
EPD - Low Value	AUTO - MAN - OOS	Use this parameter to set an lower threshold for the measured density value, in order to detect possible problems in the process indicated by too low density. User input: 5-digit floating-point number Factory setting: 0.2000
EPD - High Value	AUTO - MAN - OOS	Use this parameter to set an upper threshold for the measured density value. User input: 5-digit floating-point number Factory setting: 6.0000

Transducer block		
Parameter	Write access with operating mode (MODE_BLK)	Description
EPD - Unit	read only	Displays the unit of the empty pipe detection (EPD).  Note! The appropriate unit is taken from the parameter "System Unit - Density" (see Seite 106).
EPD - Responcetime	AUTO - MAN - OOS	Use this parameter to enter the time span for which the criteria for an empty pipe have to be satisfied without interruption before a notice message or fault message is generated. User input: fixed-point number: 1.0...60.0 s Factory setting: 1.0 s
I/O Module - Type	read only	Use this parameter to view the FOUNDATION Fieldbus module type.
I/O Module - HW-Revision	read only	Use this parameter to view the hardware revision number of the I/O module.
I/O Module - HW-Identification	read only	Use this parameter to view the hardware ID number of the I/O module.
I/O Module - SW-Revision	read only	Use this parameter to view the software revision number of the I/O module.
I/O Module - SW-Identification	read only	Use this parameter to view the software ID number of the I/O module.
I/O Module - Production-No.	read only	Use this parameter to view the production number of the I/O module.
Low Flow Cut Off - Assign	AUTO - MAN - OOS	Use this parameter to assign the switching point for Low flow cut off rate suppression. Options: OFF MASS FLOW VOLUME FLOW COR. VOLUME FLOW Factory setting: MASS FLOW
Low Flow Cut Off - On-Value	AUTO - MAN - OOS	Use this parameter to assign a value to the switch-on point for Low flow cut off. Low flow cut off is active if the setting is a value not equal to 0. The sign of the flow value is highlighted on the display to indicate that Low flow cut off is active. User input: depends on nominal diameter Factory setting: 0.0000  Note! With low flow cut off active, the status condition of the process variable changes to UNCERTAIN.

Transducer block		
Parameter	Write access with operating mode (MODE_BLK)	Description
Low Flow Cut Off - Off-Value	AUTO - MAN - OOS	Use this parameter to assign a value to the switch-off point for Low flow cut off. Enter the OFF-VALUE as a positive hysteresis from the ON-VALUE. User input: 0...100% Factory setting: 50% Example: Low Flow Cut Off - Assign = VOLUME FLOW Low Flow Cut Off - Off-Value = 50% Low Flow Cut Off - On-Value = 10 Low Flow Cut Off - Unit = l/s This results in a Low Flow Cut Off - Off Value of 15 l/s $10 \text{ l/s} + (10 \text{ l/s} \times 0,5) = 15 \text{ l/s}$ 
Low Flow Cut Off - Unit	AUTO - MAN - OOS	Displays the unit of the Low flow cut off.  Note! The appropriate unit is taken from the corresponding parameter "System Unit - Mass Flow", "System Unit - Volume Flow" or "System Unit - Cor. Volume Flow"
Mass Flow	read only	Displays the current measured value and the status of the first process variable (Mass Flow) made available to the Analog Input Function Block as an input value.
Mass Flow Unit	read only	Displays the unit of the mass flow.  Note! The unit is set in the associated Analog Input Function Block via the parameter group "XD_SCALE" (see Seite 150).
MODE_BLK	AUTO - OOS	Displays the current (Actual) and desired (Target) operating mode of the Transducer block, the permitted modes (Permitted) supported by the Resource Block and the normal operating mode (Normal). Display: AUTO - MAN - OOS  Note! The Transducer block supports the following operating modes: • AUTO (automatic operation) The block is executed. • MAN (manual intervention by the operator) • OOS (Out Of Service) The block has the status "Out Of Service". The process variables are updated, but the status of the process variables changes to BAD.

F06-53xFF-xx-05-xx-xx-en-000

Transducer block		
Parameter	Write access with operating mode (MODE_BLK)	Description
Reference Density	read only	Displays the current measured value and the status of the fifth process variable (Reference Density) made available to the Analog Input Function Block as an input value.
Reference Density - Unit	read only	Displays the unit of the reference density.  Note! The unit is set in the associated Analog Input Function Block via the parameter group "XD_SCALE" (see Seite 150).
Reference Param. - Cor. Volume Calc.	AUTO - MAN - OOS	This parameter is used to set the reference density for calculating the corrected volume flow. Options: CALC. REF. DENSITY FIX REF. DENSITY Factory setting: CALC. REF. DENSITY
Reference Param. - Fixed Ref. Density	AUTO - MAN - OOS	 Note! This input is not active unless the FIX REF. DENSITY setting was selected in the parameter "Reference Param. - Cor. Volume Calc.". In this parameter, a fixed value for the reference density can be entered, with which the corrected volume flow or corrected volume is calculated. User input: 5-digit floating-point number Factory setting: 1
Reference Param. - Fixed Ref. Density Unit	read only	Display of the unit used for the standard density in the calculation of corrected volume flow.  Note! The appropriate unit is taken from the corresponding parameter "System Unit - Reference Density" (see Seite 107).
Reference Param. - Expansion Coefficient	AUTO - MAN - OOS	 Note! This input is not active unless the CALC. REF. DENSITY setting was selected in the parameter "Reference Param. - Cor. Volume Calc.". For temperature compensated calculations of the reference density an expansion coefficient specific to the fluid is required and can be entered in this parameter. User input: 5-digit floating-point number Factory setting: 0.5000 e-3 [1/K]

Transducer block		
Parameter	Write access with operating mode (MODE_BLK)	Description
Reference Param. - Expansion Coefficient Squarely	AUTO - MAN - OOS	Use this parameter to enter a squarely expansion coefficient, if the temperature compensation follows a non-linear behaviour. User input: 5-digit floating-point number Factory setting: 0 e-6 [1/K²]
Reference Param. - Reference Temperature	AUTO - MAN - OOS	 Note! This input is not active unless the CALC. REF. DENSITY setting was selected in the parameter "Reference Param. - Cor. Volume Calc.". Input of the reference temperature for calculation corrected volume flow, corrected volume and reference density. User input: 5-digit floating-point number Factory setting: 20.000 The reference density is calculated as follows: $\rho_N = \rho \cdot (1 + \alpha \Delta t + \beta \Delta t^2) ; \text{ where } \Delta t = t - t_N$ ρ_N = Reference density ρ = Actual measured density of fluid (measured value Promass) t = Actual measured temperature of fluid (measured value Promass) t_N = Ref. temperature for calculating reference density (e.g. 20 °C) α = Vol. expansion coefficient of the fluid. Unit = [1/K]; K = Kelvin β = Square vol. expansion coefficient of the fluid. Unit = [1/K²]
Reference Param. - Ref. Temperature Unit	read only	Display of the unit used for the temperature in the calculation of corrected volume flow.  Note! The appropriate unit is taken from the corresponding parameter "System Unit - Temperature" (see Seite 107).
Sensor - Serial Number	read only	Use this parameter to view the serial number of the sensor.
Sensor - Type	read only	Use this parameter to view the sensor type (e.g. Promass F).
Sensor - HW-Revision	read only	Use this parameter to view the hardware revision number of the sensor.
Sensor - HW-Identification	read only	Use this parameter to view the hardware ID number of the sensor.
Sensor - Production-No.	read only	Use this parameter to view the production number of the sensor.
Sensor - SW-Rev. S-DAT	read only	Use this parameter to view the software revision number of the software used to create the content of the S-DAT™.


Transducer block		
Parameter	Write access with operating mode (MODE_BLK)	Description
Sensor Data - K-Factor	AUTO - MAN - OOS	This parameter shows the current calibration factor for the sensor. Factory setting: depends on nominal diameter and calibration  Note! If the service code is used to call this parameter, this value can be edited.
Sensor Data - Zeropoint	AUTO - MAN - OOS	This parameter shows the current zero-point correction value for the sensor. User input: max. 5-digit number: -99999 ...+99999 Factory setting: depends on calibration
Sensor Data - Nominal Diameter	AUTO - MAN - OOS	This parameter shows the nominal diameter for the sensor. Factory setting: depends on the size of the sensor  Note! If the service code is used to call this parameter, this value can be edited.
Sensor Data - Min. Temp. Meas.	read only	Display of the lowest fluid temperature measured.
Sensor Data - Max. Temp. Meas.	read only	Display of the highest fluid temperature measured.
Sensor Data - Min. Temp. Carr.	read only	Display of the lowest carrier tube temperature measured.
Sensor Data - Max. Temp. Carr.	read only	Display of the highest carrier tube temperature measured.
Sensor Data - Temperature Unit	read only	Displays the unit of the Temperature.  Note! The appropriate unit is taken from the corresponding parameter "System Unit - Temperature" (see Seite 107).
Sensor Data - Temp. Coeff. KM	read only	This parameter shows the temperatur coefficient KM.
Sensor Data - Temp. Coeff. KM 2	read only	This parameter shows the temperatur coefficient KM 2.
Sensor Data - Temp. Coeff. KT	read only	This parameter shows the temperatur coefficient KT.
Sensor Data - Cal. Coeff. KD 1	read only	This parameter shows the calibration coefficient KD 1.
Sensor Data - Cal. Coeff. KD 2	read only	This parameter shows the calibration coefficient KD 2.

Transducer block		
Parameter	Write access with operating mode (MODE_BLK)	Description
Sensor Data - Density Coeff. C 0	AUTO - MAN - OOS	This parameter shows the actual density coefficient C 0.  Note! If the service code is used to call this parameter, this value can be edited.  Caution! A density adjustment can alter the calibration value of this coefficient.
Sensor Data - Density Coeff. C 1	AUTO - MAN - OOS	This parameter shows the actual density coefficient C 1.  Note! If the service code is used to call this parameter, this value can be edited.  Caution! A density adjustment can alter the calibration value of this coefficient.
Sensor Data - Density Coeff. C 2	AUTO - MAN - OOS	This parameter shows the actual density coefficient C 2.  Note! If the service code is used to call this parameter, this value can be edited.  Caution! A density adjustment can alter the calibration value of this coefficient.
Sensor Data - Density Coeff. C 3	AUTO - MAN - OOS	This parameter shows the actual density coefficient C 3.  Note! If the service code is used to call this parameter, this value can be edited.  Caution! A density adjustment can alter the calibration value of this coefficient.
Sensor Data - Density Coeff. C 4	AUTO - MAN - OOS	This parameter shows the actual density coefficient C 4.  Note! If the service code is used to call this parameter, this value can be edited.  Caution! A density adjustment can alter the calibration value of this coefficient.
Sensor Data - Density Coeff. C 5	AUTO - MAN - OOS	This parameter shows the actual density coefficient C 5.  Note! If the service code is used to call this parameter, this value can be edited.  Caution! A density adjustment can alter the calibration value of this coefficient.

Transducer block		
Parameter	Write access with operating mode (MODE_BLK)	Description
Service/Analys. - Osc. Frequency	AUTO - MAN - OOS	This parameter is only used for service purpose.  Note! If the service code is used to call this function, this value is editable.
Service/Analys. - Exciter Current	AUTO - MAN - OOS	This parameter is only used for service purpose.  Note! If the service code is used to call this function, this value is editable.
Service/Analys. - Monitoring Mode	AUTO - MAN - OOS	This parameter is only used for service purpose.  Note! If the service code is used to call this function, this value is editable.
Service/Analys. - Monitoring Osc. Amplitude	AUTO - MAN - OOS	This parameter is only used for service purpose.  Note! If the service code is used to call this function, this value is editable.
Service/Analys. - Monitoring Gain Amplifier	AUTO - MAN - OOS	This parameter is only used for service purpose.  Note! If the service code is used to call this function, this value is editable.
Service/Analys. - Gas Mode	AUTO - MAN - OOS	This parameter is only used for service purpose.  Note! If the service code is used to call this function, this value is editable.
Service/Analys. - Gas Type	AUTO - MAN - OOS	This parameter is only used for service purpose.  Note! If the service code is used to call this function, this value is editable.
Service/Analys. - Sonic Velocity	AUTO - MAN - OOS	This parameter is only used for service purpose.  Note! If the service code is used to call this function, this value is editable.
Service/Analys. - T. Coeff. Sonic Velocity	AUTO - MAN - OOS	This parameter is only used for service purpose.  Note! If the service code is used to call this function, this value is editable.

Transducer block		
Parameter	Write access with operating mode (MODE_BLK)	Description
Simulation - Measurand	AUTO - MAN - OOS	Use this parameter to set all inputs, outputs and totalizers to their defined flow-response modes, in order to check whether they respond correctly. During this time, the words "SIMULATION MEASURAND" appear on the display. Options: OFF MASS FLOW VOLUME FLOW COR. VOLUME FLOW DENSITY REFERENCE DENSITY TEMPERATURE Factory setting: OFF  Note! The active simulation mode is passed on to subsequent function blocks via the status condition (UNCERTAIN) of the process variable.  Caution! • The measuring device cannot be used for measuring while this simulation is in progress. • The setting is not saved if the power supply fails.
Simulation - Value Measurand	AUTO - MAN - OOS	 Note! The parameter is not visible unless the parameter "Simulation - Measurand" is active. Use this parameter to define a selectable value (e.g. 12 m³/s). This is used to test the associated parameters in the flowmeter itself and downstream function blocks. User input: 5-digit floating-point number Factory setting: 0  Caution! The setting is not saved if the power supply fails.
Simulation - Unit	read only	Displays the unit used for the simulation.  Note! Depending on the selection in the parameter "Simulation - Measurand", the unit is taken over from the corresponding parameter "System Unit -"
ST_REV	read only	Displays the revision status of the static data.  Note! The revision status parameter is incremented on each modification of static data.

Transducer block		
Parameter	Write access with operating mode (MODE_BLK)	Description
System - Reset	AUTO - MAN - OOS	Use this parameter to perform a reset of the measuring system. Options: NO RESTART SYSTEM (restart without interrupting power supply) ORIGINAL TRANSMITTER DATA Factory setting: NO
System - T-DAT Save/Load	AUTO - MAN - OOS	Use this parameter to save the parameter settings / configuration of the transmitter in a transmitter DAT (T-DAT), or to load the parameter settings from the T-DAT into the internal EEPROM. Application examples: • After commissioning, the current measuring-point parameters can be saved to the T-DAT as a backup. • If the transmitter is replaced for some reason, the data from the T-DAT can be loaded into the new transmitter (EEPROM). Options: CANCEL SAVE (from EEPROM to T-DAT) LOAD (from T-DAT to EEPROM) Factory setting: CANCEL  Note! If the power supply fails, the totalizer readings are automatically saved to the EEPROM.
System - Install. Direction Sensor	AUTO - MAN - OOS	Use this parameter to reverse the sign of the flow quantity, if necessary. Options: NORMAL (flow as indicated by the arrow) INVERSE (flow opposite to direction indicated by the arrow) Factory setting: NORMAL  Note! Ascertain the actual direction of fluid flow with reference to the direction indicated by the arrow on the sensor (nameplate).

Transducer block		
Parameter	Write access with operating mode (MODE_BLK)	Description
System - Pressure Shock Suppression	AUTO - MAN - OOS	The closure of a valve can cause brief but severe movements of the fluid in the piping system, movements which the measuring system registers. The pulses totaled in this way result in a totalizer reading error, particularly in the case of filling processes. For this reason, the measuring device is equipped with Pressure shock suppression (= short-term signal suppression) which can eliminate system-related "disruptions".  Note! Note that Pressure shock suppression cannot be used unless the Low flow cut off is active (see parameter "Low Flow Cut Off - On-Value on Seite 93). Use this parameter to define the time span for active pressure shock suppression. Activation of the Pressure shock suppression Pressure pulse suppression is activated after the flow falls below the ON_Value of the Low flow cut off (see point 1 in grafic). While Pressure shock suppression is active, the following conditions apply: • Flow reading on display → 0 • Totalizer reading → the totalizers are pegged at the last correct value. Deactivation of the Pressure shock suppression The Pressure shock suppression is deactivated after the time interval, set in this parameter, has passed (see point 2 in grafic).  Note! The actual flow value is displayed and output, when the time interval for the Pressure shock suppression has passed and the flow exceeds the OFF-VALUE of the Low flow cut off (see point 3 in grafic).  Low flow cutoff OFF-Value ON-Value Pressure shock suppression → inactive → active → inactive Given time User input: max. 4-digit number, incl. unit: 0.00...100.00 s Factory setting: 0.00 s

Transducer block		
Parameter	Write access with operating mode (MODE_BLK)	Description
System - Density Damping	AUTO - MAN - OOS	The density filter allows the sensitivity of the density measuring signal to be lowered with respect to variations in the density of the fluid, e.g. with inhomogeneous liquids. The damping acts on all parameters and outputs of the measuring device. User input: max. 5-digit number, including unit: 0.00...100.00 s Factory setting: 0.00 s
System - Flow Damping	AUTO - MAN - OOS	Using the interference blanking (= time constant for exponential filter) the sensitivity of the flow measurement signal can be reduced with respect to transient flows and interference peaks; e.g. with fluid containing solids or gas bubbles, etc. The damping acts on all parameters and outputs of the measuring device. User input: 0...100 s Factory setting: 0 s
System - Positive Zero Return	AUTO - MAN - OOS	Use this parameter to interrupt evaluation of measured variables. This is necessary when a piping system is being cleaned, for example. This setting acts on all parameter and outputs of the measuring device. Options: OFF ON (signal output is set to the zero flow value, temperature and density are output normally) Factory setting: OFF  Note! - The active Positive Zero Return is passed on to subsequent function blocks via the status condition (UNCERTAIN) of the process variable. - Interruption of the processing of measured values can, also using cyclic scheduled data transmission, be controlled or initiated via the Discrete Output function block.

Transducer block		
Parameter	Write access with operating mode (MODE_BLK)	Description
System Value Mass Flow	read only	The currently measured mass flow appears on the display. Display shows: 5-digit floating-point number, including unit and sign (e.g. 462.87 kg/h; -731.63 lb/min; etc.)
System Unit Mass Flow	AUTO - MAN - OOS	Use this parameter to select the unit for the mass flow (mass/time). The unit you select here is also valid for: • Simulation • Low flow cut off Options: Metric: gram → g/s; g/min; g/h; g/day kilogram → kg/s; kg/min; kg/h; kg/day ton → t/s; t/min; t/h; t/day US: ounce → oz/s; oz/min; oz/h; oz/day pound → lb/s; lb/min; lb/h; lb/day ton → ton/s; ton/min; ton/h; ton/day Factory setting: kg/h  Note! The unit selected here has no influence on the transmitted process variable to the Analog Input Function block.

Transducer block		
Parameter	Write access with operating mode (MODE_BLK)	Description
System Value Volume Flow	read only	The volume flow appears on the display. The volume flow is derived from the measured mass flow and the measured density of the fluid. Display shows: 5-digit floating-point number, including unit and sign (e.g. 5.5445 dm³/min; 1.4359 m³/h; -731.63 us gal/d; etc.)
System Unit Volume Flow	AUTO - MAN - OOS	Use this parameter to select the unit for the volume flow (volume/time). The unit you select here is also valid for: • Simulation • Low flow cut off Options: Metric: – Kubikzentimeter → cm³/s; cm³/min; cm³/h; cm³/day – Kubikdezimeter → dm³/s; dm³/min; dm³/h; dm³/day – Kubikmeter → m³/s; m³/min; m³/h; m³/day – Milliliter → ml/s; ml/min; ml/h; ml/day – Liter → l/s; l/min; l/h; l/day – Hektoliter → hl/s; hl/min; hl/h; hl/day – Megaliter → Ml/s MEGA; Ml/min MEGA; Ml/h MEGA; Ml/day MEGA US: – Cubic centimeter → cc/s; cc/min; cc/h; cc/day – Acre foot → af/s; af/min; af/h; af/day – Cubic foot → ft³/s; ft³/min; ft³/h; ft³/day – Fluid ounce → fl. oz/s; fl. oz/min; fl. oz/h; fl. oz/day – Gallon → us gal/s; us gal/min; us gal/h; us gal/day – Million gallon → us Mgal/s; us Mgal/min; us Mgal/h; us Mgal/day – Barrel (normal fluids: 31,5 gal/bbl) → us bbl/s NORM.; us bbl/min NORM.; us bbl/h NORM.; us bbl/day NORM. – Barrel (beer: 31,0 gal/bbl) → us bbl/s BEER; us bbl/min BEER; us bbl/h BEER; us bbl/day BEER – Barrel (petrochemicals: 42,0 gal/bbl) → us bbl/s PETR.; us bbl/min PETR.; us bbl/h PETR.; us bbl/day PETR. – Barrel (filling tanks: 55,0 gal/bbl) → us bbl/s TANK; us bbl/min TANK; us bbl/h TANK; us bbl/day TANK Imperial: – Gallon → imp. gal/s; imp. gal/min; imp. gal/h; imp. gal/day – Mega gallon → imp. Mgal/s; imp. Mgal/min; imp. Mgal/h; imp. Mgal/day – Barrel (beer: 36,0 gal/bbl) → imp. bbl/s BEER; imp. bbl/min BEER; imp. bbl/h BEER; imp. bbl/day BEER – Barrel (petrochemicals: 42,0 gal/bbl) → imp. bbl/s PETR.; imp. bbl/min PETR.; imp. bbl/h PETR.; imp. bbl/day PETR. Factory setting: m³/h  Note! The unit selected here has no influence on the transmitted process variable to the Analog Input Function block.

Transducer block		
Parameter	Write access with operating mode (MODE_BLK)	Description
System Value Cor. Volume Flow	read only	The corrected volume flow appears on the display. The corrected volume flow is derived from the measured mass flow and the reference density (density at reference temperature, measured or fixed entry) of the fluid. Display shows: 5-digit floating-point number, including unit and sign (e.g. 1.3549 Nm³/h; 7.9846 scm/day; etc.)
System Unit Corrected Volume Flow	AUTO - MAN - OOS	Use this parameter to select the unit for the corrected volume flow (corrected volume/time). The unit you select here is also valid for: • Simulation • Low flow cut off Options: Metric: Normliter → Nl/s; Nl/min; Nl/h; Nl/day Normkubikmeter → Nm³/s; Nm³/min; Nm³/h; Nm³/day US: Standard cubic meter → Sm³/s; Sm³/min; Sm³/h; Sm³/day Standard cubic foot → Scf³/s; Scf³/min; Scf³/h; Scf³/day Factory setting: Nm³/h  Note! The unit selected here has no influence on the transmitted process variable to the Analog Input Function block.
System Value Density	read only	The currently measured density or its specific gravity appears on the display. Display shows: 5-digit floating-point number, including unit corresponding to 0.100000...6.00000 kg/dm³ (e.g. 1.2345 kg/dm³; 993.5 kg/dm³; 1.0015 SG_20 °C; etc.)
System Unit Density	AUTO - MAN - OOS	Use this parameter to select the unit for the fluid density. The unit you select here is also valid for: • Simulation • Density adjustment value • Density response value for EPD Options: Metric → g/cm³; g/cc; kg/dm³; kg/l; kg/m³; SD 4 °C, SD 15 °C, SD 20 °C; SG 4 °C, SG 15 °C, SG 20 °C US → lb/cft; lb/gal; us lb/bbl (NORM.); us lb/bbl (BEER); us lb/bbl (PETR.); us lb/bbl (TANKS) Imperial → imp. lb/gal; imp. lb/bbl (BEER); imp. lb/bbl (PETR.) Factory setting: kg/l SD = Specific Density, SG = Specific Gravity The specific density is the ratio of fluid density to water (at water temperature = 4, 15, 20 °C)  Note! The unit selected here has no influence on the transmitted process variable to the Analog Input Function block.

Transducer block		
Parameter	Write access with operating mode (MODE_BLK)	Description
System Value Reference Density	read only	The density of the fluid, at reference temperature, appears on the display. The reference density can either be measured or entered as a fixed value (see parameter "Reference Param. - Fixed Ref. Density" on Seite 95). Display shows: 5-digit floating-point number, including unit corresponding to 0.100000...6.00000 kg/dm³ (e.g. 1.2345 kg/dm³; 993.5 kg/dm³; 1.0015 SG 20 °C; etc.)
System Unit Reference Density	AUTO - MAN - OOS	Use this parameter to select the unit for the reference density. The unit you select here is also valid for: • Simulation • Fixed reference density (for calculation of corrected volume flow) Options: Metric → kg/Nm³; kg/Nl US → g/Scg; kg/Sm; lb/Scf Factory setting: kg/Nl  Note! The unit selected here has no influence on the transmitted process variable to the Analog Input Function block.
System Value Temperature	read only	The currently measured temperature appears on the display. Display shows: max. 4-digit fixed-point number, including unit and sign (e.g. -23.4 °C; 160.0 °F; 295.4 K; etc.)
System Unit Temperature	AUTO - MAN - OOS	Use this parameter to select the unit for the temperature. The unit you select here is also valid for: • Simulation • Reference temperature (for corrected volume measurement with measured reference density) Options: °C (Celsius) K (Kelvin) °F (Fahrenheit) R (Rankine) Factory setting: °C  Note! The unit selected here has no influence on the transmitted process variable to the Analog Input Function block.

Transducer block		
Parameter	Write access with operating mode (MODE_BLK)	Description
STRATEGY	AUTO - OOS	Parameter for grouping and thus faster evaluation of blocks. Grouping is carried out by entering the same numerical value in the parameter "STRATEGY" for each individual block. Factory setting: 0  Note! This data is neither checked nor processed by the Transducer block.
TAG_DESC	AUTO - OOS	Entry of a user-specific text of max. 32 characters for unique identification and assignment of the block. Factory setting: (_ _ _ _ _) without text
Temperature	read only	Displays the current measured value and the status of the sixth process variable (Temperature) made available to the Analog Input Function Block as an input value.
Temperature Unit	read only	Displays the unit of the temperature.  Note! The unit is set in the associated Analog Input Function Block via the parameter group "XD_SCALE" (see Seite 150).
Totalizer 1	read only	Displays the current measured value and the status of the seventh process variable (Totalizer 1) made available to the Analog Input Function Block as an input value.
Totalizer 1 - Unit	read only	Displays the unit of the totalizer 1.  Note! The unit is set in the associated Analog Input Function Block via the parameter group "XD_SCALE" (see Seite 150).
Totalizer 1 - System Value	AUTO - MAN - OOS	Use this parameter to view the total for the totalizer's measured variable aggregated since measuring commenced. The value can be positive or negative, depending on the setting selected in the parameter "Totalizer 1 - Mode", and the direction of flow. Display shows: max. 7-digit floating-point number, including sign and unit (e.g. 15467.04 m³; -4925.631 kg)  Note! - The effect of the setting in the parameter "Totalizer 1 - Mode" is as follows: - If the setting is "BALANCE", the totalizer balances flow in the positive and negative directions. - If the setting is "FORWARD", the totalizer registers only flow in the positive direction. - If the setting is "REVERSE", the totalizer registers only flow in the negative direction. - The totalizer's response to faults is defined in the parameter "Totalizers - Failsafe All".

Transducer block		
Parameter	Write access with operating mode (MODE_BLK)	Description
Totalizer 1 - System Unit	AUTO - MAN - OOS	Use this parameter to define the unit for the totalizer's measured variable, as selected beforehand. Options: Metric – Massefluss → g; kg; t – Volumenfluss → cm³; dm³; m³; ml; l; hl; Ml – Normvolumenfluss → Nl; Nm³ US – Massefluss → oz; lb; ton – Volumenfluss → cc; af; ft³; oz f; gal; Mgal; bbl (NORM.); bbl (BEER); bbl (PETR.); bbl (TANKS) – Normvolumenfluss → Sm³; Scf Imperial – Normvolumenfluss → imp. gal; imp. Mgal; bbl (BEER); imp. bbl (PETR.) Factory setting: kg  Note! The unit selected here has no influence on the transmitted process variable.
Totalizer 1 - Assign	AUTO - MAN - OOS	Use this parameter to assign a measured variable to the totalizer. Options: OFF MASS FLOW VOLUME FLOW CORRECTED VOLUME FLOW Factory setting: MASS FLOW  Note! The totalizer is reset to "0" as soon as the selection is changed.
Totalizer 1 - Mode	AUTO - MAN - OOS	Use this parameter to define how the flow components are to be totaled by the totalizer. Options: BALANCE (positive and negative flow components) The positive and negative flow components are balanced. In other words, net flow in the flow direction is registered. FORWARD Positive flow components only REVERSE Negative flow components only Factory setting: BALANCE

Transducer block		
Parameter	Write access with operating mode (MODE_BLK)	Description
Totalizer 1 - Reset	AUTO - MAN - OOS	Reset the parameter "Totalizer 1 - System Value" and the current measured value "Totalizer 1" to zero. Options: NO YES Factory setting: NO  Note! Resetting of the totalizer can, also using cyclic scheduled data transmission, be controlled or initiated via the Discrete Output function block.
Totalizer 2	read only	Displays the current measured value and the status of the eighth process variable (Totalizer 2) made available to the Analog Input Function Block as an input value.
Totalizer 2 - Unit	read only	Displays the unit of the totalizer 2.  Note! The unit is set in the associated Analog Input Function Block via the parameter group "XD_SCALE" (see Seite 150).
Totalizer 2 - System Value	AUTO - MAN - OOS	Use this parameter to view the total for the totalizer's measured variable aggregated since measuring commenced. The value can be positive or negative, depending on the setting selected in the parameter "Totalizer 2 - Mode", and the direction of flow. Display shows: max. 7-digit floating-point number, including sign and unit (e.g. 15467.04 m³; -4925.631 kg)  Note! - The effect of the setting in the parameter "Totalizer 2 - Mode" is as follows: - If the setting is "BALANCE", the totalizer balances flow in the positive and negative directions. - If the setting is "FORWARD", the totalizer registers only flow in the positive direction. - If the setting is "REVERSE", the totalizer registers only flow in the negative direction. - The totalizer's response to faults is defined in the parameter "Totalizers - Failsafe All".

Transducer block		
Parameter	Write access with operating mode (MODE_BLK)	Description
Totalizer 2 - System Unit	AUTO - MAN - OOS	Use this parameter to define the unit for the totalizer's measured variable, as selected beforehand. Options: Metric – Massefluss → g; kg; t – Volumenfluss → cm³; dm³; m³; ml; l; hl; Ml – Normvolumenfluss → Nl; Nm³ US – Massefluss → oz; lb; ton – Volumenfluss → cc; af; ft³; oz f; gal; Mgal; bbl (NORM.); bbl (BEER); bbl (PETR.); bbl (TANKS) – Normvolumenfluss → Sm³; Scf Imperial – Normvolumenfluss → imp. gal; imp. Mgal; bbl (BEER); imp. bbl (PETR.) Factory setting: m³  Note! The unit selected here has no influence on the transmitted process variable.
Totalizer 2 - Assign	AUTO - MAN - OOS	Use this parameter to assign a measured variable to the totalizer. Options: OFF MASS FLOW VOLUME FLOW CORRECTED VOLUME FLOW Factory setting: VOLUME FLOW  Note! The totalizer is reset to "0" as soon as the selection is changed.
Totalizer 2 - Mode	AUTO - MAN - OOS	Use this parameter to define how the flow components are to be totaled by the totalizer. Options: BALANCE (positive and negative flow components) The positive and negative flow components are balanced. In other words, net flow in the flow direction is registered. FORWARD Positive flow components only REVERSE Negative flow components only Factory setting: FORWARD

Transducer block		
Parameter	Write access with operating mode (MODE_BLK)	Description
Totalizer 2 - Reset	AUTO - MAN - OOS	Reset the parameter "Totalizer 2 - System Value" and the current measured value "Totalizer 2" to zero. Options: NO YES Factory setting: NO  Note! Resetting of the totalizer can, also using cyclic scheduled data transmission, be controlled or initiated via the Discrete Output function block.
Totalizer 3	read only	Displays the current measured value and the status of the ninth process variable (Totalizer 3) made available to the Analog Input Function Block as an input value.
Totalizer 3 - Unit	read only	Displays the unit of the totalizer 3.  Note! The unit is set in the associated Analog Input Function Block via the parameter group "XD_SCALE" (see Seite 150).
Totalizer 3 - System Value	AUTO - MAN - OOS	Use this parameter to view the total for the totalizer's measured variable aggregated since measuring commenced. The value can be positive or negative, depending on the setting selected in the parameter "Totalizer 3 - Mode", and the direction of flow. Display shows: max. 7-digit floating-point number, including sign and unit (e.g. 15467.04 m³; -4925.631 kg)  Note! - The effect of the setting in the parameter "Totalizer 3 - Mode" is as follows: - If the setting is "BALANCE", the totalizer balances flow in the positive and negative directions. - If the setting is "FORWARD", the totalizer registers only flow in the positive direction. - If the setting is "REVERSE", the totalizer registers only flow in the negative direction. - The totalizer's response to faults is defined in the parameter "Totalizers - Failsafe All".

Transducer block		
Parameter	Write access with operating mode (MODE_BLK)	Description
Totalizer 3 - System Unit	AUTO - MAN - OOS	Use this parameter to define the unit for the totalizer's measured variable, as selected beforehand. Options: Metric – Massefluss → g; kg; t – Volumenfluss → cm³; dm³; m³; ml; l; hl; Ml – Normvolumenfluss → NI; Nm³ US – Massefluss → oz; lb; ton – Volumenfluss → cc; af; ft³; oz f; gal; Mgal; bbl (NORM.); bbl (BEER); bbl (PETR.); bbl (TANKS) – Normvolumenfluss → Sm³; Scf Imperial – Normvolumenfluss → imp. gal; imp. Mgal; bbl (BEER); imp. bbl (PETR.) Factory setting: Nm³  Note! The unit selected here has no influence on the transmitted process variable.
Totalizer 3 - Assign	AUTO - MAN - OOS	Use this parameter to assign a measured variable to the totalizer. Options: OFF MASS FLOW VOLUME FLOW CORRECTED VOLUME FLOW Factory setting: CORRECTED VOLUME FLOW  Note! The totalizer is reset to "0" as soon as the selection is changed.
Totalizer 3 - Mode	AUTO - MAN - OOS	Use this parameter to define how the flow components are to be totalled by the totalizer. Options: BALANCE (positive and negative flow components) The positive and negative flow components are balanced. In other words, net flow in the flow direction is registered. FORWARD Positive flow components only REVERSE Negative flow components only Factory setting: REVERSE

Transducer block		
Parameter	Write access with operating mode (MODE_BLK)	Description
Totalizer 3 - Reset	AUTO - MAN - OOS	Reset the parameter "Totalizer 3 - System Value" and the current measured value "Totalizer 3" to zero. Options: NO YES Factory setting: NO  Note! Resetting of the totalizer can, also using cyclic scheduled data transmission, be controlled or initiated via the Discrete Output function block.
Totalizers - Reset All	AUTO - MAN - OOS	Reset the parameters "Totalizer 1 - System Value", "Totalizer 2 - System Value", "Totalizer 3 - System Value" and the current measured values "Totalizer 1", "Totalizer 2", "Totalizer 3" to zero. Options: NO YES Factory setting: NO  Note! Resetting of the totalizer can, also using cyclic scheduled data transmission, be controlled or initiated via the Discrete Output function block.
Totalizers - Failsafe All	AUTO - MAN - OOS	Use this parameter to define the common response of all totalizers (1...3) to error. Options: STOP The totalizer is paused until the fault is rectified. The totalizer stops at the last value prior to the occurrence of the error. ACTUAL VALUE The totalizer continues to count is based on the current flow measured value. The fault is ignored. HOLD VALUE The totalizer continues to count the flow is based on the last valid flow value (before the fault occurred). Factory setting: STOP

Transducer block		
Parameter	Write access with operating mode (MODE_BLK)	Description
Transducer Error	read only	Displays the active device error. Options: • No Error (normal state) • Electronic Failure • Data Integrity Error • Mechanical Error • I/O Failure • General Error  Note! • Display of the device error is standardized. A precise statement concerning the pending error is available via the device-specific error display, which can be read off in the parameter "Diagnosis - Actual System Condition". • A precise error description as well as notes on remedying errors can be found in the Operating Instructions Promass 83 FF BA065D/06/en.
Transducer Type	read only	Displays the Transducer block type. Display: Standard flow with calibration
Un/Locking - Access code	AUTO - MAN - OOS	All the measuring system data is protected from accidental modification. Only when the code has been entered in this parameter can the manufacturer-specific parameters be programmed and the device configuration modified. You can enable programming by entering: • Code 83 (factory setting) • Personal code (parameter "Define Private Code") User input: max. 4-digit number: 0...9999  Note! • If the hardware write protection is enabled then access to the manufacturer-specific parameters is blocked even if the right code is entered. • You can disable programming again by entering any number (other than the access code) in this parameter. • The Endress+Hauser service organization can be of assistance if you mislay your personal code. • Certain parameters are not accessible unless a special service code is entered. This service code is known only to the Endress+Hauser service organization. Please contact your Endress+Hauser service center if you require clarification.

Transducer block		
Parameter	Write access with operating mode (MODE_BLK)	Description
Un/Locking - Define Private code	AUTO - MAN - OOS	For entry of the personal code used to access the manufacturer-specific parameters in the Transducer block. User input: 0...9999 (max. 4-digit number) Factory setting: 83  Note! • If the code number is "0", programming is always enabled. • Parameter configuration has to be enabled before this code can be changed. When parameter configuration is disabled this parameter is not available; this precaution prevents others from changing your personal code without your knowledge and consent.
Un-/Locking - Access Status	read only	Use this parameter to check the access status for the parameter matrix. Display shows: LOCKED (Parameterization disabled) ACCESS CUSTOMER (Parameterization enabled) ACCESS SERVICE (Parameterization enabled)
UPDATE_EVT	AUTO - MAN - OOS	Displays whether static block data has been modified, including date and time.
User Interface - Language	AUTO - MAN - OOS	Use this parameter to select the language for all texts, parameters and messages shown on the local display. Options: ENGLISH DEUTSCH FRANCAIS ESPANOL ITALIANO NEDERLANDS DANSK NORSK SVENSKA SUOMI BAHASA INDONESIA JAPANESE (syllabary)
User Interface - Damping	AUTO - MAN - OOS	Use this parameter to enter a time constant defining how the display reacts to severely fluctuating flow variables, either very quickly (enter a low time constant) or with damping (enter a high time constant). User input: 0...100 seconds Factory setting: 1 s  Note! Setting the time constant to zero seconds switches off damping.

Transducer block		
Parameter	Write access with operating mode (MODE_BLK)	Description
User Interface - Contrast LCD	AUTO - MAN - OOS	Use this parameter to optimize display contrast to suit local operating conditions. User input: 10...100% Factory setting: 50%
User Interface Main Line - Assign	AUTO - MAN - OOS	Use this parameter to define the display value assigned to the main line (the top line of the local display) during normal measuring operation. Options: OFF MASS FLOW MASS FLOW IN % VOLUME FLOW VOLUME FLOW IN % CORRECTED VOLUME FLOW CORRECTED VOLUME FLOW IN % DENSITY REFERENCE DENSITY TEMPERATURE TOTALIZER 1 TOTALIZER 2 TOTALIZER 3 AI 1 - OUT VALUE AI 2 - OUT VALUE AI 3 - OUT VALUE AI 4 - OUT VALUE AI 5 - OUT VALUE AI 6 - OUT VALUE AI 7 - OUT VALUE PID - IN VALUE (manipulated variable) PID - CAS_IN VALUE (external set point) PID - OUT VALUE (controlled variable) Factory setting: MASS FLOW
User Interface Main Line - 100% Value	AUTO - MAN - OOS	 Note! The input is not active unless one of the following was selected in the parameter "User Interface Main Line - Assign": • MASS FLOW IN % • VOLUME FLOW IN % • CORRECTED VOLUME FLOW IN % Use this parameter to define the flow value to be shown on the display as the 100% value. User input: 5-digit floating-point number Factory setting: 10  Note! The appropriate unit is taken from the corresponding parameter ("System Unit - Mass Flow", "System Unit - Volume Flow", or "System Unit - Corrected Volume Flow").

Transducer block		
Parameter	Write access with operating mode (MODE_BLK)	Description
User Interface Main Line - Format	AUTO - MAN - OOS	Use this parameter to define the maximum number of places after the decimal point displayed for the reading in the main line. Options: XXXXX. - XXXX.X - XXX.XX - XX.XXX -X.XXXX Factory setting: X.XXXX  Note! - Note that this setting only affects the reading as it appears on the display, it has no influence on the accuracy of the system's calculations. - The places after the decimal point as computed by the measuring device cannot always be displayed, depending on this setting and the engineering unit. In these instances an arrow appears on the display between the measured value and the engineering unit (e.g. 1.2→ kg/h), indicating that the measuring system is computing with more decimal places than can be shown on the display.
User Interface Main Line - Multiplex Assign	AUTO - MAN - OOS	Use this parameter to define the second reading to be displayed in the main line alternately (every 10 seconds) with the value defined in the parameter "User Interface Main Line - Assign". Options: OFF MASS FLOW MASS FLOW IN % VOLUME FLOW VOLUME FLOW IN % CORRECTED VOLUME FLOW CORRECTED VOLUME FLOW IN % DENSITY REFERENCE DENSITY TEMPERATURE TOTALIZER 1 TOTALIZER 2 TOTALIZER 3 AI 1 - OUT VALUE AI 2 - OUT VALUE AI 3 - OUT VALUE AI 4 - OUT VALUE AI 5 - OUT VALUE AI 6 - OUT VALUE AI 7 - OUT VALUE PID - IN VALUE (manipulated variable) PID - CAS_IN VALUE (external set point) PID - OUT VALUE (controlled variable) Factory setting: OFF

Transducer block		
Parameter	Write access with operating mode (MODE_BLK)	Description
User Interface Main Line - Multiplex 100% Value	AUTO - MAN - OOS	 Note! The input is not active unless one of the following was selected in the parameter "User Interface Main Line - Multiplex Assign": • MASS FLOW IN % • VOLUME FLOW IN % • CORRECTED VOLUME FLOW IN % Use this parameter to define the flow value to be shown on the display as the 100% value. User input: 5-digit floating-point number Factory setting: 10  Note! The appropriate unit is taken from the corresponding parameter ("System Unit - Mass Flow", "System Unit - Volume Flow", or "System Unit - Corrected Volume Flow").
User Interface Main Line - Multiplex Format	AUTO - MAN - OOS	Use this parameter to define the maximum number of places after the decimal point displayed for the reading in the main line. Options: XXXXX. - XXXX.X - XXX.XX - XX.XXX -X.XXXX Factory setting: X.XXXX  Note! • Note that this setting only affects the reading as it appears on the display, it has no influence on the accuracy of the system's calculations. • The places after the decimal point as computed by the measuring device cannot always be displayed, depending on this setting and the engineering unit. In these instances an arrow appears on the display between the measured value and the engineering unit (e.g. 1.2→ kg/h), indicating that the measuring system is computing with more decimal places than can be shown on the display.

Transducer block		
Parameter	Write access with operating mode (MODE_BLK)	Description
User Interface Add. Line - Assign	AUTO - MAN - OOS	Use this parameter to define the display value assigned to the additional line (the middle line of the local display) during normal measuring operation. Options: OFF MASS FLOW MASS FLOW IN % VOLUME FLOW VOLUME FLOW IN % CORRECTED VOLUME FLOW CORRECTED VOLUME FLOW IN % DENSITY REFERENCE DENSITY TEMPERATURE MASS FLOW BARGRAPH IN % VOLUME FLOW BARGRAPH IN % CORRECTED VOLUME FLOW BARGRAPH IN % TOTALIZER 1 TOTALIZER 2 TOTALIZER 3 AI 1 - OUT VALUE AI 2 - OUT VALUE AI 3 - OUT VALUE AI 4 - OUT VALUE AI 5 - OUT VALUE AI 6 - OUT VALUE AI 7 - OUT VALUE PID - IN VALUE (manipulated variable) PID - CAS_IN VALUE (external set point) PID - OUT VALUE (controlled variable) DEVICE PD-TAG BLANK LINE Factory setting: TOTALIZER 1
User Interface Add. Line - 100% Value	AUTO - MAN - OOS	 Note! The input is not active unless one of the following was selected in the parameter "User Interface Add. Line - Assign": • MASS FLOW IN % • VOLUME FLOW IN % • CORRECTED VOLUME FLOW IN % • MASS FLOW BARGRAPH IN % • VOLUME FLOW BARGRAPH IN % • CORRECTED VOLUME FLOW BARGRAPH IN % Use this parameter to define the flow value to be shown on the display as the 100% value. User input: 5-digit floating-point number Factory setting: 10  Note! The appropriate unit is taken from the corresponding parameter ("System Unit - Mass Flow", "System Unit - Volume Flow", or "System Unit - Corrected Volume Flow").

Transducer block		
Parameter	Write access with operating mode (MODE_BLK)	Description
User Interface Add. Line - Format	AUTO - MAN - OOS	 Note! The option is not active unless a number was selected in the parameter "User Interface Add. Line - Assign". Use this parameter to define the maximum number of places after the decimal point displayed for the reading in the additional line. Options: XXXXX. - XXXX.X - XXX.XX - XX.XXX -X.XXXX Factory setting: X.XXXX  Note! - Note that this setting only affects the reading as it appears on the display, it has no influence on the accuracy of the system's calculations. - The places after the decimal point as computed by the measuring device cannot always be displayed, depending on this setting and the engineering unit. In these instances an arrow appears on the display between the measured value and the engineering unit (e.g. 1.2 → kg/h), indicating that the measuring system is computing with more decimal places than can be shown on the display.
User Interface Add. Line - Display Mode	AUTO - MAN - OOS	 Note! The option is not active unless one of the following was selected in the parameter "User Interface Add. Line - Assign": - MASS FLOW BARGRAPH IN % - VOLUME FLOW BARGRAPH IN % - CORRECTED VOLUME FLOW BARGRAPH IN % Use this parameter to define the format of the bar graph. Options: STANDARD Simple bar graph with 25 / 50 / 75% gradations and integrated sign. F-x3xxxx-20-xx-xx-xx-000 SYMMETRY Symmetrical bar graph for positive and negative directions of flow, with -50 / 0 / +50% gradations and integrated sign. F-x3xxxx-20-xx-xx-xx-001 Factory setting: STANDARD

Transducer block		
Parameter	Write access with operating mode (MODE_BLK)	Description
User Interface Add. Line - Multiplex Assign	AUTO - MAN - OOS	Use this parameter to define the second reading to be displayed in the additional line alternately (every 10 seconds) with the value defined in the parameter "User Interface Add. Line - Assign". Options: OFF MASS FLOW MASS FLOW IN % VOLUME FLOW VOLUME FLOW IN % CORRECTED VOLUME FLOW CORRECTED VOLUME FLOW IN % DENSITY REFERENCE DENSITY TEMPERATURE MASS FLOW BARGRAPH IN % VOLUME FLOW BARGRAPH IN % CORRECTED VOLUME FLOW BARGRAPH IN % TOTALIZER 1 TOTALIZER 2 TOTALIZER 3 AI 1 - OUT VALUE AI 2 - OUT VALUE AI 3 - OUT VALUE AI 4 - OUT VALUE AI 5 - OUT VALUE AI 6 - OUT VALUE AI 7 - OUT VALUE PID - IN VALUE (manipulated variable) PID - CAS_IN VALUE (external set point) PID - OUT VALUE (controlled variable) DEVICE PD-TAG BLANK LINE Factory setting: OFF  Note! Multiplex mode is suspended as soon as a fault / notice message is generated. The message in question appears on the display. - Fault message (identified by a lightning icon): Multiplex mode is resumed as soon as the fault is no longer active. - Notice message (identified by an exclamation mark): Multiplex mode is resumed as soon as the notice message is no longer active.

Transducer block		
Parameter	Write access with operating mode (MODE_BLK)	Description
User Interface Add. Line - Multiplex 100% Value	AUTO - MAN - OOS	 Note! The input is not active unless one of the following was selected in the parameter "User Interface Add. Line - Multiplex Assign": • MASS FLOW IN % • VOLUME FLOW IN % • CORRECTED VOLUME FLOW IN % • MASS FLOW BARGRAPH IN % • VOLUME FLOW BARGRAPH IN % • CORRECTED VOLUME FLOW BARGRAPH IN % Use this parameter to define the flow value to be shown on the display as the 100% value. User input: 5-digit floating-point number Factory setting: 10  Note! The appropriate unit is taken from the corresponding parameter ("System Unit - Mass Flow", "System Unit - Volume Flow", or "System Unit - Corrected Volume Flow").
User Interface Add. Line - Multiplex Format	AUTO - MAN - OOS	 Note! The option is not active unless a number was selected in the parameter "User Interface Add. Line - Multiplex Assign". Use this parameter to define the maximum number of places after the decimal point for the second value displayed in the additional line. Options: XXXXX. - XXXX.X - XXX.XX - XX.XXX -X.XXXX Factory setting: X.XXXX  Note! • Note that this setting only affects the reading as it appears on the display, it has no influence on the accuracy of the system's calculations. • The places after the decimal point as computed by the measuring device cannot always be displayed, depending on this setting and the engineering unit. In these instances an arrow appears on the display between the measured value and the engineering unit (e.g. 1.2 → kg/h), indicating that the measuring system is computing with more decimal places than can be shown on the display.

Transducer block		
Parameter	Write access with operating mode (MODE_BLK)	Description
User Interface Add. Line - Multiplex Display Mode	AUTO - MAN - OOS	Note! The option is not active unless one of the following was selected in the parameter "User Interface Add. Line - Multiplex Assign": • MASS FLOW BARGRAPH IN % • VOLUME FLOW BARGRAPH IN % • CORRECTED VOLUME FLOW BARGRAPH IN % Use this parameter to define the format of the bar graph. Options: STANDARD Simple bar graph with 25 / 50 / 75% gradations and integrated sign. +25+50+75% F-x3xxxx-20-xx-xx-xx-000 SYMMETRY Symmetrical bar graph for positive and negative directions of flow, with -50 / 0 / +50% gradations and integrated sign. -50+50% F-x3xxxx-20-xx-xx-xx-001 Factory setting: STANDARD

Transducer block		
Parameter	Write access with operating mode (MODE_BLK)	Description
User Interface Info. Line - Assign	AUTO - MAN - OOS	Use this parameter to define the display value assigned to the information line (the bottom line of the local display) during normal measuring operation. Options: OFF MASS FLOW MASS FLOW IN % VOLUME FLOW VOLUME FLOW IN % CORRECTED VOLUME FLOW CORRECTED VOLUME FLOW IN % DENSITY REFERENCE DENSITY TEMPERATURE MASS FLOW BARGRAPH IN % VOLUME FLOW BARGRAPH IN % CORRECTED VOLUME FLOW BARGRAPH IN % TOTALIZER 1 TOTALIZER 2 TOTALIZER 3 AI 1 - OUT VALUE AI 2 - OUT VALUE AI 3 - OUT VALUE AI 4 - OUT VALUE AI 5 - OUT VALUE AI 6 - OUT VALUE AI 7 - OUT VALUE PID - IN VALUE (manipulated variable) PID - CAS_IN VALUE (external set point) PID - OUT VALUE (controlled variable) DEVICE PD-TAG BLANK LINE Factory setting: OPERATING/SYSTEM CONDITIONS
User Interface Info. Line - 100% Value	AUTO - MAN - OOS	 Note! The input is not active unless one of the following was selected in the parameter "User Interface Info. Line - Assign": • MASS FLOW IN % • VOLUME FLOW IN % • CORRECTED VOLUME FLOW IN % • MASS FLOW BARGRAPH IN % • VOLUME FLOW BARGRAPH IN % • CORRECTED VOLUME FLOW BARGRAPH IN % Use this parameter to define the flow value to be shown on the display as the 100% value. User input: 5-digit floating-point number Factory setting: 10  Note! The appropriate unit is taken from the corresponding parameter ("System Unit - Mass Flow", "System Unit - Volume Flow", or "System Unit - Corrected Volume Flow").

Transducer block		
Parameter	Write access with operating mode (MODE_BLK)	Description
User Interface Info. Line - Format	AUTO - MAN - OOS	Note! The option is not active unless a number was selected in the parameter "User Interface Info. Line - Assign". Use this parameter to define the maximum number of places after the decimal point displayed for the reading in the information line. Options: XXXXX. - XXXX.X - XXX.XX - XX.XXX -X.XXXX Factory setting: X.XXXX Note! Note that this setting only affects the reading as it appears on the display, it has no influence on the accuracy of the system's calculations. The places after the decimal point as computed by the measuring device cannot always be displayed, depending on this setting and the engineering unit. In these instances an arrow appears on the display between the measured value and the engineering unit (e.g. 1.2 → kg/h), indicating that the measuring system is computing with more decimal places than can be shown on the display.
User Interface Info. Line - Display Mode	AUTO - MAN - OOS	Note! The option is not available unless one of the following was selected in the parameter "User Interface Info. Line - Assign": MASS FLOW BARGRAPH IN % VOLUME FLOW BARGRAPH IN % CORRECTED VOLUME FLOW BARGRAPH IN % Use this parameter to define the format of the bar graph. Options: STANDARD Simple bar graph with 25 / 50 / 75% gradations and integrated sign. +25+50+75 % F-x3xxxx-20-xx-xx-xx-000 SYMMETRY Symmetrical bar graph for positive and negative directions of flow, with -50 / 0 / +50% gradations and integrated sign. -50+50 % F-x3xxxx-20-xx-xx-xx-001 Factory setting: STANDARD

Transducer block		
Parameter	Write access with operating mode (MODE_BLK)	Description
User Interface Info. Line - Multiplex Assign	AUTO - MAN - OOS	Use this parameter to define the second reading to be displayed in the information line alternately (every 10 seconds) with the value defined in the parameter "User Interface Info. Line - Assign". Options: OFF MASS FLOW MASS FLOW IN % VOLUME FLOW VOLUME FLOW IN % CORRECTED VOLUME FLOW CORRECTED VOLUME FLOW IN % DENSITY REFERENCE DENSITY TEMPERATURE MASS FLOW BARGRAPH IN % VOLUME FLOW BARGRAPH IN % CORRECTED VOLUME FLOW BARGRAPH IN % TOTALIZER 1 TOTALIZER 2 TOTALIZER 3 AI 1 - OUT VALUE AI 2 - OUT VALUE AI 3 - OUT VALUE AI 4 - OUT VALUE AI 5 - OUT VALUE AI 6 - OUT VALUE AI 7 - OUT VALUE PID - IN VALUE (manipulated variable) PID - CAS_IN VALUE (external set point) PID - OUT VALUE (controlled variable) DEVICE PD-TAG BLANK LINE OPERATING/SYSTEM CONDITIONS Factory setting: OFF  Note! Multiplex mode is suspended as soon as a fault / notice message is generated. The message in question appears on the display. • Fault message (identified by a lightning icon): Multiplex mode is resumed as soon as the fault is no longer active. • Notice message (identified by an exclamation mark): Multiplex mode is resumed as soon as the notice message is no longer active.

Transducer block		
Parameter	Write access with operating mode (MODE_BLK)	Description
User Interface Info. Line - Multiplex 100% Value	AUTO - MAN - OOS	 Note! The input is not active unless one of the following was selected in the parameter "User Interface Info. Line - Multiplex Assign": • MASS FLOW IN % • VOLUME FLOW IN % • CORRECTED VOLUME FLOW IN % • MASS FLOW BARGRAPH IN % • VOLUME FLOW BARGRAPH IN % • CORRECTED VOLUME FLOW BARGRAPH IN % Use this parameter to define the flow value to be shown on the display as the 100% value. User input: 5-digit floating-point number Factory setting: 10  Note! The appropriate unit is taken from the corresponding parameter ("System Unit - Mass Flow", "System Unit - Volume Flow", or "System Unit - Corrected Volume Flow").
User Interface Info. Line - Multiplex Format	AUTO - MAN - OOS	 Note! The option is not active unless a number was selected in the parameter "User Interface Info. Line - Multiplex Assign". Use this parameter to define the maximum number of places after the decimal point for the second value displayed in the information line. Options: XXXXX. - XXXX.X - XXX.XX - XX.XXX -X.XXXX Factory setting: X.XXXX  Note! • Note that this setting only affects the reading as it appears on the display, it has no influence on the accuracy of the system's calculations. • The places after the decimal point as computed by the measuring device cannot always be displayed, depending on this setting and the engineering unit. In these instances an arrow appears on the display between the measured value and the engineering unit (e.g. 1.2 → kg/h), indicating that the measuring system is computing with more decimal places than can be shown on the display.

Transducer block		
Parameter	Write access with operating mode (MODE_BLK)	Description
User Interface Info. Line - Multiplex Display Mode	AUTO - MAN - OOS	Note! The option is not active unless one of the following was selected in the parameter "User Interface Info. Line - Multiplex Assign": • MASS FLOW BARGRAPH IN % • VOLUME FLOW BARGRAPH IN % • CORRECTED VOLUME FLOW BARGRAPH IN % Use this parameter to define the format of the bar graph. Options: STANDARD Simple bar graph with 25 / 50 / 75% gradations and integrated sign. +25 +50 +75 % F-x3xxxxx-20-xx-xx-xx-000 SYMMETRY Symmetrical bar graph for positive and negative directions of flow, with -50 / 0 / +50% gradations and integrated sign. -50 +50 % F-x3xxxxx-20-xx-xx-xx-001 Factory setting: STANDARD

Transducer block		
Parameter	Write access with operating mode (MODE_BLK)	Description
Volume Flow	AUTO - MAN - OOS	Displays the current measured value and the status of the second process variable (Volume Flow) made available to the Analog Input Function Block as an input value.
Volume Flow Unit	AUTO - MAN - OOS	Displays the unit of the volume flow.  Note! The unit is set in the associated Analog Input Function Block via the parameter group "XD_SCALE" (see Seite 150).
Zeropoint Adjustment	AUTO - MAN - OOS	This parameter enables a zero point adjustment to be automatically carried out. The new zero point determined by the measuring system is adopted by the "Sensor Data - Zeropoint" parameter. Options: CANCEL START Factory setting: CANCEL  Caution! Before carrying out the calibration, please refer to BA065D/06/en "Promass 83 FF Operating Instructions" where a detailed description of the zero point adjustment is given.  Note! • Programming is locked during zero point adjustment. • If the zero point adjustment is not possible, e.g. with a flow velocity > 0.1 m/s, or has been cancelled, then the message "Zeropoint Adjustment failure - Error No. 731" is shown in the parameter "Diagnosis - Actual System Condition". • The zeropoint adjustment can, also using cyclic scheduled data transmission, be controlled or initiated via the Discrete Output function block.

4 Function blocks – general


The function blocks contain the basic automation functions of the field device. We distinguish between different function blocks, e.g. Analog Input Function Block, PID function block (PID controller), etc.

Each of these function blocks is used to execute different application functions. This means that local control functions, for example, can be carried out directly in the field, and device errors such as amplifier errors are reported to the automation system automatically.

The function blocks process the input values in accordance with their specific algorithm and their internally available parameters. They generate output values that are made available to other function blocks for further processing by linking the individual function blocks with each other.

5 Analog Input Function Block


In the Analog Input Function Block (AI) the process variables are prepared by the Transducer Block for the subsequent automation functions (e.g. scaling, limit value processing). The automation function is defined by the connections of the outputs.



OUT = output value and output status of the Analog Input Function Block

5.1 Signal processing

The figure shows the internal structure of the Analog Input Function Blocks:



The Analog Input Function Block receives its input value from the Transducer Block. The parameter CHANNEL (see Page 141) is used to select which input value is to be processed by the Analog Input Function Block.

- Parameter CHANNEL = 1 → Mass Flow
- Parameter CHANNEL = 2 → Volume Flow
- Parameter CHANNEL = 3 → Corrected Volume Flow
- Parameter CHANNEL = 4 → Density
- Parameter CHANNEL = 5 → Reference Density
- Parameter CHANNEL = 6 → Temperature
- Parameter CHANNEL = 7 → Totalizer 1
- Parameter CHANNEL = 8 → Totalizer 2
- Parameter CHANNEL = 9 → Totalizer 3
- Parameter CHANNEL = 16 → Discrete Output, for AI Function block not relevant

The parameter group SIMULATE (see Page 149) allows you to replace the input value with a simulation value and to activate simulation. By specifying the status and the simulation value the reaction of the complete Analog Input Function Block can be tested.

The parameter L_TYPE is used to select the linearisation type of the input or simulation value (see Page 144):

- Direct signal conversion
The value is forwarded without conversion ($XD_SCALE = OUT_SCALE$).
Select this option if the input value is already in the physical unit you want.
- Indirect signal conversion
With this setting the measured value from the Transducer Block (input value) is re-scaled linearly via the input scaling XD_SCALE to the desired output range OUT_SCALE (further information on rescaling of the input value can be found on Page 136).
- Indirect signal conversion with square root
With this setting the measured value from the Transducer Block (input value) is re-scaled via the parameter group XD_SCALE and recalculated using a square root function. It is then rescaled again to the desired output range via the parameter group OUT_SCALE .

The parameter LOW_CUT (see Page 147) allows a limit value to be specified for the Low Flow Cut Off. The Low Flow Cut Off is activated via the parameter IO_OPTS (see Page 144). If the converted primary value (PV) is below the limit value then it is set to a value of "Zero".

In the parameter PV_FTIME (see Page 148) a filter time can be specified for filtering the converted primary value (PV). If a time of 0 seconds is specified then no filtration takes place.

The parameter group MODE_BLK (see Page 147) is used to select the operating mode of the Analog Input Function Block. If the operating mode MAN (manual) is selected then the output value OUT (see Page 147) can be specified directly.

The output value OUT is compared with warning and alarm limits (e.g. HI_LIM, LO_LO_LIM, etc.) that can be entered via various parameters. If one of these limit values is violated then a limit value process alarm (e.g. HI_ALM, LO_LO_ALM, etc.) is triggered.

The major functions and parameters of the Analog Input Function Block are listed below; you will find an overview of all the available parameters starting on Seite 138.

5.2 Selecting the operating mode

The operating mode is set via the parameter group MODE_BLK (see Page 147). The Analog Input Function Block supports the following operating modes:

- AUTO
- MAN
- OOS



Note!

The block status OOS is also shown via the parameter BLOCK_ERR (see Page 141). In operating mode OOS, if write protection is not enabled, you can access all the write parameters without restriction.

5.3 Selection of the process variable

The Promass 83 FF has seven Analog Input Function Blocks. The process variables of the Transducer Block that are to be processed are assigned via the parameter CHANNEL (see Page 141).

The Promass 83 FF is configured in the factory as follows:

- Function block 1, Parameter CHANNEL = 1 → Mass Flow
- Function block 2, Parameter CHANNEL = 2 → Volume Flow
- Function block 3, Parameter CHANNEL = 3 → Corr. Volume Flow
- Function block 4, Parameter CHANNEL = 4 → Density
- Function block 5, Parameter CHANNEL = 5 → Reference Density
- Function block 6, Parameter CHANNEL = 6 → Temperature
- Function block 7, Parameter CHANNEL = 7 → Totalizer 1

5.4 Linearisation types

In the Analog Input Function Block the input value can be linearised by the Transducer Block using the parameter L_TYPE (see Page 144). The following types of linearisation are available:

- Direct
With this setting the measured value from the Transducer Block (input value) avoids the Linearisation function and is looped unchanged with the same unit by the Analog Input Function Block.
- Indirect
With this setting the measured value from the Transducer Block (input value) is re-scaled linearly via the input scaling XD_SCALE to the desired output range OUT_SCALE.
- Indirect Square Root
With this setting the measured value from the Transducer Block (input value) is re-scaled via the parameter group XD_SCALE and recalculated using an evolution function. It is then rescaled again to the desired output range via the parameter group OUT_SCALE.

5.5 Selection of units

A change in the unit for the volume flow or totalizer is defined in the relevant Analog Input Function Block, in the parameter group XD_SCALE (see Page 150) via the element UNIT. The unit set here is copied from the Transducer Block.



Note!

The selection of the unit in the Transducer Block has no effect on the unit selected in the Analog Input Function Block with which the field device works. The unit selection in the Transducer block only effect to the display, the density adjust and the simulation.

5.6 Status of the output value OUT

The status of the parameter group OUT communicates to the subsequent function blocks the status of the Analog Input Function Block and the validity of the output value OUT. The following status values can be displayed:

- **GOOD_NON_CASCADE**
The output value OUT is valid and can be used for further processing.
- **Uncertain**
The output value OUT can only be used for further processing to a limited extent. This status of the process variable in the Transducer Block is forwarded via the status of the output parameter OUT.
- **BAD**
The output value OUT is invalid. Occurs when the Analog Input Function Block is switched to operating mode OOS (Out Of Service). Brought about if the status of the process variable from the Transducer Block is the same, since this status is similarly forwarded to the status of OUT. The status is shown via the parameter BLOCK_ERR = Input Failure.

5.7 Simulation of input/output

Parameters of the Analog Input Function Block allow simulation of the input and output of the function block:

1. Simulation of the input of the Analog Input Function Block:
The parameter group SIMULATE (see Page 149) can be used to specify the input value (measured value and status). Since the simulation value runs through the entire function block, all the parameter settings of the block can be checked.



Note!

If simulation is blocked by the jumper on the I/O board then simulation mode cannot be activated in the parameter SIMULATE (see Page 149). In the Resource Block, the parameter BLOCK_ERROR (see Page 80) shows whether simulation of the Analog Input Function Block is possible.

2. Simulation of the output of the Analog Input Function Block:
Set the operating mode in the parameter group MODE_BLK (see Page 147) to MAN and specify the desired output value directly in the parameter OUT (see Page 147).

5.8 Diagnosis

The parameter BLOCK_ERR shows the current block status and in the event of an error, the cause of this (see Page 141).

5.9 Rescaling the input value

In the Analog Input Function Block the input value or input range can be scaled in accordance with the automation requirements.

Example:

- The system unit in the Transducer Block is kg/h.
- The measurement range of the sensor is 0...30 kg/h.
- The output range to the process control system should be 0...100%.


The Analog Input Function Block must be configured as follows:

- Parameter CHANNEL (see Page 141)
Option: Channel = 1 → mass flow
- Parameter L_TYPE (see Page 144)
Option: L_TYPE = Indirect
The measured value from the Transducer Block (input value) is rescaled linearly via the input scaling XD_SCALE to the desired output range OUT_SCALE.
- Parameter group XD_SCALE (see Page 150)

XD_SCALE 0 %	= 0
XD_SCALE 100 %	= 30
XD_SCALE UNIT	= kg/h
- Parameter group OUT_SCALE (see Page 148)

OUT_SCALE 0 %	= 0
OUT_SCALE 100 %	= 100
OUT_SCALE UNIT	= %

The result is that with an input value of, for example, 15 m³/h a value of 50% is output via the parameter OUT.



5.10 Limit values

The limit values are based on the output value OUT. If the output value OUT exceeds or does not reach the defined limit values then an alarm is sent to the fieldbus host system via the limit value process alarms.

The following limit values can be defined:

- | | | | |
|-------------|----------------|----------|----------------|
| – HI_HI_LIM | (see Page 142) | – HI_LIM | (see Page 143) |
| – LO_LO_LIM | (see Page 145) | – LO_LIM | (see Page 145) |

5.11 Alarm detection and processing

Process alarms provide information on particular block statuses and block events. The status of the process alarms is communicated to the fieldbus host system via the parameter BLOCK_ALM (see Page 140). The parameter ACK_OPTION (see Page 138) specifies whether an alarm must be confirmed via the fieldbus host system.

The following process alarms are generated by the Analog Input Function Block:

• Block process alarms

A block process alarm is triggered via the parameter BLOCK_ERR (see Page 141). The parameter BLOCK_ALM (see Page 140) is used to show the block process alarms and communicate them to the fieldbus host system. The following process alarms can be generated by the Analog Input Function Block:

- SIMULATE ACTIVE
- INPUT FAILURE
- OUT OF SERVICE
- BLOCK CONFIG ERROR

If the option of the process alarm (BLOCK ALM) has **not** been enabled in the parameter ACK_OPTION (see Page 138), the process alarms must be acknowledged in the parameter BLOCK_ALM (see Page 140).

• Limit value process alarms

If a limit value is infringed then the priority specified for the limit value alarm will be checked before the limit value violation is communicated to the fieldbus host system. The priority that specifies the action in the event of an active limit value violation is determined by the following parameters:

- | | | | |
|-------------|----------------|----------|----------------|
| – HI_HI_PRI | (see Page 143) | – HI_PRI | (see Page 143) |
| – LO_LO_PRI | (see Page 146) | – LO_PRI | (see Page 146) |

The status of the limit value process alarms is communicated to the fieldbus host system via the following parameters:

- | | | | |
|-------------|----------------|----------|----------------|
| – HI_HI_ALM | (see Page 142) | – HI_ALM | (see Page 142) |
| – LO_LO_ALM | (see Page 145) | – LO_ALM | (see Page 145) |

If the option of a limit value process alarm has **not** been enabled in the parameter ACK_OPTION (see Page 138) then this must be acknowledged directly in its parameter (see list).




Note!

The parameter ALARM_SUM (see Page 140) shows the current status of all the process alarms.

5.12 Parameters of the Analog Input Function Block

The following table shows all the available parameters of the Analog Input function block.

Analog Input Function Block		
Parameter	Write access with operating mode (MODE_BLK)	Description
ACK_OPTION	AUTO - MAN - OOS	This parameter is used to specify whether a process alarm must be acknowledged at the time of alarm recognition by the fieldbus host system. If this option is enabled the process alarm is acknowledged automatically. Options: HI_HI_ALM Upper limit value alarm HI_ALM Upper limit value warning LO_LO_ALM Lower limit value alarm LO_ALM Lower limit value warning BLOCK ALM Block alarm Factory setting: The option is not enabled for any alarm, the alarms must be acknowledged
ALARM_HYS	AUTO - MAN - OOS	For entry of the hysteresis value for the upper and lower warning or alarm limit values. The alarm conditions remain active so long as the measured value is within the hysteresis. The hysteresis value affects the following warning and alarm limit values of the Analog Input Function Block: • HI_HI_ALM (Upper limit value alarm) • HI_ALM (Upper limit value warning) • LO_LO_ALM (Lower limit value alarm) • LO_ALM (Lower limit value warning) User input: 0...50% Factory setting: 0.5%  Note! The hysteresis value relates to a percentage of the range of the parameter group OUT_SCALE in the Analog Input Function Block (see Page 148). (Continued on next Page)

Analog Input Function Block		
Parameter	Write access with operating mode (MODE_BLK)	Description
ALARM_HYS (Continuation)	AUTO - MAN - OOS	Example: The top diagram shows the limit values defined for the warnings LO_LIM and HI_LIM with their respective hystereses (gray background) and the signal curve of the output value OUT. The bottom two diagrams show the behaviour of the associated alarms HI_ALM and LO_ALM in relation to the changing signal curve (0 = no alarm, 1 = alarm output). a = The block output value OUT exceeds the limit value HI_LIM, HI_ALM is activated. b = The block output value OUT is below the hysteresis value of HI_LIM, HI_ALM is deactivated. c = The block output value OUT is below the limit value LO_LIM, LO_ALM is activated. d = The block output value OUT exceeds the hysteresis value of LO_LIM, LO_ALM is deactivated. 

F06-53xFF-xx-05-xx-xx-de-002

Analog Input Function Block		
Parameter	Write access with operating mode (MODE_BLK)	Description
ALARM_SUM	AUTO - MAN - OOS	Displays the current status of the process alarms in the Analog Input Function Block. Display: HI_HI_ALM Violation of the upper limit value alarm HI_ALM Violation of the upper limit value warning LO_LO_ALM Violation of the lower limit value alarm LO_ALM Violation of the lower limit value warning BLOCK_ALM Block alarm  Note! In addition the process alarms can also be disabled in this parameter group.
ALERT_KEY	AUTO - MAN - OOS	For entry of the identification number of the plant unit. This information can be used by the fieldbus host system for sorting alarms and events. User input: 1...255 Factory setting: 0
BLOCK_ALM	AUTO - MAN - OOS	Displays the current block status with information on pending configuration, hardware or system errors, including details of the alarm time (date, time) when the error occurred. The block alarm is triggered in the event of the following block errors: • SIMULATE ACTIVE • INPUT FAILURE • OUT OF SERVICE • BLOCK CONFIG ERROR  Note! If the option of the alarm has not been enabled in the parameter ACK_OPTION, the alarm can only be acknowledged via this parameter.

Analog Input Function Block		
Parameter	Write access with operating mode (MODE_BLK)	Description
BLOCK_ERR	read only	Displays the active block error. Display: SIMULATE ACTIVE Simulation in the parameter group "Simulate" of the Analog Input Function Block is active. INPUT FAILURE Input fault, the input value of the Transducer Block has a status of BAD. OUT OF SERVICE The block has the status "Out Of Service". BLOCK CONFIG ERROR The unit selected via the parameter group XD_SCALE does not match the measured variable of the selected process variable. If linearisation type "Direct" is selected in the parameter L_TYPE, the scalings of the parameter groups XD_SCALE and OUT_SCALE do not match.
CHANNEL	OOS	Assignment between the logical hardware channels of the Transducer Block and the input of the relevant Analog Input Function Block. The Transducer Block of the Promass 83 FF provides two process variables for the following input channels of the Analog Input Function Blocks: Options: 0 = Initialized 1 = Mass Flow 2 = Volume Flow 3 = Corrected Volume Flow 4 = Density 5 = Reference Density 6 = Temperature 7 = Totalizer 1 8 = Totalizer 2 9 = Totalizer 3 16 = Discrete Output (this option has no effect) Factory setting: AI function block 1: CHANNEL = 1 (Mass Flow) AI function block 2: CHANNEL = 2 (Volume Flow) AI function block 3: CHANNEL = 3 (Corrected Volume Flow) AI function block 4: CHANNEL = 4 (Density) AI function block 5: CHANNEL = 5 (Reference Density) AI function block 6: CHANNEL = 6 (Temperature) AI function block 7: CHANNEL = 7 (Totalizer 1)  Note! With option 0 = Initialized, the operating mode of the function block does not switch to the status AUTO.

Analog Input Function Block		
Parameter	Write access with operating mode (MODE_BLK)	Description
FIELD_VAL	read only	Displays the process variable with the associated status from the Transducer block. The value relates to a percentage of the input range XD_SCALE and when simulation is active is replaced by the simulation value. $\text{FIELD_VAL} = \frac{100 \times (\text{process variable PV} - \text{XD_SCALE_0\%})}{(\text{XD_SCALE_100\%} - \text{XD_SCALE_0\%})}$  Note! The desired process variables from the Transducer block and the input value of the Analog Input Function Block are matched via the parameter CHANNEL.
GRANT_DENY	AUTO - MAN - OOS	Locks or unlocks the access authorisation of a fieldbus host system on the field device.  Note! This parameter is not evaluated by the Promass 83 FF.
HI_ALM	AUTO - MAN - OOS	Alarm status display for the upper warning limit value (HI_LIM), including details of the time of the alarm (date, time) and the value that triggered the alarm.  Note! - In addition the active block alarm can be acknowledged in this parameter group. - If the option of the alarm has not been enabled in the parameter ACK_OPTION, the alarm can only be acknowledged via this parameter.
HI_HI_ALM	AUTO - MAN - OOS	Alarm status display for the upper alarm limit value (HI_HI_LIM), including details of the time of the alarm (date, time) and the value that triggered the alarm.  Note! - In addition the active block alarm can be acknowledged in this parameter group. - If the option of the alarm has not been enabled in the parameter ACK_OPTION, the alarm can only be acknowledged via this parameter.
HI_HI_LIM	AUTO - MAN - OOS	Entry of the alarm limit value for the upper alarm (HI_HI_ALM). If the output value OUT exceeds this limit value then the alarm status parameter HI_HI_ALM is output. User input: Range and unit of OUT_SCALE Factory setting: 3402823466 x 10³⁸


Analog Input Function Block		
Parameter	Write access with operating mode (MODE_BLK)	Description
HI_HI_PRI	AUTO - MAN - OOS	Specifies the action taken when the upper alarm limit value (HI_HI_LIM) is exceeded. User input: 0 The violation of the upper alarm limit is not evaluated. 1 No notification if the upper alarm limit is infringed. 2 Reserved for block alarms. 3-7 The violation of the upper alarm limit is output as a user notice with the appropriate priority (3 = low priority, 7 = high priority). 8-15 The violation of the upper alarm limit is output as a critical alarm with the appropriate priority (8 = low priority, 15 = high priority). Factory setting: 0
HI_LIM	AUTO - MAN - OOS	Entry of the alarm limit value for the upper warning (HI_ALM). If the output value OUT exceeds this limit value then the alarm status parameter HI_ALM is output. User input: Range and unit of OUT_SCALE Factory setting: $3402823466 \times 10^{38}$
HI_PRI	AUTO - MAN - OOS	Specifies the action taken when the upper warning limit value (HI_LIM) is exceeded. User input: 0 The violation of the upper warning limit is not evaluated. 1 No notification if the upper warning limit is infringed. 2 Reserved for block alarms. 3-7 The violation of the upper warning limit is output as a user notice with the appropriate priority (3 = low priority, 7 = high priority). 8-15 The violation of the upper warning limit is output as a critical alarm with the appropriate priority (8 = low priority, 15 = high priority). Factory setting: 0

Analog Input Function Block		
Parameter	Write access with operating mode (MODE_BLK)	Description
IO_OPTS	OOS	Activates the options for processing the input and output values of the function block (I/O options). The Analog Input Function Block supports the following options: Options: Low Cut Off (low flow cut off) Factory setting: not enabled  Note! The activation point of the low flow cut off can be entered via the parameter LOW-CUT (see Page 147).
L_TYPE	MAN	Selects the type of linearisation for the input value. Options: Uninitialized Direct With this setting the measured value from the Transducer Block (input value) avoids the linearisation function and is looped unchanged with the same unit by the Analog Input Function Block. With this option the scaling and unit of the parameter groups XD_SCALE and OUT_SCALE must be identical. If this is not the case, the function block switches to operating mode OOS. $PV = \text{Input value}$ Indirect (linear conversion) With this setting the measured value from the Transducer Block (input value) is rescaled linearly via the input scaling XD_SCALE to the desired output range OUT_SCALE. $PV = \frac{X}{100} \cdot (Y - Z) - Z$ X = FIELD_VAL Y = OUTSCALE_100% Z = OUTSCALE_0% Indirect Square Root With this setting the measured value from the Transducer Block (input value) is rescaled via the parameter group XD_SCALE and recalculated using a square root function. It is then rescaled again to the desired output range via the parameter group OUT_SCALE. $PV = \sqrt{\frac{X}{100}} \cdot (Y - Z) - Z$ X = FIELD_VAL Y = OUTSCALE_100% Z = OUTSCALE_0% Factory setting: Uninitialized  Note! With option Uninitialized, the operating mode of the function block does not switch to the status AUTO.

Analog Input Function Block		
Parameter	Write access with operating mode (MODE_BLK)	Description
LO_ALM	AUTO - MAN - OOS	Alarm status display for the lower warning limit value (LO_LIM), including details of the time of the alarm (date, time) and the value that triggered the alarm.  Note! - In addition the active block alarm can be acknowledged in this parameter group. - If the option of the alarm has not been enabled in the parameter ACK_OPTION, the alarm can only be acknowledged via this parameter.
LO_LIM	AUTO - MAN - OOS	Entry of the alarm limit value for the lower warning (LO_ALM). If the output value OUT is below this limit value then the alarm status parameter LO_ALM is output. User input: Range and unit of OUT_SCALE Factory setting: $-3402823466 \times 10^{38}$
LO_LO_ALM	read only	Alarm status display for the lower alarm limit value (LO_LO_LIM), including details of the time of the alarm (date, time) and the value that triggered the alarm.  Note! - In addition the active block alarm can be acknowledged in this parameter group. - If the option of the alarm has not been enabled in the parameter ACK_OPTION, the alarm can only be acknowledged via this parameter.
LO_LO_LIM	AUTO - MAN - OOS	Entry of the alarm limit value for the lower alarm (LO_LO_ALM). If the output value OUT is below this limit value then the alarm status parameter LO_LO_ALM is output. User input: Range and unit of OUT_SCALE Factory setting: $-3402823466 \times 10^{38}$

Analog Input Function Block		
Parameter	Write access with operating mode (MODE_BLK)	Description
LO_LO_PRI	AUTO - MAN - OOS	Specifies the action taken when the lower alarm limit value (LO_LO_LIM) is not reached. User input: 0 The violation of the lower alarm limit is not evaluated. 1 No notification to master if the lower alarm limit is infringed. 2 Reserved for block alarms. 3-7 The violation of the lower alarm limit is output as a user notice with the appropriate priority (3 = low priority, 7 = high priority). 8-15 The violation of the lower alarm limit is output as a critical alarm with the appropriate priority (8 = low priority, 15 = high priority). Factory setting: 0
LO_PRI	AUTO - MAN - OOS	Specifies the action taken when the lower warning limit value (LO_LIM) is exceeded. User input: 0 The violation of the lower warning limit is not evaluated. 1 No notification to master if the lower warning limit is infringed. 2 Reserved for block alarms. 3-7 The violation of the lower warning limit is output as a user notice with the appropriate priority (3 = low priority, 7 = high priority). 8-15 The violation of the lower warning limit is output as a critical alarm with the appropriate priority (8 = low priority, 15 = high priority). Factory setting: 0

Analog Input Function Block		
Parameter	Write access with operating mode (MODE_BLK)	Description
LOW_CUT	AUTO - MAN - OOS	For entry of a limit value for the Low Flow Cut Off. If the converted measured value is below this limit value then PV is shown as zero. User input: Range and unit of OUT_SCALE Factory setting: 0  Note! • This parameter is only active if the I/O option Low Flow Cut Off has been selected in the parameter IO_OPTS (see Page 144). • The unit used is copied from the parameter group OUT_SCALE.
MODE_BLK	AUTO - MAN - OOS	Displays the current (Actual) and desired (Target) operating mode of the Analog Input Function Block, the permitted modes (Permitted) supported by the Resource Block and the normal operating mode (Normal). Display: AUTO MAN OOS  Note! The Analog Input Function Block supports the following operating modes: • AUTO (automatic operation) The block is executed. • MAN (manual intervention by the operator) The output value OUT can be specified. • OOS (Out Of Service) The block has the status "Out Of Service". With the output value OUT the last valid value is output. The status of the output value OUT switches to BAD.
OUT	MAN - OOS	Displays the output value with alarm evaluation and the status of the Analog Input Function Block.  Note! • If MAN (manual) is selected for the operating mode in the parameter MODE_BLK then the output value OUT can be specified manually here. • The unit used is copied from the parameter group OUT_SCALE.

Analog Input Function Block		
Parameter	Write access with operating mode (MODE_BLK)	Description
OUT_SCALE	MAN - OOS	Definition of the output range (lower and upper limit), the physical unit and the number of decimal places for the output value (OUT). Factory setting: Analog Input Function Block 1 = 0...100 kg/h Analog Input Function Block 2 = 0...100 m³/h Analog Input Function Block 3 = 0...100 Nm³/h Analog Input Function Block 4 = 0...100 kg/l Analog Input Function Block 5 = 0...100 kg/Nl Analog Input Function Block 6 = 0...100 °C Analog Input Function Block 7 = 0...100 kg  Note! Defining the measurement range in this parameter group does not restrict the output value OUT. If the output value OUT is outside the measurement range, this value is transferred nonetheless.
PV	read only	Displays the process variable used for the block execution, including the status of the process variable.  Note! The unit used is copied from the parameter group OUT_SCALE.
PV_FTIME	AUTO - MAN - OOS	Entry of the filter time constant (in seconds) of the digital filter of the 1st order. This time is required in order for 63% of a change in the parameter FIELD_VAL to have an effect on the value of PV. The diagram shows the signal curves of the Analog Input Function Block over time:  a) The parameter FIELD_VAL changes. b) The parameter PV has reacted 63% to the change in the parameter FIELD_VAL. Factory setting: 0 s

Analog Input Function Block		
Parameter	Write access with operating mode (MODE_BLK)	Description
SIMULATE	AUTO - MAN - OOS	Simulation of the input value and input status. Since this value runs through the entire algorithm, the behaviour of the Analog Input Function Block can be checked. Factory setting: Simulation Disabled  Note! The parameter BLOCK_ERROR of the Resource Block shows whether simulation is possible.
ST_REV	read only	Displays the revision status of the static data.  Note! The revision status parameter is incremented on each modification of static data.
STATUS_OPTS	OOS	Specifies the options for status processing and processing of the output parameter OUT. The following options will be supported: Options: Uncertain if MAN mode The status of the output value OUT changes to UNCERTAIN if the operating mode is set to "MAN" Propagate Fault Forward Fault is forwarded on. The status of the Transducer block is passed on to succeeding function blocks via the parameter BKCAL_OUT. Factory setting: no options active
STRATEGY	AUTO - MAN - OOS	Parameter for grouping and thus faster evaluation of blocks. Grouping is carried out by entering the same numerical value in the parameter STRATEGY for each individual block. Factory setting: 0  Note! This data is neither checked nor processed by the Analog Input Function Block.
TAG_DESC	AUTO - MAN - OOS	Entry of a user-specific text of max. 32 characters for unique identification and assignment of the block. Factory setting: " _ _ _ _ _ " without text
UPDATE_EVT	read only	Displays whether static block data has been modified, including date and time.

Analog Input Function Block		
Parameter	Write access with operating mode (MODE_BLK)	Description
XD_SCALE	MAN - OOS	In this parameter group, the corresponding process variable from the Transducer block is scaled and the unit is determined. User input: Process variable of the sensor. Factory setting: Analog Input Function Block 1 = 0...100 kg/h Analog Input Function Block 2 = 0...100 m³/h Analog Input Function Block 3 = 0...100 Nm³/h Analog Input Function Block 4 = 0...100 kg/l Analog Input Function Block 5 = 0...100 kg/Nl Analog Input Function Block 6 = 0...100 °C Analog Input Function Block 7 = 0...100 kg  Note! - Defining the measurement range in this parameter group does not represent a restriction. If the value is outside the measurement range, it is transferred nonetheless. - The unit options depend on the corresponding channel: Channel = 1, only units for the mass flow are valid Channel = 2, only units for the volume flow are valid Channel = 3, only units for the corrected volume flow are valid Channel = 4, only units for the density are valid Channel = 5, only units for the reference density are valid Channel = 6, only units for the temperature are valid Channel = 7, only units for the totalizer 1 are valid Channel = 8, only units for the totalizer 2 are valid Channel = 9, only units for the totalizer 3 are valid If a unit that does not match is selected, the function block switches to operating mode OOS (Out Of Service). - The unit selected in this parameter group is also valid for the Transducer Block. - Entry of the measurement range via the parameter XD_SCALE does not restrict the output. - A description of the rescaling of an input value via the parameter XD_SCALE can be found on Page 136.

6 Discrete Output Function block

The Discrete Output function block (DO, Discrete Output) processes a discrete setpoint value received from an upstream function block or higher level process control system, with which various instrument functions (e.g. zero point adjustment or totalizer reset) can be initiated in the subsequent Transducer block.




CAS_IN_D = Remote setpoint value from another function block

OUT_D = Discrete output value and status

BKCAL_OUT_D = Discrete output value and status required by BKCAL_IN_D input of another block for output tracking.

6.1 Signal processing

The figure shows the internal structure of the Discrete Output function blocks:



In the CAS operating mode (cascade operation), the Discrete Output function block receives, via the function block input CAS_IN_D, a discrete signal from an upstream function block. This signal controls the setpoint value (parameter SP_D) of the function block, and after internal calculation is sent as an output signal (parameter OUT_D) to the Transducer block for control of instrument functions (e.g. zero point adjustment). The output value and status of the Discrete Output function block is communicated to the upstream block via the output BKCAL_OUT_D.

Signal processing in the RCAS operating mode (remote cascade operation) is largely identical to the CAS operating mode. However, in this operating mode, control of the parameter SP_D does not take place via an upstream function block but through a process control system. The output value and status of the Discrete Output function block is communicated to the process control system as an answer message via parameter RCAS_OUT_D.

In the AUTO operating mode (automatic operation), the set point value (parameter SP_D) is prescribed directly in the Discrete Output function block. In this case, the parameter CAS_IN_D is not taken into consideration in the internal calculation.

In the MAN operating mode (HAND), the output value (parameter OUT_D) can be prescribed directly in the Discrete Output function block. No internal calculation takes place.

The major functions and parameters of the Discrete Output Function Block are listed below; you will find an overview of all the available parameters starting on Seite 154.

6.2 Selection of the process variable

The operating mode is set via the parameter group MODE_BLK (see Seite 157). The Discrete Output Function Block supports the following operating modes:

- AUTO
- MAN
- CAS
- RCAS
- OOS

6.3 Safety behavior

There is a safety default available (fault state) for the Discrete Output function block. This is activated when a fault condition (of the corresponding valid set point value) exists longer than defined in the parameter FSTATE_TIME, or when the parameter SET_FSTATE in the Resource block is activated. The safety operation is determined via the parameters FSTATE_TIME, FSTATE_VAL_D, and IO_OPTS.

6.4 Assignment between the Discrete Output Function block and the Transducer block

The assignment or connection between the Discrete Output function block and the Transducer block takes place in the Discrete Output function block via the parameter CHANNEL. Since in Promass 83 only one Transducer block exists, the value must be set to 16.

Parameter CHANNEL = 16 → Discrete Output Function block

6.5 Values for the parameters CAS_IN_D, RCAS_IN_D, OUT_D, and SP_D

Via the Discrete Output function block, different instrument functions in the Transducer block can be initiated via manufacturer-specific, fixed set point values from an upstream function block.

Here it must be observed that the desired function is only then executed when a status change from the value 0 (Discrete state 0) to the corresponding function value (following table) takes place. The value 0 always serves as the starting point for the corresponding control of instrument functions. A status change from a value not equal to zero to another value has no effect.

Input allocation of the parameter CAS_IN_D, RCAS_IN_D, OUT_D, SP_D

Status changes	Action
Discrete state 0 → Discrete state 1	reserved
Discrete state 0 → Discrete state 2	Positive Zero Return ON
Discrete state 0 → Discrete state 3	Positive Zero Return OFF
Discrete state 0 → Discrete state 4	Zero Point Adjustment
Discrete state 0 → Discrete state 5	reserved
Discrete state 0 → Discrete state 6	reserved
Discrete state 0 → Discrete state 7	Reset Totalizers 1, 2, 3
Discrete state 0 → Discrete state 8	Reset Totalizer 1
Discrete state 0 → Discrete state 9	Reset Totalizer 2
Discrete state 0 → Discrete state 10	Reset Totalizer 3

Example for the control of creep suppression via the Discrete Output function block.

The following example shows how the creep suppression can be activated or deactivated via the Discrete Output function block during a cleaning procedure.

1. In the first step, the connection between the Discrete Output function block and the Transducer block must be established. Here, the value 16 must be assigned to the parameter CHANNEL in the Discrete Output function block.

Parameter CHANNEL = 16 → Discrete Output

2. In the CAS operating mode, the Discrete Output function block processes the set point value prescribed at the input CAS_IN_D from the upstream function block and transfers it to the Transducer block.

Activating the creep suppression

With a starting value of 0 (Discrete state 0), the creep suppression is activated by a status change from 0 to 2 at input CAS_IN_D.

Deactivating the creep suppression

The creep suppression can only then be deactivated when the input value at CAS_IN_D has first been set to output value 0 (Discrete state 0). Only then can the creep suppression be deactivated through a status change from 0 to 2 at input CAS_IN_D.

6.6 Parameter Discrete Output Funktionsblock

The following table shows all the available parameters of the Discrete Output function block.

Discrete Output Funktionsblock		
Parameter	Write access with operating mode (MODE_BLK)	Description
ALERT_KEY	AUTO - MAN - OOS - CAS - RCAS	For entry of the identification number of the plant unit. This information can be used by the fieldbus host system for sorting alarms and events. User input: 1...255 Factory setting: 0
BLOCK_ALM	AUTO - MAN - OOS - CAS - RCAS	Displays the current block status with information on pending configuration, hardware or system errors, including details of the alarm time (date, time) when the error occurred. The block alarm is triggered in the event of the following block errors: • SIMULATE ACTIVE • INPUT FAILURE • OUTPUT FAILURE • READBACK FAILURE • OUT OF SERVICE • BLOCK CONFIG ERROR
BKCAL_OUT_D	read only	Displays the discrete output value and output status transferred in the case of cascade control to the input BKCAL_IN_D of the preceding function block.
BLOCK_ERR	read only	Displays the active block error. Display: SIMULATE ACTIVE Simulation in the parameter group "SIMULATE_D" of the Discrete Output Function Block is active. INPUT FAILURE Input fault, the input value of the Transducer Block has a status of BAD. OUTPUT FAILURE Fault in Transducer block. OUT OF SERVICE The block has the status "Out Of Service". BLOCK CONFIG ERROR • An operating switchover is not possible, since the value of the Period of Execution time = 0. • A switchover to the RCAS operating mode is not possible, since the selection Uninitialized in the parameter SHED_OPT was made.

Discrete Output Funktionsblock		
Parameter	Write access with operating mode (MODE_BLK)	Description
CAS_IN_D	AUTO - MAN - OOS - CAS - RCAS	Displays the discrete setpoint value and status copied from an external function block in operating mode CAS. Discrete state 0 = Starting point, no effect Discrete state 1 = reserved Discrete state 2 = Positive Zero Return ON Discrete state 3 = Positive Zero Return OFF Discrete state 4 = Zero Point Adjustment Discrete state 5 = reserved Discrete state 6 = reserved Discrete state 7 = Reset Totalizers 1, 2, 3 Discrete state 8 = Reset Totalizer 1 Discrete state 9 = Reset Totalizer 2 Discrete state 10 = Reset Totalizer 3  Note! - The desired function will only then be carried out when a status change from 0 (Discrete state 0) to the corresponding function value (e.g. Discrete state 2 = Positive Zero Return ON) takes place. - The remote setpoint value read in via the parameter CAS_IN_D is only used if the Discrete Output Function Block is in operating mode CAS. In operating mode AUTO the value of parameter SP_D is used as a setpoint value.
CHANNEL	OOS	 Note! With Promass 83, this parameter is fixed at the selection 16. Assignment between the logical hardware channels of the Transducer Block and the input of the Discrete Output Function Blocks. Options: 0 = initialized 1 = Mass Flow (this option is not supported) 2 = Volume Flow (this option is not supported) 3 = Corrected Volume Flow (this option is not supported) 4 = Density (this option is not supported) 5 = Reference Density (this option is not supported) 6 = Temperature (this option is not supported) 7 = Totalizer 1 (this option is not supported) 8 = Totalizer 2 (this option is not supported) 9 = Totalizer 3 (this option is not supported) 16 = Discrete Output
FSTATE_TIME	AUTO - MAN - OOS - CAS - RCAS	Input of the delay time which must expire with a fault of the external lead value (parameter RCAS_IN_D), before the defined fault operation is initiated. Factory setting: 0 s  Note! After expiry of the delay time and a still active fault, the following values are used for further processing: - If in the parameter IO_OPTS the option Fault State to value was selected, the value of the parameter FSATE_VAL_D (fault replacement value) will be used. - If in the parameter IO_OPTS the option Fault State to value was not selected, the value of the parameter RCAS_IN_D will continue to be used.

Discrete Output Funktionsblock		
Parameter	Write access with operating mode (MODE_BLK)	Description
FSTATE_VAL_D	AUTO - MAN - OOS - CAS - RCAS	Entry of a fault condition replacement value for the parameter RCAS_IN_D. This value will be used for further processing instead of the parameter RCAS_IN_D when the following conditions are fulfilled: • An active fault of the parameter RCAS_IN_D exists. • The delay time FSTATE_TIME has expired. • The option Fault State to value has been selected in the parameter IO_OPTS. Options: 0 = Starting point, no effect 1 = reserved 2 = Positive Zero Return ON 3 = Positive Zero Return OFF 4 = Zero Point Adjustment 5 = reserved 6 = reserved 7 = Reset Totalizer 1, 2, 3 8 = Reset Totalizer 1 9 = Reset Totalizer 2 10 = Reset Totalizer 3 Factory setting: 0
GRANT_DENY	AUTO - MAN - OOS - CAS - RCAS	Locks or unlocks the access authorisation of a fieldbus host system on the field device.  Note! This parameter is not evaluated by the Promass 83 FF.
IO_OPTS	OOS	Activates the options for processing the input and output values of the function block (I/O options). Options: • PV for BKCAL_OUT For BKCAL_OUT_D, the value of parameter PV_D is used instead of the parameter SP_D. • SP-PV Track in MAN SP_D follows PV_D in the MAN operating mode. • SP-PV Track in LO SP_D follows PV_D in the LO operating mode. • Invert Inverting of the output value OUT_D to the Transducer block. • Fault State to value When fault operation is initiated, FSTATE_VAL_D is used as set point value. • Use Fault State Value on restart During instrument startup, FSTATE_VAL_D is used as set point value until a valid value is available. • Target to MAN if Fault State activated When fault operation is initiated, the requested (Target) operating mode of the parameter group MODE_BLK is set to MAN, and the original target operating mode is lost. After leaving the fault operation, the block remains in MAN and must be set to the desired operating mode by the user. Factory setting: not enabled

Discrete Output Funktionsblock		
Parameter	Write access with operating mode (MODE_BLK)	Description
MODE_BLK	AUTO - MAN - OOS - CAS - RCAS	Displays the current (Actual) and desired (Target) operating mode of the Discrete Output Function Block, the permitted modes (Permitted) supported by the Resource Block, and the normal operating mode (Normal). Display: AUTO - MAN - OOS - CAS - RCAS The Discrete Output Function Block supports the following operating modes: • AUTO (Automatic Operation) The setpoint value specified by the user via the parameter SP_D is used in the execution of the internal Discrete Output algorithm. • MAN (Manual Intervention by the Operator) The parameter OUT_D can be specified directly by the user. • OOS (Out Of Service) The block has the status "Out Of Service". The Discrete Output algorithm of the block is not executed. The last valid value is output at the parameter OUT_D and the status changes to BAD. • CAS (Cascade Mode) Via the input or parameter CAS_IN_D, the Discrete Output Function Block receives the setpoint value for internal calculation of the actuating variable directly from another function block. The internal Discrete Output algorithm is executed. • RCAS (External Cascade) Via the parameter RCAS_IN_D, the Discrete Output Function Block receives the setpoint value for internal calculation of the actuating variable directly from the fieldbus host system. The internal Discrete Output algorithm is executed.
OUT_D	MAN - OOS	Displays the discrete output value and the status of the Discrete Output Funktionsblocks.  Note! If MAN (manual) is selected for the operating mode in the parameter MODE_BLK then the output value OUT_D can be specified manually here.
PV_D	read only	Display of the discrete process variable value and status determined in the parameter READBACK_D.
PV_STATE	AUTO - MAN - OOS - CAS - RCAS	In this parameter, the Fieldbus host system can store a reference to a description of the possible conditions of the parameter PV_D.  Note! This parameter is not evaluated by the Promass 83 FF..
RCAS_IN_D	AUTO - MAN - OOS - CAS - RCAS	In this parameter the analog actuating variable provided by the fieldbus host system (value and status) is read in for internal calculation of the actuating variable and displayed.  Note! This parameter is only active in operating mode RCAS.


Discrete Output Funktionsblock		
Parameter	Write access with operating mode (MODE_BLK)	Description
RCAS_OUT_D	read only	Displays the analog output value and output status of the specified setpoint value transferred to the fieldbus host system in the course of cascade control.  Note! This parameter is only active in operating mode RCAS.
READBACK_D	read only	Display of the input signal condition and status of the answer message input.
SHED_OPT	AUTO - MAN - OOS - CAS - RCAS	Selects the action taken if the monitoring time is exceeded (see parameter SHED_RCAS on Seite 84) in operating mode RCAS. During the monitoring time parameter updating between the fieldbus host system and the Discrete Output Function Block is checked. If the parameters are not being updated then on expiry of the monitoring time the Discrete Output Function Block switches from operating mode RCAS to the mode selected here. Options: Uninitialized NormalShed_NormalReturn NormalShed_NoReturn ShedToAuto_NormalReturn ShedToAuto_NoReturn ShedToManual_NormalReturn ShedToManual_NoReturn ShedToRetainedTarget_NormalReturn ShedToRetainedTarget_NoReturn Factory setting: Uninitialized
SIMULATE_D	AUTO - MAN - OOS - CAS - RCAS	Simulation of the value and status of the process variable PV_D. Factory setting: Simulation Disabled (Simulation not active)  Note! - During the simulation, the value of OUT_D is not passed on to the Transducer block. The Transducer block keeps the last valid value from before the simulation was activated. - The parameter BLOCK_ERROR of the Resource block shows whether a simulation is possible.
SP_D	AUTO - MAN - OOS	Entry of the discrete setpoint value. User input: 0 = Starting point, no effect 1 = reserved 2 = Positive Zero Return ON 3 = Positive Zero Return OFF 4 = Zero Point Adjustment 5 = reserved 6 = reserved 7 = Reset Totalizer 1, 2, 3 8 = Reset Totalizer 1 9 = Reset Totalizer 2 10 = Reset Totalizer 3

Discrete Output Funktionsblock		
Parameter	Write access with operating mode (MODE_BLK)	Description
ST_REV	read only	Displays the revision status of the static data.  Note! The revision status parameter is incremented on each modification of static data.
STATUS_OPTS	OOS	Selects the available status options for specifying the status processing and processing of the output parameter OUT_D. Options: Propagate Fault Backward Pass on fault operation to upstream blocks. Factory setting: no option active
STRATEGY	AUTO - MAN - OOS - CAS - RCAS	Parameter for grouping and thus faster evaluation of blocks. Grouping is carried out by entering the same numerical value in the parameter STRATEGY for each individual block. Factory setting: 0  Note! This data is neither checked nor processed by the Discrete Output Function Block.
TAG_DESC	AUTO - MAN - OOS - CAS - RCAS	Entry of a user-specific text of max. 32 characters for unique identification and assignment of the block. Factory setting: "-----" without text
UPDATE_EVT	read only	Displays whether static block data has been modified, including date and time.
XD_STATE	AUTO - MAN - OOS - CAS - RCAS	In this parameter, the Fieldbus host system can store a reference to a description of the possible conditions of the parameter PV_D.  Note! This parameter is not evaluated by the Promass 83 FF.

7 PID Function Block (PID controller)

A PID Function Block contains the input channel processing, the proportional integral differential control (PID) and the analog output channel processing. The configuration of the PID Function Block depends on the automation task. The following can be realized: basic controls, feedforward control rejection, cascade control, cascade control with limiting.

The possibilities available for processing measured values within the PID Function Block include: signal scaling and limiting, operating mode control, actuating, limiting control, limit detection, signal status propagation.




F06-53xFFxx-16-xx-xx-en-003

- IN = Input of the controlled variable from another function block.
- CAS_IN = Input of the remote setpoint value from another function block.
- BKCAL_IN = Input of the feedback value and status from the output BKCAL_OUT of the subsequent function block, to prevent reset window and to initialise the control loop.
- TRK_IN_D = Discrete input for activating the external output tracking function.
- TRK_VAL = Input for the external value for tracking from another function block.
- FF_VAL = Input for the disturbance variable from another function block. (Feedforward control)
- OUT = Output value and status (actuating variable) of the PID Function Block.
- BKCAL_OUT = Output for the feedback value and status transferred to the input BKCAL_IN of the upstream function block to prevent reset window and to provide bumpless transfer to closed loop control.

7.1 Signal processing in the PID Function Block

The diagram shows the internal structure of the PID Function Block:



F06-53xFFxx-16-xx-xx-en-004

7.2 PID Function Block equation

The PID Function Block (PID controller) can be used for various automation strategies. The function block has a flexible control algorithm that can be configured differently depending on the application.

$$y = \text{GAIN} \cdot \left(e + \frac{1}{\text{RESET}} \cdot \int e \cdot \Delta t + \text{RATE} \cdot \frac{\Delta e}{\Delta t} \right) + F$$

- y = Actuating variable calculated from the PID algorithm.
- GAIN = Proportional gain factor (P-term)
- RESET = Time constant for the integral action in seconds (I-term)
- RATE = Time constant for the derivative action in seconds (D-term)
- e = Control deviation (e = setpoint value - PV)
- F = Disturbance variable (F = FF_VAL • FF_GAIN)

The output variable OUT results following checking of the range limits OUT_HI_LIM and OUT_LO_LIM (see Page 178).

The PID Function Block consists of a proportional term, an integral term and a derivative term. The actuating variable is calculated on the basis of the control deviation between the setpoint value SP and the process variable PV (controlled variable).

The individual PID actions are used in the calculation of the actuating variable as follows:

- Proportional term - GAIN - :
The proportional term reacts directly and immediately to a change in the setpoint value SP or the process variable PV (controlled variable). The actuating variable is modified by the proportional factor GAIN, which corresponds to the control deviation multiplied by the gain factor. If a controller works only with the proportional term, then the control has a remaining control deviation.
- Integral term - RESET - :
The control deviation arising from the calculation of the actuating variable using the proportional term is integrated via the integral term of the controller until this control deviation is negligible. The integral function RESET corrects the actuating variable depending on the size and duration of the control deviation. If the value for the integral function RESET is set to zero then the controller works with pure I-control. The influence of the integral term on the control is greater if the value of the integral function RESET is reduced.
- Derivative term - RATE - :
In the case of control sections with long delays, e.g. temperature controls, it is useful to use the derivative term RATE of the controller. Using the derivative term RATE the actuating variable is calculated as a function of the change in the control deviation.

7.3 Selecting the operating mode

The operating mode is set via the parameter group MODE_BLK (see Page 177). The PID Function Block supports the following operating modes:

- AUTO
- MAN
- OOS
- CAS
- RCAS
- ROUT



Note!

The block status OOS is also shown via the parameter BLOCK_ERR (see Page 170). In operating mode OOS, if write protection is not enabled, you can access all the write parameters without restriction.

7.4 Setpoint selection

The PID Function Block works with different setpoint values (reference inputs) depending on the active operating mode:

- The PID Function Block is in operating mode AUTO:
The setpoint value of the parameter SP (see Page 181) is used to calculate the actuating variable. This setpoint value is entered manually by the operator in the parameter SP.
- The PID Function Block is in operating mode CAS:
The setpoint value of the parameter CAS_IN (see Page 170) is used to calculate the actuating variable. This setpoint value is copied from an external function block or a host computer and read in via the input parameter CAS_IN in the PID Function Block.
- The PID Function Block is in operating mode RCAS:
The setpoint value of the parameter RCAS_IN (see Page 180) is used to calculate the actuating variable. This setpoint value is copied from the fieldbus host system and read in via the input parameter RCAS_IN in the PID Function Block.



Note!

The range of setpoint value input can be restricted via the parameters SP_HI_LIM and SP_LO_LIM (see Page 181).

7.5 Damping

Specifying a time in the parameter PV_FTIME (see Page 179) slows down the reaction of the internal process variables to changes in the input value IN (controlled variable). This output filter is useful where the input value fluctuates greatly. Where a time of 0 seconds is specified, the output value is not filtered.

7.6 Limit Values

The limit values are based on the value of the process variable PV (see Page 179). If the process variable PV exceeds or does not reach the defined limit values then an alarm is sent to the fieldbus host system via the limit value process alarms. The following limit values can be defined:

– HI_HI_LIM	(see Page 174)	– HI_LIM	(see Page 175)
– LO_LO_LIM	(see Page 176)	– LO_LIM	(see Page 176)
– DV_HI_ALM	(see Page 171)	– DV_LO_ALM	(see Page 172)

7.7 Alarm detection and processing

Process alarms provide information on particular block statuses and block events. The status of the process alarms is communicated to the fieldbus host system via the parameter BLOCK_ALM (see Page 170). The parameter ACK_OPTION (see Page 138) specifies whether an alarm must be acknowledged via the fieldbus host system.

The following process alarms are generated by the PID Function Block:

- Block process alarms

A block process alarm is triggered via the parameter BLOCK_ERR (see Page 170). The parameter BLOCK_ALM (see Page 170) is used to show the block process alarms and communicate them to the fieldbus host system. The following block process alarm can be generated by the PID Function Block:

- OUT OF SERVICE

If the option of the process alarm (BLOCK ALM) has **not** been enabled in the parameter ACK_OPTION (see Page 166), the process alarms can only be acknowledged in the parameter BLOCK_ALM (see Page 170).

- Limit value process alarms

If a limit value is violated then the priority specified for the limit value alarm will be checked before the limit value violation is communicated to the fieldbus host system. The priority that specifies the action in the event of an active limit value violation is determined by the following parameters:

– HI_HI_PRI	(see Page 174)	– HI_PRI	(see Page 175)
– LO_LO_PRI	(see Page 176)	– LO_PRI	(see Page 177)
– DV_HI_PRI	(see Page 172)	– DV_LO_PRI	(see Page 173)

The status of the limit value process alarms is communicated to the fieldbus host system via the following parameters:

– HI_HI_ALM	(see Page 174)	– HI_ALM	(see Page 174)
– LO_LO_ALM	(see Page 176)	– LO_ALM	(see Page 175)
– DV_HI_ALM	(see Page 171)	– DV_LO_ALM	(see Page 172)

If the option of a limit value process alarm has **not** been enabled in the parameter ACK_OPTION (see Page 166) then this must be acknowledged directly in its parameter (see list).




Note!

The parameter ALARM_SUM (see Page 168) shows the current status of all the process alarms.

7.8 Example: Basic PID control strategy

The continual flow into a container is to be controlled.

The volume flow of the medium is captured via a flow transmitter (FT) and made available to the PID Function Block via an Analog Input Function Block. The PID Function Block may be either in the flowmeter or in the control valve. The actuating variable that is forwarded to the control valve (FV) is calculated in the PID Function Block using the deviation between the measured volume flow and the specified setpoint value (desired volume flow).



F06-53\Fxxx-16-xx-xx-en-006


Connecting blocks

The PID Function Block receives its input value (controlled variable) from an Analog Input Function Block (output parameter OUT). This input value, which corresponds to the measured volume flow of the flowmeter, is read in via the parameter IN (see Page 175) in the PID Function Block.

In operating mode AUTO the setpoint value is specified manually via the parameter SP (see Page 181).

The actuating variable calculated in the PID Function Block is connected to the input parameter CAS_IN of the Analog Output Function Block via the output parameter OUT (see Page 178). The Analog Output Function Block forwards this actuating variable to the control valve.

In addition, the output parameter BKCAL_OUT of the Analog Output Function Block is read into the PID Function Block via the input parameter BKCAL_IN (see Page 170) in order to provide bumpless transfer to closed loop control.



F06-53\Fxxx-16-xx-xx-en-007

7.9 PID Function Block configuration

The measurement range of the flowmeter (controlled variable) is 0 ... 30 m³/h. The desired flow value (setpoint value) is specified manually via the parameter SP and should be 15 m³/h. The Analog Output Function Block is actuated over an output range of 0 ... 100%.

Configuration:

- Setting the input range and input unit of the controlled variable at input IN:

PV_SCALE 0 %	= 0
PV_SCALE 100%	= 30
PV_SCALE UNIT	= m ³ /h

- Setting the output range and output unit of the actuating variable at output OUT:

OUT_SCALE 0 %	= 0
OUT_SCALE 100%	= 100
OUT_SCALE UNIT	= %

- Defining the input limits for the setpoint value range:

SP_LO_LIM	= 0
SP_HI_LIM	= 30

- Defining the output limits for the actuating variable at output OUT:

OUT_LO_LIM	= 0
OUT_HI_LIM	= 100

- Setting the bypass function:

In order to be able to deactivate the bypass function via the parameter BYPASS, the option Bypass Enable must first be activated via the parameter CONTROL_OPTS.

- Setting the control parameter (depending on the controlled system):

GAIN - proportional gain factor (P-term)
 RESET- time constant for the integral action in seconds (I-term)
 RATE- time constant for the derivative action in seconds (D-term)

- Specifying the setpoint value via parameter SP:

SP = 15


- Configuration of the limit value and control deviation alarms and associated priorities, if required.

- In order for the PID Function Block to be executed the operating mode must be set to AUTO.

7.10 Parameters of the PID Function Block


The following table shows all the available parameters of the PID Function Block:

PID Function Block (PID controller)		
Parameter	Write access with operating mode (MODE_BLK)	Description
ACK_OPTION	ROUT - RCAS - CAS - AUTO - MAN - OOS	This parameter is used to specify whether a process alarm must be acknowledged at the time of alarm recognition by the fieldbus host system. If this option is enabled the process alarm is acknowledged automatically. Options: HI_HI_ALM Upper limit value alarm HI_ALM Upper limit value warning LO_LO_ALM Lower limit value alarm LO_ALM Lower limit value warning DV_HI_ALM Limit value alarm for upper control deviation (SP-PV) DV_LO_ALM Limit value alarm for lower control deviation (SP-PV) BLOCK_ALM Block alarm Factory setting: The option is not enabled for any alarm, the alarms must be acknowledged

PID Function Block (PID controller)		
Parameter	Write access with operating mode (MODE_BLK)	Description
ALARM_HYS	ROUT - RCAS - CAS - AUTO - MAN - OOS	For entry of the hysteresis value for the upper and lower warning or alarm limit values. The alarm conditions remain active as long as the measured value is within the hysteresis. The hysteresis value affects the following warning and alarm limit values of the PID Function Block: • HI_HI_ALM (Upper limit value alarm) • HI_ALM (Upper limit value warning) • LO_LO_ALM (Lower limit value alarm) • LO_ALM (Lower limit value warning) • DV_HI_ALM (Limit value for upper control deviation) • DV_LO_ALM (Limit value for lower control deviation) User input: 0...50% Factory setting: 0.5  Note! The hysteresis value relates to a percentage of the range of the parameter group PV_SCALE in the PID Function Block (see Page 180). Example: The top diagram shows the alarm limit values defined LO_LIM and HI_LIM with their respective hystereses (gray background) and the signal curve of the process variable PV. The bottom two diagrams show the behaviour of the associated alarms HI_ALM and LO_ALM in relation to the changing signal curve (0 = no alarm, 1 = alarm output). a = Process variable PV exceeds the limit value HI_LIM, HI_ALM is activated. b = Process variable PV is below the hysteresis value of HI_LIM, HI_ALM is deactivated. c = Process variable PV is below the limit value LO_LIM, LO_ALM is activated. d = Process variable PV exceeds the hysteresis value of LO_LIM, LO_ALM is deactivated. 

F06-53kFFxx-05-xx-xx-de-002

PID Function Block (PID controller)		
Parameter	Write access with operating mode (MODE_BLK)	Description
ALARM_SUM	ROUT - RCAS - CAS - AUTO - MAN - OOS	Displays the current status of the process alarms. Display: HI_HI_ALM Violation of the upper limit value alarm. HI_ALM Violation of the upper limit value warning. LO_LO_ALM Violation of the lower limit value alarm. LO_ALM Violation of the lower limit value warning. DV_HI_ALM Violation of the limit value alarm for the upper control deviation. DV_LO_ALM Violation of the limit value alarm for the lower control deviation. BLOCK ALM Block alarm  Note! In addition the process alarms can also be disabled in this parameter group.
ALERT_KEY	ROUT - RCAS - CAS - AUTO - MAN - OOS	For entry of the identification number of the plant unit. This information can be used by the fieldbus host system for sorting alarms and events. User input: 1...255 Factory setting: 0
BAL_TIME	ROUT - RCAS - CAS - AUTO - MAN - OOS	This parameter is used to enter the time for which the weighting factor counteracts the integral term of the saturation (calculated actuating variable > OUT_HI_LIM). Factory setting: 0 s

PID Function Block (PID controller)		
Parameter	Write access with operating mode (MODE_BLK)	Description
BKCAL_HYS	ROUT - RCAS - CAS - AUTO - MAN - OOS	For entry of the hysteresis value for the upper and lower actuating variable range limit value OUT_HI_LIM and OUT_LO_LIM. The hysteresis value relates to a percentage of the value in the parameter group OUT_SCALE (see Page 179). If the calculated actuating variable is outside the range defined by the range limit values then this range violation is shown in the monitoring parameter LIMITS in the parameter group OUT and communicated to the subsequent blocks. The range violation remains active whilst the value of the calculated actuating variable is outside the hysteresis value. User input: 0...50% Factory setting: 0.5% Example: The top diagram shows the defined actuating variable range limit values OUT_HI_LIM and OUT_LO_LIM with the hysteresis BKCAL_HYS (gray background) and the signal curve of the calculated actuating variable. The bottom diagram shows the behaviour of the range limit value monitor LIMITS in the parameter group OUT to the changing signal curve of the calculated actuating variable. "NotLimited" = No range limit value violation "HighLimited" = Range limit value violation is output "LowLimited" = Range limit value violation is output a = The calculated actuating variable exceeds the upper actuating variable range limit value OUT_HI_LIM. In the parameter group OUT the status "HighLimited" is output via LIMITS. b = The calculated actuating variable is below the hysteresis value BKCAL_HYS of the upper actuating variable range limit value OUT_HI_LIM. In the parameter group OUT the status "NotLimited" is output via LIMITS. c = The calculated actuating variable is below the lower actuating variable range limit value OUT_LO_LIM. In the parameter group OUT the status "LowLimited" is output via LIMITS. d = The calculated actuating variable exceeds the hysteresis value BKCAL_HYS of the lower actuating variable range limit value OUT_LO_LIM. In the parameter group OUT the status "NotLimited" is output via LIMITS. 

F06-53#FFxx-05-xx-xx-en-004

PID Function Block (PID controller)		
Parameter	Write access with operating mode (MODE_BLK)	Description
BKCAL_IN	ROUT - RCAS - CAS - AUTO - MAN - OOS	Displays the analog input value and status copied in the case of cascade control from the output BKCAL_OUT of the subsequent function block. The cascade control is initialised with this value to prevent reset window.
BKCAL_OUT	read only	Displays the analog output value and output status transferred in the case of cascade control to the input BKCAL_IN of the preceding function block. The cascade control is initialised with this value to provide bumpless transfer.
BLOCK_ALM	ROUT - RCAS - CAS - AUTO - MAN - OOS	Displays the current block status with information on pending configuration, hardware or system errors, including details of the alarm time (date, time) when the error occurred.  Note! If the option of the alarm has not been enabled in the parameter ACK_OPTION, the alarm can only be acknowledged via this parameter.
BLOCK_ERR	read only	Displays the active block error. Display: OUT OF SERVICE (The block has the status "Out Of Service".)
BYPASS	MAN - OOS	This parameter can be used to activate and deactivate calculation of the actuating variable by the PID control algorithm. Options: Uninitialized OFF Bypass deactivated: the actuating variable determined by the PID control algorithm is output via the parameter OUT. ON BYPASS activated: the value of the setpoint value SP is output directly via the parameter OUT.  Caution! The parameter BYPASS is enabled in the controller options (parameter CONTROL_OPTS). This must be set before commissioning.
CAS_IN	ROUT - RCAS - CAS - AUTO - MAN - OOS	Displays the remote setpoint value and status copied from an external function block in operating mode CAS. This value is shown in the unit of the parameter group PV_SCALE.  Note! The remote setpoint value read in via the parameter CAS_IN is only used if the PID Function Block is in operating mode CAS. In operating mode AUTO the value of parameter SP is used as a setpoint value.

PID Function Block (PID controller)		
Parameter	Write access with operating mode (MODE_BLK)	Description
CONTROL_OPTS	OOS	Selects the available controller options for specifying the automation strategy. Options: Bypass Enable Activates the parameter BYPASS Direct Acting Direct effect Track Enable Activates tracking Track in Manual Operating mode MAN with active tracking PV for BKCAL_OUT Use value and status of the parameter PV for the parameter BKCAL_OUT No OUT Limits in Manual No output restriction in operating mode MAN. If the range limit value OUT_HI_LIM or OUT_LO_LIM is exceeded or not reached, this has no effect on the parameter OUT. Factory setting: no option activated
DV_HI_ALM	ROUT - RCAS - CAS - AUTO - MAN - OOS	Status display of the alarm for the upper control deviation, including details of the time of the alarm (date, time) and the value that triggered the alarm. The controlled variable exceeds the setpoint value by more than the value specified in the parameter DV_HI_LIM.  Note! In addition the active block alarm can be acknowledged in this parameter group.
DV_HI_LIM	ROUT - RCAS - CAS - AUTO - MAN - OOS	Entry of the limit value for the upper control deviation. If the controlled variable exceeds the setpoint value by this value, then the warning DV_HI_ALM is output. User input: Range and unit of PV_SCALE Factory setting: $3402823466 \times 10^{38}$  Note! If the setting for the end of the scale is changed in the parameter PV_SCALE this value should be modified accordingly.

PID Function Block (PID controller)		
Parameter	Write access with operating mode (MODE_BLK)	Description
DV_HI_PRI	ROUT - RCAS - CAS - AUTO - MAN - OOS	Specifies the action taken when the upper control deviation (DV_HI_LIM) is exceeded. User input: 0 Violation of the limit value for the upper control deviation is not valuated. 1 No notification if the limit value for the upper control deviation is infringed. 2 Reserved for block alarms. 3-7 Violation of the limit value for the upper control deviation is output with the appropriate priority (3 = low priority, 7 = high priority) as a user notice. 8-15 Violation of the limit value for the upper control deviation is output as a critical alarm with the appropriate priority (8 = low priority, 15 = high priority). Factory setting: 0
DV_LO_ALM	ROUT - RCAS - CAS - AUTO - MAN - OOS	Alarm status display for the lower control deviation, including details of the time of the alarm (date, time) and the value that triggered the alarm. The controlled variable is below the setpoint value by more than the value specified in the parameter DV_LO_LIM.  Note! In addition the active block alarm can be acknowledged in this parameter group.
DV_LO_LIM	ROUT - RCAS - CAS - AUTO - MAN - OOS	Entry of the limit value for the lower control deviation. If the controlled variable is below the setpoint value by this value then the warning DV_LO_ALM is output. User input: Range and unit of PV_SCALE Factory setting: $-3402823466 \times 10^{38}$  Note! If the setting for the end of the scale is changed in the parameter PV_SCALE this value should be modified accordingly.


PID Function Block (PID controller)		
Parameter	Write access with operating mode (MODE_BLK)	Description
DV_LO_PRI	ROUT - RCAS - CAS - AUTO - MAN - OOS	Specifies the action taken if the lower control deviation (DV_LO_LIM) is not reached. User input: 0 Violation of the limit value for the lower control deviation is not evaluated. 1 No notification if the limit value for the lower control deviation is violated. 2 Reserved for block alarms. 3-7 Violation of the limit value for the lower control deviation is output with the appropriate priority (3 = low priority, 7 = high priority) as a user notice. 8-15 Violation of the limit value for the lower control deviation is output as a critical alarm with the appropriate priority (8 = low priority, 15 = high priority). Factory setting: 0
FF_GAIN	MAN - OOS	Entry of the disturbance gain for the feedforward control. Factory setting: 0  Note! The disturbance gain is multiplied by the disturbance variable (FF_VAL), the result is added to the calculated actuating variable.
FF_SCALE	MAN - OOS	Definition of the measurement range (lower and upper limit), the physical unit and the number of decimal places for the disturbance variable (FF_VAL). Factory setting: 0...100%
FF_VAL	ROUT - RCAS - CAS - AUTO - MAN - OOS	Display and entry of the value and status of the disturbance variable. User input: Range and unit of FF_SCALE
GAIN	ROUT - RCAS - CAS - AUTO - MAN - OOS	Entry of proportional gain factor. Factory setting: 0  Note! If the value 0 is specified for this parameter then the status of the parameter OUT changes to BAD.


PID Function Block (PID controller)		
Parameter	Write access with operating mode (MODE_BLK)	Description
GRANT_DENY	ROUT - RCAS - CAS - AUTO - MAN - OOS	Releases or restricts the access authorisation of a fieldbus host system on the field device.  Note! This parameter is not evaluated by the Promass 83 FF.
HI_ALM	ROUT - RCAS - CAS - AUTO - MAN - OOS	Alarm status display for the upper warning limit value (HI_LIM), including details of the time of the alarm (date, time) and the value that triggered the alarm.  Note! In addition the active block alarm can be acknowledged in this parameter group.
HI_HI_ALM	ROUT - RCAS - CAS - AUTO - MAN - OOS	Alarm status display for the upper alarm limit value (HI_HI_LIM), including details of the time of the alarm (date, time) and the value that triggered the alarm.  Note! In addition the active block alarm can be acknowledged in this parameter group.
HI_HI_LIM	ROUT - RCAS - CAS - AUTO - MAN - OOS	Entry of the alarm limit value for the upper alarm (HI_HI_ALM). If the value PV exceeds this limit value then the alarm status parameter HI_HI_ALM is output. User input: Range and unit of PV_SCALE Factory setting: 3402823466 x 10³⁸  Note! If the setting for the end of the scale is changed in the parameter PV_SCALE this value should be modified accordingly.
HI_HI_PRI	ROUT - RCAS - CAS - AUTO - MAN - OOS	Specifies the action taken when the upper alarm limit value (HI_HI_LIM) is exceeded. User input: 0 The violation of the upper alarm limit is not evaluated. 1 No notification if the upper alarm limit value is infringed. 2 Reserved for block alarms. 3-7 The violation of the upper alarm limit is output as a user notice with the appropriate priority (3 = low priority, 7 = high priority). 8-15 The violation of the upper alarm limit is output as a critical alarm with the appropriate priority (8 = low priority, 15 = high priority). Factory setting: 0

PID Function Block (PID controller)		
Parameter	Write access with operating mode (MODE_BLK)	Description
HI_LIM	ROUT - RCAS - CAS - AUTO - MAN - OOS	Entry of the alarm limit value for the upper warning (HI_ALM). If the value PV exceeds this limit value then the alarm status parameter HI_ALM is output. User input: Range and unit of PV_SCALE Factory setting: 3402823466 x 10³⁸  Note! If the setting for the end of the scale is changed in the parameter PV_SCALE this value should be modified accordingly.
HI_PRI	ROUT - RCAS - CAS - AUTO - MAN - OOS	Specifies the action taken when the upper warning limit value (HI_LIM) is exceeded. User input: 0 The violation of the upper warning limit value is not evaluated. 1 No notification if the upper warning limit value is infringed. 2 Reserved for block alarms. 3-7 The violation of the upper warning limit value is output as a user notice with the appropriate priority (3 = low priority, 7 = high priority). 8-15 The violation of the upper warning limit value is output as a critical alarm with the appropriate priority (8 = low priority, 15 = high priority). Factory setting: 0
IN	ROUT - RCAS - CAS - AUTO - MAN - OOS	Displays the controlled variable with information on the status and value.  Note! Scaling of the input range and selection of the unit of the controlled variable are carried out via the parameter group PV_SCALE.
LO_ALM	ROUT - RCAS - CAS - AUTO - MAN - OOS	Alarm status display for the lower warning limit value (LO_LIM), including details of the time of the alarm (date, time) and the value that triggered the alarm.  Note! In addition the active block alarm can be acknowledged in this parameter group.

PID Function Block (PID controller)		
Parameter	Write access with operating mode (MODE_BLK)	Description
LO_LIM	ROUT - RCAS - CAS - AUTO - MAN - OOS	Entry of the alarm limit value for the lower warning (LO_ALM). If the value PV exceeds this limit value then the alarm status parameter LO_ALM is output. User input: Range and unit of PV_SCALE Factory setting: -3402823466 x 10³⁸  Note! If the setting for the end of the scale is changed in the parameter PV_SCALE this value should be modified accordingly.
LO_LO_ALM	ROUT - RCAS - CAS - AUTO - MAN - OOS	Alarm status display for the lower alarm limit value (LO_LO_LIM), including details of the time of the alarm (date, time) and the value that triggered the alarm.  Note! In addition the active block alarm can be acknowledged in this parameter group.
LO_LO_LIM	ROUT - RCAS - CAS - AUTO - MAN - OOS	Entry of the alarm limit value for the lower alarm (LO_LO_ALM). If the value PV is below this limit value then the alarm status parameter LO_LO_ALM is output. User input: Range and unit of PV_SCALE Factory setting: -3402823466 x 10³⁸  Note! If the setting for the end of the scale is changed in the parameter PV_SCALE this value should be modified accordingly.
LO_LO_PRI	ROUT - RCAS - CAS - AUTO - MAN - OOS	Specifies the action taken when the lower alarm limit value (LO_LO_LIM) is not reached. User input: 0 The violation of the lower alarm limit is not evaluated. 1 No notification if the lower alarm limit value is infringed. 2 Reserved for block alarms. 3-7 The violation of the lower alarm limit is output as a user notice with the appropriate priority (3 = low priority, 7 = high priority). 8-15 The violation of the lower alarm limit is output as a critical alarm with the appropriate priority (8 = low priority, 15 = high priority). Factory setting: 0

PID Function Block (PID controller)		
Parameter	Write access with operating mode (MODE_BLK)	Description
LO_PRI	ROUT - RCAS - CAS - AUTO - MAN - OOS	Specifies the action taken when the lower warning limit value (LO_LIM) is not reached. User input: 0 The violation of the lower warning limit value is not evaluated. 1 No notification if the lower warning limit value is infringed. 2 Reserved for block alarms. 3-7 The violation of the lower warning limit value is output as a user notice with the appropriate priority (3 = low priority, 7 = high priority). 8-15 The violation of the lower warning limit value is output as a critical alarm with the appropriate priority (8 = low priority, 15 = high priority). Factory setting: 0
MODE_BLK	ROUT - RCAS - CAS - AUTO - MAN - OOS	Displays the current (Actual) and desired (Target) operating mode of the PID Function Block, the permitted modes (Permitted) supported by the Resource Block, and the normal operating mode (Normal). Display: AUTO - MAN - OOS - CAS - RCAS The PID Function Block supports the following operating modes: • AUTO (Automatic Operation) The setpoint value specified by the user via the parameter SP is used in the execution of the internal PID algorithm. • MAN (Manual Intervention by the Operator) The parameter OUT can be specified directly by the user. • OOS (Out Of Service) The block has the status "Out Of Service". The PID algorithm of the block is not executed. The last valid value is output at the parameter OUT and the status changes to BAD. • CAS (Cascade Mode) Via the input or parameter CAS_IN, the PID Function Block receives the setpoint value for internal calculation of the actuating variable directly from another function block. The internal PID algorithm is executed. • RCAS (External Cascade) Via the parameter RCAS_IN, the PID Function Block receives the setpoint value for internal calculation of the actuating variable directly from the fieldbus host system. The internal PID algorithm is executed. • ROUT (External Output) Via the parameter ROUT_IN, the PID Function Block receives the actuating value directly from the fieldbus host system. The actuating variable is output again via the parameter OUT without the internal PID algorithm being executed.

PID Function Block (PID controller)		
Parameter	Write access with operating mode (MODE_BLK)	Description
OUT	MAN - OOS	Displays the output value (actuating variable) of the PID Function Block. The output value contains the value, the limit value status, the status and the alarm evaluation. The output value OUT is a function of the range limit value OUT_HI_LIM and OUT_LO_LIM. If the calculated actuating variable is outside the range limit values then the value of the range limit value in question is output as the output value OUT (see diagram).  OUT_SCALE_EU_100 OUT_HI_LIM BKCAL_HYS Calculated actuating variable OUT_LO_LIM BKCAL_HYS OUT_SCALE_EU_0 t OUT_HI_LIM OUT OUT_LO_LIM t F06-53xFFxx-05-xx-xx-en-005  Note! If MAN (manual intervention by the operator) is selected for the operating mode in the parameter MODE_BLK then the output value OUT can be specified manually here. The unit used is copied from the parameter group OUT_SCALE, the input area corresponds to OUT_SCALE ±10%.
OUT_HI_LIM	ROUT - RCAS - CAS - AUTO - MAN - OOS	Entry of the maximum permissible analog actuating variable that can be output from the PID Function Block. User input: Range and unit of OUT_SCALE ±10 Factory setting: 100
OUT_LO_LIM	ROUT - RCAS - CAS - AUTO - MAN - OOS	Entry of the minimum permissible analog actuating variable that can be output from the PID Function Block. User input: Range and unit of OUT_SCALE ±10 Factory setting: 0

PID Function Block (PID controller)		
Parameter	Write access with operating mode (MODE_BLK)	Description
OUT_SCALE	OOS	Definition of the measurement range (lower and upper limit), the physical unit and the number of decimal places for the actuating variable (OUT). Factory setting: 0...100%  Note! The range limits are defined via the parameters OUT_HI_LIM and OU_LO_LIM.
PV	read only	Displays the process variable used for the block execution, including the status.  Note! The unit used is copied from the parameter group PV_SCALE.
PV_FTIME	ROUT - RCAS - CAS - AUTO - MAN - OOS	Entry of the filter time constant (in seconds) of the digital filter of the 1st order. This time is required in order for 63% of a change in the controlled variable at input IN to have an effect on the value of PV. The diagram shows the signal curves between the parameters IN and PV over time:  a) The parameter IN changes. b) The parameter PV has reacted 63% to the change in the parameter IN. Factory setting: 0 s

F06-53x7Fxxx-05-xx-xx-en-006

PID Function Block (PID controller)		
Parameter	Write access with operating mode (MODE_BLK)	Description
PV_SCALE	OOS	Definition of the measurement range (lower and upper limit), the physical unit and the number of decimal places for the process variable (PV). Factory setting: 0...100%  Note! If this parameter group is modified then the following parameters should be checked and modified if necessary: • DV_HI_LIM • DV_LO_LIM • HI_LIM • HI_HI_LIM • LO_LIM • LO_LO_LI • RCAS_IN • RCAS_OUT • SP_LO_LIM • SP_HI_LIM • SP
RATE	ROUT - RCAS - CAS - AUTO - MAN - OOS	Entry of the time constant for the derivative action (D-term) Factory setting: 0 s
RCAS_IN	ROUT - RCAS - CAS - AUTO - MAN - OOS	In this parameter the analog actuating variable provided by the fieldbus host system (value and status) is read in for internal calculation of the actuating variable and displayed.  Note! • Value statement and unit of PV_SCALE • If the setting for the end of the scale is changed in the parameter PV_SCALE this value should be modified accordingly. • This parameter is only active in operating mode RCAS.
RCAS_OUT	read only	Displays the analog output value and output status of the specified setpoint value transferred to the fieldbus host system in the course of cascade control. The cascade control is initialised with this value to provide bumpless transfer.  Note! • Value statement and unit of PV_SCALE • If the setting for the end of the scale is changed in the parameter PV_SCALE this value should be modified accordingly. • This parameter is only active in operating mode RCAS.
RESET	ROUT - RCAS - CAS - AUTO - MAN - OOS	Entry of the time constant for the integral action (I-term) Factory setting: $3402823466 \times 10^{38} \text{ s}$  Note! The integral function is disabled by entering 0 seconds.

PID Function Block (PID controller)		
Parameter	Write access with operating mode (MODE_BLK)	Description
ROUT_IN	ROUT - RCAS - CAS - AUTO - MAN - OOS	In this parameter the actuating variable provided by the fieldbus host system (value and status) is read in and displayed.  Note! - Value statement and unit of OUT_SCALE - This parameter is only active in operating mode ROUT. - The PID algorithm is no longer executed.
ROUT_OUT	read only	Displays the analog output value and output status of the actuating variable transferred to the fieldbus host system in the course of cascade control. The cascade control is initialised with this value to provide bumpless transfer.  Note! - Value statement and unit of OUT_SCALE - This parameter is only active in operating mode ROUT.
SHED_OPT		Selects the action taken if the monitoring time is exceeded (see parameter SHED_RCAS, SHED_ROUT on Page 84) in operating mode RCAS or ROUT. During the monitoring time parameter updating between the fieldbus host system and the PID Function Block is checked. If the parameters are not being updated then on expiry of the monitoring time the PID Function Block switches from operating mode RCAS or ROUT to the mode selected here. Options: Uninitialized NormalShed_NormalReturn NormalShed_NoReturn ShedToAuto_NormalReturn ShedToAuto_NoReturn ShedToManual_NormalReturn ShedToManual_NoReturn ShedToRetainedTarget_NormalReturn ShedToRetainedTarget_NoReturn Factory setting: Uninitialized
SP	AUTO - MAN - OOS	Entry of the analog setpoint value. User input: Range and unit of PV_SCALE ± 10  Note! If the setting for the end of the scale is changed in the parameter PV_SCALE this value should be modified accordingly.
SP_HI_LIM	ROUT - RCAS - CAS - AUTO - MAN - OOS	Entry of the upper limit of the setpoint value. User input: Range and unit of PV_SCALE ± 10 Factory setting: 100  Note! If the setting for the end of the scale is changed in the parameter PV_SCALE this value should be modified accordingly.

PID Function Block (PID controller)		
Parameter	Write access with operating mode (MODE_BLK)	Description
SP_LO_LIM	ROUT - RCAS - CAS - AUTO - MAN - OOS	Entry of the lower limit of the setpoint value. User input: Value and range of PV_SCALE ± 10 Factory setting: 100  Note! If the setting for the end of the scale is changed in the parameter PV_SCALE this value should be modified accordingly.
SP_RATE_DN	ROUT - RCAS - CAS - AUTO - MAN - OOS	Entry of the ramping rate of a diminishing setpoint value in operating mode AUTO. Factory setting: $3402823466 \times 10^{38}$ PV per second  Note! - If the value "0" is entered then this parameter is deactivated and the setpoint value is used directly. - The speed restriction is only active in operating mode AUTO.
SP_RATE_UP	ROUT - RCAS - CAS - AUTO - MAN - OOS	Entry of the ramping rate of an increasing setpoint value in operating mode AUTO. Factory setting: $3402823466 \times 10^{38}$ PV per second  Note! - If the value "0" is entered then this parameter is deactivated and the setpoint value is used directly. - The speed restriction is only active in operating mode AUTO.
ST_REV	read only	Displays the revision status of the static data.  Note! The revision status parameter is incremented on each modification of static data.

PID Function Block (PID controller)		
Parameter	Write access with operating mode (MODE_BLK)	Description
STATUS_OPTS	OOS	Selects the available status options for specifying the status processing and processing of the output parameter OUT. The PID Function Block supports the following options: Options: IFS if Bad IN Trigger disturbance status of subsequent Analog Output function block if the controlled variable (IN) changes the status to BAD. IFS if Bad CAS_IN Trigger disturbance status of subsequent Analog Output Function Block if the external setpoint value (CAS_IN) changes the status to BAD. Use Uncertain as Good The status UNCERTAIN is used as GOOD. Target In Manual if Bad IN Switch to operating mode MAN if the controlled variable switches the status to BAD. Factory setting: no option active
STRATEGY	ROUT - RCAS - CAS - AUTO - MAN - OOS	Parameter for grouping and thus faster evaluation of blocks. Grouping is carried out by entering the same numerical value in the parameter STRATEGY for each individual block. Factory setting: 0  Note! This data is neither checked nor processed by the PID Function Block.
TAG_DESC	ROUT - RCAS - CAS - AUTO - MAN - OOS	Entry of a user-specific text of max. 32 characters for unique identification and assignment of the block. Factory setting: "-----" without text
TRK_IN_D	ROUT - RCAS - CAS - AUTO - MAN - OOS	Displays the discrete input (value and status) that initiate the external tracking function. On activation of tracking the operating mode switches to LO (Local Compulsory Tracking). In so doing the actuating variable at the output OUT adopts the value specified at input TRK_VAL.
TRK_SCALE	MAN - OOS	Definition of the measurement range (lower and upper limit), the physical unit and the number of decimal places for the external tracking variable (TRK_VAL). Factory setting: 0...100%
TRK_VAL	ROUT - RCAS - CAS - AUTO - MAN - OOS	Displays the analog input value and input status read in from another function block for the external tracking function in the unit of parameter group TRK_SCALE.
UPDATE_EVT	read only	Displays whether static block data has been modified, including date and time.

8 Index key words FOUNDATION Fieldbus

A

ACK_OPTION	
AI Function block	138
PID Function block	166
Resource block	79
Alarm detection	
AI Function block	137
PID Function block	163
Resource block	78
Transducer block	88
Alarm processing	
Resource block	78
ALARM_HYS	
AI Function block	138
PID Function block	167
ALARM_SUM	
AI Function block	140
PID Function block	168
Resource block	79
ALERT_KEY	
AI Function block	140
DO Function block	154
PID Function block	168
Resource block	79
Transducer block	89
Analog Input Function block (AI)	132

B

BAL_TIME	
PID Function block	168
BKCAL_HYS	
PID Function block	169
BKCAL_IN	
PID Function block	170
BKCAL_OUT	
PID Function block	170
BKCAL_OUT_D	
DO Function block	154
Block model	75
Block output values	
Transducer block	87
Block status	
Resource block	77
BLOCK_ALM	
AI Function block	140
DO Function block	154
PID Function block	170
Resource block	79
Transducer block	89
BLOCK_ERR	
AI Function block	141
DO Function block	154
PID Function block	170

BLOCK_ERR (continuation)	
Resource block	80
Transducer block	90
BYPASS	
PID Function block	170

C

CAS_IN	
PID Function block	170
CAS_IN_D	
DO Function block	155
CHANNEL	
AI Function block	141
DO Function block	155
CLR_FSTATE	
Resource block	80
Configuration	
PID Function block	165
CONFIRM_TIME	
Resource block	80
CONTROL_OPTS	
PID Function block	171
CYCLE_SEL	
Resource block	80
CYCLE_TYPE	
Resource block	80

D

Damping	
PID Function block	162
DD_RESOURCE	
Resource block	80
DD_REV	
Resource block	80
DEV_REV	
Resource block	80
DEV_TYPE	
Resource block	80
Diagnosis	
AI Function block	135
Transducer block	88
Discrete Output Function block	151
DV_HI_ALM	
PID Function block	171
DV_HI_LIM	
PID Function block	171
DV_HI_PRI	
PID Function block	172
DV_LO_ALM	
PID Function block	172
DV_LO_LIM	
PID Function block	172
DV_LO_PRI	
PID Function block	173

F

FAULT_STATE	
Resource block	81
FEATURES	
Resource block	81
FEATURES_SEL	
Resource block	81
FF_GAIN	
PID Function block	173
FF_SCALE	
PID Function block	173
FF_VAL	
PID Function block	173
FIELD_VAL	
AI Function block	142
FREE_SPACE	
Resource block	81
FREE_TIME	
Resource block	81
FSTATE_VAL_D	
DO Function block	156
FSTATE_TIME	
DO Function block	155
Function blocks	131

G

GAIN	
PID Function block	173
GRANT_DENY	
AI Function block	142
DO Function block	156
PID Function block	174
Resource block	81

H

HARD_TYPES	
Resource block	82
HI_ALM	
AI Function block	142
PID Function block	174
HI_HI_ALM	
AI Function block	142
PID Function block	174
HI_HI_LIM	
AI Function block	142
PID Function block	174
HI_HI_PRI	
AI Function block	143
PID Function block	174
HI_LIM	
AI Function block	143
PID Function block	175
HI_PRI	
AI Function block	143
PID Function block	175

I

IN	
PID Function block	175
IO_OPTS	
AI Function block	144
DO Function block	156
ITK_VER	
Resource block	82

L

Limit values	
AI Function block	137
PID Function block	163
LIM_NOTIFY	
Resource block	82
Linearisation	
AI Function block	134
LOW_CUT	
AI Function block	147
LO_ALM	
AI Function block	145
PID Function block	175
LO_LIM	
AI Function block	145
PID Function block	176
LO_LO_ALM	
AI Function block	145
PID Function block	176
LO_LO_LIM	
AI Function block	145
PID Function block	176
LO_LO_PRI	
AI Function block	146
PID Function block	176
LO_PRI	
AI Function block	146
PID Function block	177
L_TYPE	
AI Function block	144

M

Manufacturer-specific parameters	89
MANUFAC_ID	
Resource block	82
MAX_NOTIFY	
Resource block	82
MEMORY_SIZE	
Resource block	82
MIN_CYCLE_T	
Resource block	82
MODE_BLK	
AI Function block	147
DO Function block	157
PID Function block	177
Resource block	82
Transducer block	94

N

NV_CYCLE_T	
Resource block	83

O

Operating mode	
AI Function block	133
PID Function block	162
Resource block	77
Transducer block	88
OUT	
AI Function block	147
PID Function block	178
Output value	
AI Function block	135
OUT_D	
DO Function block	157
OUT_HI_LIM	
PID Function block	178
OUT_LO_LIM	
PID Function block	178
OUT_SCALE	
AI Function block	148
PID Function block	179

P

Parameter	
DO Function block	154
AI Function block	138
PID Function block	166
Resource block	79
Transducer block	89
PID Function block	160
PID Function Block equation	161
Process variable	
AI Function block	134
PV	
AI Function block	148
PID Function block	179
PV_D	
DO Function block	157
PV_FTIME	
AI Function block	148
PID Function block	179
PV_SCALE	
PID Function block	180
PV_STATE	
DO Function block	157

R

RATE	
PID Function block	180
RCAS_IN	
PID Function block	180
RCAS_IN_D	
DO Function block	157

RCAS_OUT	
PID Function block	180
RCAS_OUT_D	
DO Function block	158
READBACK_D	
DO Function block	158
Rescaling	
AI Function block	136
RESET	
PID Function block	180
Resource block	77
RESTART	
Resource block	83
ROUT_IN	
PID Function block	181
ROUT_OUT	
PID Function block	181
RS_STATE	
Resource block	83

S

Selection process variable	
DO Function block	152
Setpoint selection	
PID Function block	162
SET_FSTATE	
Resource block	83
SHED_OPT	
DO Function block	158
PID Function block	181
SHED_RCAS	
Resource block	84
SHED_ROUT	
Resource block	84
Signal processing	
AI Function block	132
DO Function block	151
PID Function block	160
Transducer block	86
SIMULATE	
AI Function block	149
SIMULATE_D	
DO Function block	158
Simulation	
AI Function block	135
Resource block	78
SP	
PID Function block	181
SP_D	
DO Function block	158
SP_HI_LIM	
PID Function block	181
SP_LO_LIM	
PID Function block	182

S (continuation)

SP_RATE_DN	
PID Function block	182
SP_RATE_UP	
PID Function block	182
STATUS_OPTS	
AI Function block	149
STATUS_OPTS	
DO Function block	159
PID Function block	183
STRATEGY	
AI Function block	149
DO Function block	159
PID Function block	183
Resource block	84
Transducer block	108
ST_REV	
AI Function block	149
DO Function block	159
PID Function block	182
Resource block	84
Transducer block	100

T

TAG_DESC	
AI Function block	149
DO Function block	159
PID Function block	183
Resource block	84
Transducer block	108
TEST_RW	
Resource block	84
Transducer block	86
Transducer Error	
Transducer block	115
Transducer Type	
Transducer block	115
TRK_IN_D	
PID Function block	183
TRK_SCALE	
PID Function block	183
TRK_VAL	
PID Function block	183

U

Units	
AI Function block	134
UPDATE_EVT	
AI Function block	149
DO Function block	159
PID Function block	183
Resource block	84
Transducer block	116

W

Write protection	
Resource block	78
WRITE_ALM	
Resource block	85
WRITE_LOCK	
Resource block	85
WRITE_PRI	
Resource block	85

X

XD_SCALE	
AI Function block	150
XD_STATE	
DO Function block	159

Europe			
Austria □ Endress+Hauser Ges.m.b.H. Wien Tel. (01) 88056-0, Fax (01) 88056-35		Netherland □ Endress+Hauser B.V. Naarden Tel. (035) 6958611, Fax (035) 6958825	
Belarus □ Belorgsintez Minsk Tel. (0172) 508473, Fax (0172) 508583		Norway □ Endress+Hauser A/S Tranby Tel. (032) 859850, Fax (032) 859851	
Belgium / Luxembourg □ Endress+Hauser N.V. Brussels Tel. (02) 2480600, Fax (02) 2480553		Poland □ Endress+Hauser Polska Sp. z o.o. Warszawa Tel. (022) 7201090, Fax (022) 7201085	
Bulgaria INTERTECH-AUTOMATION Sofia Tel. (02) 664869, Fax (02) 9631389		Portugal Technisis, Lda Cacém Tel. (21) 4267290, Fax (21) 4267299	
Croatia □ Endress+Hauser GmbH+Co. Zagreb Tel. (01) 6637785, Fax (01) 6637823		Romania Romconseng S.R.L. Bucharest Tel. (01) 4101634, Fax (01) 4112501	
Cyprus I+G Electrical Services Co. Ltd. Nicosia Tel. (02) 484788, Fax (02) 484690		Russia □ Endress+Hauser Moscow Office Moscow Tel. (095) 1587564, Fax (095) 1589871	
Czech Republic □ Endress+Hauser GmbH+Co. Praha Tel. (026) 6784200, Fax (026) 6784179		Slovakia Transcom Technik s.r.o. Bratislava Tel. (7) 44888684, Fax (7) 44887112	
Denmark □ Endress+Hauser A/S Søborg Tel. (70) 131132, Fax (70) 132133		Slovenia □ Endress+Hauser D.O.O. Ljubljana Tel. (061) 5192217, Fax (061) 5192298	
Estonia ELVI-Aqua Tartu Tel. (7) 441638, Fax (7) 441582		Spain □ Endress+Hauser S.A. Sant Just Desvern Tel. (93) 4803366, Fax (93) 4733839	
Finland □ Endress+Hauser Oy Helsinki Tel. (0204) 83160, Fax (0204) 83161		Sweden □ Endress+Hauser AB Sollentuna Tel. (08) 55511600, Fax (08) 55511655	
France □ Endress+Hauser S.A. Huningue Tel. (389) 696768, Fax (389) 694802		Switzerland □ Endress+Hauser AG Reinach/BL 1 Tel. (061) 7157575, Fax (061) 7111650	
Germany □ Endress+Hauser Messtechnik GmbH+Co. Weil am Rhein Tel. (07621) 975-01, Fax (07621) 975-555		Turkey Intek Endüstriyel Ölçü ve Kontrol Sistemlerilis-tanbul Tel. (0212) 2751355, Fax (0212) 2662775	
Great Britain □ Endress+Hauser Ltd. Manchester Tel. (0161) 2865000, Fax (0161) 9981841		Ukraine Photonika GmbH Kiev Tel. (44) 26881, Fax (44) 26908	
Greece I & G Building Services Automation S.A. Athens Tel. (01) 9241500, Fax (01) 9221714		Yugoslavia Rep. Meris d.o.o. Beograd Tel. (11) 4441966, Fax (11) 4441966	
Hungary Mile Ipari-Elektro Budapest Tel. (01) 4319800, Fax (01) 4319817			
Iceland BIL ehf Reykjavik Tel. (05) 619616, Fax (05) 619617		Africa	
Ireland Flomeaco Company Ltd. Kildare Tel. (045) 868615, Fax (045) 868182		Egypt Anasia Heliopolis/Cairo Tel. (02) 4179007, Fax (02) 4179008	
Italy □ Endress+Hauser S.p.A. Cernusco s/N Milano Tel. (02) 921921, Fax (02) 92107153		Morocco Oussama S.A. Casablanca Tel. (02) 241338, Fax (02) 402657	
Latvia Rino TK Riga Tel. (07) 315087, Fax (07) 315084		South Africa □ Endress+Hauser Pty. Ltd. Sandton Tel. (011) 4441386, Fax (011) 4441977	
Lithuania UAB "Agava" Kaunas Tel. (07) 202410, Fax (07) 207414		Tunisia Controle, Maintenance et Regulation Tunis Tel. (01) 793077, Fax (01) 788595	
America			
Argentina □ Endress+Hauser Argentina S.A. Buenos Aires Tel. (01) 145227970, Fax (01) 145227909		Bolivia Tritec S.R.L. Cochabamba Tel. (042) 56993, Fax (042) 50981	
		Brazil □ Samson Endress+Hauser Ltda. Sao Paulo Tel. (011) 50313455, Fax (011) 50313067	
		Canada □ Endress+Hauser Ltd. Burlington, Ontario Tel. (905) 6819292, Fax (905) 6819444	
		Chile □ Endress+Hauser Chile Ltd. Santiago Tel. (02) 3213009, Fax (02) 3213025	
		Colombia Colsein Ltda. Bogota D.C. Tel. (01) 2367659, Fax (01) 6104186	
		Costa Rica EURO-TEC S.A. San Jose Tel. (02) 961542, Fax (02) 961542	
		Ecuador Insetec Cia. Ltda. Quito Tel. (02) 269148, Fax (02) 461833	
		Guatemala ACISA Automatizacion Y Control Industrial S.A. Ciudad de Guatemala, C.A. Tel. (03) 345985, Fax (03) 327431	
		Mexico □ Endress+Hauser S.A. de C.V. Mexico City Tel. (5) 5682405, Fax (5) 5687459	
		Paraguay Incoel S.R.L. Asuncion Tel. (021) 213989, Fax (021) 226583	
		Uruguay Circular S.A. Montevideo Tel. (02) 925785, Fax (02) 929151	
		USA □ Endress+Hauser Inc. Greenwood, Indiana Tel. (317) 535-7138, Fax (317) 535-8498	
		Venezuela Controval C.A. Caracas Tel. (02) 9440966, Fax (02) 9444554	
		Asia	
		China □ Endress+Hauser Shanghai Instrumentation Co. Ltd. Shanghai Tel. (021) 54902300, Fax (021) 54902303	
		□ Endress+Hauser Beijing Office Beijing Tel. (010) 68344058, Fax (010) 68344068	
		Hong Kong □ Endress+Hauser HK Ltd. Hong Kong Tel. 25283120, Fax 28654171	
		India □ Endress+Hauser (India) Pvt Ltd. Mumbai Tel. (022) 8521458, Fax (022) 8521927	
		Indonesia PT Grama Bazita Jakarta Tel. (21) 7975083, Fax (21) 7975089	
		Japan □ Sakura Endress Co. Ltd. Tokyo Tel. (0422) 540613, Fax (0422) 550275	
		Malaysia □ Endress+Hauser (M) Sdn. Bhd. Petaling Jaya, Selangor Darul Ehsan Tel. (03) 7334848, Fax (03) 7338800	
		Pakistan Speedy Automation Karachi Tel. (021) 7722953, Fax (021) 7736884	
		Papua-Neuguinea SBS Electrical Pty Limited Port Moresby Tel. 3251188, Fax 3259556	
		Philippines □ Endress+Hauser Philippines Inc. Metro Manila Tel. (2) 3723601-05, Fax (2) 4121944	
		Singapore □ Endress+Hauser (S.E.A.) Pte., Ltd. Singapore Tel. 5668222, Fax 5666848	
		South Korea □ Endress+Hauser (Korea) Co., Ltd. Seoul Tel. (02) 6587200, Fax (02) 6592838	
		Taiwan Kingjarl Corporation Taipei R.O.C. Tel. (02) 27183938, Fax (02) 27134190	
		Thailand □ Endress+Hauser Ltd. Bangkok Tel. (2) 9967811-20, Fax (2) 9967810	
		Vietnam Tan Viet Bao Co. Ltd. Ho Chi Minh City Tel. (08) 8335225, Fax (08) 8335227	
		Iran PATSA Co. Tehran Tel. (021) 8754748, Fax (021) 8747761	
		Israel Instrumetrics Industrial Control Ltd. Netanya Tel. (09) 8357090, Fax (09) 8350619	
		Jordan A.P. Parpas Engineering S.A. Amman Tel. (06) 4643246, Fax (06) 4645707	
		Kingdom of Saudi Arabia Anasia Ind. Agencies Jeddah Tel. (02) 6710014, Fax (02) 6725929	
		Lebanon Network Engineering Jbeil Tel. (3) 944080, Fax (9) 548038	
		Sultanate of Oman Mustafa Sultan Science & Industry Co. LLC. Ruwi Tel. 602009, Fax 607066	
		United Arab Emirates Descon Trading EST. Dubai Tel. (04) 2653651, Fax (04) 2653264	
		Yemen Yemen Company for Ghee and Soap Industry Taiz Tel. (04) 230664, Fax (04) 212338	
		Australia + New Zealand	
		Australia ALSTOM Australia Limited Milperra Tel. (02) 97747444, Fax (02) 97744667	
		New Zealand EMC Industrial Group Limited Auckland Tel. (09) 4155110, Fax (09) 4155115	
		All other countries	
		□ Endress+Hauser GmbH+Co. Instruments International D-Weil am Rhein Germany Tel. (07621) 975-02, Fax (07621) 975345	

For more Endress+Hauser product please visit: www.ainstru.com
<http://www.endress.com>
 Mail: Sales@ainstru.com