



Level



Pressure



Flow



Temperature



Liquid
Analysis



Registration



Systems
Components



Services



Solutions

Description of Device Functions

Proline Promass 83

Coriolis Mass Flow Measuring System




Table of Contents

1	Notes on using this Manual	7
1.1	Using the table of contents to locate a function description	7
1.2	Using the graphic of the function matrix to locate a function description	7
1.3	Using the index of the function matrix to locate a function description	7
2	Function matrix	8
2.1	General layout of the function matrix	8
2.1.1	Blocks (A, B, C, etc.)	8
2.1.2	Groups (AAA, AEA, CAA, etc.)	8
2.1.3	Function groups (000, 020, 060, etc.)	8
2.1.4	Functions (0000, 0001, 0002, etc.)	8
2.1.5	Codes identifying cells	9
2.2	Function matrix Proline Promass 83	10
3	Block MEASURED VARIABLES	11
3.1	Group MEASURING VALUES	12
3.1.1	Function group MAIN VALUES	12
3.1.2	Function group ADDITIONAL VALUES	13
3.2	Group SYSTEM UNITS	17
3.2.1	Function group CONFIGURATION	17
3.2.2	Function group ADDITIONAL CONFIGURATION	20
3.3	Group SPECIAL-UNITS	22
3.3.1	Function group ARBITRARY UNIT	22
4	Block QUICK SETUP	25
4.1	Setup Commissioning	27
4.2	Pulsating flow Setup menu	29
4.3	Gas measurement Setup menu	31
4.4	Batching Setup menu	32
4.5	Data back-up/transfer	34
5	Block USER INTERFACE	35
5.1	Group CONTROL	36
5.1.1	Function group BASIC CONFIGURATION	36
5.1.2	Function group UNLOCKING/ LOCKING	38
5.1.3	Function group OPERATION	39
5.2	Group MAIN LINE	40
5.2.1	Function group CONFIGURATION	40
5.2.2	Function group MULTIPLEX	42
5.3	Group ADDITIONAL LINE	44
5.3.1	Function group CONFIGURATION	44
5.3.2	Function group MULTIPLEX	47
5.4	Group INFORMATION LINE	50
5.4.1	Function group CONFIGURATION	50
5.4.2	Function group MULTIPLEX	53
6	Block TOTALIZERS	56
6.1	Group TOTALIZER (1...3)	57
6.1.1	Function group CONFIGURATION	57
6.1.2	Function group OPERATION	59
6.2	Group HANDLING TOTALIZER	60

7	Block OUTPUTS	61
7.1	Group CURRENT OUTPUT (1...3)	62
7.1.1	Function group CONFIGURATION	62
7.1.2	Function group OPERATION	72
7.1.3	Function group INFORMATION	73
7.2	Group PULSE/FREQUENCY OUTPUT (1...2)	74
7.2.1	Function group CONFIGURATION	74
7.2.2	Function group OPERATION	96
7.2.3	Function group INFORMATION	100
7.3	Group RELAY OUTPUT (1...2)	101
7.3.1	Function group CONFIGURATION	101
7.3.2	Function group OPERATION	105
7.3.3	Function group INFORMATION	107
7.3.4	Information on the response of the relay output	108
7.3.5	Switching behavior of the relay output	109
8	Block INPUTS	111
8.1	Group STATUS INPUT	112
8.1.1	Function group CONFIGURATION	112
8.1.2	Function group OPERATION	113
8.1.3	Function group INFORMATION	114
8.2	Group CURRENT INPUT	115
8.2.1	Function group CONFIGURATION	115
8.2.2	Function group OPERATION	117
8.2.3	Function group INFORMATION	118
9	Block BASIC FUNCTION	119
9.1	Group HART	120
9.1.1	Function group CONFIGURATION	120
9.1.2	Function group INFORMATION	121
9.2	Group PROCESS PARAMETER	122
9.2.1	Function group CONFIGURATION	122
9.2.2	Function group EPD PARAMETER	125
9.2.3	Function group REFERENCE PARAMETER	127
9.2.4	Function group ADJUSTMENT	129
9.2.5	Function group PRESSURE CORRECTION	132
9.3	Group SYSTEM PARAMETER	133
9.3.1	Function group CONFIGURATION	133
9.4	Group SENSOR DATA	135
9.4.1	Function group CONFIGURATION	135
9.4.2	Function group FLOW COEFFICIENT	136
9.4.3	Function group DENSITY COEFFICIENT	137
9.4.4	Function group ADDITIONAL COEFFICIENT	138
10	Block SPECIAL FUNCTION	139
10.1	Group DENSITY FUNCTIONS	141
10.1.1	Function group CONFIGURATION	141
10.2	Group BATCHING FUNCTION	147
10.2.1	Function group CONFIGURATION	147
10.2.2	Function group VALVE PARAMETER	153
10.2.3	Examples of setting parameters for batching processes	155
10.2.4	Function group SUPERVISION	158
10.2.5	Function group OPERATION	162
10.2.6	Function group INFORMATION	164

10.3	Group ADVANCED DIAGNOSIS	166
10.3.1	Function group CONFIGURATION	166
10.3.2	Function group ACQUISITION	167
10.3.3	Function group MASS FLOW	168
10.3.4	Function group DENSITY	169
10.3.5	Function group REFERENCE DENSITY	170
10.3.6	Function group TEMPERATURE	171
10.3.7	Function group TUBE DAMPING	172
10.3.8	Function group ELECTRODYNAMIC SENSORS	173
10.3.9	Function group OPERATING FREQUENCY FLUCTUATION	175
10.3.10	Function group TUBE DAMPING FLUCTUATION	177
11	Block SUPERVISION	179
11.1	Group SYSTEM	180
11.1.1	Function group CONFIGURATION	180
11.1.2	Function group OPERATION	183
11.2	Group VERSION-INFO	185
11.2.1	Function group DEVICE	185
11.2.2	Function group SENSOR	185
11.2.3	Function group AMPLIFIER	186
11.2.4	Function group F-CHIP	187
11.2.5	Function group I/O MODULE	187
11.2.6	Function groups INPUT/OUTPUT 1...4	188
12	Factory settings	189
12.1	SI units (not for USA and Canada)	189
12.1.1	Low flow cut off, full scale value, pulse value – Liquid	189
12.1.2	Low flow cut off, full scale value, pulse value – Gas	189
12.1.3	Language	190
12.1.4	Density, length, temperature	190
12.2	US units (only for USA and Canada)	191
12.2.1	Low flow cut off, full scale value, pulse value – Liquid	191
12.2.2	Low flow cut off, full scale value, pulse value – Gas	191
12.2.3	Language, density, length, temperature	191

Registered trademarks

HART®

Registered trademark of HART Communication Foundation, Austin, USA

HistoROM™, S-DAT®, T-DAT®, F-CHIP®

Registered trademarks of Endress+Hauser Flowtec AG, Reinach, CH

1 Notes on using this Manual

There are various ways of locating the description of a function of your choice in the manual:

1.1 Using the table of contents to locate a function description

The designations of all the cells in the function matrix are listed in the table of contents. You can use these unambiguous designations (such as USER INTERFACE, INPUTS, OUTPUTS, etc.) to choose whichever functions are applicable to a particular set of conditions. The page references show you exactly where to find the detailed descriptions of the functions in question. The table of contents is on page 3.

1.2 Using the graphic of the function matrix to locate a function description


This step-by-step, top-down approach starts with the blocks, the highest level, and factory down through the matrix to the description of the function you need:

1. All blocks available, and their related groups, are illustrated on page 10. Select the block (or the group within the block) which you need for your application and use the page reference to locate the information corresponding to the next level.
2. The page in question contains a graphic showing of the block with all its subordinate groups, function groups and functions. Select the function which you need for your application and use the page reference to locate the detailed function description.

1.3 Using the index of the function matrix to locate a function description

Each “cell” in the function matrix (blocks, groups, function groups, functions) has a unique identifier in the form of a code consisting of one or three letters or a three- or four-digit number. The code identifying a selected “cell” appears at the top right on the local display.

Example:



A0001653-en


The function matrix index lists the codes for all the available “cells” in alphabetic and consecutive order, complete with the page references for the corresponding functions. The index to the function matrix is on page 193.

2 Function matrix

2.1 General layout of the function matrix

The function matrix consists of four levels:

Blocks -> Groups -> Function groups -> Functions



A0000961

2.1.1 Blocks (A, B, C, etc.)

The blocks are the highest-level grouping of the operation options for the device. The blocks include, for example: MEASURED VARIABLES, QUICK SETUP, USER INTERFACE, TOTALIZER, etc.

2.1.2 Groups (AAA, AEA, CAA, etc.)

A block consists of one or more groups. Each group represents a more detailed selection of the operation options in the higher-order block. The groups in the USER INTERFACE block, for example, include: CONTROL, MAIN LINE, ADDITIONAL LINE, etc.

2.1.3 Function groups (000, 020, 060, etc.)

A group consists of one or more function groups. Each function group represents a more detailed selection of the operation options in the higher-order group. The function groups in the CONTROL group, for example, include: BASIC CONFIGURATION, UN-/LOCKING, OPERATION, etc.

2.1.4 Functions (0000, 0001, 0002, etc.)

Each function group consists of one or more functions. The functions are used to operate and configure the device. Numerical values can be entered or parameters selected and saved. The functions in the BASIC CONFIGURATION function group include LANGUAGE, DISPLAY DAMPING, CONTRAST LCD, etc. The procedure for changing the language of the user interface, for example, is as follows:

1. Select the block USER INTERFACE.
2. Select the group CONTROL.
3. Select the function group BASIC CONFIGURATION.
4. Select the function LANGUAGE (here you can set the language required).

2.1.5 Codes identifying cells

Each cell (block, group, function group and function) in the function matrix has an individual, unique code.

Blocks:

The code is a letter (A, B, C, etc.)

Groups:

The code consists of three letters (AAA, ABA, BAA, etc.).

The first letter matches the block code (i.e. each group in block A has a code starting with an A _ _; the codes of the groups in block B start with a B _ _, etc.). The other two letters are for identifying the group within the respective block.

Function groups:


The code consists of three digits (000, 001, 100, etc.).

Functions:

The code consists of four digits (0000, 0001, 0201, etc.).

The first three digits are the same as the code for the function group.

The last digit in the code is a counter for the functions in the function group, incrementing from 0 to 9 (e.g. function 0005 is the sixth function in group 000).



A0001251

2.2 Function matrix Proline Promass 83


BLOCKS		GROUPS		Function groups
MEASURED VARIABLES A (see p. 11)	→	MEASURING VALUES AAA	→	see p. 12
		SYSTEM UNITS ACA	→	see p. 17
		SPECIAL-UNITS AEA	→	see p. 22
↓				
QUICK SETUP B (see p. 25)	→	Commissioning and application setups	→	see p. 25
↓				
USER INTERFACE C (see p. 35)	→	CONTROL CAA	→	see p. 36
		MAIN LINE CCA	→	see p. 40
		ADDITIONAL LINE CEA	→	see p. 44
		INFORMATION LINE CGA	→	see p. 50
↓				
TOTALIZERS D (see p. 56)	→	TOTALIZER 1 DAA	→	see p. 57
		TOTALIZER 2 DAB	→	see p. 57
		TOTALIZER 3 DAC	→	see p. 57
		HANDLING TOTALIZER DJA	→	see p. 60
↓				
OUTPUTS E (see p. 61)	→	CURRENT OUTPUT 1 EAA	→	see p. 62
		CURRENT OUTPUT 2 EAB	→	see p. 62
		CURRENT OUTPUT 3 EAC	→	see p. 62
		PULSE/FREQ. OUTPUT 1 ECA	→	see p. 74
		PULSE/FREQ. OUTPUT 2 ECB	→	see p. 74
		RELAY OUTPUT 1 EGA	→	see p. 101
		RELAY OUTPUT 2 EGB	→	see p. 101
↓				
INPUTS F (see p. 111)	→	STATUS INPUT FAA	→	see p. 112
		CURRENT INPUT FCA	→	see p. 115
↓				
BASIC FUNCTION G (see p. 119)	→	HART GAA	→	see p. 120
		PROCESS PARAMETER GIA	→	see p. 122
		SYSTEM PARAMETER GLA	→	see p. 133
		SENSOR DATA GNA	→	see p. 135
↓				
SPECIAL FUNCTION H (see p. 139)	→	DENSITY FUNCTIONS HAA	→	see p. 141
		BATCHING FUNCTION HCA	→	see p. 147
		ADVANCED DIAGNOSIS HEA	→	see p. 166
↓				
SUPERVISION J (see p. 179)	→	SYSTEM JAA	→	see p. 180
		VERSION-INFO JCA	→	see p. 185

3 Block MEASURED VARIABLES

Block	Groups	Function groups	Functions												
MEASURED VARIABLES (A)	MEASURING VALUES (AAA) p. 12	⇕	⇒												
			MAIN VALUES (000) p. 12	⇒	MASS FLOW (0000) p. 12	⇕	VOLUME FLOW (0001) p. 12	CORRECTED VOL. FLOW (0004) p. 12	DENSITY (0005) p. 12	REFERENCE DENSITY (0006) p. 12	TEMPERATURE (0008) p. 12	PRESSURE (0009) p. 12			
			↑ ↓												
	ADDITIONAL VALUES (002) p. 13	⇕	⇒												
			TARGET MASS FLOW (0020) p. 13	⇕	% TARGET MASS FLOW (0021) p. 13	TARGET VOLUME FLOW (0022) p. 13	% TARGET VOLUME FLOW (0023) p. 13	CORR. TARGET VOL. FLOW (0024) p. 14	CARRIER MASS FLOW (0025) p. 14	CARRIER VOL. FLOW (0027) p. 14	% CARRIER VOLUME FLOW (0028) p. 15	CORR. CARR. VOLUME FLOW (0029) p. 15			
			↑ ↓												
	% BLACK LIQUOR (0030) p. 15	⇕													
			*BAUME (0031) p. 15	*API (0033) p. 15	*PLATO (0034) p. 16	*BALLING (0035) p. 16	*BRIX (0036) p. 16	OTHERS (0037) p. 16							
	SYSTEM UNITS (ACA) p. 17	⇕	⇒												
			CONFIGURATION (040) p. 17	⇕	UNIT MASS FLOW (0400) p. 17	⇕	UNIT MASS (0401) p. 17	UNIT VOLUME FLOW (0402) p. 18	UNIT VOLUME (0403) p. 18	UNIT CORR. VOL. FLOW (0404) p. 19	UNIT CORR. VOLUME (0405) p. 19				
			↑ ↓												
SPECIAL-UNITS (AEA) p. 22	⇕	⇒													
		ADDITIONAL CONFIGURATION (042) p. 20	⇕	UNIT DENSITY (0420) p. 20	⇕	UNIT REFERENCE DENSITY (0421) p. 20	UNIT TEMPERATURE (0422) p. 21	UNIT LENGTH (0424) p. 21	UNIT PRESSURE (0426) p. 21						
		↑ ↓													
ARBITRARY UNIT (060) p. 22	⇕	⇒													
		TEXT ARB. MASS (0600) p. 22	⇕	FACTOR ARB. MASS (0601) p. 22	TEXT ARB. VOLUME (0602) p. 23	FACTOR ARB. VOLUME (0603) p. 23	TEXT ARB. DENSITY (0604) p. 23	FACTOR ARB. DENSITY (0605) p. 23	TEXT ARB. CONCENTR. (0606) p. 24	FACT. ARB. CONCENT. (0607) p. 24					
		↑ ↓													


3.1 Group MEASURING VALUES

3.1.1 Function group MAIN VALUES



Function description MEASURED VARIABLES → MEASURING VALUES → MAIN VALUES	
 Note! ■ The engineering units of all the measured variables shown here can be set in the “SYSTEM UNITS” group. ■ If the fluid in the pipe flows backwards, a negative sign prefixes the flow reading on the display.	
MASS FLOW (0000)	The currently measured mass flow appears on the display. Display: 5-digit floating-point number, including unit and sign (e.g. 462,87 kg/h; -731.63 lb/min; etc.)
VOLUME FLOW (0001)	The calculated volume flow appears on the display. The volume flow is derived from the measured mass flow and the measured density of the fluid. Display: 5-digit floating-point number, including unit and sign (e.g. 5.5445 dm³/min; 1.4359 m³/h; -731.63 gal/d; etc.)
CORRECTED VOLUME FLOW (0004)	The calculated corrected volume flow appears on the display. The calculated corrected volume flow is derived from the measured mass flow and the reference density of the fluid (density at reference temperature, measured or fixed entry). Display: 5-digit floating-point number, including unit and sign (e.g. 1.3549 Nm³/h; 7.9846 scm/day; etc.)
DENSITY (0005)	The currently measured density or its specific gravity appears on the display. Display: 5-digit floating-point number, incl. unit, corresponds to 0.1000 to 6.0000 kg/dm³ (e.g. 1.2345 kg/dm³; 993.5 kg/m³; 1.0015 SG_20 °C; etc.)
REFERENCE DENSITY (0006)	The density of the fluid, at reference temperature, appears on the display. The reference density can be calculated with the measured density or also specified via the function FIXED REF. DENSITY (6461), (see page 127), or read in directly via the current input. Display: 5-digit floating-point number, incl. unit, corresponds to 0.1000 to 6.0000 kg/dm³ (e.g. 1.2345 kg/dm³; 993.5 kg/m³; 1.0015 SG_20 °C; etc.)
TEMPERATURE (0008)	The currently measured temperature appears on the display. Display: max. 4-digit fixed-point number, including unit and sign (e.g. -23.4 °C; 160.0 °F; 295.4 K; etc.)
PRESSURE (0009)	The currently measured pressure appears on the display. This function is not available unless “pressure” was selected in the ASSIGN CURRENT INPUT function (5200). Display: max. 4-digit fixed-point number, including unit and sign (e.g. 50.0 barg; etc.)

3.1.2 Function group ADDITIONAL VALUES



Function description	
MEASURED VARIABLES → MEASURING VALUES → ADDITIONAL VALUES	
TARGET MASS FLOW (0020)	 Note! This function is not available unless one of the following was selected: ■ in the function DENSITY FUNCTION (7000), see page 141: – % MASS / % VOLUME – FLEXIBLE and in the function MODE (7010), see page 144, the selection % MASS 2D or % MASS 3D Use this function to display the currently measured mass flow of the target fluid. Target fluid = carried material (e.g. lime powder). Display: 5-digit floating-point number, including unit and sign
% TARGET MASS FLOW (0021)	 Note! This function is not available unless one of the following was selected: ■ in the function DENSITY FUNCTION (7000), see page 141: – % MASS / % VOLUME – FLEXIBLE and in the function MODE (7010), see page 144, the selection % MASS 2D or % MASS 3D In this function, the currently measured mass flow of the target fluid is displayed as a % (of the overall mass flow). Target fluid = carried material (e.g. lime powder). Display: 5-digit floating-point number, including unit and sign
TARGET VOLUME FLOW (0022)	 Note! This function is not available unless one of the following was selected: ■ in the function DENSITY FUNCTION (7000), see page 141: – % MASS / % VOLUME – FLEXIBLE and in the function MODE (7010), see page 144, the selection % VOLUME 2D or % VOLUME 3D In this function, the currently measured volume flow of the target fluid is displayed. Target fluid = carried material (e.g. lime powder). Display: 5-digit floating-point number, including unit and sign
% TARGET VOLUME FLOW (0023)	 Note! This function is not available unless one of the following was selected: ■ in the function DENSITY FUNCTION (7000), see page 141: – % MASS / % VOLUME – FLEXIBLE and in the function MODE (7010), see page 144, the selection % VOLUME 2D or % VOLUME 3D Use this function to display the currently measured volume flow of the target fluid as a % (of the overall volume flow). Target fluid = carried material (e.g. lime powder). Display: 5-digit floating-point number, including unit and sign


Function description MEASURED VARIABLES → MEASURING VALUES → ADDITIONAL VALUES	
CORRECTED TARGET VOLUME FLOW (0024)	 Note! This function is not available unless % MASS / % VOLUME was selected in the DENSITY FUNCTION function (7000), (see page 141). Use this function to display the currently measured corrected volume flow of the target fluid. Target fluid = carried material (e.g. lime powder). Display: 5-digit floating-point number, including unit and sign
CARRIER MASS FLOW (0025)	 Note! This function is not available unless one of the following was selected: ■ in the function DENSITY FUNCTION (7000), see page 141: – % MASS / % VOLUME – FLEXIBLE and in the function MODE (7010), see page 144, the selection % MASS 2D or % MASS 3D Use this function to display the currently measured mass flow of the carrier fluid. Carrier fluid = transporting liquid (e.g. water). Display: 5-digit floating-point number, including unit and sign
% CARRIER MASS FLOW (0026)	 Note! This function is not available unless one of the following was selected: ■ in the function DENSITY FUNCTION (7000), see page 141: – % MASS / % VOLUME – FLEXIBLE and in the function MODE (7010), see page 144, the selection % MASS 2D or % MASS 3D Use this function to display the currently measured mass flow of the carrier fluid as a % (of the overall mass flow). Carrier fluid = transporting liquid (e.g. water). Display: 5-digit floating-point number, including unit and sign
CARRIER VOLUME FLOW (0027)	 Note! This function is not available unless one of the following was selected: ■ in the function DENSITY FUNCTION (7000), see page 141: – % MASS / % VOLUME – FLEXIBLE and in the function MODE (7010), see page 144, the selection % VOLUME 2D or % VOLUME 3D Use this function to display the currently measured volume flow of the carrier fluid. Carrier fluid = transporting liquid (e.g. water). Display: 5-digit floating-point number, including unit and sign

Function description MEASURED VARIABLES → MEASURING VALUES → ADDITIONAL VALUES	
% CARRIER VOLUME FLOW (0028)	 Note! This function is not available unless one of the following was selected: ■ in the function DENSITY FUNCTION (7000), see page 141: – % MASS / % VOLUME – FLEXIBLE and in the function MODE (7010), see page 144, the selection % VOLUME 2D or % VOLUME 3D Use this function to display the currently measured volume flow of the carrier fluid as a % (of the overall mass flow). Carrier fluid = transporting liquid (e.g. water). Display: 5-digit floating-point number, including unit and sign
CORRECTED CARRIER VOLUME FLOW (0029)	 Note! This function is not available unless % MASS / % VOLUME was selected in the DENSITY FUNCTION function (7000), (see page 141). Use this function to display the currently measured corrected volume flow of the carrier fluid. Carrier fluid = transporting liquid (e.g. water). Display: 5-digit floating-point number, including unit and sign
% BLACK LIQUOR (0030)	 Note! This function is not available unless %-BLACK LIQUOR was selected in the DENSITY FUNCTION function (7000), (see page 141). The concentration in %-BLACK LIQUOR is displayed. Display: 5-digit floating-point number, incl. units
°BAUME (0031)	 Note! This function is not available unless °BAUME was selected in the DENSITY FUNCTION function (7000), (see page 141). The concentration in °BAUME is displayed. Display: 5-digit floating-point number, incl. units
°API (0033)	 Note! This function is not available unless °API was selected in the DENSITY FUNCTION function (7000), (see page 141). The concentration in °API is displayed. Display: 5-digit floating-point number, incl. units

Function description MEASURED VARIABLES → MEASURING VALUES → ADDITIONAL VALUES	
°PLATO (0034)	 Note! This function is not available unless °PLATO was selected in the DENSITY FUNCTION function (7000), (see page 141). The concentration in °PLATO is displayed. Display: 5-digit floating-point number, incl. units
°BALLING (0035)	 Note! This function is not available unless °BALLING was selected in the DENSITY FUNCTION function (7000), (see page 141). The concentration in °BALLING is displayed. Display: 5-digit floating-point number, incl. units
°BRIX (0036)	 Note! This function is not available unless °BRIX was selected in the DENSITY FUNCTION function (7000), (see page 141). The concentration in °BRIX is displayed. Display: 5-digit floating-point number, incl. units
OTHERS (0037)	 Note! This function is not available unless FLEXIBLE was selected in the DENSITY FUNCTION function (7000), (see page 141) and this function is not available unless OTHERS 2D or OTHERS 3D was selected in the MODE function (7010), (see page 144). Displays the concentration in the unit, which was defined in the function TEXT ARBITRARY CONCENTRATION (0606), (see page 24). Display: 5-digit floating-point number, incl. units

3.2 Group SYSTEM UNITS

3.2.1 Function group CONFIGURATION




Function description	
MEASURED VARIABLES → SYSTEM UNITS → CONFIGURATION	
You can select the units for measured variables in this function group.	
UNIT MASS FLOW (0400)	Use this function to select the unit for displaying the mass flow (mass/time). The unit you select here is also valid for: ■ Current outputs ■ Frequency outputs ■ Relay switch points (limit value for mass flow, flow direction) ■ Low flow cut off Options: Metric: gram → g/s; g/min; g/h; g/day kilogram → kg/s; kg/min; kg/h; kg/day ton → t/s; t/min; t/h; t/day US: ounce → oz/s; oz/min; oz/h; oz/day pound → lb/s; lb/min; lb/h; lb/day ton → ton/s; ton/min; ton/h; ton/day For arbitrary units (see function TEXT ARBITRARY MASS on page 22) ____ → ____/s; ____/min; ____/h; ____/day Factory setting: Country-dependent (kg/h or US-lb/min)  Note! If you defined a unit of mass in the ARBITRARY UNIT 060 function group (see page 22) the unit in question is shown here.
UNIT MASS (0401)	Use this function to select the unit for displaying the mass. The unit you select here is also valid for: ■ Pulse value (e.g. kg/p) Options: Metric → g; kg; t US → oz; lb; ton For free selectable units → ____ (see function TEXT ARBITRARY MASS on page 22) Factory setting: Country-dependent (kg or US-lb)  Note! ■ If you defined a unit of mass in the ARBITRARY UNIT 060 function group (see page 22) the unit in question is shown here. ■ The unit of the totalizers is independent of your choice here. The unit for each totalizer is selected separately for the totalizer in question.

Function description MEASURED VARIABLES → SYSTEM UNITS → CONFIGURATION	
UNIT VOLUME FLOW (0402)	Use this function to select the unit for displaying the volume flow (volume/time). The unit you select here is also valid for: ■ Current outputs ■ Frequency outputs ■ Relay switch points (limit value for volume flow, flow direction) ■ Low flow cut off Options: Metric: Cubic centimeter → cm³/s; cm³/min; cm³/h; cm³/day Cubic decimeter → dm³/s; dm³/min; dm³/h; dm³/day Cubic meter → m³/s; m³/min; m³/h; m³/day Milliliter → ml/s; ml/min; ml/h; ml/day Liter → l/s; l/min; l/h; l/day Hectoliter → hl/s; hl/min; hl/h; hl/day Megaliter → Ml/s; Ml/min; Ml/h; Ml/day US: Cubic centimeter → cc/s; cc/min; cc/h; cc/day Acre foot → af/s; af/min; af/h; af/day Cubic foot → ft³/s; ft³/min; ft³/h; ft³/day Fluid ounce → oz f/s; oz f/min; oz f/h; oz f/day Gallon → gal/s; gal/min; gal/h; gal/day Kilogallon → Kgal/s; Kgal/min; Kgal/h; Kgal/day Million gallon → Mgal/s; Mgal/min; Mgal/h; Mgal/day Barrel (normal fluids: 31.5 gal/bbl) → bbl/s; bbl/min; bbl/h; bbl/day Barrel (beer: 31.0 gal/bbl) → bbl/s; bbl/min; bbl/h; bbl/day Barrel (petrochemicals: 42.0 gal/bbl) → bbl/s; bbl/min; bbl/h; bbl/day Barrel (filling tanks: 55.0 gal/bbl) → bbl/s; bbl/min; bbl/h; bbl/day Imperial Gallon → gal/s; gal/min; gal/h; gal/day Mega gallon → Mgal/s; Mgal/min; Mgal/h; Mgal/day Barrel (beer: 36.0 gal/bbl) → bbl/s; bbl/min; bbl/h; bbl/day Barrel (petrochemicals: 34.97 gal/bbl) → bbl/s; bbl/min; bbl/h; bbl/day For arbitrary units (see function TEXT ARBITRARY VOLUME on page 23) ____ → ____/s; ____/min; ____/h; ____/day Factory setting: Country-dependent (m³/h or US-Mgal/day)  Note! If you defined a unit of volume in the ARBITRARY UNIT 060 function group (see page 22) the unit in question is shown here.
UNIT VOLUME (0403)	Use this function to select the unit for displaying the volume. The unit you select here is also valid for: Pulse weighting (e.g. m³/p) Options: Metric → cm³; dm³; m³; ml; l; hl; Ml Mega US → cc; af; ft³; oz f; gal; Kgal; Mgal; bbl (normal fluids); bbl (beer); bbl (petrochemicals) → bbl (filling tanks) Imperial → gal; Mgal; bbl (beer); bbl (petrochemicals) For free selectable units → ____ (see function TEXT ARBITRARY VOLUME on page 23) Factory setting: m³  Note! ■ If you defined a unit of volume in the ARBITRARY UNIT 060 function group (see page 22) the unit in question is shown here. ■ The unit of the totalizers is independent of your choice here. The unit for each totalizer is selected separately for the totalizer in question.

Function description MEASURED VARIABLES → SYSTEM UNITS → CONFIGURATION	
UNIT CORRECTED VOLUME FLOW (0404)	Use this function to select the unit for displaying the corrected volume flow (corrected volume/time). The unit you select here is also valid for: ■ Current outputs ■ Frequency outputs ■ Relay switch points (limit value for corrected volume flow, flow direction) ■ Low flow cut off Options: Metric: l/s l/min l/h l/day Nm^3/s Nm^3/min Nm^3/h Nm^3/day US: Sm^3/s; Sm^3/min; Sm^3/h; Sm^3/day Scf/s; Scf/min; Scf/h; Scf/day Factory setting: Nm^3/h
UNIT CORRECTED VOLUME (0405)	Use this function to select the unit for displaying the corrected volume. The unit you select here is also valid for: ■ Pulse value (e.g. Nm^3/p) Options: Metric: Nm^3 l US: Sm^3 Scf Factory setting: Nm^3  Note! The unit of the totalizers is independent of your choice here. The unit for each totalizer is selected separately for the totalizer in question.

3.2.2 Function group ADDITIONAL CONFIGURATION




Function description	
MEASURED VARIABLES → SYSTEM UNITS → ADDITIONAL CONFIGURATION	
UNIT DENSITY (0420)	Use this function to select the unit for displaying the fluid density. The unit you select here is also valid for: ■ Current outputs ■ Frequency outputs ■ Relay switch points (limit value for density) ■ Density response value for EPD ■ Density adjustment value Options: Metric → g/cm³; g/cc; kg/dm³; kg/l; kg/m³; SD 4 °C, SD 15 °C, SD 20 °C; SG 4 °C, SG 15 °C, SG 20 °C US → lb/ft³; lb/gal; lb/bbl (normal fluids); lb/bbl (beer); lb/bbl (petrochemicals); lb/bbl (filling tanks) Imperial → lb/gal; lb/bbl (beer); lb/bbl (petrochemicals) Factory setting: kg/l SD = Specific Density, SG = Specific Gravity The specific density is the ratio of fluid density to water density (at water temperature = 4, 15, 20 °C).
UNIT REFERENCE DENSITY (0421)	Use this function to select the unit for displaying the reference density. The unit you select here is also valid for: ■ Current outputs ■ Frequency outputs ■ Relay switch points (limit value for density) ■ Fixed reference density (for calculation of corrected volume flow) ■ Current input (read in the reference density via current input) Options: Metric: kg/Nm³ kg/Nl US: g/ScC kg/Sm³ lb/Scf Factory setting: kg/Nl

Function description MEASURED VARIABLES → SYSTEM UNITS → ADDITIONAL CONFIGURATION	
UNIT TEMPERATURE (0422)	Use this function to select the unit for displaying the temperature. The unit you select here is also valid for: ■ Current outputs ■ Frequency outputs ■ Current input ■ Relay switch points (limit value for temperature) ■ Reference temperature (for corrected volume measurement with measured reference density) Options: °C (Celsius) K (Kelvin) °F (Fahrenheit) °R (Rankine) Factory setting: °C
UNIT LENGTH (0424)	Use this function to select the unit for displaying the length of the nominal diameter. The unit you select here is valid for: ■ Nominal diameter of sensor (function NOMINAL DIAMETER (6804) on page 135) Options: MILLIMETER INCH Factory setting: MILLIMETER
UNIT PRESSURE (0426)	Use this function to select the unit for pressure. The unit you select here is valid for: ■ Specified pressure (see function PRESSURE (6501) on page 132) Options: bar a bar g psi a psi g Factory setting: bar g

3.3 Group SPECIAL-UNITS

3.3.1 Function group ARBITRARY UNIT



Function description	
MEASURED VARIABLES → SPECIAL-UNITS → ARBITRARY UNIT	
Use this function group to define a free selectable unit for mass, mass flow, volume, volume flow, density and concentration (optional).	
TEXT ARBITRARY MASS (0600)	Use this function to enter a text for the selectable mass unit / mass flow unit. You define only the text, the unit of time is provided from a choice of options (s, min, h, day). User input: xxxxxxx (max. 4 characters) Valid characters are A-Z, 0-9, +, -, decimal point, white space or underscore Factory setting: “ _ _ _ _ ” (No text) Example: If your text entry is “CENT” (for centner), this text string appears on the display complete with the unit of time, e.g. “CENT/min”: CENT = Mass (text input) CENT / min = Mass flow as shown (on the display)
FACTOR ARBITRARY MASS (0601)	Use this function to define a quantity factor (without time) for the selectable mass-/ mass flow unit. The mass unit on which this factor is based is one kilogram. User input: 7-digit floating-point number Factory setting: 1 Reference quantity: kg Example: One centner is equivalent to 50 kg → 0.02 centner = 1 kg User input: 0.02

Function description MEASURED VARIABLES → SPECIAL-UNITS → ARBITRARY UNIT	
TEXT ARBITRARY VOLUME (0602)	Use this function to enter a text for the selectable volume unit / volume flow unit. You define only the text, the unit of time is provided from a choice of options (s, min, h, day). User input: xxxxxxx (max. 4 characters) Valid characters are A-Z, 0-9, +, -, decimal point, white space or underscore Factory setting: “ _ _ _ _ ” (No text) Example: If your text entry is “GLAS”, this text string appears on the display complete with the unit of time, e.g. “GLAS/min”: GLAS = Volume (text input) GLAS / min = Volume flow as shown (on the display)
FACTOR ARBITRARY VOLUME (0603)	Use this function to define a quantity factor (without time) for the selectable unit. The volume unit on which this factor is based is one liter. User input: 7-digit floating-point number Factory setting: 1 Reference quantity: Liter Example: The volume of a glass is 0.5 l → 2 glasses = 1 liter User input: 2
TEXT ARBITRARY DENSITY (0604)	Use this function to enter a text for the selectable density unit. User input: xxxxxxx (max. 4 characters) Valid characters are A-Z, 0-9, +, -, decimal point, white space or underscore Factory setting: “ _ _ _ _ ” (No text) Example: Enter text “CE_L” (for centner per liter).
FACTOR ARBITRARY DENSITY (0605)	Use this function to define a quantity factor for the selectable density unit. The density unit on which this factor is based is one kg/l. User input: 7-digit floating-point number Factory setting: 1 Reference quantity: kg/l Example: One centner per liter is equivalent to 50 kg/l → 0.02 centner/l = 1 kg/l User input: 0.02

Function description	
MEASURED VARIABLES → SPECIAL-UNITS → ARBITRARY UNIT	
TEXT ARBITRARY CONCENTRATION (0606)	 Note! This function is not available unless the optional software package CONCENTRATION is installed. Use this function to enter a text for the selectable concentration unit (user-defined density unit). User input: xxxxxxx (max. 4 characters) Valid characters are A-Z, 0-9, +, -, decimal point, white space or underscore Factory setting: “ _ _ _ _ ” (No text) Example: Enter text “HFCS” (for High Fructose Corn Syrup).
FACTOR ARBITRARY CONCENTRATION (0607)	 Note! This function is not available unless the optional software package CONCENTRATION is installed and an option selected in the function DENSITY FUNCTION (7000), (see page 141). Use this function to define a factor for the selectable concentration unit, see function TEXT ARBITRARY CONCENTRATION (0606). User input: 7-digit floating-point number Factory setting: 1 Reference quantity: Arbitrary concentration unit / % Example: The measured concentration 1% should be output as 0.01 HFCS value User input → 0.01 [HFCS]


4 Block QUICK SETUP

Block	Group	Function groups	Functions
QUICK SETUP (B)	⇒	⇒	QUICK SETUP COMMISSION (1002) p. 25 ⇒ QUICK SETUP PULS.FLOW (1003) p. 25 QUICK SETUP GAS MEASUR. (1004) p. 25 QUICK SETUP BATCH/DOSING (1005) p. 26 T-DAT SAVE/LOAD (1009) p. 26

Function description QUICK SETUP	
QUICK SETUP COMMISSIONING (1002)	Use this function to start the Setup menu for commissioning. Options: YES NO Factory setting: NO  Note! You will find a flowchart of the COMMISSIONING setup menu on page 27. For more information on Setup menus, please refer to the Operating Instructions <i>Proline Promass 83</i>, BA 059D/06/en.
QUICK SETUP PULSATING FLOW (1003)	Use this function to start the application-specific Setup menu for pulsating flow. Options: YES NO Factory setting: NO  Note! You will find a flowchart of the PULSATING FLOW setup menu on page 29. For more information on Setup menus, please refer to the Operating Instructions <i>Proline Promass 83</i>, BA 059D/06/en.
QUICK SETUP GAS MEASUR. (1004)	Use this function to start the application specific Setup menu for the gas measurement. Options: YES NO Factory setting: NO  Note! You will find a flowchart of the GAS MEASUREMENT setup menu on page 31. For more information on Setup menus, please refer to the Operating Instructions <i>Proline Promass 83</i>, BA 059D/06/en.

Function description QUICK SETUP	
QUICK SETUP BATCHING/DOSING (1005)	 Note! This function is only available when the optional software package BATCHING is installed. Use this function to start the (optional) application specific Setup menu for batching. Options: YES NO Factory setting: NO  Note! You will find a flowchart of the BATCHING setup menu on page 32. For more information on Setup menus, please refer to the Operating Instructions <i>Proline Promass 83</i>, BA 059D/06/en.
T-DAT SAVE/LOAD (1009)	Use this function to save the parameter settings / configuration of the transmitter in a transmitter DAT (T-DAT), or to load the parameter settings from the T-DAT into the EEPROM (manual safety function). Application examples: ■ After commissioning, the current measuring point parameters can be saved to the T-DAT as a backup. ■ If the transmitter is replaced for some reason, the data from the T-DAT can be loaded into the new transmitter (EEPROM). Options: CANCEL SAVE (from EEPROM to T-DAT) LOAD (from the T-DAT into EEPROM) Factory setting: CANCEL  Note! ■ If the target device has an older software version, the message “TRANSM. SW–DAT” is displayed during startup. Then only the “SAVE” function is available. ■ LOAD This function is only possible if the target device has the same software version as, or a more recent software version than, the source device. ■ SAVE This function is always available.

4.1 Setup Commissioning




A0004561-en

- ① Selecting “DELIVERY SETTINGS” returns each selected unit to the factory setting. Selecting “ACTUAL SETTING” applies the units you have set previously.
- ② Only units not yet configured in the current Setup are offered for selection in each cycle. The unit for mass, volume and corrected volume is derived from the corresponding flow unit.
- ③ The “YES” option remains visible until all the units have been configured. “NO” is the only option displayed when no further units are available.
- ④ Only the outputs not yet configured in the current Setup are offered for selection in each cycle.
- ⑤ The “YES” option remains visible until all the outputs have been configured. “NO” is the only option displayed when no further outputs are available.
- ⑥ The “automatic parameterization of the display” option contains the following basic settings/factory settings:
YES: Main line = Mass flow; Additional line = Totalizer 1; Information line = Operating/system conditions
No: The existing (selected) settings remain.
- ⑦ The QUICK SETUP BATCHING is only available when the optional software package BATCHING is installed.

**Note!**

- The display returns to the cell QUICK SETUP COMMISSIONING (1002) if you press the  key combination during parameter interrogation. The stored parameters remain valid.
- The “Commissioning” Quick Setup must be carried out before one of the Quick Setups explained below is run.

4.2 Pulsating flow Setup menu



A0002615-en

- ① Only totalizers not yet configured in the current Setup are offered for selection in each cycle.
- ② The “YES” option remains visible until all the totalizers have been configured. “NO” is the only option displayed when no further totalizers are available.
- ③ Only the outputs not yet configured in the current Quick Setup are offered for selection in each cycle.
- ④ The “YES” option remains visible until all the outputs have been configured. “NO” is the only option displayed when no further outputs are available.


**Note!**

- The display returns to the cell QUICK SETUP PULSATING FLOW (1003) if you press the key combination during parameter interrogation.
- You can call up this Setup menu either directly from the “COMMISSIONING” Setup menu or manually by means of the function QUICK SETUP PULSATING FLOW (1003).

Settings for the Pulsating Flow Setup menu:

Fct. code	Function name	Suggested settings	Description
Call up through the function matrix:			
B	QUICK SETUP	QUICK SETUP PULSATING FLOW	see p. 25
1003	QUICK SETUP PULS.FLOW	YES	see p. 25
Basic configuration:			
2002	DISPLAY DAMPING	1 second	see p. 36
3002	TOTALIZER MODE (DAA)	BALANCE	see p. 58
3002	TOTALIZER MODE (DAB)	BALANCE	see p. 58
3002	TOTALIZER MODE (DAC)	BALANCE	see p. 58
Select the signal type: CURRENT OUTPUT (1...n)			
4004	MEASURING MODE	PULSATING FLOW	see p. 68
4005	TIME CONSTANT	1 second	see p. 70
Select the signal type: FREQ./PULSE OUTPUT (1...2) / operating mode: FREQUENCY			
4206	MEASURING MODE	PULSATING FLOW	see p. 79
4208	TIME CONSTANT	0 seconds	see p. 84
Select the signal type: FREQ./PULSE OUTPUT (1...2) / operating mode: PULSE			
4225	MEASURING MODE	PULSATING FLOW	see p. 87
Other settings:			
8005	ALARM DELAY	0 seconds	see p. 181
6400	ASSIGN LF CUT OFF	MASS FLOW	see p. 122
6402	ON-VALUE LOW FLOW CUT OFF	Depends on diameter (DN [mm]): – DN 1 = 0.02 [kg/h] or [l/h] – DN 2 = 0.10 [kg/h] or [l/h] – DN 4 = 0.45 [kg/h] or [l/h] – DN 8 = 2.0 [kg/h] or [l/h] – DN 15 = 6.5 [kg/h] or [l/h] – DN 15* = 18 [kg/h] or [l/h] – DN 25 = 18 [kg/h] or [l/h] – DN 25* = 45 [kg/h] or [l/h] – DN 40 = 45 [kg/h] or [l/h] – DN 40* = 70 [kg/h] or [l/h] – DN 50 = 70 [kg/h] or [l/h] – DN 50* = 180 [kg/h] or [l/h] – DN 80 = 180 [kg/h] or [l/h] – DN 100 = 350 [kg/h] or [l/h] – DN 150 = 650 [kg/h] or [l/h] – DN 250 = 1800 [kg/h] or [l/h] *DN 15, 25, 40 “FB” = Full bore versions Promass I	see p. 122
6403	OFF-VALUE LOW FLOW CUT OFF	50%	see p. 122
6404	PRESSURE SHOCK SUPPRESSION	0 s	see p. 123

4.3 Gas measurement Setup menu




A0002502-en

Settings for the Gas Measurement Setup menu:			
Fct. code	Function name	Suggested settings	Description
Call up through the function matrix:			
B	QUICK SETUP	QUICK SETUP GAS MEASUR.	see p. 25
1004	QUICK SETUP GAS MEASUR.	YES	see p. 25
Basic configuration:			
6420	EMPTY PIPE DETECTION	No entry possible, the selection changes automatically to OFF.	see p. 125
6400	ASSIGN LOW FLOW CUT OFF	For gas measurement we recommend to switch off the low flow cut off. OFF	see p. 122
6402	ON-VALUE LOW FLOW CUT OFF	If you don't switch off the low flow cut off: 0.0000	see p. 122
6403	OFF-VALUE LOW FLOW CUT OFF	If you don't switch off the low flow cut off: 50%	see p. 122

4.4 Batching Setup menu

This Setup menu guides the user systematically through all the device functions that have to be adjusted and configured for batching operation.

The Setup menu settings result in a (simple) one-stage batching process. The parameters for additional settings, e.g. for automatic compensation of after-runs or multistage batching must be manually set in the function matrix.



A0004644-en



Note!

- This Setup menu is only available when the optional software package BATCHING is installed in the measuring device. By means of the order option, the software package can already be installed in the measuring device when delivered from the factory or it can be ordered at a later date from Endress + Hauser and installed as an optional software package.

- The display returns to the function QUICK SETUP BATCHING/DOSING (1005), if you press the ESC key combination during parameter interrogation.
- At the start of the Setup, general device parameters are optimally configured for measuring signal processing and output response.
- Then you can enter the specific batching parameters, starting with the options list “Batching 1...6”. In this way, by running through the Setup menu a number of times, up to six different batching parameter sets (incl. special naming) can be created and called up as necessary.
- In order to enjoy full functionality, it is advisable to let the display parameters be set automatically. This means that the lowest display line is configured as the batching menu. Softkeys are displayed which can be used to start or stop the batching process in the HOME position. In this way, the measuring device can be fully deployed as a “batch controller”.



Caution!

By running the Setup, certain device parameters are optimally set for discontinuous operation. Should the measuring device be used for continuous flow measurement at a later time, we recommend you to rerun the “COMMISSIONING” or the “PULSATING FLOW” Setup.

Settings for the Batching Setup menu:

Fct. code	Function name	Suggested settings	Description
Call up through the function matrix:			
B	QUICK SETUP	QUICK SETUP BATCHING/DOSING	see p. 25
1005	QUICK SETUP BATCHING/DOSING	YES	see p. 26
Settings (functions with a gray background are set automatically):			
6400	ASSIGN LOW FLOW CUT OFF	Mass	see p. 122
6402	ON-VALUE LOW FLOW CUT OFF	Table value	see p. 122
6403	OFF-VALUE LOW FLOW CUT OFF	50%	see p. 122
6603	FLOW DAMPING	0 seconds	see p. 133
6404	PRESSURE SHOCK SUPPRESSION	0 seconds	see p. 123
7200	BATCH SELECTOR	BATCH #1	see p. 147
7202	BATCH NAME	BATCH #1	see p. 147
7201	ASSIGN BATCH VARIABLE	Mass	see p. 148
7203	BATCH QUANTITY	0	see p. 148
7204	FIX COMPENSATION QUANTITY	0	see p. 149
7205	COMPENSATION MODE	OFF	see p. 149
7208	BATCH STAGES	1	see p. 152
7209	INPUT FORMAT	Value input	see p. 152
4700	ASSIGN RELAY	BATCHING VALVE 1	see p. 101
4780	TERMINAL NUMBER	Output (display only)	see p. 107
7220	OPEN VALVE 1	0% or 0 [unit]	see p. 153
7240	MAXIMUM BATCHING TIME	0 seconds (Off)	see p. 158
7241	MIN. BATCHING QUANTITY	0 seconds	see p. 159
7242	MAX. BATCHING QUANTITY	0 seconds	see p. 160
2200	ASSIGN (Main line)	BATCH NAME	see p. 40
2220	ASSIGN (Multiplex main line)	Off	see p. 42
2400	ASSIGN (Additional line)	BATCH DOWNWARDS	see p. 44
2420	ASSIGN (Multiplex additional line)	Off	see p. 47
2600	ASSIGN (Info line)	BATCHING KEYS	see p. 50
2620	ASSIGN (Multiplex info line)	Off	see p. 53

4.5 Data back-up/transfer

You can use the T-DAT SAVE/LOAD function to transfer data (device parameters and settings) between the T-DAT (removable memory) and the EEPROM (device memory).


This is required for the following applications:

- Creating a backup: current data are transmitted from an EEPROM to the T-DAT.
- Replacing a transmitter: current data are copied from an EEPROM to the T-DAT, then transmitted to the EEPROM of the new transmitter.
- Duplicating data: current data are copied from an EEPROM to the T-DAT, then transmitted to EEPROMs of identical measuring points.



Note!

Installing and removing the T-DAT → Operating Instructions of the Promass 83 (BA059D)



Data storage/transmission with T-DAT SAVE/LOAD

a0001221-en

Notes on the LOAD and SAVE options:

LOAD:

Data are transmitted from the T-DAT to the EEPROM.



Note!

- Previously saved settings on the EEPROM are deleted.
- This selection is available only if the T-DAT contains valid data.
- This selection can be made only if the software version of the T-DAT is the same or newer than that of the EEPROM. Otherwise, the error message "TRANSM. SW-DAT" appears after the restart and the LOAD function is subsequently no longer available.

SAVE:

Data are transmitted from the EEPROM to the T-DAT.

5 Block USER INTERFACE

Block	Groups	Function groups	Functions
USER INTERFACE (C)	CONTROL (CAA) p. 36	⇒ ⇕ ⇕	⇒ ⇕ ⇕
			BASIC CONFIG. (200) p. 36
			⇒ ⇕ ⇕
	UN-/LOCKING (202) p. 38	⇒ ⇕ ⇕	⇒ ⇕ ⇕
			UN-/LOCKING (202) p. 38
			⇒ ⇕ ⇕
	OPERATION (204) p. 39	⇒ ⇕ ⇕	⇒ ⇕ ⇕
			OPERATION (204) p. 39
			⇒ ⇕ ⇕
	TEST DISPLAY (2040) p. 39	⇒ ⇕ ⇕	⇒ ⇕ ⇕
			TEST DISPLAY (2040) p. 39
			⇒ ⇕ ⇕
	LANGUAGE (2000) p. 36	⇒ ⇕ ⇕	⇒ ⇕ ⇕
			LANGUAGE (2000) p. 36
			⇒ ⇕ ⇕
	DISPLAY DAMPING (2002) p. 36	⇒ ⇕ ⇕	⇒ ⇕ ⇕
			DISPLAY DAMPING (2002) p. 36
			⇒ ⇕ ⇕
	CONTRAST LCD (2003) p. 37	⇒ ⇕ ⇕	⇒ ⇕ ⇕
			CONTRAST LCD (2003) p. 37
			⇒ ⇕ ⇕
	DEF. PRIVATE CODE (2021) p. 38	⇒ ⇕ ⇕	⇒ ⇕ ⇕
			DEF. PRIVATE CODE (2021) p. 38
			⇒ ⇕ ⇕
	STATUS ACCESS (2022) p. 38	⇒ ⇕ ⇕	⇒ ⇕ ⇕
			STATUS ACCESS (2022) p. 38
			⇒ ⇕ ⇕
	ACCESS CODE CNTR (2023) p. 38	⇒ ⇕ ⇕	⇒ ⇕ ⇕
			ACCESS CODE CNTR (2023) p. 38
			⇒ ⇕ ⇕
	BACKLIGHT (2004) p. 35	⇒ ⇕ ⇕	⇒ ⇕ ⇕
			BACKLIGHT (2004) p. 35
			⇒ ⇕ ⇕
	MAIN LINE (CCA) p. 40	⇕ ⇕ ⇕	⇕ ⇕ ⇕
			⇕ ⇕ ⇕
			⇕ ⇕ ⇕
	CONFIGURATION (220) p. 40	⇕ ⇕ ⇕	⇕ ⇕ ⇕
			CONFIGURATION (220) p. 40
			⇕ ⇕ ⇕
	MULTIPLY (222) p. 42	⇕ ⇕ ⇕	⇕ ⇕ ⇕
			MULTIPLY (222) p. 42
			⇕ ⇕ ⇕
	ASSIGN (2200) p. 40	⇕ ⇕ ⇕	⇕ ⇕ ⇕
			ASSIGN (2200) p. 40
			⇕ ⇕ ⇕
	100% VALUE (2201) p. 41	⇕ ⇕ ⇕	⇕ ⇕ ⇕
			100% VALUE (2201) p. 41
			⇕ ⇕ ⇕
	FORMAT (2202) p. 41	⇕ ⇕ ⇕	⇕ ⇕ ⇕
			FORMAT (2202) p. 41
			⇕ ⇕ ⇕
	100% VALUE (2221) p. 43	⇕ ⇕ ⇕	⇕ ⇕ ⇕
			100% VALUE (2221) p. 43
			⇕ ⇕ ⇕
	FORMAT (2222) p. 43	⇕ ⇕ ⇕	⇕ ⇕ ⇕
			FORMAT (2222) p. 43
			⇕ ⇕ ⇕
	ADDITIONAL LINE (CEA) p. 44	⇕ ⇕ ⇕	⇕ ⇕ ⇕
			⇕ ⇕ ⇕
			⇕ ⇕ ⇕
	CONFIGURATION (240) p. 44	⇕ ⇕ ⇕	⇕ ⇕ ⇕
			CONFIGURATION (240) p. 44
			⇕ ⇕ ⇕
	MULTIPLY (242) p. 47	⇕ ⇕ ⇕	⇕ ⇕ ⇕
			MULTIPLY (242) p. 47
			⇕ ⇕ ⇕
	ASSIGN (2400) p. 44	⇕ ⇕ ⇕	⇕ ⇕ ⇕
			ASSIGN (2400) p. 44
			⇕ ⇕ ⇕
	100% VALUE (2401) p. 45	⇕ ⇕ ⇕	⇕ ⇕ ⇕
			100% VALUE (2401) p. 45
			⇕ ⇕ ⇕
	FORMAT (2402) p. 46	⇕ ⇕ ⇕	⇕ ⇕ ⇕
			FORMAT (2402) p. 46
			⇕ ⇕ ⇕
	DISPLAY MODE (2403) p. 46	⇕ ⇕ ⇕	⇕ ⇕ ⇕
			DISPLAY MODE (2403) p. 46
			⇕ ⇕ ⇕
	100% VALUE (2421) p. 48	⇕ ⇕ ⇕	⇕ ⇕ ⇕
			100% VALUE (2421) p. 48
			⇕ ⇕ ⇕
	FORMAT (2422) p. 49	⇕ ⇕ ⇕	⇕ ⇕ ⇕
			FORMAT (2422) p. 49
			⇕ ⇕ ⇕
	DISPLAY MODE (2423) p. 49	⇕ ⇕ ⇕	⇕ ⇕ ⇕
			DISPLAY MODE (2423) p. 49
			⇕ ⇕ ⇕
	INFORMATION LINE (CGA) p. 50	⇕ ⇕ ⇕	⇕ ⇕ ⇕
			⇕ ⇕ ⇕
			⇕ ⇕ ⇕
	CONFIGURATION (260) p. 50	⇕ ⇕ ⇕	⇕ ⇕ ⇕
			CONFIGURATION (260) p. 50
			⇕ ⇕ ⇕
	MULTIPLY (262) p. 53	⇕ ⇕ ⇕	⇕ ⇕ ⇕
			MULTIPLY (262) p. 53
			⇕ ⇕ ⇕
	ASSIGN (2600) p. 50	⇕ ⇕ ⇕	⇕ ⇕ ⇕
			ASSIGN (2600) p. 50
			⇕ ⇕ ⇕
	100% VALUE (2601) p. 51	⇕ ⇕ ⇕	⇕ ⇕ ⇕
			100% VALUE (2601) p. 51
			⇕ ⇕ ⇕
	FORMAT (2602) p. 52	⇕ ⇕ ⇕	⇕ ⇕ ⇕
			FORMAT (2602) p. 52
			⇕ ⇕ ⇕
	DISPLAY MODE (2603) p. 52	⇕ ⇕ ⇕	⇕ ⇕ ⇕
			DISPLAY MODE (2603) p. 52
			⇕ ⇕ ⇕
	100% VALUE (2621) p. 54	⇕ ⇕ ⇕	⇕ ⇕ ⇕
			100% VALUE (2621) p. 54
			⇕ ⇕ ⇕
	FORMAT (2622) p. 55	⇕ ⇕ ⇕	⇕ ⇕ ⇕
			FORMAT (2622) p. 55
			⇕ ⇕ ⇕
	DISPLAY MODE (2623) p. 55	⇕ ⇕ ⇕	⇕ ⇕ ⇕
			DISPLAY MODE (2623) p. 55
			⇕ ⇕ ⇕


5.1 Group CONTROL

5.1.1 Function group BASIC CONFIGURATION

USER INTERFACE C	⇒	CONTROL CAA	⇒	BASIC CONFIGURATION 200
Function description USER INTERFACE → CONTROL → BASIC CONFIGURATION				
LANGUAGE (2000)	Use this function to select the language for all texts, parameters and messages shown on the local display.  Note! The displayed options depend on the available language group shown in the LANGUAGE GROUP (8226) function. Options: Language group WEST EU / USA: ENGLISH DEUTSCH FRANCAIS ESPANOL ITALIANO NEDERLANDS PORTUGUESE Language group EAST EU / SCAND: ENGLISH NORSK SVENSKA SUOMI POLISH RUSSIAN CZECH Language group ASIA: ENGLISH BAHASA INDONESIA JAPANESE (syllabary) Language group CHINA: ENGLISH CHINESE Factory setting: Country-dependent (page 190)  Note! ■ If you press the / keys at startup, the language defaults to “ENGLISH”. ■ You can change the language group via the configuration software FieldCare. Please do not hesitate to contact your E+H sales office if you have any questions.			
DISPLAY DAMPING (2002)	Use this function to enter a time constant defining how the display reacts to severely fluctuating flow variables, either very quickly (enter a low time constant) or with damping (enter a high time constant). User input: 0...100 seconds Factory setting: 1 s  Note! Setting the time constant to zero seconds switches off damping.			


Function description	
USER INTERFACE → CONTROL → BASIC CONFIGURATION	
CONTRAST LCD (2003)	Use this function to optimize display contrast to suit local operating conditions. User input: 10...100% Factory setting: 50%
BACKLIGHT (2004)	Use this function to optimize the backlight to suit local operating conditions. User input: 0...100%  Note! Entering the value “0” means that the backlight is “switched off”. The display then no longer emits any light, i.e. the display texts can no longer be read in the dark. Factory setting: 50%

5.1.2 Function group UNLOCKING/ LOCKING



Function description USER INTERFACE → CONTROL → UNLOCKING/ LOCKING	
ACCESS CODE (2020)	All data of the measuring system are protected against inadvertent change. Programming is disabled and the settings cannot be changed until a code is entered in this function. If you press the / keys in any function, the measuring system automatically goes to this function and the prompt to enter the code appears on the display (when programming is disabled). You can enable programming by entering your personal code (Factory setting = 83, see function DEFINE PRIVATE CODE (2021)). User input: max. 4-digit number: 0 ...9999  Note! ■ Programming is disabled if you do not press a key within 60 seconds following automatic return to the HOME position. ■ You can also disable programming in this function by entering any number (other than the defined private code). ■ The Endress+Hauser service organization can be of assistance if you mislay your personal code.
DEFINE PRIVATE CODE (2021)	Use this function to specify a personal code for enabling programming in the function ACCESS CODE. User input: 0...9999 (max. 4-digit number) Factory setting: 83  Note! ■ Programming is always enabled with the code "0". ■ Programming has to be enabled before this code can be changed. When programming is disabled this function is not available, thus preventing others from accessing your personal code.
STATUS ACCESS (2022)	Use this function to check the access status for the function matrix. Display: ACCESS CUSTOMER (parameterization possible) LOCKED (parameterization disabled)
ACCESS CODE COUNTER (2023)	Displays how often the customer code, service code or the digit "0" (code-free) has been entered to gain access to the function matrix. Display: max. 7-digit number: 0...9999999 Factory setting: 0


5.1.3 Function group OPERATION



Function description	
USER INTERFACE → CONTROL → OPERATION	
TEST DISPLAY (2040)	Use this function to test the operability of the local display and its pixels. Options: OFF ON Factory setting: OFF Test sequence: 1. Start the test by selecting ON. 2. All pixels of the main line, additional line and information line are darkened for minimum 0.75 second. 3. Main line, additional line and information line show an “8” in each field for minimum 0.75 seconds. 4. Main line, additional line and information line show a “0” in each field for minimum 0.75 seconds. 5. Main line, additional line and information line show nothing (blank display) for minimum 0.75 second. When the test is completed, the local display returns to its initial state and the setting changes to OFF.

5.2 Group MAIN LINE


5.2.1 Function group CONFIGURATION



Function description	
USER INTERFACE → MAIN LINE → CONFIGURATION	
1 2 3 Esc A0001253 1 = main line, 2 = additional line, 3 = information line	
ASSIGN (2200)	In this function, a value to be displayed is assigned to the main line (top line in the local display). This value is displayed during normal operation. Options (standard): OFF MASS FLOW MASS FLOW IN % VOLUME FLOW VOLUME FLOW IN % CORRECTED VOLUME FLOW CORRECTED VOLUME FLOW IN % DENSITY REFERENCE DENSITY TEMPERATURE ACTUAL CURRENT (1...3) ACTUAL FREQUENCY (1...2) TOTALIZER (1...3) ACTUAL CURRENT INPUT Factory setting: MASS FLOW Advanced options with optional software package BATCHING: BATCH NAME ("BATCH # 1" or "BEER 330", etc.) BATCH QUANTITY (overall quantity to be batched) BATCH COUNTER (batching processes carried out) BATCH SUM (effective total batching quantity)  Note! The options given in the BATCHING software package always refer to the batching selected ("BATCH # 1", "BATCH # 2", etc.) in the BATCH SELECTOR function (page 147). Example: If BATCH # 1 was selected in the BATCH SELECTOR function (7200), then only the values from BATCH # 1 (batch name, batch quantity etc.) can be displayed. (continued on next page)

Function description USER INTERFACE → MAIN LINE → CONFIGURATION	
ASSIGN (continued)	Advanced options with optional software package CONCENTRATION: TARGET MASS FLOW % TARGET MASS FLOW TARGET VOLUME FLOW % TARGET VOLUME FLOW CORRECTED TARGET VOLUME FLOW CARRIER MASS FLOW % CARRIER MASS FLOW CARRIER VOLUME FLOW % CARRIER VOLUME FLOW CORRECTED CARRIER VOLUME FLOW % BLACK LIQUOR °BAUME °API °PLATO °BALLING °BRIX OTHERS (_ _ _ flexible concentration) Advanced options with optional software package ADVANCED DIAGNOSIS: MASS FLOW DEVIATION DENSITY DEVIATION REFERENCE DENSITY DEVIATION TEMPERATURE DEVIATION TUBE DAMPING DEVIATION ELECTRODYNAMIC SENSOR DEVIATION OPERATING FREQUENCY FLUCTUATION DEVIATION TUBE DAMPING FLUCTUATION DEVIATION
100% VALUE (2201)	 Note! This function is not available unless one of the following was selected in the ASSIGN function (2200): ■ MASS FLOW IN % ■ VOLUME FLOW IN % ■ CORRECTED VOLUME FLOW IN % Use this function to define the flow value to be shown on the display as the 100% value. User input: 5-digit floating-point number Factory setting: 10 kg/s, 10 l/s or 10 NI/s
FORMAT (2202)	Use this function to define the maximum number of places after the decimal point displayed for the reading in the main line. Options: XXXXX. - XXXX.X - XXX.XX - XX.XXX -X.XXXX Factory setting: X.XXXX  Note! ■ Note that this setting only affects the reading as it appears on the display, it has no influence on the accuracy of the system's calculations. ■ The places after the decimal point as computed by the measuring device cannot always be displayed, depending on this setting and the engineering unit. In such instances an arrow appears on the display between the measuring value and the engineering unit (e.g. 1.2 → kg/h), indicating that the measuring system is computing with more decimal places than can be shown on the display.

5.2.2 Function group MULTIPLEX




Function description	
USER INTERFACE → MAIN LINE → MULTIPLEX	
ASSIGN (2220)	Use this function to define the second reading to be displayed in the main line alternately (every 10 seconds) with the value defined in the ASSIGN function (2200). Options (standard): OFF MASS FLOW MASS FLOW IN % VOLUME FLOW VOLUME FLOW IN % CORRECTED VOLUME FLOW CORRECTED VOLUME FLOW IN % DENSITY REFERENCE DENSITY TEMPERATURE ACTUAL CURRENT (1...3) ACTUAL FREQUENCY (1...2) TOTALIZER (1...3) ACTUAL CURRENT INPUT Factory setting: OFF Advanced options with optional software package BATCHING: BATCH NAME ("BATCH # 1" or "BEER 330", etc.) BATCH QUANTITY (overall quantity to be batched) BATCH COUNTER (batching processes carried out) BATCH SUM (effective total batching quantity) Note! The options given in the BATCHING software package always refer to the batching selected ("BATCH # 1", "BATCH # 2", etc.) in the BATCH SELECTOR function (page 147). Example: If BATCH # 1 was selected in the BATCH SELECTOR function (7200), then only the values from BATCH # 1 (batch name, batch quantity etc.) can be displayed. Advanced options with optional software package CONCENTRATION: TARGET MASS FLOW % TARGET MASS FLOW TARGET VOLUME FLOW % TARGET VOLUME FLOW CORRECTED TARGET VOLUME FLOW CARRIER MASS FLOW % CARRIER MASS FLOW CARRIER VOLUME FLOW % CARRIER VOLUME FLOW CORRECTED CARRIER VOLUME FLOW % BLACK LIQUOR °BAUME °API °PLATO °BALLING °BRIX OTHERS (_ _ _ flexible concentration) (continued on next page)

Function description USER INTERFACE → MAIN LINE → MULTIPLEX	
ASSIGN (continued)	Advanced options with optional software package ADVANCED DIAGNOSIS: MASS FLOW DEVIATION DENSITY DEVIATION REFERENCE DENSITY DEVIATION TEMPERATURE DEVIATION TUBE DAMPING DEVIATION ELECTRODYNAMIC SENSOR DEVIATION OPERATING FREQUENCY FLUCTUATION DEVIATION TUBE DAMPING FLUCTUATION DEVIATION
100% VALUE (2221)	 Note! This function is not available unless one of the following was selected in the ASSIGN function (2220): ■ MASS FLOW IN % ■ VOLUME FLOW IN % ■ CORRECTED VOLUME FLOW IN % Use this function to define the flow value to be shown on the display as the 100% value. User input: 5-digit floating-point number Factory setting: 10 kg/s, 10 l/s or 10 Nl/s
FORMAT (2222)	Use this function to define the maximum number of places after the decimal point for the second value displayed in the main line. Options: XXXXX. - XXXX.X - XXX.XX - XX.XXX -X.XXXX Factory setting: X.XXXX  Note! ■ Note that this setting only affects the reading as it appears on the display, it has no influence on the accuracy of the system's calculations. ■ The places after the decimal point as computed by the measuring device cannot always be displayed, depending on this setting and the engineering unit. In such instances an arrow appears on the display between the measuring value and the engineering unit (e.g. 1.2 → kg/h), indicating that the measuring system is computing with more decimal places than can be shown on the display.

5.3 Group ADDITIONAL LINE

5.3.1 Function group CONFIGURATION




Function description	
USER INTERFACE → ADDITIONAL LINE → CONFIGURATION	
1 2 3 Esc A0001253 1 = main line, 2 = additional line, 3 = information line	
ASSIGN (2400)	In this function, a value to be displayed is assigned to the additional line (middle line in the local display). This value is displayed during normal operation. Options (standard): OFF MASS FLOW MASS FLOW IN % VOLUME FLOW VOLUME FLOW IN % CORRECTED VOLUME FLOW CORRECTED VOLUME FLOW IN % DENSITY REFERENCE DENSITY TEMPERATURE MASS FLOW BARGRAPH IN % VOLUME FLOW BARGRAPH IN % CORRECTED VOLUME FLOW BARGRAPH IN % ACTUAL CURRENT (1...3) ACTUAL FREQUENCY (1...2) TOTALIZER (1...3) TAG NAME ACTUAL CURRENT INPUT Factory setting: TOTALIZER 1 Advanced options with optional software package BATCHING: BATCH NAME ("BATCH # 1" or "BEER 330", etc.) BATCH QUANTITY (overall quantity to be batched) BATCH COUNTER (batching processes carried out) BATCH SUM (effective total batching quantity) BATCH UPWARDS (batching progress upwards) BATCH DOWNWARDS (batching progress downwards) (continued on next page)

Function description USER INTERFACE → ADDITIONAL LINE → CONFIGURATION	
ASSIGN (continued)	 Note! The options given in the BATCHING software package always refer to the batching selected ("BATCH # 1", "BATCH # 2", etc.) in the BATCH SELECTOR function (page 147). Example: If BATCH # 1 was selected in the BATCH SELECTOR function (7200), then only the values from BATCH # 1 (batch name, batch quantity etc.) can be displayed. Advanced options with optional software package CONCENTRATION: TARGET MASS FLOW % TARGET MASS FLOW TARGET VOLUME FLOW % TARGET VOLUME FLOW CORRECTED TARGET VOLUME FLOW CARRIER MASS FLOW % CARRIER MASS FLOW CARRIER VOLUME FLOW % CARRIER VOLUME FLOW CORRECTED CARRIER VOLUME FLOW % BLACK LIQUOR ° BAUME ° API ° PLATO ° BALLING ° BRIX OTHERS (_ _ _ flexible concentration) Advanced options with optional software package ADVANCED DIAGNOSIS: MASS FLOW DEVIATION DENSITY DEVIATION REFERENCE DENSITY DEVIATION TEMPERATURE DEVIATION TUBE DAMPING DEVIATION ELECTRODYNAMIC SENSOR DEVIATION OPERATING FREQUENCY FLUCTUATION DEVIATION TUBE DAMPING FLUCTUATION DEVIATION
100% VALUE (2401)	 Note! This function is not available unless one of the following was selected in the ASSIGN function (2400): ■ MASS FLOW IN % ■ VOLUME FLOW IN % ■ CORRECTED VOLUME FLOW IN % ■ MASS FLOW BARGRAPH IN % ■ VOLUME FLOW BARGRAPH IN % ■ CORRECTED VOLUME FLOW BARGRAPH IN % Use this function to define the flow value to be shown on the display as the 100% value. User input: 5-digit floating-point number Factory setting: 10 kg/s, 10 l/s or 10 nl/s

Function description	
USER INTERFACE → ADDITIONAL LINE → CONFIGURATION	
FORMAT (2402)	 Note! This function is not available unless a number was selected in the ASSIGN function (2400). Use this function to define the maximum number of places after the decimal point displayed for the reading in the additional line. Options: XXXXX. - XXXX.X - XXX.XX - XX.XXX -X.XXXX Factory setting: X.XXXX  Note! ■ Note that this setting only affects the reading as it appears on the display, it has no influence on the accuracy of the system's calculations. ■ The places after the decimal point as computed by the measuring device cannot always be displayed, depending on this setting and the engineering unit. In such instances an arrow appears on the display between the measuring value and the engineering unit (e.g. 1.2 → kg/h), indicating that the measuring system is computing with more decimal places than can be shown on the display.
DISPLAY MODE (2403)	 Note! This function is not available unless one of the following was selected in the ASSIGN function (2400): ■ MASS FLOW BARGRAPH IN % ■ VOLUME FLOW BARGRAPH IN % ■ CORRECTED VOLUME FLOW BARGRAPH IN % Use this function to define the format of the bar graph. Options: STANDARD Simple bar graph with 25 / 50 / 75% gradations and integrated sign. +25 +50 +75 % A0001258 SYMMETRY Symmetrical bar graph for positive and negative directions of flow, with -50 / 0 / +50% gradations and integrated sign.. -50 0 +50 % A0001259 Factory setting: STANDARD

5.3.2 Function group MULTIPLEX




Function description	
USER INTERFACE → ADDITIONAL LINE → MULTIPLEX	
ASSIGN (2420)	Use this function to define the second reading to be displayed in the additional line alternately (every 10 seconds) with the value defined in the function ASSIGN (2400). Options (standard): OFF MASS FLOW MASS FLOW IN % VOLUME FLOW VOLUME FLOW IN % CORRECTED VOLUME FLOW CORRECTED VOLUME FLOW IN % DENSITY REFERENCE DENSITY TEMPERATURE MASS FLOW BARGRAPH IN % VOLUME FLOW BARGRAPH IN % CORRECTED VOLUME FLOW BARGRAPH IN % ACTUAL CURRENT (1...3) ACTUAL FREQUENCY (1...2) TOTALIZER (1...3) TAG NAME ACTUAL CURRENT INPUT Factory setting: OFF Advanced options with optional software package BATCHING: BATCH NAME (“BATCH # 1” or “BEER 330”, etc.) BATCH QUANTITY (overall quantity to be batched) BATCH COUNTER (batching processes carried out) BATCH SUM (effective total batching quantity) BATCH UPWARDS (batching progress upwards) BATCH DOWNWARDS (batching progress downwards) Note! The options given in the BATCHING software package always refer to the batching selected (“BATCH # 1”, “BATCH # 2”, etc.) in the BATCH SELECTOR function (page 147). Example: If BATCH # 1 was selected in the BATCH SELECTOR function (7200), then only the values from BATCH # 1 (batch name, batch quantity etc.) can be displayed. (continued on next page)

Function description USER INTERFACE → ADDITIONAL LINE → MULTIPLEX	
ASSIGN (continued)	Advanced options with optional software package CONCENTRATION: TARGET MASS FLOW % TARGET MASS FLOW TARGET VOLUME FLOW % TARGET VOLUME FLOW CORRECTED TARGET VOLUME FLOW CARRIER MASS FLOW % CARRIER MASS FLOW CARRIER VOLUME FLOW % CARRIER VOLUME FLOW CORRECTED CARRIER VOLUME FLOW % BLACK LIQUOR °BAUME °API °PLATO °BALLING °BRIX OTHERS (_ _ _ _ flexible concentration) Advanced options with optional software package ADVANCED DIAGNOSIS: MASS FLOW DEVIATION DENSITY DEVIATION REFERENCE DENSITY DEVIATION TEMPERATURE DEVIATION TUBE DAMPING DEVIATION ELECTRODYNAMIC SENSOR DEVIATION OPERATING FREQUENCY FLUCTUATION DEVIATION TUBE DAMPING FLUCTUATION DEVIATION  Note! Multiplex mode is suspended as soon as a fault / notice message is generated. The message in question appears on the display. ■ Fault message (identified by a lightning icon): – If “ON” was selected in the ACKNOWLEDGE FAULTS (8004) function, multiplex mode is continued as soon as the fault has been acknowledged and is no longer active. – If “OFF” was selected in the ACKNOWLEDGE FAULTS (8004) function, multiplex mode is continued as soon as the fault is no longer active. ■ Notice message (identified by an exclamation mark): – Multiplex mode is continued as soon as the notice message is no longer active.
100% VALUE (2421)	 Note! This function is not available unless one of the following was selected in the ASSIGN function (2420): ■ MASS FLOW IN % ■ VOLUME FLOW IN % ■ CORRECTED VOLUME FLOW IN % ■ MASS FLOW BARGRAPH IN % ■ VOLUME FLOW BARGRAPH IN % ■ CORRECTED VOLUME FLOW BARGRAPH IN % Use this function to define the flow value to be shown on the display as the 100% value. User input: 5-digit floating-point number Factory setting: 10 kg/s, 10 l/s or 10 NI/s

Function description	
USER INTERFACE → ADDITIONAL LINE → MULTIPLEX	
FORMAT (2422)	Note! This function is not available unless a number was selected in the ASSIGN function (2420). Use this function to define the maximum number of places after the decimal point for the second value displayed in the additional line. Options: XXXXX. - XXXX.X - XXX.XX - XX.XXX -X.XXXX Factory setting: X.XXXX Note! ■ Note that this setting only affects the reading as it appears on the display, it has no influence on the accuracy of the system's calculations. ■ The places after the decimal point as computed by the measuring device cannot always be displayed, depending on this setting and the engineering unit. In such instances an arrow appears on the display between the measuring value and the engineering unit (e.g. 1.2 → kg/h), indicating that the measuring system is computing with more decimal places than can be shown on the display.
DISPLAY MODE (2423)	Note! This function is not available unless one of the following was selected in the ASSIGN function (2420): ■ MASS FLOW BARGRAPH IN % ■ VOLUME FLOW BARGRAPH IN % ■ CORRECTED VOLUME FLOW BARGRAPH IN % Use this function to define the format of the bar graph. Options: STANDARD Simple bar graph with 25 / 50 / 75% gradations and integrated sign. +25 +50 +75 % A0001258 SYMMETRY Symmetrical bar graph for positive and negative directions of flow, with -50 / 0 / +50% gradations and integrated sign.. -50 0 +50 % A0001259 Factory setting: STANDARD

5.4 Group INFORMATION LINE

5.4.1 Function group CONFIGURATION



Function description	
USER INTERFACE → INFORMATION LINE → CONFIGURATION	
1 2 3 Esc	
A0001253	
1 = main line, 2 = additional line, 3 = information line	
ASSIGN (2600)	In this function, a value to be displayed is assigned to the information line (bottom line in the local display). This value is displayed during normal operation. Options: OFF MASS FLOW MASS FLOW IN % VOLUME FLOW VOLUME FLOW IN % CORRECTED VOLUME FLOW CORRECTED VOLUME FLOW IN % DENSITY REFERENCE DENSITY TEMPERATURE MASS FLOW BARGRAPH IN % VOLUME FLOW BARGRAPH IN % CORRECTED VOLUME FLOW BARGRAPH IN % ACTUAL CURRENT (1...3) ACTUAL FREQUENCY (1...2) TOTALIZER (1...3) TAG NAME OPERATING/SYSTEM CONDITIONS FLOW DIRECTION READING ACTUAL CURRENT INPUT Factory setting: OPERATING/SYSTEM CONDITIONS (continued on next page)

Esc

-


+

E

Function description USER INTERFACE → INFORMATION LINE → CONFIGURATION	
ASSIGN (continued)	Advanced options with optional software package BATCHING: BATCHING KEYS (softkeys on the local display)  Note! ■ If you select the BATCHING OPERATING KEYS, the multiplex display functionality (function ASSIGN (2620), etc.) is not available in the information line. ■ For information on the functional concept of the batching menu, See Operating Instructions <i>Proline Promass 83</i>, BA 059D/06/en/, chapter Operation. Advanced options with optional software package CONCENTRATION: TARGET MASS FLOW % TARGET MASS FLOW TARGET VOLUME FLOW % TARGET VOLUME FLOW CORRECTED TARGET VOLUME FLOW CARRIER MASS FLOW % CARRIER MASS FLOW CARRIER VOLUME FLOW % CARRIER VOLUME FLOW CORRECTED CARRIER VOLUME FLOW % BLACK LIQUOR °BAUME °API °PLATO °BALLING °BRIX OTHERS (_ _ _ flexible concentration) Advanced options with optional software package ADVANCED DIAGNOSIS: MASS FLOW DEVIATION DENSITY DEVIATION REFERENCE DENSITY DEVIATION TEMPERATURE DEVIATION TUBE DAMPING DEVIATION ELECTRODYNAMIC SENSOR DEVIATION OPERATING FREQUENCY FLUCTUATION DEVIATION TUBE DAMPING FLUCTUATION DEVIATION
100% VALUE (2601)	 Note! This function is not available unless one of the following was selected in the ASSIGN function (2600): ■ MASS FLOW IN % ■ VOLUME FLOW IN % ■ CORRECTED VOLUME FLOW IN % ■ MASS FLOW BARGRAPH IN % ■ VOLUME FLOW BARGRAPH IN % ■ CORRECTED VOLUME FLOW BARGRAPH IN % Use this function to define the flow value to be shown on the display as the 100% value. User input: 5-digit floating-point number Factory setting: 10 kg/s, 10 l/s or 10 nl/s

Function description	
USER INTERFACE → INFORMATION LINE → CONFIGURATION	
FORMAT (2602)	 Note! This function is not available unless a number was selected in the ASSIGN function (2600). Use this function to define the maximum number of places after the decimal point displayed for the reading in the information line. Options: XXXXX. - XXXX.X - XXX.XX - XX.XXX -X.XXXX Factory setting: X.XXXX  Note! ■ Note that this setting only affects the reading as it appears on the display, it has no influence on the accuracy of the system's calculations. ■ The places after the decimal point as computed by the measuring device cannot always be displayed, depending on this setting and the engineering unit. In such instances an arrow appears on the display between the measuring value and the engineering unit (e.g. 1.2 → kg/h), indicating that the measuring system is computing with more decimal places than can be shown on the display.
DISPLAY MODE (2603)	 Note! This function is not available unless one of the following was selected in the ASSIGN function (2600): ■ MASS FLOW BARGRAPH IN % ■ VOLUME FLOW BARGRAPH IN % ■ CORRECTED VOLUME FLOW BARGRAPH IN % Use this function to define the format of the bar graph. Options: STANDARD Simple bar graph with 25 / 50 / 75% gradations and integrated sign. +25 +50 +75 % A0001258 SYMMETRY Symmetrical bar graph for positive and negative directions of flow, with -50 / 0 / +50% gradations and integrated sign.. -50 0 +50 % A0001259 Factory setting: STANDARD

5.4.2 Function group MULTIPLEX



Function description	
USER INTERFACE → INFORMATION LINE → MULTIPLEX	
 Note! If you select the BATCHING OPERATING KEYS in the function ASSIGN (2600), the multiplex display functionality is not available in the information line.	
ASSIGN (2620)	Use this function to define the second reading to be displayed in the information line alternately (every 10 seconds) with the value defined in the function ASSIGN (2600). Options: OFF MASS FLOW MASS FLOW IN % VOLUME FLOW VOLUME FLOW IN % CORRECTED VOLUME FLOW CORRECTED VOLUME FLOW IN % DENSITY REFERENCE DENSITY TEMPERATURE MASS FLOW BARGRAPH IN % VOLUME FLOW BARGRAPH IN % CORRECTED VOLUME FLOW BARGRAPH IN % ACTUAL CURRENT (1...3) ACTUAL FREQUENCY (1...2) TOTALIZER (1...3) TAG NAME OPERATING/SYSTEM CONDITIONS DISPLAY FLOW DIRECTION ACTUAL CURRENT INPUT Factory setting: OFF (continued on next page)

Function description USER INTERFACE → INFORMATION LINE → MULTIPLEX	
ASSIGN (continued)	Advanced options with optional software package CONCENTRATION: TARGET MASS FLOW % TARGET MASS FLOW TARGET VOLUME FLOW % TARGET VOLUME FLOW CORRECTED TARGET VOLUME FLOW CARRIER MASS FLOW % CARRIER MASS FLOW CARRIER VOLUME FLOW % CARRIER VOLUME FLOW CORRECTED CARRIER VOLUME FLOW % BLACK LIQUOR °BAUME °API °PLATO °BALLING °BRIX OTHERS (_ _ _ _ flexible concentration) Advanced options with optional software package ADVANCED DIAGNOSIS: MASS FLOW DEVIATION DENSITY DEVIATION REFERENCE DENSITY DEVIATION TEMPERATURE DEVIATION TUBE DAMPING DEVIATION ELECTRODYNAMIC SENSOR DEVIATION OPERATING FREQUENCY FLUCTUATION DEVIATION TUBE DAMPING FLUCTUATION DEVIATION  Note! Multiplex mode is suspended as soon as a fault / notice message is generated. The message in question appears on the display. ■ Fault message (identified by a lightning icon): – If “ON” was selected in the ACKNOWLEDGE FAULTS (8004) function, multiplex mode is continued as soon as the fault has been acknowledged and is no longer active. – If “OFF” was selected in the ACKNOWLEDGE FAULTS (8004) function, multiplex mode is continued as soon as the fault is no longer active. ■ Notice message (identified by an exclamation mark): – Multiplex mode is continued as soon as the notice message is no longer active.
100% VALUE (2621)	 Note! This function is not available unless one of the following was selected in the ASSIGN function (2620): ■ MASS FLOW IN % ■ VOLUME FLOW IN % ■ CORRECTED VOLUME FLOW IN % ■ MASS FLOW BARGRAPH IN % ■ VOLUME FLOW BARGRAPH IN % ■ CORRECTED VOLUME FLOW BARGRAPH IN % Use this function to define the flow value to be shown on the display as the 100% value. User input: 5-digit floating-point number Factory setting: 10 kg/s, 10 l/s or 10 NI/s


Function description	
USER INTERFACE → INFORMATION LINE → MULTIPLEX	
FORMAT (2622)	Note! This function is not available unless a number was selected in the ASSIGN function (2620). Use this function to define the maximum number of places after the decimal point for the second value displayed in the information line. Options: XXXXX. - XXXX.X - XXX.XX - XX.XXX -X.XXXX Factory setting: X.XXXX Note! ■ Note that this setting only affects the reading as it appears on the display, it has no influence on the accuracy of the system's calculations. ■ The places after the decimal point as computed by the measuring device cannot always be displayed, depending on this setting and the engineering unit. In such instances an arrow appears on the display between the measuring value and the engineering unit (e.g. 1.2 → kg/h), indicating that the measuring system is computing with more decimal places than can be shown on the display.

6 Block TOTALIZERS

Block	Groups	Function groups	Functions						
TOTALIZERS (D) p. 888	TOTALIZER 1 (DAA) p. 57	⇐	CONFIGURATION (300) p. 57	⇐	ASSIGN (3000) p. 57	⇐	UNIT TOTALIZER (3001) p. 58	TOTALIZER MODE (3002) p. 58	RESET TOTALIZER (3003) p. 58
		⇐		⇐	⇐	⇐	⇐	⇐	
	TOTALIZER 2 (DAB) p. 57	⇐	CONFIGURATION (300) p. 57	⇐	ASSIGN (3000) p. 57	⇐	UNIT TOTALIZER (3001) p. 58	TOTALIZER MODE (3002) p. 58	RESET TOTALIZER (3003) p. 58
		⇐		⇐	⇐	⇐	⇐	⇐	
TOTALIZER 3 (DAC) p. 57	TOTALIZER 3 (DAC) p. 57	⇐	CONFIGURATION (300) p. 57	⇐	ASSIGN (3000) p. 57	⇐	UNIT TOTALIZER (3001) p. 58	TOTALIZER MODE (3002) p. 58	RESET TOTALIZER (3003) p. 58
		⇐		⇐	⇐	⇐	⇐	⇐	
	TOTALIZER 3 (DAC) p. 57	⇐	CONFIGURATION (300) p. 57	⇐	ASSIGN (3000) p. 57	⇐	UNIT TOTALIZER (3001) p. 58	TOTALIZER MODE (3002) p. 58	RESET TOTALIZER (3003) p. 58
		⇐		⇐	⇐	⇐	⇐	⇐	
HANDLING TOTALIZER (DIA) p. 60	HANDLING TOTALIZER (DIA) p. 60	⇐	HANDLING TOTALIZER (DIA) p. 60	⇐	RESET ALL TOTAL (3800) p. 60	⇐	FAILSAFE ALL TOT.		
		⇐		⇐	⇐	⇐	⇐	⇐	

6.1 Group TOTALIZER (1...3)


6.1.1 Function group CONFIGURATION



Function description	
TOTALIZERS → TOTALIZER (1...3) → CONFIGURATION	
The function descriptions below apply to totalizers 1...3; the totalizers are independently configurable.	
ASSIGN (3000)	Use this function to assign a measured variable to the totalizer in question. Options (standard): OFF MASS FLOW VOLUME FLOW CORRECTED VOLUME FLOW Advanced options with optional software package CONCENTRATION: TARGET MASS TARGET VOLUME TARGET CORRECTED VOLUME CARRIER MASS CARRIER VOLUME CARRIER CORRECTED VOLUME Factory setting: MASS FLOW  Note! ■ The totalizer is reset to “0” as soon as the selection is changed. ■ If you select OFF in the function group CONFIGURATION of the totalizer in question, only the ASSIGN (3000) function remains visible.


Function description TOTALIZERS → TOTALIZER (1...3) → CONFIGURATION	
UNIT TOTALIZER (3001)	Use this function to define the unit for the totalizer's measured variable, as selected beforehand. Options (for the MASS FLOW assignment): Metric → g; kg; t US → oz; lb; ton Arbitrary unit → _ _ _ _ Factory setting: kg Options (for the VOLUME FLOW assignment): Metric → cm³; dm³; m³; ml; l; hl; Ml Mega US → cc; af; ft³; oz f; gal; Kgal; Mgal; bbl (normal fluids); bbl (beer); bbl (petrochemicals); bbl (filling tanks) Imperial → gal; Mgal; bbl (beer); bbl (petrochemicals) Arbitrary unit → _ _ _ _ Factory setting: m³ Options (for the CORRECTED VOLUME FLOW assignment): Metric → Nl; Nm³ US → Sm³; Scf Factory setting: Nm³
TOTALIZER MODE (3002)	Use this function to define how the flow components are to be totalized. Options: BALANCE Positive and negative flow components. The positive and negative flow components are balanced. In other words, net flow in the flow direction is registered. FORWARD (only positive flow components) REVERSE (only negative flow components) Factory setting: Totalizer 1 = BALANCE Totalizer 2 = FORWARD Totalizer 3 = REVERSE
RESET TOTALIZER (3003)	Use this function to reset the sum and the overflow of the totalizer to zero. Options: NO YES Factory setting: NO  Note! If the device is equipped with a status input, with the appropriate configuration a reset for each individual totalizer can also be triggered by a pulse (see the function ASSIGN STATUS INPUT (5000) on page 112).

6.1.2 Function group OPERATION



Function description	
TOTALIZERS → TOTALIZER (1...3) → OPERATION	
The function descriptions below apply to totalizers 1...3; the totalizers are independently configurable.	
SUM (3040)	Use this function to view the total for the totalizer's measured variable aggregated since measuring commenced. The value can be positive or negative, depending on the setting selected in the function "TOTALIZER MODE" (3002), and the direction of flow. Display: max. 7-digit floating-point number, including sign and unit (e.g. 15467.04 m³; -4925.631 kg)  Note! ■ The effect of the setting in the "TOTALIZER MODE" function (see page 58) is as follows: – If the setting is "BALANCE", the totalizer balances flow in the positive and negative directions. – If the setting is "FORWARD", the totalizer registers only flow in the positive direction. – If the setting is "REVERSE", the totalizer registers only flow in the negative direction. ■ The totalizer's response to faults is defined in the "FAILSAFE ALL TOTALIZERS" function (3801), (see page 60).
OVERFLOW (3041)	Use this function to view the overflow for the totalizer aggregated since measuring commenced. Total flow quantity is represented by a floating-point number consisting of max. 7 digits. You can use this function to view higher numerical values (>9,999,999) as overflows. The effective quantity is thus the total of OVERFLOW plus the value returned by the SUM function. Example: Reading for 2 overflows: $2 \cdot 10^7$ kg (= 20,000,000 kg) The value displayed in the function SUM = 196,845.7 kg Effective total quantity = 20,196,845.7 kg Display: integer with exponent, including sign and unit, e.g. $2 \cdot 10^7$ kg

6.2 Group HANDLING TOTALIZER




Function description	
TOTALIZERS → HANDLING TOTALIZER → Handling totalizer functions	
RESET ALL TOTALIZERS (3800)	Use this function to reset the totals (including all overflows) of the totalizers (1...3) to "zero" (= RESET). Options: NO YES Factory setting: NO  Note! If the device has a status input and if it is appropriately configured, a reset for the totalizer (1...3) can also be triggered by a pulse (see the ASSIGN STATUS INPUT function (5000) on page 112).
FAILSAFE ALL TOTALIZERS (3801)	Use this function to define the common response of all totalizers (1...3) in case of error. Options: STOP The totalizer is paused until the fault is rectified. ACTUAL VALUE The totalizer continues to count based on the current flow measuring value. The fault is ignored . HOLD VALUE The totalizer continues to count the flow that based on the last valid flow value (before the fault occurred). Factory setting: STOP

7 Block OUTPUTS

Block	Groups	Function groups	Functions									
OUTPUTS (E)	CURRENT 1...3 (EAA, B, C) p. 62	⇒	CONFIGURATION (400) p. 62	⇒	ASSIGN CURRENT OUTPUT (4000) p. 62	⇒	CURRENT SPAN (4001) p. 64	VALUE 0...4 mA (4002) p. 65	VALUE 20 mA (4003) p. 67	MEASURING MODE (4004) p. 68	TIME CONSTANT (4005) p. 70	FAILSAFE MODE (4006) p. 71
		⇕	⇕	⇒	ACTUAL CURRENT (4040) p. 72	⇒	SIMULATION CURRENT (4041) p. 72	VALUE SIMUL. CURRENT (4042) p. 72				
		⇕	⇕	⇒	TERMINAL NUMBER (4080) p. 73							
		⇕	⇕	⇒	OPERATION MODE (4200) p. 74	⇒	ASSIGN FREQUENCY (4201) p. 75	START VALUE FREQUENCY (4202) p. 76	END VALUE FREQUENCY (4203) p. 76	VALUE F LOW (4204) p. 77	VALUE F HIGH (4205) p. 77	MEASURING MODE (4206) p. 79
	PULSE/FREQ. 1...2 (ECA, ECB) p. 74	⇒	CONFIGURATION (420) p. 74	⇒	OPERATION MODE (4200) p. 74	⇒	ASSIGN FREQUENCY (4201) p. 75	START VALUE FREQUENCY (4202) p. 76	END VALUE FREQUENCY (4203) p. 76	VALUE F LOW (4204) p. 77	VALUE F HIGH (4205) p. 77	MEASURING MODE (4206) p. 79
		⇕	⇕	⇒	TERMINAL NUMBER (4080) p. 73							
		⇕	⇕	⇒	OPERATION MODE (4200) p. 74	⇒	ASSIGN FREQUENCY (4201) p. 75	START VALUE FREQUENCY (4202) p. 76	END VALUE FREQUENCY (4203) p. 76	VALUE F LOW (4204) p. 77	VALUE F HIGH (4205) p. 77	MEASURING MODE (4206) p. 79
		⇕	⇕	⇒	TERMINAL NUMBER (4080) p. 73							
	RELAY 1...2 (EGA, EGB) p. 112	⇒	CONFIGURATION (470) p. 101	⇒	ASSIGN RELAY (4700) p. 101	⇒	ON VALUE (4701) p. 102	SWITCH-ON DELAY (4702) p. 103	OFF-VALUE (4703) p. 103	SWITCH-OFF DELAY (4704) p. 103	MEASURING MODE (4705) p. 104	TIME CONSTANT (4706) p. 104
		⇕	⇕	⇒	ACTUAL STATUS RELAY (4740) p. 105	⇒	SIMUL. SWITCH POINT (4741) p. 105	VALUE SIMUL. SWITCH PT. (4742) p. 106				
		⇕	⇕	⇒	TERMINAL NUMBER (4780) p. 107							
		⇕	⇕	⇒	TERMINAL NUMBER (4780) p. 107							


7.1 Group CURRENT OUTPUT (1...3)


7.1.1 Function group CONFIGURATION








Function description	
OUTPUTS → CURRENT OUTPUT (1...3) → CONFIGURATION	
ASSIGN CURRENT OUTPUT (4000)	Use this function to assign a measured variable to the current output. Options: OFF MASS FLOW VOLUME FLOW CORRECTED VOLUME FLOW DENSITY REFERENCE DENSITY TEMPERATURE Advanced options with optional software package BATCHING: BATCH UPWARDS (batching progress upwards) BATCH DOWNWARDS (batching progress downwards)  Note! ■ The current range selected (function CURRENT SPAN (4001)) corresponds to a batching rate of 0 – 100%, based on the batching quantity. ■ The batching software automatically sets the values for 0/4 mA and 20 mA (function VALUE 0_4 mA (4002) and VALUE 20 mA (4003)). Example with upward batching: Value 0/4 mA = 0 [unit]; value 20 mA = batching quantity [unit]. Advanced options with optional software package CONCENTRATION: TARGET MASS FLOW % TARGET MASS FLOW TARGET VOLUME FLOW % TARGET VOLUME FLOW CORRECTED TARGET VOLUME FLOW CARRIER MASS FLOW % CARRIER MASS FLOW CARRIER VOLUME FLOW % CARRIER VOLUME FLOW CORRECTED CARRIER VOLUME FLOW % BLACK LIQUOR °BAUME °API °PLATO °BALLING °BRIX OTHERS (_ _ _ _ flexible concentration) (continued on next page)

Function description	
OUTPUTS → CURRENT OUTPUT (1...3) → CONFIGURATION	
ASSIGN CURRENT OUTPUT (continued)	Advanced options with optional software package ADVANCED DIAGNOSIS: MASS FLOW DEVIATION DENSITY DEVIATION REFERENCE DENSITY DEVIATION TEMPERATURE DEVIATION TUBE DAMPING DEVIATION ELECTRODYNAMIC SENSOR DEVIATION OPERATING FREQUENCY FLUCTUATION DEVIATION TUBE DAMPING FLUCTUATION DEVIATION Factory setting: MASS FLOW  Note! If you select OFF, the only function shown in the CONFIGURATION function group is this function, in other words ASSIGN CURRENT OUTPUT (4000).

Function description																																													
OUTPUTS → CURRENT OUTPUT (1...3) → CONFIGURATION																																													
CURRENT SPAN (4001)	Use this function to define the current range. The selection specifies the operational range and the lower and upper signal on alarm. For the current output 1 the option HART can be defined additionally. Options: 0–20 mA 4–20 mA 4–20 mA HART (only current output 1) 4–20 mA NAMUR 4–20 mA HART NAMUR (only current output 1) 4–20 mA US 4–20 mA HART US (only current output 1) 0–20 mA (25 mA) 4–20 mA (25 mA) 4–20 mA (25 mA) HART (only current output 1) Factory setting: 4–20 mA HART NAMUR (current output 1) 4–20 mA NAMUR (current output 2...3)  Note! ■ The option HART is only supported by the current output designated as current output 1 in the device software, (terminals 26 and 27, see function TERMINAL NUMBER (4080) on page 73). ■ When switching the hardware from an active (factory setting) to a passive output signal select a current span of 4–20 mA (See Operating Instructions <i>Proline Promass 83</i>, BA 059D/06/en/). Current span, operational range and signal on alarm level  <table><tr><th>a</th><th>1</th><th>2</th><th>3</th></tr><tr><td>0-20 mA</td><td>0 - 20.5 mA</td><td>0</td><td>22</td></tr><tr><td>4-20 mA</td><td>4 - 20.5 mA</td><td>2</td><td>22</td></tr><tr><td>4-20 mA HART</td><td>4 - 20.5 mA</td><td>2</td><td>22</td></tr><tr><td>4-20 mA NAMUR</td><td>3.8 - 20.5 mA</td><td>3.5</td><td>22.6</td></tr><tr><td>4-20 mA HART NAMUR</td><td>3.8 - 20.5 mA</td><td>3.5</td><td>22.6</td></tr><tr><td>4-20 mA US</td><td>3.9 - 20.8 mA</td><td>3.75</td><td>22.6</td></tr><tr><td>4-20 mA HART US</td><td>3.9 - 20.8 mA</td><td>3.75</td><td>22.6</td></tr><tr><td>0-20 mA (25 mA)</td><td>0 - 24 mA</td><td>0</td><td>25</td></tr><tr><td>4-20 mA (25 mA)</td><td>4 - 24 mA</td><td>2</td><td>25</td></tr><tr><td>4-20 mA (25 mA) HART</td><td>4 - 24 mA</td><td>2</td><td>25</td></tr></table> A0001222 <i>a = Current span</i> <i>1 = Operational range (measuring information)</i> <i>2 = Lower signal on alarm level</i> <i>3 = Upper signal on alarm level</i>  Note! ■ If the measured value exceeds the measuring range (as defined in the functions VALUE 0_4 mA (4002) and VALUE 20 mA (4003)) a notice message is generated (#351...354, current span). ■ In case of a fault the behavior of the current output is according to the selected option in the function FAILSAFE MODE (4006). Change the error category in the function ASSIGN SYSTEM ERROR (8000) to generate a fault message instead of a notice message.	a	1	2	3	0-20 mA	0 - 20.5 mA	0	22	4-20 mA	4 - 20.5 mA	2	22	4-20 mA HART	4 - 20.5 mA	2	22	4-20 mA NAMUR	3.8 - 20.5 mA	3.5	22.6	4-20 mA HART NAMUR	3.8 - 20.5 mA	3.5	22.6	4-20 mA US	3.9 - 20.8 mA	3.75	22.6	4-20 mA HART US	3.9 - 20.8 mA	3.75	22.6	0-20 mA (25 mA)	0 - 24 mA	0	25	4-20 mA (25 mA)	4 - 24 mA	2	25	4-20 mA (25 mA) HART	4 - 24 mA	2	25
a	1	2	3																																										
0-20 mA	0 - 20.5 mA	0	22																																										
4-20 mA	4 - 20.5 mA	2	22																																										
4-20 mA HART	4 - 20.5 mA	2	22																																										
4-20 mA NAMUR	3.8 - 20.5 mA	3.5	22.6																																										
4-20 mA HART NAMUR	3.8 - 20.5 mA	3.5	22.6																																										
4-20 mA US	3.9 - 20.8 mA	3.75	22.6																																										
4-20 mA HART US	3.9 - 20.8 mA	3.75	22.6																																										
0-20 mA (25 mA)	0 - 24 mA	0	25																																										
4-20 mA (25 mA)	4 - 24 mA	2	25																																										
4-20 mA (25 mA) HART	4 - 24 mA	2	25																																										





Function description	
OUTPUTS → CURRENT OUTPUT (1...3) → CONFIGURATION	
VALUE 0_4 mA (4002)	Use this function to assign the 0/4 mA current a value. The value can be higher or lower than the value assigned to 20 mA (function VALUE 20 mA (4003), see page 67). Positive and negative values are permissible, depending on the measured variable in question (e.g. mass flow). Example: 4 mA assigned value = - 250 kg/h 20 mA assigned value = +750 kg/h Calculated current value = 8 mA (at zero flow)  Note! Note that values with different signs cannot be entered for 0/4 mA and 20 mA (function 4003) if SYMMETRY is the setting selected for the MEASURING MODE function (4004). In this case, the message "INPUT RANGE EXCEEDED" appears on the display. Example for STANDARD measuring mode:  ① = Initial value (0 to 20 mA) ② = Lower signal on alarm level: depends on the setting in the function CURRENT SPAN ③ = Initial value (4 to 20 mA): depends on the setting in the function CURRENT SPAN ④ = Full scale value (0/4 to 20 mA): depends on the setting in the function CURRENT SPAN ⑤ = Maximum current value: depends on the setting in the function CURRENT SPAN ⑥ = Failsafe mode (upper signal on alarm level): depends on the setting in the functions CURRENT SPAN (page 64) and FAILSAFE MODE, (page 60) A = Measuring range User input: 5-digit floating-point number, with sign Factory setting: 0 [kg/h] or 0.5 [kg/l] or -50 [°C]  Note! ■ The appropriate unit is taken from the following functions: – UNIT MASS FLOW (0400) – UNIT VOLUME FLOW (0402) – UNIT CORRECTED VOLUME FLOW (0404) – UNIT DENSITY (0420) – UNIT REFERENCE DENSITY (0421) – UNIT TEMPERATURE (0422) (see page 17 till page 21). ■ If the option BATCH UPWARDS or BATCH DOWNWARDS (only possible with the optional software package BATCHING) is selected in the function ASSIGN CURRENT OUTPUT (4000), the value 0/4 mA is automatically specified in this function and cannot be edited.  Caution! The current output responds differently, depending on the parameters set in the various functions. Some examples of parameter settings and their effect on the current output are given in the following section.

A0001223

Function description OUTPUTS → CURRENT OUTPUT (1...3) → CONFIGURATION	
VALUE 0_4 mA (continued)	Parameter setting example A: 1. VALUE 0_4 mA (4002) = not equal to zero flow (e.g. -5 kg/h) VALUE 20 mA (4003) = not equal to zero flow (e.g. 10 kg/h) or 2. VALUE 0_4 mA (4002) = not equal to zero flow (e.g. 100 kg/h) VALUE 20 mA (4003) = not equal to zero flow (e.g. -40 kg/h) and MEASURING MODE (4004) = STANDARD When you enter the values for 0/4 mA and 20 mA, the working range of the measuring device is defined. If the effective flow drops below or exceeds this working range (see Fig. ①), a fault/notice message is generated (#351-354, current range) and the current output responds in accordance with the parameter settings in the function FAILSAFE MODE (4006). 1)  2)  A0001262 Parameter setting example B: 1. VALUE 0_4 mA (4002) = equal to zero flow (e.g. 0 kg/h) VALUE 20 mA (4003) = not equal to zero flow (e.g. 10 kg/h) or 2. VALUE 0_4 mA (4002) = not equal to zero flow (e.g. 100 kg/h) VALUE 20 mA (4003) = equal to zero flow (e.g. 0 kg/h) and MEASURING MODE (4004) = STANDARD When you enter the values for 0/4 mA and 20 mA, the working range of the measuring device is defined. In doing so, one of the two values is configured as zero flow (e.g. 0 kg/h). If the effective flow drops below or exceeds the value configured as the zero flow, no fault/notice message is generated and the current output retains its value. If the effective flow drops below or exceeds the other value, a fault/notice message is generated (#351-354, current range) and the current output responds in accordance with the parameter settings in the function FAILSAFE MODE (4006). 1)  2)  A0001264 Deliberately only one flow direction is output with this setting and flow values in the other flow direction are suppressed. Parameter setting example C: MEASURING MODE (4004) = SYMMETRY The current output signal is independent of the direction of flow (absolute amount of the measured variable). The 0_4 mA value ① and the 20 mA value ② must have the same sign (+ or -). The “20 mA VALUE” ③ (e.g. backflow) corresponds to the mirrored 20 mA VALUE ② (e.g. flow).  A0001249 ASSIGN RELAY (4700) = FLOW DIRECTION With this setting e.g. the flow direction output via a switching contact can be made. Parameter setting example D: MEASURING MODE (4004) = PULSATING FLOW → page 68 ff.


Function description OUTPUTS → CURRENT OUTPUT (1...3) → CONFIGURATION	
VALUE 20 mA (4003)	Use this function to assign the 20 mA current a value. The value can be higher or lower than the value assigned to 0/4 mA (function VALUE 0_4 mA (4002), see page 65). Positive and negative values are permissible, depending on the measured variable in question (e.g. mass flow). Example: 4 mA assigned value = -250 kg/h 20 mA assigned value = +750 kg/h Calculated current value = 8 mA (at zero flow)  Note! Note that values with different signs cannot be entered for 0/4 mA (function 4002) and 20 mA, if SYMMETRY is the setting selected in the function MEASURING MODE (4004). In this case, the message "INPUT RANGE EXCEEDED" appears. User input: 5-digit floating-point number, with sign Factory setting: Depends on nominal diameter [kg/h] or 2 [kg/l] or 200 [°C]  Note! ■ The appropriate unit is taken from the following functions: – UNIT MASS FLOW(0400) – UNIT VOLUME FLOW(0402) – UNIT CORRECTED VOLUME FLOW(0404) – UNIT DENSITY(0420) – UNIT REFERENCE DENSITY(0421) – UNIT TEMPERATURE(0422) (see page 17 till page 21). ■ If the option BATCH UPWARDS or BATCH DOWNWARDS, (only possible with the optional software package BATCHING) is selected in the function ASSIGN CURRENT OUTPUT (4000), the value 20 mA is automatically specified in this function and cannot be edited. ■ The appropriate unit is taken from the function UNIT MASS FLOW (0400) (see page 17). ■ A description of the selection STANDARD in the function MEASURING MODE is given on page 68.  Caution! It is very important to read and comply with the information in the function VALUE 0_4 mA (under "ⓘ Caution"; Examples of parameter settings) on page 65.

Function description OUTPUTS → CURRENT OUTPUT (1...3) → CONFIGURATION	
MEASURING MODE (4004)	Use this function to define the measuring mode for the current output. Options: STANDARD SYMMETRY PULSATING FLOW Factory setting: STANDARD Description of the individual options: ■ STANDARD The current output signal is proportional to the measured variable. The flow components outside the scaled measuring range (defined by the 0_4 mA VALUE ① and the 20 mA VALUE ②) are taken into account as follows for signal output. – If one of the values is defined as equal to the zero flow (e.g. VALUE 0_4 mA = 0 kg/h), no message is given if this value is exceeded or not achieved and the current output retains its value (in example 4 mA). If the other value is exceeded or not achieved, the message “CURRENT OUTPUT AT FULL SCALE VALUE” appears and the current output responds in accordance with the parameter setting in the function FAILSAFE MODE (4006). – If both values defined are not equal to the zero flow (for example VALUE 0_4 mA = –5 kg/h, VALUE 20 mA = 10 kg/h), the message “CURRENT OUTPUT AT FULL SCALE VALUE” appears if the measuring range is exceeded or not achieved and the current output responds in accordance with the parameter settings in the function FAILSAFE MODE (4006). A0001248 ■ SYMMETRY The current output signal is independent of the direction of flow (absolute amount of the measured variable). The 0_4 mA VALUE ① and the 20 mA VALUE ② must have the same sign (+ or –). The “20 mA VALUE” ③ (e.g. backflow) corresponds to the mirrored 20 mA VALUE ② (e.g. flow). A0001249 Note! ■ The direction of flow can be output via the configurable relay or status outputs. ■ SYMMETRY cannot be selected unless the values in the VALUE 0_4 mA (4002) and VALUE 20 mA (4003) functions have the same sign or one of the values is zero. If the values have different signs, SYMMETRY cannot be selected and an “ASSIGNMENT NOT POSSIBLE” message is displayed. (continued on next page)

Function description	
OUTPUTS → CURRENT OUTPUT (1...3) → CONFIGURATION	
Detailed explanations and information (continued)	2. Defined measuring range (①–②): ① and ② have different signs  A0001272 Flow a (—) outside, b (---) within the measuring range.  A0001273 ■ STANDARD a (—): The flow components outside the scaled measuring range cannot be taken into account for signal output. A fault message is generated (# 351...354, current range) and the current output responds in accordance with the parameter settings in the function FAILSAFE MODE (4006). b (....): The current output signal is proportional to the measured variable assigned.  A0001274 ■ SYMMETRY This option is not available under these circumstances, because the 0_4 mA value and the 20 mA value have different signs. ■ PULSATING FLOW Flow components outside the measuring range are buffered, balanced and output after a maximum delay of 60 seconds.  A0001275
TIME CONSTANT (4005)	Use this function to enter a time constant defining how the current output signal reacts to severely fluctuating measured variables, either very quickly (enter a low time constant) or with damping (enter a high time constant). User input: fixed-point number 0.01...100.00 s Factory setting: 1.00 s


Function description	
OUTPUTS → CURRENT OUTPUT (1...3) → CONFIGURATION	
FAILSAFE MODE (4006)	For safety reasons it is advisable to ensure that the current output assumes a predefined state in the event of a fault. The setting you select here affects only the current output. It has no effect on other outputs and the display (e.g. totalizers). Options: MIN. CURRENT The current output adopts the value of the lower signal on alarm level (as defined in the function CURRENT SPAN (4001), see page 64. MAX. CURRENT The current output adopts the value of the upper signal on alarm level (as defined in the function CURRENT SPAN (4001), see page 64. HOLD VALUE (not recommended) Measuring value output is based on the last measuring value saved before the error occurred . ACTUAL VALUE Measured value output is based on the current flow measurement. The fault is ignored . Factory setting: MIN. CURRENT

7.1.2 Function group OPERATION



Function description	
OUTPUTS → CURRENT OUTPUT (1...3) → OPERATION	
ACTUAL CURRENT (4040)	Use this function to view the computed actual value of the output current. Display: 0.00...25.00 mA
SIMULATION CURRENT (4041)	Use this function to activate simulation of the current output. Options: OFF ON Factory setting: OFF Note! ■ The “SIMULATION CURRENT OUTPUT” message indicates that simulation is active. ■ The measuring device continues to measure while simulation is in progress, i.e. the current measuring values are output correctly via the other outputs. Caution! The setting is not saved if the power supply fails.
VALUE SIMULATION CURRENT (4042)	Note! The function is not visible unless the function SIMULATION CURRENT (4041) is active (= ON). Use this function to define a freely selectable value (e.g. 12 mA) to be output at the current output. This value is used to test downstream devices and the measuring device itself. User input: 0.00...25.00 mA Factory setting: 0.00 mA Caution! The setting is not saved if the power supply fails.


7.1.3 Function group INFORMATION



Function description	
OUTPUTS → CURRENT OUTPUT 1 → INFORMATION	
TERMINAL NUMBER (4080)	Use this function to view the numbers of the terminals (in the connection compartment) and the polarity used by the current output.

7.2 Group PULSE/FREQUENCY OUTPUT (1...2)


7.2.1 Function group CONFIGURATION






Function description	
OUTPUTS → PULSE/FREQ. OUTP. (1...2) → CONFIGURATION (GENERAL)	
OPERATION MODE (4200)	Use this function to configure the output as a pulse, frequency or status output. The functions available in this function group vary, depending on which option you select here. Options: PULSE FREQUENCY STATUS Factory setting: PULSE

Function description	
OUTPUTS → PULSE/FREQUENCY OUTPUT (1...2) → CONFIGURATION (FREQUENCY)	
ASSIGN FREQUENCY (4201)	 Note! This function is not available unless the FREQUENCY setting was selected in the OPERATION MODE function (4200). Use this function to assign a measured variable to the frequency output. Options: OFF MASS FLOW VOLUME FLOW CORRECTED VOLUME FLOW DENSITY REFERENCE DENSITY TEMPERATURE Advanced options with optional software package CONCENTRATION: TARGET MASS FLOW % TARGET MASS FLOW TARGET VOLUME FLOW % TARGET VOLUME FLOW CORRECTED TARGET VOLUME FLOW CARRIER MASS FLOW % CARRIER MASS FLOW CARRIER VOLUME FLOW % CARRIER VOLUME FLOW CORRECTED CARRIER VOLUME FLOW % BLACK LIQUOR °BAUME °API °PLATO °BALLING °BRIX OTHERS (_ _ _ flexible concentration) Advanced options with optional software package ADVANCED DIAGNOSIS: MASS FLOW DEVIATION DENSITY DEVIATION REFERENCE DENSITY DEVIATION TEMPERATURE DEVIATION TUBE DAMPING DEVIATION ELECTRODYNAMIC SENSOR DEVIATION OPERATING FREQUENCY FLUCTUATION DEVIATION TUBE DAMPING FLUCTUATION DEVIATION Factory setting: MASS FLOW  Note! If you select OFF, the only function shown in the CONFIGURATION function group is this function, in other words ASSIGN FREQUENCY (4201).



Function description OUTPUTS → PULSE/FREQUENCY OUTPUT (1...2) → CONFIGURATION (FREQUENCY)	
START VALUE FREQUENCY (4202)	 Note! This function is not available unless the FREQUENCY setting was selected in the OPERATION MODE function (4200). Use this function to define an initial frequency for the frequency output. You define the associated measured value of the measuring range in the VALUE F LOW function (4204) described on page 77. User input: 5-digit fixed-point number: 0...10000 Hz Factory setting: 0 Hz Example: ■ VALUE F LOW = 0 kg/h, initial frequency = 0 Hz: i.e. a frequency of 0 Hz is output at a flow of 0 kg/h. ■ VALUE F LOW = 1 kg/h, initial frequency = 10 Hz: i.e. a frequency of 10 Hz is output at a flow of 1 kg/h.
END VALUE FREQUENCY (4203)	 Note! This function is not available unless the FREQUENCY setting was selected in the OPERATION MODE function (4200). Use this function to define a full scale frequency for the frequency output. You define the associated measured value of the measuring range in the VALUE F HIGH function (4205) described on page 77. User input: 5-digit fixed-point number 2...10000 Hz Factory setting: 10000 Hz Example: ■ VALUE F HIGH = 10000 kg/h, full scale frequency = 10000 Hz: i.e. a frequency of 10000 Hz is output at a flow of 10000 kg/h. ■ VALUE F HIGH = 3600 kg/h, full scale frequency = 10000 Hz: i.e. a frequency of 10000 Hz is output at a flow of 3600 kg/h.  Note! In the FREQUENCY operating mode the output signal is symmetrical (on/off ratio = 1:1). At low frequencies the pulse duration is limited to a maximum of 2 seconds, i.e. the on/off ratio is no longer symmetrical.






Function description	
OUTPUTS → PULSE/FREQUENCY OUTPUT (1...2) → CONFIGURATION (FREQUENCY)	
VALUE F LOW (4204)	Note! This function is not available unless the FREQUENCY setting was selected in the OPERATION MODE function (4200). Use this function to assign a variable to the start value frequency (4202). The value can be higher or lower than the value assigned to the VALUE F HIGH. Positive and negative values are permissible, depending on the measured variable in question (e.g. mass flow). You define a measuring range by defining the VALUE F LOW and VALUE F HIGH values. User input: 5-digit floating-point number Factory setting: 0 [kg/h] or 0 [kg/l] or -50 [°C] Note! - For a graphic illustration VALUE F LOW see the VALUE F HIGH function (4205). - Note that values with different signs cannot be entered for VALUE F LOW and VALUE F HIGH, if SYMMETRY is the setting selected for the MEASURING MODE function (4206). In this case, the message "INPUT RANGE EXCEEDED" appears on the display. - The appropriate unit is taken from the UNIT MASS FLOW (0400), UNIT VOLUME FLOW (0402), UNIT CORRECTED VOLUME FLOW (0404), UNIT DENSITY (0420), UNIT REFERENCE DENSITY (0421) or UNIT TEMPERATURE (0422) function (see p. 17 to p. 21).
VALUE F HIGH (4205)	Note! This function is not available unless the FREQUENCY setting was selected in the OPERATION MODE function (4200). Use this function to assign a variable to the end value frequency (4203). The value can be higher or lower than the value assigned to the VALUE F LOW. Positive and negative values are permissible, depending on the measured variable in question (e.g. mass flow). You define a measuring range by defining the VALUE F LOW and VALUE F HIGH values. User input: 5-digit floating-point number Factory setting: Depends on nominal diameter [kg/h] or 2 [kg/l] or 200 [°C] Note! Note that values with different signs cannot be entered for VALUE F LOW and VALUE F HIGH, if SYMMETRY is the setting selected for the MEASURING MODE function (4206). In this case, the message "INPUT RANGE EXCEEDED" appears on the display.  ① = VALUE f min ② = VALUE f max (continued on next page)



Function description OUTPUTS → PULSE/FREQUENCY OUTPUT (1...2) → CONFIGURATION (FREQUENCY)	
VALUE F HIGH (continued)	Parameter setting example 1: 1. VALUE F LOW (4204) = not equal to zero flow (e.g. −5 kg/h) VALUE F HIGH (4205) = not equal to zero flow (e.g. 10 kg/h) or 2. VALUE F LOW (4204) = not equal to zero flow (e.g. 100 kg/h) VALUE F HIGH (4205) = not equal to zero flow (e.g. −40 kg/h) and MEASURING MODE (4004) = STANDARD When you enter the values for VALUE F LOW and VALUE F HIGH the working range of the measuring device is defined. If the effective flow drops below or exceeds this working range (see Fig. ①), a fault/notice message is generated (#355-358, frequency area) and the frequency output responds in accordance with the parameters set in the function FAILSAFE MODE (4209).  A0001276 Parameter setting example 2: 1. VALUE F LOW (4204) = not equal to zero flow (e.g. 0 kg/h) VALUE F HIGH (4205) = not equal to zero flow (e.g. 10 kg/h) or 2. VALUE F LOW (4204) = not equal to zero flow (e.g. 100 kg/h) VALUE F HIGH (4205) = not equal to zero flow (e.g. 0 kg/h) and MEASURING MODE (4004) = STANDARD When you enter the values for VALUE F LOW and VALUE F HIGH the working range of the measuring device is defined. In doing so, one of the two values is configured as zero flow (e.g. 0 kg/h). If the effective flow drops below or exceeds the value configured as the zero flow, no fault/notice message is generated and the frequency output retains its value. If the effective flow drops below or exceeds the other value, a fault/notice message is generated (#355-358, frequency area) and the frequency output responds in accordance with the parameters set in the function FAILSAFE MODE (4209).  A0001277 Deliberately only one flow direction is output with this setting and flow values in the other flow direction are suppressed. Parameter setting example 3: MEASURING MODE (4206) = SYMMETRY The frequency output signal is independent of the direction of flow (absolute amount of the measured variable). The VALUE F LOW ① and VALUE F HIGH ② must have the same sign (+ or −). The “VALUE F HIGH” ③ (e.g. backflow) corresponds to the mirrored VALUE F HIGH ② (e.g. flow).  A0001278 ASSIGN RELAY (4700) = FLOW DIRECTION With this setting e.g. the flow direction output via a switching contact can be made. Parameter setting example 4: MEASURING MODE (4004) = PULSATING FLOW → page 68 ff.

Function description	
OUTPUTS → PULSE/FREQUENCY OUTPUT (1...2) → CONFIGURATION (FREQUENCY)	
MEASURING MODE (4206)	Note! This function is not available unless the FREQUENCY setting was selected in the OPERATION MODE function (4200). Use this function to define the measuring mode for the frequency output. Options: STANDARD SYMMETRY PULSATING FLOW Factory setting: STANDARD Description of the individual options: ■ STANDARD The frequency output signal is proportional to the measured variable. The flow components outside the scaled measuring range (defined by the VALUE F LOW ① and the VALUE F HIGH ②) are not taken into account for signal output. – If one of the values is defined as equal to the zero flow (e.g. VALUE F LOW = 0 kg/h), no message is given if this value is exceeded or not achieved and the frequency output retains its value (0 Hz in the example). If the other value is exceeded or not achieved, the message “FREQUENCY OUTPUT AT FULL SCALE VALUE” appears and the frequency output responds in accordance with the parameter setting in the function FAILSAFE MODE (4209). – If both values defined are not equal to the zero flow (for example VALUE F LOW = –5 kg/h; VALUE F HIGH = 10 kg/h), the message “FREQUENCY OUTPUT AT FULL SCALE VALUE” appears if the measuring range is exceeded or not achieved and the frequency output responds in accordance with the parameter settings in the function FAILSAFE MODE (4209)... Freq. 125 100 0 ① ② Q A0001279 SYMMETRY The frequency output signal is independent of the direction of flow (absolute amount of the measured variable). The VALUE F LOW ① and VALUE F HIGH ② must have the same sign (+ or –). The VALUE F HIGH③ (e.g. backflow) corresponds to the mirrored VALUE F HIGH ② (e.g. flow). Freq. 125 100 0 ③ ① ② Q A0001280 Note! ■ The direction of flow can be output via the configurable relay or status outputs. ■ SYMMETRY cannot be selected unless the values in the VALUE F LOW (4204) and VALUE F HIGH (4205) functions have the same sign or one of the values is zero. If the values have different signs, SYMMETRY cannot be selected and an “ASSIGNMENT NOT POSSIBLE” message is displayed. (continued on next page)

Function description OUTPUTS → PULSE/FREQUENCY OUTPUT (1...2) → CONFIGURATION (FREQUENCY)	
MEASURING MODE (continued)	■ PULSATING FLOW If flow is characterized by severe fluctuations as is the case, for example, with reciprocating pumps, flow components outside the measuring range are buffered, balanced and output after a maximum delay of 60 seconds. If the buffered data cannot be processed within approx. 60 seconds, a fault/notice message appears. Under certain plant conditions, flow values can aggregate in the buffer, for example in the case of prolonged and unwanted fluid backflow. However, this buffer is reset in all relevant programming adjustments which affect the frequency output.



Function description	
OUTPUTS → PULSE/FREQUENCY OUTPUT (1...2) → CONFIGURATION (FREQUENCY)	
OUTPUT SIGNAL (4207)	 Note! Function is not available unless the FREQUENCY setting was selected in the OPERATION MODE (4200) function. For selecting the output configuration of the frequency output. Options: 0 = PASSIVE - POSITIVE 1 = PASSIVE - NEGATIVE 2 = ACTIVE - POSITIVE 3 = ACTIVE - NEGATIVE Factory setting: PASSIVE - POSITIVE Explanation ■ PASSIVE = power is supplied to the frequency output by means of an external power supply. ■ ACTIVE = power is supplied to the frequency output by means of the device-internal power supply. Configuring the output signal level (POSITIVE or NEGATIVE) determines the quiescent behavior (at zero flow) of the frequency output. The internal transistor is activated as follows: ■ If POSITIVE is selected, the internal transistor is activated with a positive signal level. ■ If NEGATIVE is selected, the internal transistor is activated with a negative signal level (0 V).  Note! With the passive output configuration, the output signal levels of the frequency output depend on the external circuit (see examples). Example for passive output circuit (PASSIVE) If PASSIVE is selected, the frequency output is configured as an open collector.  A0001225 ① = Open collector ② = External power supply  Note! For continuous currents up to 25 mA ($I_{\text{max}} = 250 \text{ mA} / 20 \text{ ms}$). Example for output configuration PASSIVE-POSITIVE: Output configuration with an external pull-up resistance. In the quiescent state (at zero flow), the output signal level at the terminals is 0 V. + $U_{\text{max}} = 30 \text{ V DC}$  A0004687 ① = Open collector ② = Pull-Up-Resistance ③ = Transistor activation in "POSITIVE" quiescent state (at zero flow) ④ = Output signal level in quiescent state (at zero flow) (continued on next page)

Function description OUTPUTS → PULSE/FREQUENCY OUTPUT (1...2) → CONFIGURATION (FREQUENCY)	
OUTPUT SIGNAL (continued)	In the operating status (flow present), the output signal level changes from 0 V to a positive voltage level.  A0001975 Example for output configuration PASSIVE-POSITIVE: Output configuration with an external pull-down resistance. In the quiescent state (at zero flow), a positive voltage level is measured via the pull-down resistance.  A0004689 ① = Open collector ② = Pull-Down-Resistance ③ = Transistor activation in "POSITIVE" quiescent state (at zero flow) ④ = Output signal level in quiescent state (at zero flow) In the operating status (flow present), the output signal level changes from a positive voltage level to 0 V.  A0001981 Example for output configuration PASSIVE-NEGATIVE: Output configuration with an external pull-up resistance. In the quiescent state (at zero flow), the output signal level at the terminals is at a positive voltage level.  A0004690 ① = Open collector ② = Pull-Up-Resistance ③ = Transistor activation in "NEGATIVE" quiescent state (at zero flow) ④ = Output signal level in quiescent state (at zero flow) In the operating status (flow present), the output signal level changes from a positive voltage level to 0 V.  A0001981 (continued on next page)

Function description	
OUTPUTS → PULSE/FREQUENCY OUTPUT (1...2) → CONFIGURATION (FREQUENCY)	
OUTPUT SIGNAL (continued)	Example for active output circuit (ACTIVE): With an active circuit, the internal power supply is 24 V. The frequency output is short-circuit proof.  ① = 24 V DC internal power supply ② = Short-circuit proof output The signal levels are to be seen as analogous to the passive circuit. The following applies for the output configuration ACTIVE-POSITIVE: In the quiescent state (at zero flow), the output signal level at the terminals is 0 V.  A0004691 A0004694 In the operating status (flow present), the output signal level changes from 0 V to a positive voltage level.  A0004692 The following applies for the output configuration ACTIVE-NEGATIVE: In the quiescent state (at zero flow), the output signal level at the terminals is at a positive voltage level.  A0004693 In the operating status (flow present), the output signal level changes from a positive voltage level to 0 V.  A0004710









Function description OUTPUTS → PULSE/FREQUENCY OUTPUT (1...2) → CONFIGURATION (FREQUENCY)	
TIME CONSTANT (4208)	 Note! This function is not available unless the FREQUENCY setting was selected in the OPERATION MODE function (4200). Use this function to enter a time constant defining how the frequency output signal reacts to severely fluctuating measured variables, either very quickly (enter a low time constant) or with damping (enter a high time constant). User input: Fixed-point number 0.00...100.00 s Factory setting: 0.00 s
FAILSAFE MODE (4209)	 Note! This function is not available unless the FREQUENCY setting was selected in the OPERATION MODE function (4200). For safety reasons it is advisable to ensure that the frequency output assumes a predefined state in the event of a fault. The setting you select here affects only the frequency output. It has no effect on other outputs and the display (e.g. totalizers). Options: FALLBACK VALUE Output is 0 Hz. FAILSAFE VALUE Output is the frequency specified in the FAILSAFE VALUE function (4211). HOLD VALUE Measured value output is based on the last measured value saved before the error occurred. ACTUAL VALUE Measured value output is based on the current flow measurement. The fault is ignored . Factory setting: FALLBACK VALUE
FAILSAFE VALUE (4211)	 Note! This function is not available unless FREQUENCY was selected in the OPERATION MODE function (4200) and FAILSAFE VALUE was selected in the FAILSAFE MODE function (4209). Use this function to define the frequency that the measuring device outputs in the event of an error. User input: max. 5-digit number: 0...12500 Hz Factory setting: 12500 Hz





Function description	
OUTPUTS → PULSE/FREQUENCY OUTPUT (1...2) → CONFIGURATION (PULSE)	
ASSIGN PULSE (4221)	 Note! This function is not available unless the PULSE setting was selected in the OPERATION MODE function (4200). Use this function to assign a measured variable to the pulse output. Options: OFF MASS FLOW VOLUME FLOW CORRECTED VOLUME FLOW Advanced options with optional software package CONCENTRATION: TARGET MASS TARGET VOLUME TARGET CORRECTED VOLUME CARRIER MASS CARRIER VOLUME CARRIER CORRECTED VOLUME Factory setting: MASS FLOW  Note! If you select OFF, the only function shown in the CONFIGURATION function group is this function, in other words ASSIGN PULSE (4221).
PULSE VALUE (4222)	 Note! This function is not available unless the PULSE setting was selected in the OPERATION MODE function (4200). Use this function to define the flow at which a pulse is triggered. These pulses can be totaled by an external totalizer, and the total flow quantity since measuring started can be registered in this way. User input: 5-digit floating-point number [unit] Factory setting: depends on nominal diameter and country, [value] [kg or lb] / impulse; corresponds to the factory setting for the pulse value (see page 189 ff.).  Note! The appropriate unit is taken from the UNIT MASS (0401), UNIT VOLUME (0403) or UNIT CORRECTED VOLUME (0405) function (see page 17 or page 19).

Function description	
OUTPUTS → PULSE/FREQUENCY OUTPUT (1...2) → CONFIGURATION (PULSE)	
PULSE WIDTH (4223)	Note! This function is not available unless the PULSE setting was selected in the OPERATION MODE function (4200). Use this function to enter the pulse width of the output pulse. User input: 0.05...2000 ms Factory setting: 100 ms Pulse output is always with the pulse width (B) entered in this function. The pauses (P) between the individual pulses are automatically configured. However, they must at least correspond to the pulse width ($B = P$). transistor conducting nonconducting  $B < P$ transistor conducting nonconducting  $B = P$ A0001233-en <i>B = Pulse width entered (the illustration applies to positive pulses)</i> <i>P = Pauses between the individual pulses</i> Note! When entering the pulse width, select a value that can still be processed by an external totalizer (e.g. mechanical totalizer, PLC, etc.). Caution! If the pulse number or frequency resulting from the pulse value entered (see function PULSE VALUE (4222) on page 85) and from the current flow is too large to maintain the pulse width selected (the time interval is smaller than the pulse width B entered), a system error message is generated (# 359...362, pulse buffer) after approx. 5 seconds buffer/balance time.

Function description	
OUTPUTS → PULSE/FREQUENCY OUTPUT (1...2) → CONFIGURATION (PULSE)	
MEASURING MODE (4225)	 Note! This function is not available unless the PULSE setting was selected in the OPERATION MODE function (4200). Use this function to define the measuring mode for the pulse output. Options: STANDARD Only positive flow components are totaled. Negative components are not taken into account. SYMMETRY Positive and negative flow components are taken into account.  Note! The direction of flow can be output via the relay output. PULSATING FLOW If flow is characterized by severe fluctuations as is the case, for example, with reciprocating pumps, the positive and negative flow components are totaled, with the signs taken into account (e.g. -10 l and +25 l = 15 l). Flow components outside the maximum pulse number per second (value/width) are buffered, balanced and output after a maximum delay of 60 seconds. If the buffered data cannot be processed within approx. 60 seconds, a fault/notice message appears. Under certain plant conditions, flow values can aggregate in the buffer, for example in the case of prolonged and unwanted fluid backflow. However, this buffer is reset in all relevant programming adjustments which affect the pulse output. STANDARD REVERSE Only negative flow components are totaled. Positive components are not taken into account. Factory setting: STANDARD

Function description OUTPUTS → PULSE/FREQUENCY OUTPUT (1...2) → CONFIGURATION (PULSE)	
OUTPUT SIGNAL (4226)	Note! Function is not available unless the PULSE setting was selected in the OPERATION MODE (4200) function. For selecting the output configuration of the pulse output. Options: 0 = PASSIVE - POSITIVE 1 = PASSIVE - NEGATIVE 2 = ACTIVE - POSITIVE 3 = ACTIVE - NEGATIVE Factory setting: PASSIVE - POSITIVE Explanation PASSIVE = power is supplied to the pulse output by means of an external power supply. ACTIVE = power is supplied to the pulse output by means of the device-internal power supply. Configuring the output signal level (POSITIVE or NEGATIVE) determines the quiescent behavior (at zero flow) of the pulse output. The internal transistor is activated as follows: If POSITIVE is selected, the internal transistor is activated with a positive signal level. If NEGATIVE is selected, the internal transistor is activated with a negative signal level (0 V). Note! With the passive output configuration, the output signal levels of the pulse output depend on the external circuit (see examples). Example for passive output circuit (PASSIVE) If PASSIVE is selected, the pulse output is configured as an open collector. A0001225 ① = Open collector ② = External power supply Note! For continuous currents up to 25 mA ($I_{max} = 250\text{ mA} / 20\text{ ms}$). Example for output configuration PASSIVE-POSITIVE: Output configuration with an external pull-up resistance. In the quiescent state (at zero flow), the output signal level at the terminals is 0 V. + $U_{max} = 30\text{ V DC}$ A0004687 ① = Open collector ② = Pull-Up-Resistance ③ = Transistor activation in "POSITIVE" quiescent state (at zero flow) ④ = Output signal level in quiescent state (at zero flow) (continued on next page)

Function description	
OUTPUTS → PULSE/FREQUENCY OUTPUT (1...2) → CONFIGURATION (PULSE)	
OUTPUT SIGNAL (continued)	In the operating status (flow present), the output signal level changes from 0 V to a positive voltage level.  A0001975 Example for output configuration PASSIVE-POSITIVE: Output configuration with an external pull-down resistance. In the quiescent state (at zero flow), a positive voltage level is measured via the pull-down resistance.    A0004689 ① = Open collector ② = Pull-Down-Resistance ③ = Transistor activation in "POSITIVE" quiescent state (at zero flow) ④ = Output signal level in quiescent state (at zero flow) In the operating status (flow present), the output signal level changes from a positive voltage level to 0 V.  A0001981 Example for output configuration PASSIVE-NEGATIVE: Output configuration with an external pull-up resistance. In the quiescent state (at zero flow), the output signal level at the terminals is at a positive voltage level.    A0004690 ① = Open collector ② = Pull-Up-Resistance ③ = Transistor activation in "NEGATIVE" quiescent state (at zero flow) ④ = Output signal level in quiescent state (at zero flow) In the operating status (flow present), the output signal level changes from a positive voltage level to 0 V.  A0001981 (continued on next page)


Function description	
OUTPUTS → PULSE/FREQUENCY OUTPUT (1...2) → CONFIGURATION (PULSE)	
OUTPUT SIGNAL (continued)	Example for active output circuit (ACTIVE): With an active circuit, the internal power supply is 24 V. The pulse output is short-circuit proof.  A0004691 ① = 24 V DC internal power supply ② = Short-circuit proof output The signal levels are to be seen as analogous to the passive circuit. The following applies for the output configuration ACTIVE-POSITIVE: In the quiescent state (at zero flow), the output signal level at the terminals is 0 V.  A0004694 In the operating status (flow present), the output signal level changes from 0 V to a positive voltage level.  A0004692 The following applies for the output configuration ACTIVE-NEGATIVE: In the quiescent state (at zero flow), the output signal level at the terminals is at a positive voltage level.  A0004693 In the operating status (flow present), the output signal level changes from a positive voltage level to 0 V.  A0004710

Function description	
OUTPUTS → PULSE/FREQUENCY OUTPUT (1...2) → CONFIGURATION (PULSE)	
FAILSAFE MODE (4227)	 Note! This function is not available unless the PULSE setting was selected in the OPERATION MODE function (4200). For safety reasons it is advisable to ensure that the pulse output assumes a predefined state in the event of a fault. The setting you select here affects only the pulse output. It has no effect on other outputs and the display (e.g. totalizers). Options: FALLBACK VALUE Output is 0 pulse. ACTUAL VALUE Measured value output is based on the current flow measurement. The fault is ignored. Factory setting: FALLBACK VALUE


Function description	
OUTPUTS → PULSE/FREQUENCY OUTPUT (1...2) → CONFIGURATION (STATUS)	
ASSIGN STATUS (4241)	 Note! This function is not available unless the STATUS setting was selected in the OPERATION MODE function (4200). Use this function to assign a switching function to the status output. Options: OFF ON (operation) FAULT MESSAGE NOTICE MESSAGE FAULT MESSAGE or NOTICE MESSAGE EMPTY PIPE DETECTION (only with active function) FLOW DIRECTION MASS FLOW LIMIT VALUE VOLUME FLOW LIMIT VALUE CORRECTED VOLUME FLOW LIMIT VALUE DENSITY LIMIT VALUE REFERENCE DENSITY LIMIT VALUE TEMPERATURE LIMIT VALUE TOTALIZER 1 LIMIT VALUE TOTALIZER 2 LIMIT VALUE TOTALIZER 3 LIMIT VALUE Advanced options with optional software package BATCHING: BATCH RUNNING > BATCH TIME >< BATCH QUANTITIES (< min. / > max. batching quantity) PROGRESS NOTE (batching end approaching)  Note! The only options available are the monitoring functions (7240 to 7243) which have a value not equal to zero (max. 3). Advanced options with optional software package CONCENTRATION: LIMIT TARGET MASS FLOW LIMIT TARGET % MASS PROPORTION FLOW LIMIT TARGET VOLUME FLOW LIMIT TARGET % VOLUME PROPORTION FLOW LIMIT TARGET CORRECTED VOLUME FLOW LIMIT CARRIER MASS FLOW LIMIT CARRIER % MASS PROPORTION FLOW LIMIT CARRIER VOLUME FLOW LIMIT CARRIER % VOLUME PROPORTION FLOW LIMIT CARRIER CORRECTED VOLUME FLOW LIMIT % BLACK LIQUOR LIMIT °BAUME > 1 LIMIT °BAUME < 1 LIMIT °API LIMIT °PLATO LIMIT °BALLING LIMIT °BRIX LIMIT OTHERS (_ _ _ flexible concentration) Advanced options with optional software package ADVANCED DIAGNOSIS: LIMIT MASS FLOW DEVIATION LIMIT DENSITY DEVIATION LIMIT REFERENCE DENSITY DEVIATION LIMIT TEMPERATURE DEVIATION LIMIT TUBE DAMPING DEVIATION LIMIT ELECTRODYNAMIC SENSOR DEVIATION LIMIT OPERATING FREQUENCY DEVIATION LIMIT TUBE DAMPING DEVIATION (continued on next page)

Function description OUTPUTS → PULSE/FREQUENCY OUTPUT (1...2) → CONFIGURATION (STATUS)	
ASSIGN STATUS (continued)	Factory setting: FAULT MESSAGE  Note! ■ The behavior of the status output is a normally closed behavior, in other words the output is closed (transistor conductive) when normal, error-free measuring is in progress. – “normal, error-free” operation: Flow direction = forwards; limit values = not exceeded; no empty or partially filled measuring tube (EPD/OED); no fault or notice message present. – Switching response like relay output, page 109 ■ If you select OFF, the only function shown in the CONFIGURATION function group is this function, in other words ASSIGN STATUS (4241). ■ Switching response like relay output, see page 109.
ON-VALUE (4242)	 Note! This function is not available unless STATUS was selected in the OPERATION MODE function (4200) and LIMIT VALUE or FLOW DIRECTION was selected in the ASSIGN STATUS function (4241). Use this function to assign a value to the switch-on point (activation of the status output). The value can be higher or lower than the switch-off point. Positive or negative values are permissible, depending on the measured variable in question (e.g. mass flow, totalizer reading). User input: 5-digit floating-point number [unit] Factory setting: 0 [kg/h] or 2 [kg/l] or 200 [°C]  Note! ■ If SYMMETRY is selected in the function MEASURING MODE (4246) and values with different signs are entered for the switch-on and switch-off points, the notice message “INPUT RANGE EXCEEDED” appears. ■ Only the switch-on point is available for flow direction output (no switch-off point). If you enter a value not equal to the zero flow (e.g. 5), the difference between the zero flow and the value entered corresponds to half the switchover hysteresis.
SWITCH-ON DELAY (4243)	 Note! This function is not available unless STATUS was selected in the OPERATION MODE function (4200) and LIMIT VALUE or FLOW DIRECTION was selected in the ASSIGN STATUS function (4241). Use this function to define a delay (0...100 seconds) for the switch-on (i.e. signal changes from “not conductive” to “conductive”) of the status output. The delay starts when the limit value is reached. The status output does switch when the delay has timed out and the switch on condition has been valid over the delay time. User input: fixed-point number: 0.0...100.0 s Factory setting: 0.0 s

Function description OUTPUTS → PULSE/FREQUENCY OUTPUT (1...2) → CONFIGURATION (STATUS)	
OFF-VALUE (4244)	 Note! This function is not available unless STATUS was selected in the OPERATION MODE function (4200) and a LIMIT VALUE was selected in the ASSIGN STATUS function (4241). Use this function to assign a value to the switch-off point (deactivation of the status output). The value can be higher or lower than the switch-on point. Positive and negative values are permissible, depending on the measured variable in question (e.g. mass flow, totalizer reading). User input: 5-digit floating-point number [unit] Factory setting: 0 [kg/h] or 2 [kg/l] or 200 [°C]  Note! ■ The appropriate unit is taken from the function UNIT VOLUME FLOW (0402) or UNIT MASS FLOW (0400). ■ If SYMMETRY is selected in the function MEASURING MODE (4246) and values with different signs are entered for the switch-on and switch-off points, the notice message "INPUT RANGE EXCEEDED" appears.
SWITCH-OFF DELAY (4245)	 Note! This function is not available unless the STATUS setting was selected in the OPERATION MODE function (4200). Use this function to define a delay (0...100 seconds) for the switch-off (i.e. signal changes from "conductive" to "not conductive") of the status output. The delay starts when the limit value is reached. The status output does switch when the delay has timed out and the switch off condition has been valid over the delay time. User input: fixed-point number: 0.0...100.0 s Factory setting: 0.0 s

Function description	
OUTPUTS → PULSE/FREQUENCY OUTPUT (1...2) → CONFIGURATION (STATUS)	
MEASURING MODE (4246)	Note! This function is not available unless STATUS was selected in the OPERATION MODE function(4200) and the status output was assigned a limit value. Use this function to define the measuring mode for the status output. Options: STANDARD The status output signal switches at the defined switch points. SYMMETRY The status output signal switches at the defined switch points, irrespective of the sign. If you define a switch point with a positive sign, the status output signal switches as soon as the value is reached in the negative direction (negative sign), (see illustration). Factory setting: STANDARD Example for the SYMMETRY measuring mode: Switch-on point Q = 4, Switch-off point Q = 10 ① = Status output switched on (conductive) ② = Status output switched off (nonconductive)  Note! ■ SYMMETRY cannot be selected unless the values in the ON-VALUE (4242) and OFF-VALUE (4244) functions have the same sign or one of the values is zero. ■ If the values have different signs, SYMMETRY cannot be selected and an “ASSIGNMENT NOT POSSIBLE” message is displayed.
TIME CONSTANT (4247)	Note! This function is not available unless the STATUS setting was selected in the OPERATION MODE function (4200). Use this function to enter a time constant defining how the measuring signal reacts to severely fluctuating measured variables, either very quickly (enter a low time constant) or with damping (enter a high time constant). Damping acts on the measuring signal before the switch status changes, and consequently before switch-on or switch-off delay is activated. The purpose of damping, therefore, is to prevent the status output changing state continuously in response to fluctuations in flow. User input: Fixed-point number 0.00 to 100.00 s Factory setting: 0.00 s

7.2.2 Function group OPERATION




Function description	
OUTPUTS → PULSE/FREQUENCY OUTPUT (1...2) → OPERATION (FREQUENCY)	
ACTUAL FREQUENCY (4301)	 Note! This function is not available unless the FREQUENCY setting was selected in the OPERATION MODE function (4200). Use this function to view the computed actual value of the output frequency. Display: 0...12500 Hz
SIMULATION FREQUENCY (4302)	 Note! This function is not available unless the FREQUENCY setting was selected in the OPERATION MODE function (4200). Use this function to activate simulation of the frequency output. Options: OFF ON Factory setting: OFF  Note! ■ The “SIMULATION FREQUENCY OUTPUT” message indicates that simulation is active. ■ The measuring device continues to measure while simulation is in progress, i.e. the current measured values are output correctly via the other outputs.  Caution! The setting is not saved if the power supply fails.

Function description	
OUTPUTS → PULSE/FREQUENCY OUTPUT (1...2) → OPERATION (FREQUENCY)	
VALUE SIMULATION FREQUENCY (4303)	 Note! This function is not available unless FREQUENCY was selected in the OPERATION MODE function (4200) and the SIMULATION FREQUENCY function (4302) is active (= ON). Use this function to define a free selectable frequency value (e.g. 500 Hz) which should be output at the frequency output (with maximum pulse frequency or shortened minimum pulse width). This value is used to test downstream devices and the measuring device itself. User input: 0...12500 Hz Factory setting: 0 Hz  Caution! The setting is not saved if the power supply fails.

Function description OUTPUTS → PULSE/FREQUENCY OUTPUT (1...2) → OPERATION (PULSE)	
SIMULATION PULSE(4322)	 Note! This function is not available unless the PULSE option was selected in the OPERATION MODE function. Use this function to activate simulation of the pulse output. Options: OFF COUNTDOWN The pulses specified in the VALUE SIMULATION PULSE function are output. CONTINUOUSLY Pulses are continuously output with the pulse width specified in the PULSE WIDTH function. Simulation is started once the CONTINUOUSLY option is confirmed with the  key.  Note! Simulation is started by confirming the CONTINUOUSLY option with the  key. The simulation can be switched off again via the SIMULATION PULSE function. Factory setting: OFF  Note! ■ The notice message #631 “SIM. PULSE” indicates that simulation is active. ■ The on/off ratio is 1:1 for both types of simulation. ■ The measuring device continues to measure while simulation is in progress, i.e. the current measured values are output correctly via the other outputs.  Caution! The setting is not saved if the power supply fails.
VALUE SIMULATION PULSE (4323)	 Note! This function is not available unless the COUNTDOWN option was selected in the SIMULATION PULSE function. Use this function to specify the number of pulses (e.g. 50) which are output during the simulation. This value is used to test downstream devices and the measuring device itself. The pulses are output with the pulse width specified in the PULSE WIDTH function. The on/off ratio is 1:1. Simulation is started once the specified value is confirmed with the  key. The display remains at 0 if the specified pulses have been output. User input: 0...10 000 Factory setting: 0  Note! Simulation is started by confirming the simulation value with the  key. The simulation can be switched off again via the SIMULATION PULSE function.  Caution! The setting is not saved if the power supply fails.

Function description OUTPUTS → PULSE/FREQUENCY OUTPUT (1...2) → OPERATION (STATUS)	
ACTUAL STATUS (4341)	 Note! This function is not available unless the STATUS setting was selected in the OPERATION MODE function (4200). Use this function to check the current status of the status output. Display: NOT CONDUCTIVE CONDUCTIVE
SIMULATION SWITCH POINT (4342)	 Note! This function is not available unless the STATUS setting was selected in the OPERATION MODE function (4200). Use this function to activate simulation of the status output. Options: OFF ON Factory setting: OFF  Note! ■ The “SIMULATION STATUS OUTPUT” message indicates that simulation is active. ■ The measuring device continues to measure while simulation is in progress, i.e. the current measured values are output correctly via the other outputs.  Caution! The setting is not saved if the power supply fails.
VALUE SIMULATION SWITCH POINT (4343)	 Note! This function is not available unless STATUS was selected in the OPERATION MODE function (4200) and the SIMULATION SWITCH POINT function (4342) is active (= ON). Use this function to define the switching response of the status output during the simulation. This value is used to test downstream devices and the measuring device itself. Options: NOT CONDUCTIVE CONDUCTIVE Factory setting: NOT CONDUCTIVE  Caution! The setting is not saved if the power supply fails.


7.2.3 Function group INFORMATION



Function description	
OUTPUTS → PULSE/FREQ. OUTP. (1...2) → INFORMATION	
TERMINAL NUMBER (4380)	Use this function to view the numbers of the terminals (in the connection compartment) and the polarity used by the pulse/frequency output.

7.3 Group RELAY OUTPUT (1...2)


7.3.1 Function group CONFIGURATION




Function description	
OUTPUTS → RELAY OUTPUT (1...2) → CONFIGURATION	
ASSIGN RELAY (4700)	Use this function to assign a switching function to the relay output. Options (standard): OFF ON (operation) FAULT MESSAGE NOTICE MESSAGE FAULT MESSAGE or NOTICE MESSAGE EPD (Empty pipe detection, only if active) FLOW DIRECTION LIMIT MASS FLOW LIMIT VOLUME FLOW LIMIT CORRECTED VOLUME FLOW LIMIT DENSITY LIMIT REFERENCE DENSITY LIMIT TEMPERATURE LIMIT TOTALIZER 1...3 Advanced options with optional software package BATCHING: BATCH VALVE 1 (e.g. to control valve 1) BATCH VALVE 2 (e.g. to control valve 2) BATCH RUNNING > BATCH TIME >< BATCH QUANTITIES (< min. / > max. batching quantity) PROGRESS NOTE (batching end approaching)  Note! ■ The batching valves defined in the function BATCH STAGES (7208) are the only available selection (max. 3). ■ The only options available are the monitoring functions (7240 to 7243) which have a value not equal to zero (max. 3). (continued on next page)

Function description OUTPUTS → RELAY OUTPUT (1...2) → CONFIGURATION	
ASSIGN RELAY (continued)	Advanced options with optional software package CONCENTRATION: LIMIT TARGET MASS FLOW LIMIT TARGET % MASS PROPORTION FLOW LIMIT TARGET VOLUME FLOW LIMIT TARGET % VOLUME PROPORTION FLOW LIMIT TARGET CORRECTED VOLUME FLOW LIMIT CARRIER MASS FLOW LIMIT CARRIER % MASS PROPORTION FLOW LIMIT CARRIER VOLUME FLOW LIMIT CARRIER % VOLUME PROPORTION FLOW LIMIT CARRIER CORRECTED VOLUME FLOW LIMIT % BLACK LIQUOR LIMIT °BAUME > 1 LIMIT °BAUME < 1 LIMIT °API LIMIT °PLATO LIMIT °BALLING LIMIT °BRIX LIMIT OTHERS (_ _ _ _ flexible concentration) Advanced options with opt. software package ADVANCED DIAGNOSIS: LIMIT MASS FLOW DEVIATION LIMIT DENSITY DEVIATION LIMIT REFERENCE DENSITY DEVIATION LIMIT TEMPERATURE DEVIATION LIMIT TUBE DAMPING DEVIATION LIMIT ELECTRODYNAMIC SENSOR DEVIATION LIMIT OPERATING FREQUENCY DEVIATION LIMIT TUBE DAMPING DEVIATION Factory setting: FAULT MESSAGE  Note! ■ It is very important to read and comply with the information on the switching characteristics of the relay output, (see page 109). ■ It is advisable to configure at least one relay output as a fault output and define the outputs' failsafe mode. ■ The relay output is configured as a normally open (NO or make) contact by default. It can be reconfigured as a normally closed (NC or break) contact by means of a jumper on the relay module (see Operating Instructions <i>Proline Promass 83</i>, BA 059D/06/en). ■ If you select OFF or ON, the only function shown in the CONFIGURATION function group is this function ASSIGN RELAY (4700).
ON VALUE (4701)	 Note! This function is not available unless LIMIT VALUE or FLOW DIRECTION was selected in the ASSIGN RELAY function (4700). Use this function to assign a value to the switch-on point (relay output pulls up). The value can be higher or lower than the switch-off point. Positive or negative values are permissible, depending on the measured variable in question (e.g. mass flow, totalizer reading). User input: 5-digit floating-point number [unit] Factory setting: 0 [kg/h] or 2 [kg/l] or 200 [°C]  Note! ■ The appropriate unit is taken from the function UNIT VOLUME FLOW (0402) or UNIT MASS FLOW (0400). ■ Only the switch-on point is available for flow direction output (no switch-off point). If you enter a value not equal to the zero flow (e.g. 5), the difference between the zero flow and the value entered corresponds to half the switchover hysteresis.

Function description OUTPUTS → RELAY OUTPUT (1...2) → CONFIGURATION	
SWITCH-ON DELAY (4702)	 Note! This function is not available unless LIMIT VALUE or FLOW DIRECTION was selected in the ASSIGN RELAY function (4700). Use this function to define a delay (0 ... 100 seconds) for pull-up (i.e. signal changes from 0 to 1) of the relay output. The delay starts when the limit value is reached. The relay output does switch when the delay has timed out and the switch on condition has been valid over the delay time. User input: fixed-point number 0.0...100.0 s Factory setting: 0.0 s
OFF-VALUE (4703)	 Note! This function is not available unless LIMIT VALUE was selected in the ASSIGN RELAY function (4700). Use this function to assign a value to the switch-off point (relay drops out). The value can be higher or lower than the switch-on point. Positive or negative values are permissible, depending on the measured variable in question (e.g. mass flow, totalizer reading). User input: 5-digit floating-point number [unit] Factory setting: 0 [kg/h] or 2 [kg/l] or 200 [°C]  Note! ■ The appropriate unit is taken from the function UNIT VOLUME FLOW (0402) or UNIT MASS FLOW (0400). ■ If SYMMETRY is selected in the function MEASURING MODE (4705) and values with different signs are entered for the switch-on and switch-off points, the notice message "INPUT RANGE EXCEEDED" appears.
SWITCH-OFF DELAY (4704)	 Note! This function is not available unless LIMIT VALUE was selected in the ASSIGN RELAY function (4700). Use this function to define a delay (0 ... 100 seconds) for dropout (i.e. signal changes from 1 to 0) of the relay output. The delay starts when the limit value is reached. The relay output does switch when the delay has timed out and the switch off condition has been valid over the delay time. User input: fixed-point number 0.0...100.0 s Factory setting: 0.0 s

Function description OUTPUTS → RELAY OUTPUT (1...2) → CONFIGURATION	
MEASURING MODE (4705)	 Note! This function is not visible unless a limit value was assigned to the relay output. Use this function to define the measuring mode for the relay output. Options: STANDARD The relay output signal switches at the defined switch points. SYMMETRY The relay output signal switches at the defined switch points, irrespective of the sign. If you define a switch point with a positive sign, the relay output switches as soon as the value is reached in the negative direction (negative sign), (see illustration). Factory setting: STANDARD Example for the SYMMETRY measuring mode: Switch-on point Q = 4 Switch-off point Q = 10 ① = Relay energized ② = Relay de-energized   Note! - SYMMETRY cannot be selected unless the values in the ON VALUE (4701) and OFF-VALUE (4703) functions have the same sign or one of the values is zero. - If the values have different signs, SYMMETRY cannot be selected and an “ASSIGNMENT NOT POSSIBLE” message is displayed.
TIME CONSTANT (4706)	Use this function to enter a time constant defining how the measuring signal reacts to severely fluctuating measured variables, either very quickly (enter a low time constant) or with damping (enter a high time constant). Damping acts on the measuring signal before the switch status changes, and consequently before switch-on or switch-off delay is activated. The purpose of damping, therefore, is to prevent the relay output changing state continuously in response to fluctuations in flow. User input: fixed-point number: 0.00...100.00 s Factory setting: 0.00 s


7.3.2 Function group OPERATION



Function description	
OUTPUTS → RELAY OUTPUT (1...2) → OPERATION	
ACTUAL STATUS RELAY OUTPUT (4740)	Use this function to check the current status of the relay output. A jumper on the contact side defines the relay output as a normally open (NO or make) or normally closed (NC or break) contact (see Operating Instruction <i>Proline Promass 83</i>, BA 059D/06/en). Display: MAKE CONTACT OPEN MAKE CONTACT CLOSED BREAK CONTACT OPEN BREAK CONTACT CLOSED
SIMULATION SWITCH POINT (4741)	Use this function to activate simulation of the relay output. Options: OFF ON Factory setting: OFF  Note! ■ The “SIMULATION RELAY” message indicates that simulation is active. ■ The measuring device continues to measure while simulation is in progress, i.e. the current measured values are output correctly via the other outputs. ■ If the “BATCH VALVE 1” option was selected in the ASSIGN RELAY (4700) function, the functional test takes place by means of the BATCH PROCEDURE (7260) function, see p. 162.  Caution! The setting is not saved if the power supply fails.

Function description	
OUTPUTS → RELAY OUTPUT (1...2) → OPERATION	
VALUE SIMULATION SWITCH POINT (4742)	 Note! The function is not visible unless the function SIMULATION SWITCH POINT (4741) is active (= ON). Use this function to define the status of the relay output during the simulation. This value is used to test downstream devices and the measuring device itself. Depending on the relay configuration (as make or break contact) the following selections are available. Options: Relay output configured as normally open (make) contact: MAKE CONTACT OPEN MAKE CONTACT CLOSED Relay output configured as normally closed (break) contact: BREAK CONTACT OPEN BREAK CONTACT CLOSED  Caution! The setting is not saved if the power supply fails.

7.3.3 Function group INFORMATION



Function description	
OUTPUTS → RELAY OUTPUT (1...2) → INFORMATION	
TERMINAL NUMBER (4780)	Use this function to view the numbers of the terminals (in the connection compartment) and the polarity used by the relay output.

7.3.4 Information on the response of the relay output


General

If you have configured the relay output signal for “LIMIT VALUE” or “FLOW DIRECTION”, you can define the requisite switch points in the ON VALUE and OFF-VALUE functions. When the measured variable in question reaches one of these predefined values, the relay output switches as shown in the illustrations below.

Relay output configured for “flow direction”

The value you entered in the function ON-VALUE defines the switch point for the positive and negative directions of flow.

If, for example, the switch point you define is $1 \text{ m}^3/\text{h}$, the relay drops out at $-1 \text{ m}^3/\text{h}$ and pulls up at $+1 \text{ m}^3/\text{h}$. Set the switch point to 0 if your process calls for direct switchover (no switching hysteresis). If low flow cut off is used, it is advisable to set hysteresis to a value higher than or equal to the low flow cut off rate.




A0001236

a = Relay energized
b = Relay de-energized

Relay output configured for limit value

The relay output signal switches as soon as the measured variable undershoots or overshoots a defined switch point.

Application: Monitoring flow or process-related boundary conditions.



A0001235
















① = SWITCH-OFF POINT, ② = SWITCH-ON POINT, ③ = Relay de-energized









A = Maximum safety (SWITCH-OFF POINT > SWITCH-ON POINT)

B = Minimum safety (SWITCH-OFF POINT < SWITCH-ON POINT)

C = Minimum safety (SWITCH-OFF POINT = SWITCH-ON POINT, this configuration is to be avoided)

7.3.5 Switching behavior of the relay output

Function	State	Relay coil	Contact*	
			NC	NO
ON (operation)	System in measuring mode	 energized	 A0001239	 A0001237
	System not in measuring mode (power supply failed)	 de-energized	 A0001240	 A0001238
Fault message	System OK	 energized	 A0001239	 A0001237
	(System or process error) Fault → Failsafe mode, outputs /inputs and totalizers	 de-energized	 A0001240	 A0001238
Notice message	System OK	 energized	 A0001239	 A0001237
	(System or process error) Fault → Continuation of measuring	 de-energized	 A0001240	 A0001238
Fault message or Notice message	System OK	 energized	 A0001239	 A0001237
	(System or process error) Fault → Failsafe mode or Note → Continuation of measuring	 de-energized	 A0001240	 A0001238

Function	State	Relay coil	Contact*	
			NC	NO
Empty pipe detection (EPD)	Measuring tube full	 A0001292	energized	 A0001239 A0001237
	Measuring tube partially filled /empty measuring tube	 A0001293	de-energized	 A0001240 A0001238
Flow direction	forward	 A0001241	energized	 A0001239 A0001237
	reverse	 A0001242	de-energized	 A0001240 A0001238
Limit value – Mass flow – Volume flow – Corrected volume flow – Density – Reference density – Temperature – Totalizer	Limit value not overshoot or undershot	 A0001243	energized	 A0001239 A0001237
	Limit value overshoot or undershot	 A0001244	de-energized	 A0001240 A0001238
* Terminal numbers in accordance with the function TERMINAL NUMBER (4780) on page 107.  Note! If the measuring device has two relays, the factory setting is: ■ Relay 1 → normally open contact (NO) ■ Relay 2 → normally closed contact (NC)  Caution! When using the optional software package BATCHING, it is advisable for the contacts (either normally open or normally closed contacts) to have the same switching response for all relay outputs used.				

8 Block INPUTS

Block	Groups	Function groups	Functions
INPUTS (F)	STATUS INPUT (FAA) p. 112	⇒ CONFIGURATION (500) p. 112	⇒ ASSIGN STATUS INPUT (5000) p. 112
		⇕ OPERATION (504) p. 113	⇕ ACTIVE LEVEL (5001) p. 112
		⇕ INFORMATION (508) p. 114	⇕ MIN. PULSE WIDTH (5002) p. 112
			⇕ SIM. STATUS IN. (5041) p. 113
	CURRENT INPUT (FCA) p. 115	⇒ CONFIGURATION (520) p. 115	⇒ ASSIGN CURRENT INPUT (5200) p. 115
		⇕ OPERATION (524) p. 117	⇕ CURRENT SPAN (5201) p. 115
		⇕ INFORMATION (528) p. 118	⇕ VALUE 0.4 mA (5202) p. 115
			⇕ VALUE 20 mA (5203) p. 116
			⇕ ERROR VALUE (5204) p. 116
			⇕ SIM. CURRENT INPUT (5241) p. 117
			⇕ VALUE SIM. CUR. INP. (5242) p. 117
			⇕ TERMINAL NUMBER (5280) p. 118
			⇕ VALUE SIM. STATUS IN. (5042) p. 113
			⇕ TERMINAL NUMBER (5080) p. 114


8.1 Group STATUS INPUT

8.1.1 Function group CONFIGURATION

INPUTS	F	⇒	STATUS INPUT	FAA	⇒	CONFIGURATION	500
--------	---	---	--------------	-----	---	---------------	-----


Function description INPUTS → STATUS INPUT → CONFIGURATION	
ASSIGN STATUS INPUT (5000)	Use this function to assign a switching function to the status input. Options: OFF RESET TOTALIZER 1 RESET TOTALIZER 2 RESET TOTALIZER 3 RESET ALL TOTALIZERS POSITIVE ZERO RETURN RESET FAULT MESSAGE ZEROPOINT ADJUSTMENT Advanced options with optional software package BATCHING: RUN BATCHING (start/stop) HOLD BATCHING (stop/continue) RESET BATCH SUM (resetting total quantity / total quantity totalizers) RESET TOTALIZER 3 & START BATCHING (reset of totalizer 3, followed by start)  Caution! If an input pulse is sent during a batching process, the batching process is canceled immediately, but totalizer 3 is not reset. This allows the partial filling to be read out correctly. Advanced options with optional software package ADVANCED DIAGNOSIS: ACQUISITION  Note! This function is not available unless the SINGLE SHOT setting is selected in the ACQUISITION MODE function (7410). Factory setting: OFF  Caution! POSITIVE ZERO RETURN is active as long as the level is available at the status input (continuous signal). All other assignments react to a change in level (pulse) at the status input.
ACTIVE LEVEL (5001)	Use this function to define whether the assigned function (see function ASSIGN STATUS INPUT) is released when the signal level is present (HIGH) or not present (LOW). Options: HIGH LOW Factory setting: HIGH
MINIMUM PULSE WIDTH (5002)	Use this function to define a minimum pulse width which the input pulse must achieve in order to trigger the selected switching function, (see function ASSIGN STATUS INPUT (5000)). User input: 20...100 ms Factory setting: 50 ms

8.1.2 Function group OPERATION



Function description	
INPUTS → STATUS INPUT → OPERATION	
ACTUAL STATUS INPUT (5040)	Use this function to view the current level of the status input. Display: HIGH LOW
SIMULATION STATUS INPUT (5041)	Use this function to simulate the status input, in other words to trigger the function assigned to the status input (see the function ASSIGN STATUS INPUT (5000) on page 112). Options: OFF ON Factory setting: OFF  Note! ■ The “SIMULATION STATUS INPUT” message indicates that simulation is active. ■ The measuring device continues to measure while simulation is in progress, i.e. the current measured values are output correctly via the other outputs.  Caution! The setting is not saved if the power supply fails.
VALUE SIMULATION STATUS INPUT (5042)	 Note! The function is not visible unless the function SIMULATION STATUS INPUT (5041) is active (= ON). Use this function to define the level to be assumed at the status output during the simulation. This value is used to test downstream devices and the measuring device itself. Options: HIGH LOW Factory setting: LOW  Caution! The setting is not saved if the power supply fails.


8.1.3 Function group INFORMATION



Function description	
INPUTS → STATUS INPUT → INFORMATION	
TERMINAL NUMBER (5080)	Use this function to view the numbers of the terminals (in the connection compartment) and the polarity used by the status input.

8.2 Group CURRENT INPUT


8.2.1 Function group CONFIGURATION



Function description	
INPUTS → CURRENT INPUT → CONFIGURATION	
ASSIGN CURRENT INPUT (5200)	Use this function to assign a process variable to the current input. Options: OFF TEMPERATURE PRESSURE REFERENCE DENSITY Factory setting: OFF
CURRENT SPAN (5201)	Use this function to define the current range. The selection specifies the operational range and the lower and upper signal on alarm. Options: 0–20 mA 4–20 mA 4–20 mA NAMUR 4–20 mA US 0–20 mA (25 mA) 4–20 mA (25 mA) Factory setting: 4–20 mA NAMUR  Note! When switching the hardware from an active (factory setting) to a passive output signal, select a current range of 4–20 mA (See Operating Instructions <i>Proline Promass 83</i>, BA 059D/06/en/). Current range / operational range (measuring information): 0–20 mA / 0...20.5 mA 4–20 mA / 4...20.5 mA 4–20 mA NAMUR / 3.8...20.5 mA 4–20 mA US / 3.9...20.8 mA 0–20 mA (25 mA) / 0...24 ma 4–20 mA (25 mA) / 4...24 mA
VALUE 0_4 mA (5202)	Use this function to assign a value to the 0/4 mA current. User input: 5-digit floating-point number Factory setting: Dependent on the process variable assigned to the current input (see function ASSIGN CURRENT INPUT, 5200). – Pressure: 0 barg – Temperature: –50 °C – Reference density: 0.50 kg/Nl  Note! The appropriate unit is taken from the functions UNIT PRESSURE (0426), UNIT TEMPERATURE (0422) or UNIT REFERENCE DENSITY (0421).


Function description INPUTS → CURRENT INPUT → CONFIGURATION	
VALUE 20 mA (5203)	Use this function to assign a value to the 20 mA current. User input: 5-digit floating-point number Factory setting: Dependent on the process variable assigned to the current input (see function ASSIGN CURRENT INPUT, 5200). – Pressure: 100 barg – Temperature: 200 °C – Reference density: 2.00 kg/Nl  Note! The appropriate unit is taken from the functions UNIT PRESSURE (0426), UNIT TEMPERATURE (0422) or UNIT REFERENCE DENSITY (0421).
ERROR VALUE (5204)	Use this function to enter a defined error value for the process variable concerned. If the current value lies outside of the selected range (see function CURRENT SPAN, 5201), then the process variable is set to the “error value” defined here and a corresponding notice message CURRENT INPUT RANGE (# 363) is generated. User input: 5-digit floating-point number Factory setting: Dependent on the process variable assigned to the current input (see function ASSIGN CURRENT INPUT, 5200). – Pressure: 50 barg – Temperature: 75 °C – Reference density: 1.25 kg/Nl  Note! ■ Triggered amplifier faults or the error behavior of the outputs do not have any influence on the current input. ■ The appropriate unit is taken from the functions UNIT PRESSURE (0426), UNIT TEMPERATURE (0422) or UNIT REFERENCE DENSITY (0421).

8.2.2 Function group OPERATION



Function description INPUTS → CURRENT INPUT → OPERATION	
ACTUAL CURRENT INPUT (5240)	The actual value of the input current appears on the display. Display: 0.0...25 mA
SIMULATION CURRENT INPUT (5241)	Use this function to activate simulation of the current output. Options: OFF ON Factory setting: OFF Note! - An active simulation is indicated by the "SIM. CURRENT 1" (# 661) notice message. - The value output for the simulation at the current input is defined in the function VALUE SIMULATION CURRENT INPUT (5242). - The measuring device remains fully operational during the simulation and the current measured values are output correctly via the other outputs and the display. Caution! The setting is not saved if the power supply fails.
VALUE SIMULATION CURRENT INPUT (5242)	Note! This function is only available if the function SIMULATION CURRENT INPUT (5241) is switched on. Use this function to specify a freely selectable value, e.g. 12 mA, which is to be simulated at the current input. This value is used to test downstream devices and the measuring device itself. User input: 0.00...25.00 mA Factory setting: 0.00 mA or 4 mA (depending on the setting in function 5201). Caution! The setting is not saved if the power supply fails.

8.2.3 Function group INFORMATION



Function description	
INPUTS → CURRENT INPUT → INFORMATION	
TERMINAL NUMBER (5280)	This function is used to display the polarity and numbers of the terminals (in the terminal compartment) occupied by the current input.

9 Block BASIC FUNCTION

Block	Groups	Function groups	Functions
BASIC FUNCTION (G)	HART (CAA) p. 120	CONFIGURATION (600) p. 120	TAG NAME (6000) p. 120
		INFORMATION (604) p. 121	MANUFACTURER ID (6040) p. 121
			TAG DESCRIPTION (6001) p. 120
			BUS ADDRESS (6002) p. 120
	PROCESS PARAMETER (GJA) p. 122		DEVICE ID (6041) p. 121
			DEVICE REVISION (6042)
			ON-VALUE LF CUT OFF (6402) p. 122
			OFF-VALUE LF CUTOFF (6403) p. 122
	EPD PARAMETER (642) p. 125		PRESSURE SHOCK SUPPR. (6404) p. 123
			EPD VALUE LOW (6423) p. 125
			EPD VALUE HIGH (6424) p. 125
			EPD RESP. TIME (6425) p. 125
	REFERENCE PARAMETER (646) p. 127		EXP. COEF. SQR. (6463) p. 127
			EXPANS. COEFF. (6462) p. 127
			FIXED REF. DENSITY (6461) p. 127
			VALUE REF-TEMP. (6464) p. 128
	ADJUSTMENT (648) p. 129		DENSITY ADJUST MODE (6482) p. 130
			DENSITY SETPOINT 1 (6483) p. 130
			MEASURE FLUID 1 (6484) p. 130
			DENSITY SET VAL2 (6485) p. 130
	PRESSURE CORRECTION (650) p. 132		MEASURE FLUID 2 (6486) p. 130
			DENSITY ADJUST REST. ORIGINAL (6487) p. 131
			DENSITY ADJUST (6488) p. 131
			REST. ORIGINAL (6488) p. 131
	SYSTEM PARAMETER (GLA) p. 133		PRESSURE (6501) p. 132
			DENSITY DAMPING (6602) p. 133
			POSITIVE ZERO (6605) p. 133
			TEMPERATURE MEASUREMENT (6606) p. 134
	SENSOR DATA (GNA) p. 135		INST. DIR. SENSOR (6600) p. 133
			ZEROPPOINT (6803) p. 135
			NOMINAL DIAMETER (6804) p. 135
			TEMPERATURE COEFF. KM 2 (6841) p. 136
	FLOW COEFF. (684) p. 136		TEMPERATURE COEFF. KT (6842) p. 136
			CALIBRATION COEFF. KD 1 (6843) p. 136
			CALIBRATION COEFF. KD 2 (6844) p. 136
			DENSITY COEFF. C1 (6851) p. 137
	DENSITY COEFF. (685) p. 137		DENSITY COEFF. C2 (6852) p. 137
			DENSITY COEFF. C3 (6853) p. 137
			DENSITY COEFF. C4 (6854) p. 137
			DENSITY COEFF. C5 (6855) p. 137
	ADDITIONAL COEFF. (686) p. 138		MAX. FLUID TEMP. (6861) p. 138
			MIN. CARRIER TEMP. (6862) p. 138
			MAX. CARRIER TEMP. (6863) p. 138
			MAX. CARRIER TEMP. (6863) p. 138


9.1 Group HART

9.1.1 Function group CONFIGURATION

BASIC FUNCTION	G	⇒	HART	GAA	⇒	CONFIGURATION	600
----------------	---	---	------	-----	---	---------------	-----

Function description BASIC FUNCTION → HART → CONFIGURATION	
TAG NAME (6000)	Use this function to enter a tag name for the measuring device. You can edit and read this tag description via the local display or the HART protocol. User input: max. 8-character text, permissible: A-Z, 0-9, +, -, punctuation marks Factory setting: "-----" (no text)
TAG DESCRIPTION (6001)	Use this function to enter a tag description for the measuring device. You can edit and read this tag description via the local display or the HART protocol. User input: max. 16-character text, permissible: A-Z, 0-9, +, -, punctuation marks Factory setting: "-----" (No text)
BUS ADDRESS (6002)	Use this function to define the address for the exchange of data with the HART protocol. User input: 0...15 Factory setting: 0  Note! Addresses 1...15: a constant 4 mA current is applied.
HART PROTOCOL (6003)	Use this function to display if the HART protocol is active. Display: OFF = HART protocol not active ON = HART protocol active  Note! The HART protocol can be activated with the selection 4-20 mA HART or 4-20 mA (25 mA) HART in the function CURRENT SPAN, (see page 64).
WRITE PROTECTION (6004)	Use this function to check whether the measuring device can be write-accessed. Display: OFF = Data exchange is possible ON = Data exchange disabled Factory setting: OFF  Note! Write protection is activated and deactivated by means of a jumper on the I/O module (see Operating Instruction <i>Proline Promass 83</i>, BA 059D/06/en).


9.1.2 Function group INFORMATION




Function description	
BASIC FUNCTION → HART → OPERATION	
MANUFACTURER ID (6040)	Use this function to view the manufacturer ID in decimal numerical format. Display: – Endress+Hauser – 17 (≅ 11 hex) for Endress+Hauser
DEVICE ID (6041)	Use this function to view the device ID in hexadecimal numerical format. Display: 51 (≅ 81 dez) for Promass 83
DEVICE REVISION (6042)	Displays the device-specific revision of the HART command interface. Display: e.g.: 5


9.2 Group PROCESS PARAMETER

9.2.1 Function group CONFIGURATION




Function description	
BASIC FUNCTION → PROCESS PARAMETER → CONFIGURATION	
ASSIGN LOW FLOW CUT OFF (6400)	Use this function to assign the switch point for low flow cut off rate suppression. Options: OFF MASS FLOW VOLUME FLOW CORRECTED VOLUME FLOW Factory setting: MASS FLOW
ON-VALUE LOW FLOW CUT OFF (6402)	Use this function to assign a value to the switch-on point for low flow cut off. Low flow cut off is active if the value entered is not equal to 0. The sign of the flow value is highlighted on the display to indicate that low flow cut off is active. User input: 5-digit floating-point number, [unit] Factory setting: Depends on nominal diameter  Note! The appropriate unit is taken from the function group SYSTEM UNITS (see page 17).
OFF-VALUE LOW FLOW CUT OFF (6403)	Enter the off-value (b) of the low flow cut off. Enter the switch-off point as a positive hysteresis (H) from the switch-on point (a). User input: Integer 0 to 100% Factory setting: 50%  ① = On-value ② = Off-value a Low flow cut off is switched on b Low flow cut off is switched off (a + a · H) H Hysteresis: 0 to 100%  Low flow cut off active Q Flow

A0003882

Function description	
BASIC FUNCTION → PROCESS PARAMETER → CONFIGURATION	
PRESSURE SHOCK SUPPRESSION (6404)	The closure of a valve can cause brief but severe movements of the fluid in the piping system, movements which the measuring system registers. The pulses totaled in this way result in a totalizer reading error, particularly in the case of batching processes. For this reason, the measuring device is equipped with pressure shock suppression (= short-term signal suppression) which can eliminate system-related “disruptions”.  Note! Note that pressure shock suppression cannot be used unless the low flow cut off is active, (see function ON-VALUE LOW FLOW CUT OFF on page 122). Use this function to define the time span for active pressure shock suppression. Activation of the pressure shock suppression Pressure shock suppression is activated after the flow falls below the switch-on point of the low flow cut off (see point a in graphic). While pressure shock suppression is active, the following conditions apply: ■ Current outputs → outputs the current corresponding to zero flow. ■ Pulse-/Freq.-output → outputs the frequency corresponding to zero flow. ■ Flow reading on display → 0 ■ Totalizer reading → the totalizers are pegged at the last correct value. Deactivation of the pressure shock suppression The pressure shock suppression is deactivated after the time interval, set in this function, has passed (see point b in graphic).  Note! The actual flow value is displayed and output, when the time interval for the pressure shock suppression has passed and the flow exceeds the switch-off point of the low flow cut off (see point c in graphic).  A0001285-en ① = Off-value (low flow cut off) ② = On-VALUE (low flow cut off) a Active when value falls below the on-value of the low flow cut off b Deactivated after specified time expires c Flow values are again used to calculate the pulses ■ Suppressed values Q Flow

Function description BASIC FUNCTION → PROCESS PARAMETER → CONFIGURATION	
PRESSURE SHOCK SUPPRESSION (6404) (continued)	User input: max. 4-digit number, incl. unit: 0.00...100.0 s Factory setting: 0.00 s


9.2.2 Function group EPD PARAMETER



Function description	
BASIC FUNCTION → PROCESS PARAMETER → EPD PARAMETER	
EMPTY PIPE DETECTION (6420)	Use this function to activate the empty pipe detection (EPD). With empty measuring tubes the density of the fluid falls below the value specified in the function EPD VALUE LOW. Options: OFF ON Factory setting: Liquid: ON Gas: OFF  Caution! ■ Select a correspondingly low EPD response value in the function EPD VALUE LOW, so that the difference to the effective density of the fluid is sufficiently large enough. This ensures that totally empty measuring tubes and not partially filled ones are detected. ■ For gas measurement we strongly recommend to switch off empty pipe detection.
EPD VALUE LOW (6423)	 Note! This function is not available unless the ON selection was selected in the EMPTY PIPE DETECTION function. Use this function to set a lower threshold for the measured density value, in order to detect possible problems in the process indicated by too low density. User input: 5-digit floating-point number Factory setting: 0.2000 kg/l
EPD VALUE HIGH (6424)	 Note! This function is not available unless the ON selection was selected in the EMPTY PIPE DETECTION function. Use this function to set an upper threshold for the measured density value. User input: 5-digit floating-point number Factory setting: 6.0000 kg/l
EPD RESPONSE TIME (6425)	Use this function to enter the time span for which the criteria for an empty pipe have to be satisfied without interruption before a notice message or fault message is generated. User input: fixed-point number: 1.0...100 s Factory setting: 1.0 s

Function description	
BASIC FUNCTION → PROCESS PARAMETER → EPD PARAMETER	
EPD EXC. CURR. MAX (6426)	Use this function to activate the empty pipe detection (EPD). In the event of inhomogeneous fluids or air bubbles, the exciting current of the measuring pipes increases. If the exciting current set in this function is exceeded, error message #700 is output similar to the functions “EPD VALUE LOW (6423)” and “EPD VALUE HIGH (6423).” User input: 5-digit floating-point number Factory setting: 100 mA (deactivated)  Note! The function is not activated until a value under 100 mA is input. Entering the value 100 mA deactivates the function.


9.2.3 Function group REFERENCE PARAMETER



Function description	
BASIC FUNCTION → PROCESS PARAMETER → REFERENCE PARAMETER	
CORRECTED VOLUME CALCULATION (6460)	This function is used to set the reference density for calculating the corrected volume flow. Options: FIXED REFERENCE DENSITY CALCULATED REFERENCE DENSITY EXTERN (with this option, the reference density can be read in via the current input) Factory setting: CALCULATED REFERENCE DENSITY
FIXED REF. DENSITY (6461)	Note! This function is not available unless the FIXED REFERENCE DENSITY setting was selected in the CORRECTED VOLUME CALCULATION function (6460). In this function, a fixed value for the reference density can be entered, with which the corrected volume flow or corrected volume is calculated. User input: 5-digit floating-point number Factory setting: 1 kg/Nl
EXPANSION COEFFICIENT (6462)	Note! This function is not available unless the CALCULATED REFERENCE DENSITY setting was selected in the CORRECTED VOLUME CALCULATION function (6460). For temperature-compensated calculations of the reference density an expansion coefficient specific to the fluid is required and can be entered in this function (see VALUE REFERENCE TEMPERATURE (6464) function on page 128). User input: 5-digit floating-point number Factory setting: $0.5000 \text{ e}^{-3} [1/\text{K}]$
EXPANSION COEFFICIENT SQUARE (6463)	Use this function to enter a square expansion coefficient, if the temperature compensation follows a nonlinear behavior (see VALUE REFERENCE TEMPERATURE (6464) function on page 128). User input: 5-digit floating-point number Factory setting: $0 \text{ e}^{-6} [1/\text{K}^2]$

Function description	
BASIC FUNCTION → PROCESS PARAMETER → REFERENCE PARAMETER	
VALUE REFERENCE TEMPERATURE (6464)	 Note! This function is not available unless the CALCULATED REFERENCE DENSITY setting was selected in the CORRECTED VOLUME CALCULATION function (6460). Entering the reference temperature for calculating the corrected volume flow, the corrected volume and the reference density. User input: 5-digit floating-point number Factory setting: 20.000 °C The reference density is calculated as follows: $\rho_N = \rho \cdot (1 + \alpha \Delta t + \beta \Delta t^2)$; Δ where $t = t - t_N$ ρ_N = Reference density ρ = currently measured fluid density (measuring value Promass) t = Actual measured temperature of fluid (measuring value Promass) t_N = Reference temperature for calculating the reference density (e.g. 20 °C) α = Volumetric expansion coefficient of the fluid, Unit = [1/K]; K = Kelvin β = Square volumetric expansion coefficient of the fluid, unit = [1/K²]

9.2.4 Function group ADJUSTMENT




Function description	
BASIC FUNCTION → PROCESS PARAMETER → ADJUSTMENT	
ZEROPOINT ADJUSTMENT (6480)	This function enables a zero point adjustment to be automatically carried out. The new zero point determined by the measuring system is adopted by the function ZEROPOINT (see page 135). Options: CANCEL START Factory setting: CANCEL Caution! Before carrying this out, please refer to the Operating Instructions <i>Proline Promass 83</i>, BA 059D/06/en for a detailed description of the procedure for zero point adjustment. Note! ■ Programming is locked during zero point adjustment. The message“ZERO ADJUST RUNNING” appears on the display. ■ If the zero point adjustment is not possible (e.g. if $v > 0.1\text{ m/s}$) or has been canceled, the alarm message “ZERO ADJUST NOT POSSIBLE” appears on the display. ■ If the Promass 83 measuring electronics are fitted with a status input, then the zero point can also be activated by using this input.

Function description BASIC FUNCTION → PROCESS PARAMETER → ADJUSTMENT	
DENSITY ADJUST MODE (6482)	Use this function to select whether a 1-point or a 2-point density adjustment should be carried out. Options: CANCEL 1-POINT 2-POINT
DENSITY SETPOINT 1 (6483)	Use this function to enter the density setpoint value for the first fluid for which you want to carry out field density adjustment. User input: 5-digit floating-point number, incl. units  Note! ■ The preset density entered here should not vary from the actual fluid density by a more than $\pm 10\%$. ■ The appropriate unit is taken from the function group SYSTEM UNITS (see page 17).
MEASURE FLUID 1 (6484)	In this function the actual density of the first fluid is measured for density adjustment. Options: CANCEL START
DENSITY SETPOINT 2 (6485)	Use this function to enter the density setpoint value for the second fluid for which you want to carry out field density adjustment. User input: 5-digit floating-point number, incl. units  Note! ■ The preset density entered here should not vary from the actual fluid density by a more than $\pm 10\%$. ■ The difference between the density setpoint values must be at least 0.2 kg/l. ■ The appropriate unit is taken from the function group SYSTEM UNITS (see page 17).
MEASURE FLUID 2 (6486)	In this function the current density of the second fluid is measured for density adjustment. Options: CANCEL START

Function description BASIC FUNCTION → PROCESS PARAMETER → ADJUSTMENT	
DENSITY ADJUST (6487)	With this function a density adjustment can be carried out on site. The density adjustment values will thus be recalculated and stored. This ensures that the values dependent on density calculations (e.g. volume flow) are as accurate as possible.  Note! Before carrying this out, please refer to the Operating Instructions <i>Proline Promass 83</i>, BA 059D/06/en for a detailed description of the procedure for density adjustment. Two types of adjustment are possible: 1-point density adjustment (with one fluid) This type of density adjustment is necessary under the following conditions: ■ The sensor does not accurately measure the density which the operator expects based on laboratory trials. ■ The characteristics of the fluid are outside the measuring points set at the factory or reference conditions under which the flowmeter has been calibrated. ■ The plant is used solely for measuring a fluid whose density is to be determined very accurately under constant conditions. 2-point density adjustment (with two fluids) This type of adjustment must always be carried out when the measuring tubes are changed mechanically, e.g. due to: ■ Deposits ■ Abrasion ■ Corrosion In such instances, the measuring tube resonance frequency is influenced in such a way that it is no longer compatible with the calibration data determined at the factory. The 2-point density adjustment takes these mechanically-based changes into account and calculates new, adjusted calibration data. Options: CANCEL MEASURE FLUID 1 MEASURE FLUID 2 DENSITY ADJUSTMENT Factory setting: CANCEL
RESTORE ORIGINAL (6488)	With this function the original density coefficient determined at the factory are restored. Options: NO YES Factory setting: NO


9.2.5 Function group PRESSURE CORRECTION



Function description	
BASIC FUNCTION → PROCESS PARAMETER → PRESSURE CORRECTION	
PRESSURE MODE (6500)	Use this function to configure an automatic pressure correction. In this way, the effect of a pressure deviation between the calibration and process pressures on the measured error for mass flow is compensated for, (see also Operating Instructions <i>Proline Promass 83</i>, BA 059D/06/en, Accuracy Chapter). Options: OFF MEASURED This selection is only available if a current input has been selected in the function ASSIGN CURRENT INPUT (5200) PRESSURE. The actual measured process pressure is read in for pressure correction via the current input. FIX A fixed process pressure for pressure correction is specified (see function PRESSURE (6501)). Factory setting: OFF
PRESSURE (6501)	 Note! This function is only available if FIX was selected in the PRESSURE MODE function (6500). Use this function to enter the value for the process pressure which should be used during pressure correction. User input: 7-digit floating-point number Factory setting: 0 bar g  Note! The appropriate unit is taken from the function group SYSTEM UNITS (see page 17).

9.3 Group SYSTEM PARAMETER

9.3.1 Function group CONFIGURATION




Function description BASIC FUNCTION → SYSTEM PARAMETER → CONFIGURATION	
INSTALLATION DIRECTION SENSOR (6600)	Use this function to reverse the sign of the flow direction, if necessary.  Note! Ascertain the actual direction of fluid flow with reference to the direction indicated by the arrow on the sensor (nameplate). Options: NORMAL (flow as indicated by the arrow) INVERSE (flow opposite to direction indicated by the arrow) Factory setting: NORMAL
DENSITY DAMPING (6602)	The density filter allows the sensitivity of the density measuring signal to be lowered with respect to variations in the density of the fluid, e.g. with inhomogeneous liquids. The damping acts on all functions and outputs of the measuring device. User input: max. 5-digit number, including unit: 0.00...100.00 s Factory setting: 0.00 s
FLOW DAMPING (6603)	Setting the filter depth of the digital filter. The sensitivity of the flow measurement signal can be reduced with respect to interference peaks (e.g. in the event of a high solid content, gas bubbles in the fluid etc.). The reaction time of the measuring device increases with every increase in the filter setting. The damping acts on all functions and outputs of the measuring device. User input: 0...100 s Factory setting: Liquid: 0,00 s Gas: 0,25 s
POSITIVE ZERO RETURN (6605)	Use this function to interrupt evaluation of measured variables. This is necessary when a piping system is being cleaned, for example. This setting acts on all function and outputs of the measuring device. Options: OFF ON (signal output is set to the “ZERO FLOW” value, temperature and density are still output) Factory setting: OFF

Function description BASIC FUNCTION → SYSTEM PARAMETER → CONFIGURATION	
TEMPERATURE MEASUREMENT (6606)	Use this function to switch between internal and external (via the current input) temperature measurement.  Note! This cell is only available if a current input is present. Options: INTERNAL EXTERNAL This option is only available if TEMPERATURE was selected in the function ASSIGN CURRENT INPUT (5200). Factory setting: INTERNAL


9.4 Group SENSOR DATA

9.4.1 Function group CONFIGURATION




Function description	
BASIC FUNCTION → SENSOR DATA → CONFIGURATION	
All sensor data (calibration factor, zero point and nominal diameter) are set at the factory and saved on the S-DAT sensor memory chip.  Caution! Under normal circumstances you should not change the following parameter settings, because changes affect numerous functions of the entire measuring facility in general and the accuracy of the measuring system in particular. For this reason, the functions described below cannot be changed even when you enter your personal code. Contact the E+H service organization if you have any questions about these functions.  Note! The individual values of the functions are also provided on the sensor nameplate.	
K-FACTOR (6800)	This function shows the current calibration factor for the sensor. Factory setting: Depends on nominal diameter and calibration
ZEROPOINT (6803)	This function shows the current zero point correction value for the sensor. Display: max. 5-digit number: -99999...+99999 Factory setting: Depends on calibration
NOMINAL DIAMETER (6804)	This function shows the nominal diameter for the sensor. Factory setting: Depends on the size of the sensor

9.4.2 Function group FLOW COEFFICIENT




Function description	
BASIC FUNCTION → SENSOR DATA → FLOW COEFFICIENT	
All flow coefficients are set at the factory. All the sensor's parameter settings are saved on the S-DAT memory chip. Contact the E+H service organization if you have any questions about these functions.	
TEMPERATURE COEFFICIENT KM (6840)	This function shows the temperature coefficient KM.
TEMPERATURE COEFFICIENT KM 2 (6841)	This function shows the temperature coefficient KM 2.
TEMPERATURE COEFFICIENT KT (6842)	This function shows the temperature coefficient KT.
CALIBRATION COEFFICIENT KD 1 (6843)	This function shows the calibration coefficient KD 1.
CALIBRATION COEFFICIENT KD 2 (6844)	This function shows the calibration coefficient KD 2.

9.4.3 Function group DENSITY COEFFICIENT



Function description	
BASIC FUNCTION → SENSOR DATA → DENSITY COEFFICIENT	
All density coefficients are set at the factory. All the sensor's parameter settings are saved on the S-DAT memory chip. Contact the E+H service organization if you have any questions about these functions.	
DENSITY COEFFICIENT C 0 (6850)	This function shows the actual density coefficient C 0.  Caution! A density adjustment can alter the calibration value of this coefficient.
DENSITY COEFFICIENT C 1 (6851)	This function shows the actual density coefficient C 1.  Caution! A density adjustment can alter the calibration value of this coefficient.
DENSITY COEFFICIENT C 2 (6852)	This function shows the actual density coefficient C 2.  Caution! A density adjustment can alter the calibration value of this coefficient.
DENSITY COEFFICIENT C 3 (6853)	This function shows the actual density coefficient C 3.  Caution! A density adjustment can alter the calibration value of this coefficient.
DENSITY COEFFICIENT C 4 (6854)	This function shows the actual density coefficient C 4.  Caution! A density adjustment can alter the calibration value of this coefficient.
DENSITY COEFFICIENT C 5 (6855)	This function shows the actual density coefficient C 5.  Caution! A density adjustment can alter the calibration value of this coefficient.

9.4.4 Function group ADDITIONAL COEFFICIENT



Function description	
BASIC FUNCTION → SENSOR DATA → ADDITIONAL COEFFICIENT	
All sensor data are set at the factory. All the sensor's parameter settings are saved on the S-DAT memory chip.  Caution! These functions are used for displaying device parameters only and consequently cannot be accessed. Contact the E+H service organization if you have any questions about these functions.	
MINIMUM FLUID TEMPERATURE (6860)	The lowest fluid temperature measured appears on the display.
MAXIMUM FLUID TEMPERATURE (6861)	The highest fluid temperature measured appears on the display.
MINIMUM TEMP. CARRIER TUBE (6862)	 Note! This function is not available for the Promass E measuring device. The lowest carrier tube temperature measured appears on the display.
MAXIMUM TEMPERATURE CARRIER TUBE (6863)	 Note! This function is not available for the Promass E measuring device. The highest carrier tube temperature measured appears on the display.

10 Block SPECIAL FUNCTION

Block	Groups	Function groups	Functions															
SPECIAL FUNCTION (H)	DENSITY FUNCTIONS (HCA) p. 141	⇕ ⇕ ⇕ ⇕ ⇕ ⇕ ⇕ ⇕ ⇕ ⇕	CONFIGURATION (700) p. 141	⇕ ⇕	DENSITY FUNCTION (7000) p. 141	⇕	REF. DENSITY CARRIER FL. (7001) p. 141	EXP. COEF. LIN. CARR. FL. (7002) p. 141	EXP. COEF. SOR. CARR. FL. (7003) p. 142	REF. DENSITY TARGET FLUID (7004) p. 142	EXP. COEF. LIN. TARG. FL. (7005) p. 142	EXP. COEF. SOR. TARG. FL. (7006) p. 143	LINEAR EXP. COEF. (7007) p. 143	SOR. EXPANSION COEFF. (7008) p. 143	REFERENCE TEMPERATURE (7009) p. 144			
			MODE (7021) p. 144	⇕														
			COEFFICIENT B3 (7039) p. 146															
			BATCH SELECTOR (720) p. 147	⇕ ⇕	BATCH NAME (7201) p. 147	ASSIGN BATCH VARIABLE (7202) p. 148	BATCH QUANTITY (7203) p. 148	FIX COMP. QUANT. (7204) p. 149	COMPENSATION MODE (7205) p. 149	CALCULATION MODE (7206) p. 151	BATCH STAGES (7208) p. 152	INPUT FORMAT (7209) p. 152						
			VALVE PARAMETER (722) p. 153	⇕ ⇕	OPEN VALVE 1 (7220) p. 153	CLOSE VALVE 1 (7221) p. 153	OPEN VALVE 2 (7222) p. 154	CLOSE VALVE 2 (7223) p. 154										
			SUPERVISION (724) p. 158	⇕ ⇕	MAXIMUM BATCHING TIME (7240) p. 158	MIN. BATCHING QUANTITY (7241) p. 159	MAX. BATCHING QUANTITY (7242) p. 160	PROGRESS NOTE (7243) p. 160	MAX. FLOW (7244) p. 161									
			OPERATION (726) p. 162	⇕ ⇕	BATCH PROCEDURE (7260) p. 162	BATCH UPWARDS (7261) p. 162	BATCH DOWNWARDS (7262) p. 163	BATCH COUNTER (7263) p. 163	BATCH SUM (7264) p. 163	RESET SUM/COUNTER (7265) p. 163								
			INFORMATION (728) p. 164	⇕ ⇕	INT. SWITCH POINT VALVE 1 (7280) p. 164	DRIP QUANTITY (7281) p. 164	VALVE 1 CLOSING TIME (7282) p. 164	BATCHING TIME (7283) p. 165										
			ADVANCED DIAGNOSIS (HEA) p. 166	⇕ ⇕ ⇕ ⇕ ⇕ ⇕ ⇕ ⇕ ⇕ ⇕	CONFIGURATION (740) p. 166	⇕ ⇕	REF. CONDITION USER (7401) p. 166	⇕	SELECT REF. CONDITION (7402) p. 166	WARNING MODE (7403) p. 166								
					ACQUISITION (741) p. 167	⇕ ⇕	ACQUISITION MODE (7410) p. 167	⇕	ACQUISITION PERIOD (7411) p. 167	ACQUISITION DO (7412) p. 167	RESET HISTORY (7413) p. 167							
MASS FLOW (742) p. 168	⇕ ⇕	REF. VALUE MASS FLOW (7420) p. 168			⇕	MASS FLOW (7421) p. 168	MINIMUM VALUE (7422) p. 168	MAXIMUM VALUE (7423) p. 168	MASS FLOW HISTORY (7424) p. 168	MASS FLOW DEVIATION (7425) p. 168	WARNING LEVEL (7426) p. 168							
DENSITY (743) p. 169	⇕ ⇕	REF. VALUE DENSITY (7430) p. 169			⇕	DENSITY (7431) p. 169	MINIMUM VALUE (7432) p. 169	MAXIMUM VALUE (7433) p. 169	DENSITY HISTORY (7434) p. 169	DENSITY DEVIATION (7435) p. 169	WARNING LEVEL (7436) p. 169							
REFERENCE DENSITY (744) p. 170	⇕ ⇕	REF. VALUE REF. DENSITY (7440) p. 170			⇕	REFERENCE DENSITY (7441) p. 170	MINIMUM VALUE (7442) p. 170	MAXIMUM VALUE (7443) p. 170	REF. DENSITY HISTORY (7444) p. 170	REF. DENSITY DEVIATION (7445) p. 170	WARNING LEVEL (7446) p. 170							
TEMPERATURE (745) p. 171	⇕ ⇕	REF. VALUE TEMPERATURE (7450) p. 171			⇕	TEMPERATURE (7451) p. 171	MINIMUM VALUE (7452) p. 171	MAXIMUM VALUE (7453) p. 171	TEMPERATURE HISTORY (7454) p. 171	TEMPERATURE DEVIATION (7455) p. 171	WARNING LEVEL (7456) p. 171							
TUBE DAMPING (746) p. 172	⇕ ⇕	REF. VALUE TUBE DAMP. (7460) p. 172			⇕	TUBE DAMPING (7461) p. 172	MINIMUM VALUE (7462) p. 172	MAXIMUM VALUE (7463) p. 172	TUBE DAMPING HISTORY (7464) p. 172	TUBE DAMPING DEVIATION (7465) p. 172	WARNING LEVEL (7466) p. 172							

Block	Groups	Function groups	Functions (continued)								
		⇕ ⇓									
		ELEC.-DYN. SENSORS (747) p. 173	⇐	REF. VALUE EL. DYN. SENS. (7470) p. 173	⇒	ELECTR.-DYN. SENSORS (7471) p. 173	MINIMUM VALUE (7472) p. 173	MAXIMUM VALUE (7473) p. 173	ELEC.-DYN. SENS. HISTORY (7474) p. 173	ELEC.-DYN. SENS. DEVIATION (7475) p. 173	WARNING LEVEL (7476) p. 174
		⇕ ⇓									
		OPERATING FREQUENCY FLUCT. (748) p. 175	⇐	REF. VALUE OP. FREQ. FLUCT. (7480) p. 175	⇒	OPERATING FREQUENCY FLUCT. (7481) p. 175	MINIMUM VALUE (7482) p. 175	MAXIMUM VALUE (7483) p. 175	OP. FREQ. FLUCT. HISTORY (7484) p. 175	OP. FREQ. FLUCT. DEVIATION (7485) p. 175	WARNING LEVEL (7486) p. 176
		⇕ ⇓									
		TUBE DAMPING FLUCT. (749) p. 177	⇐	REF. VALUE TUBE DAMP. FLUCT. (7490) p. 177	⇒	TUBE DAMPING FLUCT. (7491) p. 177	MINIMUM VALUE (7492) p. 177	MAXIMUM VALUE (7493) p. 177	TUBE DAMP. FLUCT. HISTORY (7494) p. 177	TUBE DAMP. FLUCT. DEVIATION (7495) p. 177	WARNING LEVEL (7496) p. 178

10.1 Group DENSITY FUNCTIONS

10.1.1 Function group CONFIGURATION

SPECIAL FUNCTION H ⇒ DENSITY FUNCTIONS HAA ⇒ CONFIGURATION 700

Function description SPECIAL FUNCTION → DENSITY FUNCTIONS → CONFIGURATION	
DENSITY FUNCTION (7000)	Use this function to select the desired density function which is used to calculate special density values or the percentage proportion of components in two-phase fluids. User input: OFF % MASS / % VOLUME %-BLACK LIQUOR °BAUME > 1 SG °BAUME < 1 SG °API °PLATO °BALLING °BRIX FLEXIBLE Factory setting: OFF
REFERENCE DENSITY CARRIER FLUID (7001)	 Note! This function is not available unless one of the following was selected in the DENSITY FUNCTION function (7000): ■ % MASS / % VOLUME ■ %-BLACK LIQUOR Use this function to enter the reference density (density at reference temp.) of the carrier fluid. This value is required for temperature-compensated calculation of the target fluid content in a two-phase fluid. User input: 5-digit floating-point number, incl. units Factory setting: 1.0000 kg/l  Note! ■ Carrier fluid = transporting liquid, (e.g. water) Target fluid = material transported (e.g. lime powder) ■ The appropriate unit is taken from the function UNIT REFERENCE DENSITY (0421) (see page 20).
EXPANSION COEFFICIENT LINEAR CARRIER FLUID (7002)	 Note! This function is not available unless one of the following was selected in the DENSITY FUNCTION function (7000): ■ % MASS / % VOLUME ■ %-BLACK LIQUOR Use this function to enter the fluid-specific linear expansion coefficient for the carrier fluid for linear temperature curves. This value is required for temperature-compensated calculation of the target fluid content in a two-phase fluid. User input: 5-digit floating-point number, including unit and sign Factory setting: 0.5000 e⁻³ [1/K]

Function description SPECIAL FUNCTION → DENSITY FUNCTIONS → CONFIGURATION	
SQR. EXPANSION COEFFICIENT CARRIER FLUID (7003)	 Note! This function is not available unless one of the following was selected in the DENSITY FUNCTION function (7000): ■ % MASS / % VOLUME ■ %-BLACK LIQUOR Use this function to enter the fluid-specific square expansion coefficient for the carrier fluid for nonlinear temperature curves. This value is required for temperature-compensated calculation of the target fluid content in a two-phase fluid. User input: 5-digit floating-point number, including unit and sign Factory setting: $0.0000 \text{ e}^{-6} [1/\text{K}^2]$
REFERENCE DENSITY TARGET FLUID (7004)	 Note! This function is not available unless one of the following was selected in the DENSITY FUNCTION function (7000): ■ % MASS / % VOLUME ■ %-BLACK LIQUOR Use this function to enter the reference density (density at reference temperature) of the carrier fluid. This value is required for temperature-compensated calculation of the target fluid content in a two-phase fluid. User input: 5-digit floating-point number, incl. units Factory setting: 1.0000 kg/l  Note! ■ Carrier fluid = transporting liquid, (e.g. water) Target fluid = material transported (e.g. lime powder) ■ The appropriate unit is taken from the function UNIT REFERENCE DENSITY (0421) (see page 20).
EXPANSION COEFFICIENT LINEAR TARGET FLUID (7005)	 Note! This function is not available unless one of the following was selected in the DENSITY FUNCTION function (7000): ■ % MASS / % VOLUME ■ %-BLACK LIQUOR Use this function to enter the fluid-specific linear expansion coefficient for the carrier fluid for linear temperature curves. This value is required for temperature-compensated calculation of the target fluid content in a two-phase fluid. User input: 5-digit floating-point number, including unit and sign Factory setting: $0.5000 \text{ e}^{-3} [1/\text{K}]$

Function description SPECIAL FUNCTION → DENSITY FUNCTIONS → CONFIGURATION	
SQR. EXPANSION COEFFICIENT TARGET FLUID (7006)	 Note! This function is not available unless one of the following was selected in the DENSITY FUNCTION function (7000): ■ % MASS / % VOLUME ■ %-BLACK LIQUOR Use this function to enter the fluid-specific square expansion coefficient for the carrier fluid for nonlinear temperature curves. This value is required for temperature-compensated calculation of the target fluid content in a two-phase fluid. User input: 5-digit floating-point number, including unit and sign Factory setting: 0.0000 e-6 [1/K²]
LINEAR EXPANSION COEFFICIENT (7007)	 Note! This function is not available unless one of the following was selected in the DENSITY FUNCTION function (7000): ■ °BAUME < 1 SG ■ °BAUME > 1 SG ■ °API ■ °PLATO ■ °BALLING ■ °BRIX Use this function to enter the fluid-specific linear expansion coefficient (for linear temperature curves), to calculate the temperature-compensated density functions. User input: 5-digit floating-point number, including unit and sign Factory setting: 0.5000 e-3 [1/K]
SQR. EXPANSION COEFFICIENT (7008)	 Note! This function is not available unless one of the following was selected in the DENSITY FUNCTION function (7000): ■ °BAUME < 1 SG ■ °BAUME > 1 SG ■ °API ■ °PLATO ■ °BALLING ■ °BRIX Use this function to enter the fluid-specific square expansion coefficient (for nonlinear temperature curves), to calculate the temperature-compensated density functions. User input: 5-digit floating-point number, including unit and sign Factory setting: 0.0000 e-6 [1/K²]

Function description SPECIAL FUNCTION → DENSITY FUNCTIONS → CONFIGURATION	
REFERENCE TEMPERATURE (7009)	 Note! This function is only available if OFF, °BRIX or FLEXIBLE was not selected in the function DENSITY FUNCTION (7000). Use this function to enter the reference temperature for the density functions and for calculating the corrected volume flow and the corrected volume. User input: 4-digit fixed-point number, including unit and sign Factory setting: 20 °C
MODE (7021)	 Note! This function is not available unless the FLEXIBLE setting was selected in the DENSITY FUNCTION function (7000). Use this function to select a user-specific method of calculating the concentration of the density and temperature measured. In order to use this function, the following values are required: ■ Concentration (see formula) ■ Currently measured density ■ Currently measured temperature The concentration is calculated from the density and temperature as follows: $K = A0 + A1 \cdot \rho + A2 \cdot \rho^2 + A3 \cdot \rho^3 + A4 \cdot \rho^4 + B1 \cdot T + B2 \cdot T^2 + B3 \cdot T^3$ K = Concentration ρ = currently measured density A0 = Value from function COEFFICIENT A0 (7032) A1 = Value from function COEFFICIENT A1 (7033) A2 = Value from function COEFFICIENT A2 (7034) A3 = Value from function COEFFICIENT A3 (7035) A4 = Value from function COEFFICIENT A4 (7036) B1 = Value from function COEFFICIENT B1 (7037) B2 = Value from function COEFFICIENT B2 (7038) B3 = Value from function COEFFICIENT B3 (7039) T = currently measured temperature in °C Options: % MASS 3D % VOLUME 3D % MASS 2D % VOLUME 2D OTHERS 3D OTHERS 2D Factory setting: % MASS 3D  Note! If the relation between concentration density and temperature is given as table, the equation coefficients can be determined by Endress+Hauser e.g. via a coefficient calculation program and transmitted to the measuring device.

Function description SPECIAL FUNCTION → DENSITY FUNCTIONS → CONFIGURATION	
CONCENTRATION SELECTOR (7022)	Use this function to select a concentration specification. There are four different concentration specifications available, via which various concentrations can be defined. Options: CONC. # 1 (or the name that has been defined in the function CONCENTRATION NAME (7031) for concentration specification 1) CONC. # 2 (or the name that has been defined in the function CONCENTRATION NAME (7031) for concentration specification 2) CONC. # 3 (or the name that has been defined in the function CONCENTRATION NAME (7031) for concentration specification 3) CONC. # 4 (or the name that has been defined in the function CONCENTRATION NAME (7031) for concentration specification 4) Factory setting: CONC. # 1  Note! ■ By selecting a concentration specification and the (subsequent) relevant settings, up to 4 different concentrations can be preconfigured and selected when needed. ■ All settings in the subsequent functions of this function group are each only valid for the concentration specification selected in the function CONCENTRATION SELECTOR (7022). In other words, the entry or option is assigned to the concentration specification currently selected (e.g. in the factory setting CONC. # 1).
CONCENTRATION NAME (7031)	Use this function to assign a specific name to the concentration specification. User input: max. 8-character text, permissible: A-Z, 0-9 Factory setting: Name of concentration specification (depends on selection in the function CONCENTRATION SELECTOR (7022), e.g. "CONC. # 1").
COEFFICIENT A0 (7032)	Coefficient A0 entry. User input: 5-digit floating-point number Factory setting: 0
COEFFICIENT A1 (7033)	Coefficient A1 entry. User input: 5-digit floating-point number Factory setting: 0

Function description SPECIAL FUNCTION → DENSITY FUNCTIONS → CONFIGURATION	
COEFFICIENT A2 (7034)	Coefficient A2 entry. User input: 5-digit floating-point number Factory setting: 0
COEFFICIENT A3 (7035)	Coefficient A3 entry. User input: 5-digit floating-point number Factory setting: 0
COEFFICIENT A4 (7036)	Coefficient A4 entry. User input: 5-digit floating-point number Factory setting: 0
COEFFICIENT B1 (7037)	 Note! This function does only appear if the option % MASS 3D, % VOLUME 3D or OTHERS 3D was selected in the function MODE (7021). Coefficient B1 entry. User input: 5-digit floating-point number Factory setting: 0
COEFFICIENT B2 (7038)	 Note! This function does only appear if the option % MASS 3D, % VOLUME 3D or OTHERS 3D was selected in the function MODE (7021). Coefficient B2 entry. User input: 5-digit floating-point number Factory setting: 0
COEFFICIENT B3 (7039)	 Note! This function does only appear if the option % MASS 3D, % VOLUME 3D or OTHERS 3D was selected in the function MODE (7021). Coefficient B3 entry. User input: 5-digit floating-point number Factory setting: 0

10.2 Group BATCHING FUNCTION

10.2.1 Function group CONFIGURATION

SPECIAL FUNCTION H ⇒ BATCHING FUNCTION HCA ⇒ CONFIGURATION 720

Function description SPECIAL FUNCTION → BATCHING FUNCTION → CONFIGURATION	
BATCH SELECTOR (7200)	Use this function to select a batching specification. There are six different batching specifications available by means of which different batchings can be defined. Options: BATCH # 1 (or the name which was defined for batching specification 1 in the function BATCH NAME (7201)) BATCH # 2 (or the name which was defined for batching specification 2 in the function BATCH NAME (7201)) BATCH # 3 (or the name which was defined for batching specification 3 in the function BATCH NAME (7201)) BATCH # 4 (or the name which was defined for batching specification 4 in the function BATCH NAME (7201)) BATCH # 5 (or the name which was defined for batching specification 5 in the function BATCH NAME (7201)) BATCH # 6 (or the name which was defined for batching specification 6 in the function BATCH NAME (7201)) Factory setting: BATCH #1  Note! ■ By selecting a batching specification and its related settings (explained below), up to 6 different batchings can be preconfigured and selected as necessary. ■ All the following functions in this function group, as well as the functions in the function groups VALVE PARAMETER (722) and SUPERVISION (724) are assigned to the batching specification selected here. ■ All the settings in the following functions of this function group are valid only for the batching specification selected in the function BATCH SELECTOR (7200). In other words, the entry or option is assigned to the batching specification currently selected (e.g. in the factory setting BATCH # 1).
BATCH NAME (7201)	Use this function to assign a specific name to the batching specification. User input: max. 8-character text, permissible: A-Z, 0-9 Factory setting: Name of batching specification (depends on selection in the function BATCH SELECTOR (7200), e.g. "BATCH # 1").  Note! Once an entry has been made (e.g. "BEER 33"), the batch name (BEER 33) appears in the home position when selecting the quantity and the name of the batching specification (e.g. "BATCH # 1") no longer appears.

Function description SPECIAL FUNCTION → BATCHING FUNCTION → CONFIGURATION	
ASSIGN BATCH VARIABLE (7202)	Use this function to assign a batching variable to the batching specification. Options: OFF MASS FLOW VOLUME FLOW CORRECTED VOLUME FLOW Advanced options with optional software package CONCENTRATION: TARGET MASS TARGET VOLUME TARGET CORRECTED VOLUME CARRIER MASS CARRIER VOLUME CARRIER CORRECTED VOLUME Factory setting: OFF  Note! ■ The possible assignments of the display functions are automatically extended. Once a batching variable has been selected (MASS or VOLUME), you can locally define the application-specific function of the minus key (start-stop-continue) and the plus key (stop-batching name/quantity) in the information line by means of the “batching menu” assignment. In this way, a direct batching control station is made available locally at the measuring device by means of the user interface and the controls. ■ Select OFF if the BATCHING functionality is no longer to be used. All settings related to the function (e.g. switching contact assigned to the relay output) must be assigned to another functionality.
BATCH QUANTITY (7203)	Use this function to define the quantity to be batched. User input: 5-digit floating-point number Factory setting: 0 [unit]  Note! ■ The appropriate unit is taken from the function group SYSTEM UNITS (ACA), (see page 17). ■ When the batching quantity entered here is achieved, valve 1 closes (see function CLOSE VALVE 1 (7221) on page 153).


Function description SPECIAL FUNCTION → BATCHING FUNCTION → CONFIGURATION	
FIX COMPENSATION QUANTITY (7204)	Use this function to specify a positive or negative compensation quantity. The compensation quantity balances out a constant, system-related incorrect quantity. This can be caused, for example, by a pump over-running or by the closing time of a valve. The compensation quantity is determined by the system operator. A negative compensation quantity must be specified for overbatching and a positive compensation quantity for underbatching.  Note! The compensation quantity affects batching quantity only and does not affect the after run compensation. User input: Floating-point number with sign (depends on nominal diameter) Factory setting: 0 [unit]  Note! ■ If the entry range is not sufficient for the compensation quantity, the batching quantity may have to be adjusted. ■ The appropriate unit is taken from the function group SYSTEM UNITS (ACA), (see page 17).
COMPENSATION MODE (7205)	Use this function to determine whether the after run quantity or a fixed compensation quantity should be taken into account at the next batching. Options: OFF MODE 1 MODE 2 Factory setting: OFF  Note! The pressure shock suppression must be switched off if MODE 1 or MODE 2 is selected in this function (see function PRESSURE SHOCK SUPPRESSION (6404) on page 123). Detailed explanations and information When batching using the optional software package BATCHING, process-related variable after run quantities or incorrect quantities can be determined and balanced out (by computer) by means of various functions. This ensures a high level of accuracy throughout the entire batching range. ■ Response when OFF is selected: The batching ends as soon as the quantity specified in the function BATCH QUANTITY (7203) has been achieved. If after running occurs, this is not recorded and is not taken into consideration during the next batching. In this way, in the event of process-related after running, the effective batched quantity is generally larger than the batching quantity specified. ■ Response when MODE 1 is selected: For short batchings and for batching cycles that follow on quickly from one other. Batching ends before the quantity specified in the function BATCH QUANTITY (7203) is achieved and the after run quantity is recorded. The exact batching switch-off time is calculated based on the previous after run quantities. The number of after run quantities which are to influence the calculation can be specified in the functions AVERAGING DRIP (7207) and CALCULATION MODE (7206). The after run quantity in MODE 1 is determined between the switch-off point and the first undershooting of the low flow cut off. Any subsequent fluid movements are not taken into account. (continued on next page)

Function description	
SPECIAL FUNCTION → BATCHING FUNCTION → CONFIGURATION	
COMPENSATION MODE (continued)	■ Response when MODE 2 is selected: For batchings where batching accuracy is vital and where process-related fluctuations in flow occur during after running. Batching ends before the quantity specified in the function BATCH QUANTITY (7203) is achieved and the after run quantity is recorded. The exact batching switch-off time is calculated based on the previous after run quantities. The number of after run quantities which are to influence the calculation can be specified in the functions AVERAGING DRIP (7207) and CALCULATION MODE (7206). The after run quantity in MODE 2 is determined between the switch-off point and the constant undershooting of the low-flow cut off. This means that the lower the setting is for the low-flow cut off, the longer the after run quantity is recorded. The batching is very accurate. Example diagram of a batching sequence and the respective response in MODE 1 and MODE 2: A0004711 $Q = \text{Flow}$ $t = \text{Time}$ $t_1 = \text{time period shorter than or equal to the maximum batching time}$ $A = \text{Coarse batching quantity}$ $B = \text{Fine batching quantity}$ $C = \text{After run quantity}$ $(\text{Effective batching quantity} = A + B + C)$ $1 = \text{Coarse batching starts and valve 2 opens (two-stage batching)}$ $2 = \text{Coarse batching ends / fine batching starts, valve 2 closes, valve 1 opens}$ $3 = \text{Fine batching ends, valve 1 closes (automatically when the specified batching quantity is achieved)}$ $4 = \text{After run quantity recording in MODE 1 ends}$ $5 = \text{After run quantity recording in MODE 2 ends}$ $a = \text{After run quantity recorded in MODE 1}$ $b = \text{After run quantity recorded in MODE 2}$ $s = \text{Low flow cut off}$

Function description SPECIAL FUNCTION → BATCHING FUNCTION → CONFIGURATION	
CALCULATION MODE (7206)	 Note! This function is only available if MODE 1 or MODE 2 was selected in the COMPENSATION MODE function (7206). Use this function to select the method for calculating the recorded after run quantities. Options: ALL All after run quantities are used in the calculation. SELECTION The after run quantities recorded are filtered. The smallest and largest after run quantity are not taken into account in the calculation (extreme value filter). Factory setting: ALL  Note! Machine-related (larger) “extreme values”, occurring especially at startup, delay correction and distort real reproducibility. By selecting “SELECT”, these “extreme values” are not taken into account. Example: Function CALCULATION MODE (7206) = SELECTION Function AVERAGING DRIP (7207) = 5 From five after run quantities recorded, the largest and smallest are not used. From the remaining three after run quantities, an average after run quantity is calculated which is taken into account at the next batching.
AVERAGING DRIP (7207)	 Note! This function is only available if MODE 1 or MODE 2 was selected in the COMPENSATION MODE function (7206). Use this function to specify the number of after run quantities (cycles) which are included in calculating the batching compensation mode, MODE 1 or MODE 2.  Note! The value entered in this function influences the measuring system reaction time. If you specify: ■ a small calculation depth (low value entered) = measuring system reacts quickly to differing amount of after run quantities. ■ a large calculation depth (high value entered) = measuring system reacts slowly to changing after run quantities. User input: 0...100 Factory setting: 0 [cycles]

Function description	
SPECIAL FUNCTION → BATCHING FUNCTION → CONFIGURATION	
BATCH STAGES (7208)	Use this function to define the number of batching stages. Batching can be carried out in several stages, e.g. 2-stage batching with fast and precise batching. Options: 1-stage (1 valve or 1-stage batching) 2-stage (2 valves or 2-stage batching) Factory setting: 1-stage (1 valve or 1-stage batching)  Note! ■ The batching stage selection (number of valves) is directly dependent on the configuration of the outputs. For 2-stage batching two relay outputs must be available in the measuring device. ■ The functions available in the function group VALVE PARAMETER (page 153) are dependent on the number of batching stages (number of valves) selected in this function.
INPUT FORMAT (7209)	Use this function to define the entry format of the quantities for the switch points of the valves. Options: VALUE-INPUT (e.g. 10 [unit]) %-INPUT (e.g. 80 [%]) Factory setting: VALUE-INPUT  Note! The entry format selected in this function is also used in the function groups VALVE PARAMETER (page 153) and SUPERVISION (page 158).

10.2.2 Function group VALVE PARAMETER



Function description	
SPECIAL FUNCTION → BATCHING FUNCTION → VALVE PARAMETER	
The parameters for the switching contacts of up to 2 valves can be set in the following functions. The number of switching contacts (valves) available, and thus their settings in this group, is defined in the function BATCH STAGES (7208).  Note! The following functions are only available if at least one batch stage has been selected in the function BATCH SELECTOR (7200).	
OPEN VALVE 1 (7220)	Use this function to specify the quantity value at which contact 1 opens. This is used as a switch point for valve 1 to output via an assigned output. The quantity value is entered as a % or as an absolute value, depending on the option in the function INPUT FORMAT (7209). User input: 0 to max. value or 0 to 100% (related to the batch quantity) Factory setting: 0 [unit] or 0 [%]  Note! - Dynamic tracking for %-data: If the value is entered as a %, this %-value always refers to the batching quantity (e.g. 70% of a batching quantity of 10 liters = 7 liters). If the BATCH QUANTITY (7203) is adjusted (reduced/increased), the effective quantity switch point is automatically and dynamically adjusted (e.g. taking 70% and changing the batching quantity from 10 to 20 liters, the quantity switch point is adjusted from 7 liters to 14 liters). - Dynamic tracking for value-data: If you enter value-input, this value is “absolute” for batching quantities that do not change (e.g. always 7 liters for a batching quantity of 10 liters). If the batching quantity (7203) is adjusted (reduced/increased), the quantity switch point is automatically and dynamically adjusted/tracked (e.g. with a new batching quantity changing from 10 to 20 liters, the quantity switch point is adjusted from 7 liters to 14 liters). In other words, the existing value data is tracked as a percentage of the altered batching quantity.
CLOSE VALVE 1 (7221)	Use this function to display the quantity value at which contact 1 (valve 1) closes. The quantity value is displayed either as a % or as an absolute value, depending on the option in the function INPUT FORMAT (7209). Display: Value or 100% (corresponds to the batching quantity) Factory setting: 0 [unit] or 0 [%]  Note! The switching contact for valve 1 is the “main contact”, i.e. the closing function of valve 1 is firmly assigned to the batching quantity entered, (see function BATCH QUANTITY (7203) on page 148). In this way, function CLOSE VALVE 1 is also the basis for calculating the after run quantity.

Function description SPECIAL FUNCTION → BATCHING FUNCTION → VALVE PARAMETER	
OPEN VALVE 2 (7222)	Use this function to specify the quantity value at which contact 2 opens. This is used as a switch point for valve 2 to output via an assigned output. The quantity value is entered as a % or as an absolute value, depending on the option in the function INPUT FORMAT (7209). User input: 0 to max. value or 0 to 100% (related to the batch quantity) Factory setting: 0 [unit] or 0 [%]  Note! ■ Dynamic tracking for %-data: If the value is entered as a %, this %-value always refers to the batching quantity (e.g. 70% of a batching quantity of 10 liters = 7 liters). If the BATCH QUANTITY (7203) is adjusted (reduced/increased), the effective quantity switch point is automatically and dynamically adjusted (e.g. taking 70% and changing the batching quantity from 10 to 20 liters, the quantity switch point is adjusted from 7 liters to 14 liters). ■ Dynamic tracking for value-data: If you enter value-input, this value is “absolute” for batching quantities that do not change (e.g. always 7 liters for a batching quantity of 10 liters). If the batching quantity (7203) is adjusted (reduced/increased), the quantity switch point is automatically and dynamically adjusted/tracked (e.g. with a new batching quantity changing from 10 to 20 liters, the quantity switch point is adjusted from 7 liters to 14 liters). In other words, the existing value data is tracked as a percentage of the altered batching quantity.
CLOSE VALVE 2 (7223)	Use this function to specify the quantity value at which contact 2 closes. This is used as a switch point for valve 2 to output via an assigned output. The quantity value is entered as a % or as an absolute value, depending on the option in the function INPUT FORMAT (7209). User input: 0 to max. value or 0 to 100% (related to the batch quantity) Factory setting: 0 [unit] or 0 [%]  Note! ■ Dynamic tracking for %-data: If the value is entered as a %, this %-value always refers to the batching quantity (e.g. 70% of a batching quantity of 10 liters = 7 liters). If the BATCH QUANTITY (7203) is adjusted (reduced/increased), the effective quantity switch point is automatically and dynamically adjusted (e.g. taking 70% and changing the batching quantity from 10 to 20 liters, the quantity switch point is adjusted from 7 liters to 14 liters). ■ Dynamic tracking for value-data: If you enter value-input, this value is “absolute” for batching quantities that do not change (e.g. always 7 liters for a batching quantity of 10 liters). If the batching quantity (7203) is adjusted (reduced/increased), the quantity switch point is automatically and dynamically adjusted/tracked (e.g. with a new batching quantity changing from 10 to 20 liters, the quantity switch point is adjusted from 7 liters to 14 liters). In other words, the existing value data is tracked as a percentage of the altered batching quantity.

10.2.3 Examples of setting parameters for batching processes


The two examples in the next section clearly show the effect of different entries and options in the function group.

Example 1

The first example explains the parameter setting of various functions for carrying out batching and illustrates how functions are affected when the batching quantity is changed.

The following batching is to take place:

- 2-stage batching with a batching quantity of 10 kg in total.
- Coarse batching quantity of 8 kg. Valve 2 opens at the start of the batching and closes when 8 kg is achieved.
- Fine batching of 2 kg. Valve 1 opens at the start of the batching and closes (automatically) when the batching quantity (10 kg) is achieved.
- Once 9 kg have been batched a batching progress message should be generated.
- Value-input should be entered.



A0004670

v = Flow velocity [m/s]

t = Time

V_1 = Valve 1 open

V_2 = Valve 2 open

① = Start batching/coarse batching, valves 1 (7220) and 2 (7222) open

② = Valve 2 (7223) closes, coarse batching quantity achieved

③ = Batching progress message (7243)

④ = Valve 1 (7221) closes, end of batching

x = After run quantity

The following parameter settings must be made:

- Select the unit for batching:
Function UNIT MASS (0401) page 17 = kg (kilogram)
- Select the measured variable for batching:
Function ASSIGN BATCH VARIABLE (7202) page 148 = MASS FLOW
- Enter the batching quantity:
Function BATCH QUANTITY (7203) page 148 = 10 [kg]
- Select the entry format:
Function BATCH STAGES (7208) page 152 = 2-stage
- Select the entry format:
Function INPUT FORMAT (7209) page 152 = VALUE-INPUT
- Quantity data for when the first valve should open:
Function OPEN VALVE 1 (7220) page 153 = 0 [kg]
(valve 1 closes automatically when the batching quantity is achieved = 10 [kg], display in function CLOSE VALVE 1 (7221) page 153)

- Quantity data for when the second valve should open:
Function OPEN VALVE 2 (7224) page 154 = 0 [kg]
- Quantity data for when the second valve should close:
Function CLOSE VALVE 2 (7223) page 154 = 8 [kg]
- Quantity data for when the message should be generated:
Function PROGRESS NOTE (7243) page 160 = 9 [kg]

Example 1 a

Batching specifications identical to those in example 1, however the new batching quantity is 20 kg and the message should be generated once 18 kg are batched.

The following parameters must be set **manually**:

- Enter the new batching quantity:
Function BATCH QUANTITY (7203) page 148 = 20 [kg]
- New quantity data for when the message should be generated:
Function PROGRESS NOTE (7243) page 160 = 18 [kg]

The following functions are **automatically** adjusted to suit the new batching quantity:


- Function OPEN VALVE 1 = 0 [kg]
- Function OPEN VALVE 2 = 0 [kg]
- Function CLOSE VALVE 2 = 16 [kg]

Example 2

The second example explains the parameter settings of the various functions for batching with the entry format in % for the switch points of the valves.

The following batching is to take place:

- 2-stage batching with a batching quantity of 15 kg in total.
- Coarse batching quantity from 3 to 12 kg. Valve 2 opens when 20% (3 kg) of the batching quantity is achieved and closes when 80% (12 kg) is achieved.
- Valve 1 opens at the start of the batching and closes (automatically) when the batching quantity (15 kg) is achieved.
- %-input should be entered.



A0004684

v = Flow velocity [m/s]

t = Time

V_1 = Valve 1 open

V_2 = Valve 2 open

① = Start batching, valve 1 (7220) opens

② = Valve 2 (7222) opens, coarse batching quantity starts

③ = Valve 2 (7223) closes, coarse batching quantity achieved

④ = Valve 1 (7221) closes, end of batching

x = After run quantity

The following parameter settings must be made:

- Select the unit for batching:
Function UNIT MASS (0401) page 17 = kg (kilogram)
- Select the measured variable for batching:
Function ASSIGN BATCH VARIABLE (7202) page 148 = MASS FLOW
- Enter the batching quantity:
Function BATCH QUANTITY (7203) page 148 = 15 [kg]
- Select the entry format:
Function BATCH STAGES (7208) page 152 = 2-stage
- Select the entry format:
Function INPUT FORMAT (7209) page 152 = %-INPUT
- Percentage data for when the first valve should open:
Function OPEN VALVE 1 (7220) page 153 = 0 [%]
(Valve 1 closes automatically when the batching quantity is achieved = 15 [kg], display in function CLOSE VALVE 1 (7221) page 153)
- Percentage data for when the second valve should open:
Function OPEN VALVE 2 (7224) page 154 = 20 [%] corresponds to 3 kg
- Percentage data for when the second valve should close:
Function CLOSE VALVE 2 (7223) page 154 = 80 [%] corresponds to 12 kg

Example 2 a

Batching specifications identical to those in example 1, however the new batching quantity is 45 kg.


The following parameters must be set **manually** :

- Enter the new batching quantity:
Function BATCH QUANTITY (7203) page 148 = 45 [kg]

The following functions are **automatically** adjusted to suit the new batching quantity:

- Function OPEN VALVE 1 = 0 [%]
- Function OPEN VALVE 2 = 20 [%] corresponds to 9 kg
- Function CLOSE VALVE 2 = 80 [%] corresponds to 36 kg

10.2.4 Function group SUPERVISION




Function description	
SPECIAL FUNCTION → BATCHING FUNCTION → SUPERVISION	
MAXIMUM BATCHING TIME (7240)	Use this function to specify a maximum batching time. All valves close once the specified batching time elapses, (see functions CLOSE VALVE 1...2, see page 153 ff.). This function can be used for safety reasons, for example, to ensure all batching valves close in the event of a system fault. User input: 0...30000 s Factory setting: 0 s (= deactivated)  Caution! ■ When the batching quantity is adjusted (reduced/increased), (see function BATCH QUANTITY (7203) on page 148) there is no automatic adjustment, i.e. this value must be determined again and reentered, (see also fault message # 471 in the Operating Instructions <i>Proline Promass 83</i>, BA 059D/06/en, Troubleshooting Chapter). ■ Batching (START) is not possible when the fault message is active!  Note! ■ The function is not active if you enter 0 s (factory setting). ■ This means that the batching valves are not closed by means of this function. ■ As a factory setting, this function is assigned a fault message. This appears for 60 seconds. The fault message can be acknowledged earlier by changing a batching function. ■ If this function is intended more for general monitoring purposes or if there is a short time lapse between two batching processes, it is advisable to assign this function to a notice message, (see function ERROR CATEGORY on page 181). However, while the notice message is active (60 seconds) the next batching can be started and the notice message is acknowledged. ■ This function can be output via the switch output.

Function description SPECIAL FUNCTION → BATCHING FUNCTION → SUPERVISION	
MIN. BATCHING QUANTITY (7241)	Use this function to specify a minimum batching quantity. A message is generated if the minimum batching quantity was not achieved by the time batching ends (e.g. if after run mode is active). The quantity value is entered as a % or as an absolute value, depending on the option in the function INPUT FORMAT (7209). Application: Message stating that underbatching is present (e.g. the contents of the containers does not correspond to the quantity declared). User input: 0 to max. value or 0 to 100% (related to the batch quantity) Factory setting: 0 [unit] (= deactivated)  Caution! ■ When the batching quantity is adjusted (reduced/increased), (see function BATCH QUANTITY (7203) on page 148), there is no automatic adjustment, i.e. this value must be determined again and reentered (see also the fault message # 472 in the Operating Instructions <i>Proline Promass 83</i>, BA 059D/06/en, Troubleshooting Chapter). ■ Batching (START) is not possible when the fault message is active!  Note! ■ The function is not active if you enter 0 (factory setting). ■ As a factory setting, this function is assigned a fault message. This appears for 60 seconds. The fault message can be acknowledged earlier by changing a batching function. ■ If this function is intended more for general monitoring purposes or if there is a short time lapse between two batching processes, it is advisable to assign this function to a notice message, (see function ERROR CATEGORY on page 181). However, while the notice message is active (60 seconds) the next batching can be started and the notice message is acknowledged. ■ This function can be output via the switch output.

Function description SPECIAL FUNCTION → BATCHING FUNCTION → SUPERVISION	
MAX. BATCHING QUANTITY (7242)	Use this function to specify a maximum batching quantity. If the maximum batching quantity is exceeded during batching, all valves are closed, batching is stopped and a message is generated. The quantity value is entered as a % or as an absolute value, depending on the option in the function INPUT FORMAT (7209). Application: To avoid overbatching and thus prevent critical situations caused by fluid overflow arising in the plant, (e.g. plant standstill caused by safety level switches being triggered, contamination, product loss, etc.). User input: 0...2 x max. value or 0...200% (related to the batching quantity) Factory setting: 0 [unit] (= deactivated)  Caution! ■ When the batching quantity is adjusted (reduced/increased), (see function BATCH QUANTITY (7203) on page 148), there is no automatic adjustment, i.e. this value must be determined again and reentered (see also the fault message # 472 in the Operating Instructions <i>Proline Promass 83</i>, BA 059D/06/en, Troubleshooting Chapter). ■ Batching (START) is not possible when the fault message is active!  Note! ■ The function is not active if you enter 0 (factory setting). ■ As a factory setting, this function is assigned a fault message. This appears for 60 seconds. The fault message can be acknowledged earlier by changing a batching function. ■ If this function is intended more for general monitoring purposes or if there is a short time lapse between two batching processes, it is advisable to assign this function to a notice message, (see function ERROR CATEGORY on page 181). However, while the notice message is active (60 seconds) the next batching can be started and the notice message is acknowledged. ■ This function can be output via the switch output.
PROGRESS NOTE (7243)	Use this function to define a batching quantity at which a message should be generated. When the specified batching quantity is achieved, the message is generated and signaled via the output. The quantity value is entered as a % or as an absolute value, depending on the option in the function INPUT FORMAT (7209). Application: For longer batching processes when preparing or taking measures related to production (e.g. preparing to replace container, etc.). User input: 0 to max. value or 0 to 100% (related to the batch quantity) Factory setting: 0 [unit] (= deactivated)  Caution! When the batching quantity is adjusted (reduced/increased), (see function BATCH QUANTITY (7203) on page 148), there is no automatic adjustment, i.e. this value must be determined again and reentered, (see also notice message # 473 in the Operating Instructions <i>Proline Promass 83</i>, BA 059D/06/en, Troubleshooting Chapter).  Note! ■ The function is not active if you enter 0 (factory setting). ■ This function can be output via the switch output. ■ The batching progress message remains active until batching ends.

Function description	
SPECIAL FUNCTION → BATCHING FUNCTION → SUPERVISION	
MAX. FLOW (7244)	A maximum flow value can be specified in this function. The batching process is aborted and all the valves are closed if the specified flow value is overshoot. Application: This function can be used for safety reasons, for example, to ensure all batching valves close in the event of a system fault. User input: 5-digit floating-point number Factory setting: 0 [unit] (= deactivated)  Note! ■ The appropriate unit is taken depending on the process variable selected in the ASSIGN BATCH VARIABLE parameter and the unit configured in the SYSTEM UNITS function group. ■ The function is not active if you enter 0 (factory setting). ■ If the batching process is aborted because the specified flow value is overshoot, the parameter BATCH COUNTER is not incremented. ■ New error message > MAX. FLOW with the error number #474. The error message is output automatically after 60 s. In the function ASSIGN PROCESS ERROR (8002), you can use the ERROR CATEGORY (8003) to define whether this should be treated as a fault or notice message. Factory setting = FAULT MESSAGE


10.2.5 Function group OPERATION




Function description	
SPECIAL FUNCTION → BATCHING FUNCTION → OPERATION	
BATCH PROCEDURE (7260)	Use this function to control a batching process. The batching can be started manually or a batching already running can be interrupted or stopped at any time. Options: STOP (Stop batching) START (Start batching) HOLD (Interrupt batching) GO ON (Continue batching) Factory setting: STOP  Note! ■ This function can also be controlled via the status input, (see function ASSIGN STATUS INPUT (5000) on page 112). ■ If the information line has been assigned to BATCHING MENU (see page 50), the application-specific functions of the minus key (START-STOP) and the plus key (HOLD-GO ON / batching specification) are defined locally. In this way, a direct batching control station is available locally at the measuring device by means of the user interface (not access-protected). ■ In the event of a fault: – during the batching process, the batching is canceled (STOP) and the local display alternates between displaying the batching menu and the fault message. ■ If the positive zero return is activated, (see page 133): – during the batching process, the batching is canceled (STOP). – during a pause in the batching (option HOLD), the batching cannot be restarted, (see also notice messages # 571 and # 572 in the Operating Instructions <i>Proline Promass 83</i>, BA 059D/06/en, Chapter Troubleshooting).
BATCH UPWARDS (7261)	In this function the batching progress can be read upwards, i.e. starting at 0 the quantity displayed increases until the batching process is complete. Display: Floating-point number incl. unit  Note! The value of this function can be output via the current output.

Function description SPECIAL FUNCTION → BATCHING FUNCTION → OPERATION	
BATCH DOWNWARDS (7262)	In this function the batching progress can be read downwards, i.e. starting from the batching quantity, the quantity displayed decreases until the batching process is complete. Display: Floating-point number incl. unit  Note! The value of this function can be output via the current output.
BATCH COUNTER (7263)	Use this function to display the number of batchings carried out. Display: max. 7-digit floating-point number Factory setting: 0  Note! ■ The batching quantity totalizer can be reset to 0 via the function RESET SUM/COUNTER (7265). ■ This function is reset to 0 (zero) if a different batching specification is selected in the function BATCH SELECTOR (7200).
BATCH SUM (7264)	Use this function to display the effective overall total of all the batchings carried out. Display: max. 7-digit floating-point number [unit] Factory setting: 0 [unit]  Note! ■ E.g. in 2-stage batching the effective overall total is calculated from the coarse batching quantity, fine batching quantity and after run quantity. ■ The total batching quantity can be reset to 0 via the function RESET SUM/COUNTER (7265). ■ This function is reset to 0 (zero) if a different batching specification is selected in the function BATCH SELECTOR (7200).
RESET SUM/COUNTER (7265)	Use this function to reset the batch counter and the batch sum to zero. User input: NO YES Factory setting: NO  Note! The batch counter and the batch sum can also be reset via the batching menu (information line on the local display).

10.2.6 Function group INFORMATION



Function description	
SPECIAL FUNCTION → BATCHING FUNCTION → INFORMATION	
INTERNAL SWITCH POINT VALVE 1 (7280)	Use this function to display the internal switch point of valve 1 (see function CLOSE VALVE 1 (7221) on page 153). The value displayed takes the fixed correction quantity and / or the calculated after run quantity into account. Display: max. 7-digit floating-point number [unit]  Note! The appropriate unit is taken from the function group SYSTEM UNITS (ACA), (see page 17).
DRIP QUANTITY (7281)	Displays the after run calculated (averaged) internally. The value displayed can be overwritten in this function and the after run can thus be adjusted. The after run quantity is used to optimize the internal switch point of valve 1. User input: 0...quantity [unit]  Note! The after run, entered in this function, is only used for the first batching process. For the second and following batching processes, the internally calculated after run will be used again. The appropriate unit is taken from the function group SYSTEM UNITS (ACA), (see page 17). Factory setting: 0 [unit]
VALVE 1 CLOSING TIME (7282)	Use this function to display the valve closing time calculated internally. Display: max. 7-digit floating-point number [ms]  Note! ■ The valve closing time is the period between the switch point of valve 1 and the first undershooting of the low flow cut off. ■ The data can only be taken as a general trend.

Function description	
SPECIAL FUNCTION → BATCHING FUNCTION → INFORMATION	
BATCHING TIME (7283)	In this function, you can read the batching time for the current or completed batching process, i.e. starting at 0 seconds, the time displayed increases until the batching process is complete. Application: This BATCHING TIME refers to the batch quantity determined in the BATCH SUM function for the current or last batching process.  A0001170-en Display: max. 7-digit floating-point number  Note! ■ Behavior when controlling batching process via function BATCH PROCEDURE: – STOP ⇒ BATCHING TIME is not reset and stays at the current value. – START ⇒ BATCHING TIME is reset and starts with the value 0 – HOLD ⇒ BATCHING TIME is not reset and stays at the current value. – GO ON ⇒ BATCHING TIME is not reset and continues updating on the basis of the last time value ■ The BATCHING TIME is also updated during the batching process

10.3 Group ADVANCED DIAGNOSIS

10.3.1 Function group CONFIGURATION

SPECIAL FUNCTION H ⇒ ADVANCED DIAGNOSIS HEA ⇒ CONFIGURATION 740	
Function description SPECIAL FUNCTION → ADVANCED DIAGNOSIS → CONFIGURATION	
REFERENCE CONDITION USER (7401)	Use this function to start determining the user reference status. The following values are determined: ■ MASS FLOW ■ DENSITY ■ REFERENCE DENSITY ■ TEMPERATURE ■ TUBE DAMPING ■ ELECTRODYNAMIC SENSORS ■ OPERATING FREQUENCY FLUCTUATION ■ TUBE DAMPING FLUCTUATION Options: CANCEL START Factory setting: CANCEL
SELECT REFERENCE CONDITION (7402)	Use this function to select the reference status which should be used to compare the advanced diagnosis parameters (see function ACQUISITION MODE (7410) on page 167). Options: FACTORY USER Factory setting: FACTORY
WARNING MODE (7403)	Use this function to determine whether a warning should be generated when there is a deviation between the reference status (FACTORY or USER, see function SELECT REFERENCE CONDITION (7402)) and the current measuring values. The values of the following functions are compared to the reference status : ■ MASS FLOW (7421) ■ DENSITY (7431) ■ REFERENCE DENSITY (7441) ■ TEMPERATURE (7451) ■ TUBE DAMPING (7461) ■ ELECTRODYNAMIC SENSORS (7471) ■ OPERATING FREQUENCY FLUCTUATION (7481) ■ TUBE DAMPING FLUCTUATION (7491) Options: OFF ON Factory setting: OFF

10.3.2 Function group ACQUISITION

SPECIAL FUNCTION H



ADVANCED DIAGNOSIS HEA




CONFIGURATION 740



ACQUISITION 741


Function description	
SPECIAL FUNCTION → ADVANCED DIAGNOSIS → ACQUISITION	
ACQUISITION MODE (7410)	Use this function to specify whether the advanced diagnosis parameters should be determined on a periodical or single-shot basis. Options: OFF PERIODICAL SINGLE SHOT Factory setting: OFF  Note! See the Chapter on “Commissioning” in the Operating Instructions <i>Proline Promass 83</i>, BA 059D/06/en for more information on advanced diagnosis.
ACQUISITION PERIOD (7411)	 Note! This function is not available unless PERIODICAL was selected in the ACQUISITION MODE function (7410). Use this function to specify the time interval after which the advanced diagnosis parameters should be taken. The time interval starts with the confirmation of the input. User input: 0...99999 s Factory setting: 3600 s  Note! A reference status must be defined prior to determining the diagnosis parameters, see function SELECT REFERENCE CONDITION (7402).
ACQUISITION DO (7412)	 Note! This function is not available unless SINGLE SHOT was selected in the ACQUISITION MODE function (7410). Use this function to start determining the advanced diagnosis parameters on a single-shot basis. Options: START – CANCEL Factory setting: CANCEL  Note! A reference status must be defined prior to determining the diagnosis parameters, see function SELECT REFERENCE CONDITION (7402).
RESET HISTORY (7413)	Use this function to delete all history values. Options: YES – NO Factory setting: NO

10.3.3 Function group MASS FLOW




Function description	
SPECIAL FUNCTION → ADVANCED DIAGNOSIS → MASS FLOW	
Note! The appropriate unit is taken from the function UNIT MASS FLOW (0400) (see page 17).	
REFERENCE VALUES MASS FLOW (7420)	The reference value for the mass flow appears on the display. Display: 5-digit floating-point number, including unit and sign
MASS FLOW (7421)	The measured mass flow appears on the display. Display: 5-digit floating-point number, including unit and sign
MINIMUM VALUE (7422)	The lowest mass flow value since the saved values were last reset appears on the display. Display: 5-digit floating-point number, including unit and sign
MAXIMUM VALUE (7423)	The highest mass flow value since the saved values were last reset appears on the display. Display: 5-digit floating-point number, including unit and sign
MASS FLOW HISTORY (7424)	The last ten mass flow values since the saved values were last reset appear on the display. Display: 5-digit floating-point number, including unit and sign
MASS FLOW DEVIATION (7425)	This function displays deviation between the measured mass flow and the reference values (FACTORY or USER), see page 166, selected in the function SELECT REFERENCE CONDITION (7402). Display: 5-digit floating-point number, including unit and sign
WARNING LEVEL (7426)	Note! This function is not available unless ON was selected in the WARNING MODE function (7403). Use this function to specify a limit value for the mass flow. A notice message is generated if the limit value is exceeded. User input: 0...99999 [Mass flow unit] Factory setting: 90000 kg/h

10.3.4 Function group DENSITY




Function description	
SPECIAL FUNCTION → ADVANCED DIAGNOSIS → DENSITY	
 Note! The appropriate unit is taken from the function UNIT DENSITY (0420) (see page 20).	
REFERENCE VALUE DENSITY (7430)	The reference value for the density appears on the display. Display: 5-digit floating-point number, incl. units
DENSITY (7431)	The measured density appears on the display. Display: 5-digit floating-point number, incl. units
MINIMUM VALUE (7432)	The lowest density value since the saved values were last reset appears on the display. Display: 5-digit floating-point number, incl. units
MAXIMUM VALUE (7433)	The highest density value since the saved values were last reset appears on the display. Display: 5-digit floating-point number, incl. units
DENSITY HISTORY (7434)	The last ten density values since the saved values were last reset appear on the display. Display: 5-digit floating-point number, incl. units
DENSITY DEVIATION (7435)	This function displays the deviation between the measured density and the reference values (FACTORY or USER), see page 166, selected in the function SELECT REFERENCE CONDITION (7402). Display: 5-digit floating-point number, incl. units
WARNING LEVEL (7436)	 Note! This function is not available unless ON was selected in the WARNING MODE function (7403). Use this function to specify a limit value for the density. A notice message is generated if the limit value is exceeded. User input: 0...99999 [%] Factory setting: 100%

10.3.5 Function group REFERENCE DENSITY




Function description SPECIAL FUNCTION → ADVANCED DIAGNOSIS → REFERENCE DENSITY	
 Note! The appropriate unit is taken from the function UNIT REFERENCE DENSITY (0421) (page 20).	
REFERENCE VALUE REFERENCE DENSITY (7440)	The reference value for the reference density appears on the display. Display: 5-digit floating-point number, incl. units
REFERENCE DENSITY (7441)	The measured reference density appears on the display. Display: 5-digit floating-point number, incl. units
MINIMUM VALUE (7442)	The lowest reference density value since the saved values were last reset appears on the display. Display: 5-digit floating-point number, incl. units
MAXIMUM VALUE (7443)	The highest reference density value since the saved values were last reset appears on the display. Display: 5-digit floating-point number, incl. units
REFERENCE DENSITY HISTORY (7444)	The last ten reference density values since the saved values were last reset appear on the display. Display: 5-digit floating-point number, incl. units
REFERENCE DENSITY DEVIATION (7445)	This function displays the deviation between the measured reference density and the reference values (FACTORY or USER), see page 166, selected in the function SELECT REFERENCE CONDITION (7402). Display: 5-digit floating-point number, incl. units
WARNING LEVEL (7446)	 Note! This function is not available unless ON was selected in the WARNING MODE function (7403). Use this function to specify a limit value for the reference density. A notice message is generated if the limit value is exceeded. User input: 0...99999 [%] Factory setting: 100%

10.3.6 Function group TEMPERATURE



Function description	
SPECIAL FUNCTION → ADVANCED DIAGNOSIS → TEMPERATURE	
 Note! The appropriate unit is taken from the function UNIT TEMPERATURE (0422) (see page 21).	
REFERENCE VALUE TEMPERATURE (7450)	The reference value for the temperature appears on the display. Display: 5-digit floating-point number, including unit and sign
TEMPERATURE (7451)	The currently measured temperature appears on the display. Display: 5-digit floating-point number, including unit and sign
MINIMUM VALUE (7452)	The lowest temperature value since the saved values were last reset appears on the display. Display: 5-digit floating-point number, including unit and sign
MAXIMUM VALUE (7453)	The highest temperature value since the saved values were last reset appears on the display. Display: 5-digit floating-point number, including unit and sign
TEMPERATURE HISTORY (7454)	The last ten temperature values since the saved values were last reset appear on the display. Display: 5-digit floating-point number, including unit and sign
TEMPERATURE DEVIATION (7455)	This function displays the deviation between the currently measured temperature and the reference values (FACTORY or USER), see page 166, selected in the function SELECT REFERENCE CONDITION (7402). Display: 5-digit floating-point number, including unit and sign
WARNING LEVEL (7456)	 Note! This function is not available unless ON was selected in the WARNING MODE function (7403). Use this function to specify a limit value for the temperature. A notice message is generated if the limit value is exceeded. User input: 0...99999 °C Factory setting: 100 °C

10.3.7 Function group TUBE DAMPING



Function description	
SPECIAL FUNCTION → ADVANCED DIAGNOSIS → TUBE DAMPING	
REFERENCE VALUE TUBE DAMPING (7460)	The reference value for tube damping appears on the display. Display: 5-digit floating-point number
TUBE DAMPING (7461)	The measured tube damping appears on the display. Display: 5-digit floating-point number
MINIMUM VALUE (7462)	The lowest tube damping value since the saved values were last reset appears on the display. Display: 5-digit floating-point number
MAXIMUM VALUE (7463)	The highest tube damping value since the saved values were last reset appears on the display. Display: 5-digit floating-point number
TUBE DAMPING HISTORY (7464)	The last ten tube damping values since the saved values were last reset appears on the display. Display: 5-digit floating-point number
TUBE DAMPING DEVIATION (7465)	This function displays the deviation between the measured tube damping and the reference values (FACTORY or USER), see page 166, selected in the function SELECT REFERENCE CONDITION (7402). Display: 5-digit floating-point number
WARNING LEVEL (7466)	 Note! This function is not available unless ON was selected in the WARNING MODE function (7403). Use this function to specify a limit value for tube damping. A notice message is generated if the limit value is exceeded. User input: 0...99999 [%] Factory setting: 1000%

10.3.8 Function group ELECTRODYNAMIC SENSORS

SPECIAL FUNCTION H

⇒

ADVANCED DIAGNOSIS HEA

⇒

CONFIGURATION 740

⇓

ACQUISITION 741

⇓

MASS FLOW 742

⇓

DENSITY 743

⇓

REFERENCE DENSITY 744

⇓

TEMPERATURE 745

⇓

TUBE DAMPING 746


⇓

ELEC.-DYN. SENSORS 747

Function description	
SPECIAL FUNCTION → ADVANCED DIAGNOSIS → ELECTRODYNAMIC SENSORS	
REFERENCE VALUE ELECTRODYNAMIC SENSORS (7470)	The reference value for the electrodynamic sensors appears on the display. Display: 5-digit floating-point number
ELECTRODYNAMIC SENSORS (7471)	The measuring values for the electrodynamic sensors appear on the display. Display: 5-digit floating-point number
MINIMUM VALUE (7472)	The lowest value of the electrodynamic sensors since the saved values were last reset appears on the display. Display: 5-digit floating-point number
MAXIMUM VALUE (7473)	The highest value of the electrodynamic sensors since the saved values were last reset appears on the display. Display: 5-digit floating-point number
ELECTRODYNAMIC SENSOR HISTORY (7474)	The last ten values of the electrodynamic sensors since the saved values were last reset appear on the display. Display: 5-digit floating-point number
ELECTRODYNAMIC SENSOR DEVIATION (7475)	This function displays the deviation between the measuring values for the electrodynamic sensors and the reference values (FACTORY or USER), see page 166, selected in the function SELECT REFERENCE CONDITION (7402) is displayed. Display: 5-digit floating-point number

Function description	
SPECIAL FUNCTION → ADVANCED DIAGNOSIS → ELECTRODYNAMIC SENSORS	
WARNING LEVEL (7476)	 Note! This function is not available unless ON was selected in the WARNING MODE function (7403). Use this function to specify a limit value for the electrodynamic sensors. A notice message is generated if the limit value is exceeded. User input: 0...99999 [%] Factory setting: 100%


10.3.9 Function group OPERATING FREQUENCY FLUCTUATION



Function description	
SPECIAL FUNCTION → ADVANCED DIAGNOSIS → OPERATING FREQUENCY FLUCTUATION	
REFERENCE VALUE OPERATING FREQUENCY FLUCTUATION (7480)	The reference value for the fluctuation of the operating frequency appears on the display. Display: 5-digit floating-point number, Hz
OPERATING FREQUENCY FLUCTUATION (7481)	The measured fluctuation of the operating frequency appears on the display. Display: 5-digit floating-point number, Hz
MINIMUM VALUE (7482)	The lowest value of the operating frequency fluctuation since the saved values were last reset appears on the display. Display: 5-digit floating-point number, Hz
MAXIMUM VALUE (7483)	The highest value of the operating frequency fluctuation since the saved values were last reset appears on the display. Display: 5-digit floating-point number, Hz
OPERATING FREQUENCY FLUCTUATION HISTORY (7484)	The last ten values of the operating frequency fluctuation since the saved values were last reset appear on the display. Display: 5-digit floating-point number, Hz
OPERATING FREQUENCY FLUCTUATION DEVIATION (7485)	This function displays the deviation between the measured deviation of the operating frequency and the reference values (FACTORY or USER) selected in the function SELECT REFERENCE CONDITION (7402) see page 166. Display: 5-digit floating-point number, Hz

Function description	
SPECIAL FUNCTION → ADVANCED DIAGNOSIS → OPERATING FREQUENCY FLUCTUATION	
WARNING LEVEL(7486)	 Note! This function is not available unless ON was selected in the WARNING MODE function (7403). Use this function to specify a limit value for the operating frequency fluctuation. A notice message is generated if the limit value is exceeded. User input: 0...99999 Hz Factory setting: 1000 Hz

10.3.10 Function group TUBE DAMPING FLUCTUATION



Function description	
SPECIAL FUNCTION → ADVANCED DIAGNOSIS → TUBE DAMPING FLUCTUATION	
REFERENCE VALUE TUBE DAMPING FLUCTUATION (7490)	The reference value for the fluctuation of the tube damping appears on the display. Display: 5-digit floating-point number
TUBE DAMPING FLUCTUATION (7491)	The measured fluctuation of the tube damping appears on the display. Display: 5-digit floating-point number
MINIMUM VALUE (7492)	The lowest value of the tube damping since the saved values were last reset appears on the display. Display: 5-digit floating-point number
MAXIMUM VALUE (7493)	The highest value of the tube damping fluctuation since the saved values were last reset appears on the display. Display: 5-digit floating-point number
TUBE DAMPING FLUCTUATION HISTORY (7494)	The last ten values of the tube damping fluctuation since the saved values were last reset appear on the display. Display: 5-digit floating-point number
TUBE DAMPING FLUCTUATION DEVIATION (7495)	This function displays the deviation between the measured deviation of the tube damping and the reference values (FACTORY or USER) selected in the function SELECT REFERENCE CONDITION (7402) see page 166. Display: 5-digit floating-point number

Function description	
SPECIAL FUNCTION → ADVANCED DIAGNOSIS → TUBE DAMPING FLUCTUATION	
WARNING LEVEL (7496)	 Note! This function is not available unless ON was selected in the WARNING MODE function (7403). Use this function to specify a limit value for the tube damping fluctuation. A notice message is generated if the limit value is exceeded. User input: 0...99999 Factory setting: 1000

11 Block SUPERVISION

Block	Groups	Function groups	Functions									
SUPERVISION (U)	SYSTEM (JAA) p. 180	CONFIGURATION (800) p. 180	⇕	ASSIGN SYS. ERROR (8000) p. 180	⇕	ERROR CATEGORY (8001) p. 180	ASSIGN PROC. ERROR (8002) p. 180	ERROR CATEGORY (8003) p. 181	ACKNOWL. FAULTS (8004) p. 181	ALARM DELAY (8005) p. 181	REMOVE SW-OPTION (8006) p. 182	PERMANENT STORAGE (8007) p. 182
				⇕	⇕	⇕	⇕	⇕	⇕	⇕	⇕	⇕
	OPERATION (804) p. 185	⇕	⇕	ACT. SYS. CONDITION (8040) p. 183	⇕	PREV. SYS. CONDITION (8041) p. 183	SIM. FAILSAFE MODE (8042) p. 183	SIM. MEASURAND (8043) p. 183	VALUE SIM. MEASUR. (8044) p. 184	SYSTEM RESET (8046) p. 184	OPERATION HOURS (8048) p. 184	
				⇕	⇕	⇕	⇕	⇕	⇕	⇕	⇕	
	DEVICE (810) p. 185	⇕	⇕	DEVICE SOFTWARE (8100) p. 186	⇕							
				⇕	⇕							
	SENSOR (820) p. 185	⇕	⇕	SERIAL NUMBER (8200) p. 185	⇕	SENSOR TYPE (8201) p. 185	SW REV. NO. S-DAT (8205) p. 185					
				⇕	⇕	⇕	⇕					
	AMPLIFIER (822) p. 186	⇕	⇕	SW REV. NO. AMPLIFIER (8222) p. 186	⇕	SW REV. NO. T-DAT (8225) p. 186	LANGUAGE GROUP (8226) p. 186					
				⇕	⇕	⇕	⇕					
	F-CHIP (824) p. 187	⇕	⇕	STATUS F-CHIP (8240) p. 187	⇕	SYSTEM OPTION (8241) p. 187	SW REV. NO F-CHIP (8244) p. 187					
				⇕	⇕	⇕	⇕					
	I/O MODULE (830) p. 187	⇕	⇕	I/O MODULE TYPE (8300) p. 187	⇕	SW REV.-NO. I/O MODULE (8303) p. 187						
				⇕	⇕	⇕	⇕					
	I/O SUBMODULE 1 (832) p. 188	⇕	⇕	SUB-IN-/OUTPUT TYP (8320) p. 188	⇕	SW REV. SUB-I/O (8323) p. 188						
				⇕	⇕	⇕	⇕					
	I/O SUBMODULE 2 (834) p. 188	⇕	⇕	SUB-IN-/OUTPUT TYP (8340) p. 188	⇕	SW REV. SUB-I/O (8343) p. 188						
				⇕	⇕	⇕	⇕					
	I/O SUBMODULE 3 (836) p. 188	⇕	⇕	SUB-IN-/OUTPUT TYP (8360) p. 188	⇕	SW REV. SUB-I/O (8363) p. 188						
				⇕	⇕	⇕	⇕					
	I/O SUBMODULE 4 (838) p. 188	⇕	⇕	SUB-IN-/OUTPUT TYP (8380) p. 188	⇕	SW REV. SUB-I/O (8383) p. 188						
				⇕	⇕	⇕	⇕					

11.1 Group SYSTEM


11.1.1 Function group CONFIGURATION

SUPERVISION	J	⇒	SYSTEM	JAA	⇒	CONFIGURATION	800
Function description SUPERVISION → SYSTEM → CONFIGURATION							
ASSIGN SYSTEM ERROR (8000)		Use this function to view all system errors. By selecting a certain system error, its error category can be changed in the subsequent function ERROR CATEGORY (8001). Options: CANCEL List of system errors  Note! ■ You can exit this function as follows: select “CANCEL” and confirm with . ■ A list of possible system errors is provided in the Operating Instruction Operating Instructions <i>Proline Promass 83</i>, BA 059D/06/en/					
ERROR CATEGORY (8001)		 Note! This function is only available if a system error has been selected in the function ASSIGN SYSTEM ERROR (8000). Use this function to define whether a system error triggers a notice message or a fault message. If you select FAULT MESSAGES, all outputs respond to an error in accordance with their defined error response patterns. Options: NOTICE MESSAGES (display only) FAULT MESSAGES (outputs and display)  Note! Press the key  twice to call up the function ASSIGN SYSTEM ERROR (8000).					
ASSIGN PROCESS ERROR (8002)		Use this function to view all process errors. By selecting an individual process error, its error category can be changed in the subsequent function ERROR CATEGORY (8003). Options: CANCEL List of process errors  Note! ■ You can exit this function as follows: select “CANCEL” and confirm with . ■ A list of possible process errors is provided in the Operating Instruction Operating Instructions <i>Proline Promass 83</i>, BA 059D/06/en/					

Function description SUPERVISION → SYSTEM → CONFIGURATION	
ERROR CATEGORY (8003)	 Note! This function is only available if a process error has been selected in the function ASSIGN PROCESS ERROR (8002). Use this function to define whether a process error triggers a notice message or a fault message. If you select FAULT MESSAGES, all outputs respond to an error in accordance with their defined error response patterns. Options: NOTICE MESSAGES (display only) FAULT MESSAGES (outputs and display)  Note! Press the key  twice to call up the function ASSIGN PROCESS ERROR (8002).
ACKNOWLEDGE FAULTS (8004)	Use this function to define the measuring device's response to fault messages. Options: OFF The measuring device resumes normal operation when the fault is rectified. The fault message automatically disappears from the local display. ON The measuring device resumes normal operation when the fault is rectified. The fault message appears in the local display until it is acknowledged by pressing the  button. Factory setting: OFF
ALARM DELAY (8005)	Use this function to define a time span for which the criteria for an error have to be satisfied without interruption before a fault or notice message is generated. Depending on the setting and the type of error, this suppression acts on: ■ Display ■ Current output ■ Frequency output ■ Relay output ■ Current input User input: 0...100 s (in steps of one second) Factory setting: 0 s  Caution! If this function is activated, fault and notice messages are delayed by the time corresponding to the setting before being transmitted to the higher-order controller (process controller, etc.). It is therefore imperative to check in advance in order to make sure whether a delay of this nature could affect the safety requirements of the process. If fault and notice messages may not be suppressed, a value of 0 seconds must be entered here.

Function description	
SUPERVISION → SYSTEM → CONFIGURATION	
REMOVE SW-OPTION (8006)	 Note! This function is only available if: ■ The F-CHIP software options were saved beforehand ■ The F-CHIP is not located on the I/O board of the measuring device Deletes all F-CHIP software options, such as batching, density functions, etc. Options: 0 = NO 1 = YES Factory setting: NO  Caution! If process variables which are only available via the F-CHIP software options are assigned to the local display or the outputs, these have to be reconfigured. If reconfiguration does not take place, the local display and the totalizer are set to the factory setting and the outputs are set to OFF.
PERMANENT STRORAGE (8007)	This function indicates whether permanent storage of all parameters in the EEPROM has been switched on or off. Display: “OFF” or “ON” Factory setting: ON

11.1.2 Function group OPERATION




Function description SUPERVISION → SYSTEM → OPERATION	
ACTUAL SYSTEM CONDITION (8040)	Use this function to check the present system condition. Display: “SYSTEM OK” or the fault / notice message with the highest priority.
PREVIOUS SYSTEM CONDITION (8041)	Use this function to view the fifteen most recent fault and notice messages since measuring last started. Display: The 15 most recent fault or notice messages.
SIMULATION FAILSAFE MODE (8042)	Use this function to set all inputs, outputs and totalizers to their defined failsafe modes, in order to check whether they respond correctly. During this time, the message “SIMULATION FAILSAFE MODE” appears on the display. Options: ON OFF Factory setting: OFF
SIMULATION MEASURAND (8043)	Use this function to set all inputs, outputs and totalizers to their defined flow-response modes, in order to check whether they respond correctly. During this time, the message “SIMULATION MEASURAND” appears on the display. Options: OFF MASS FLOW VOLUME FLOW CORRECTED VOLUME FLOW DENSITY REFERENCE DENSITY TEMPERATURE Factory setting: OFF  Caution! ■ The measuring device cannot be used for measuring while this simulation is in progress. ■ The setting is not saved if the power supply fails.


Function description	
SUPERVISION → SYSTEM → OPERATION	
VALUE SIMULATION MEASURAND (8044)	 Note! The function is not visible unless the function SIMULATION MEASURAND (8043) is active. Use this function to define a freely selectable value (e.g. 12 m³/s). This is used to test the associated functions in the device itself and downstream signal loops. User input: 5-digit floating-point number [unit] Factory setting: 0 [unit]  Caution! ■ The setting is not saved if the power supply fails. ■ The appropriate unit is taken from the function group SYSTEM UNITS (ACA), (see page 17).
SYSTEM RESET (8046)	Use this function to perform a reset of the measuring system. Options: NO RESTART SYSTEM (restart without interrupting power supply) Factory setting: NO
OPERATION HOURS (8048)	The hours of operation of the device appear on the display. Display: Depends on the number of hours of operation elapsed: Hours of operation < 10 hours → display format = 0:00:00 (hr:min:sec) Hours of operation 10...10,000 hours → display format = 0000:00 (hr:min) Hours of operation > 10,000 hours → display format = 000000 (hr)

11.2 Group VERSION-INFO


11.2.1 Function group DEVICE



11.2.2 Function group SENSOR




11.2.3 Function group AMPLIFIER




Function description	
SUPERVISION → VERSION-INFO → AMPLIFIER	
DEVICE SOFTWARE (8100)	Displays the current device software version.
SOFTWARE REVISION NUMBER AMPLIFIER (8222)	Use this function to view the software revision number of the amplifier.
SOFTWARE REVISION NUMBER T-DAT (8225)	Use this function to view the software revision number of the software used to create the content of the T-DAT.
LANGUAGE GROUP (8226)	Use this function to view the language group. The following language groups can be ordered: WEST EU / USA, EAST EU / SCAND., ASIA , CHINA. Display: available language group  Note! ■ The language options of the available language group are displayed in the LANGUAGE (2000) function. ■ You can change the language group via the configuration software FieldCare. Please do not hesitate to contact your E+H sales office if you have any questions.

11.2.4 Function group F-CHIP




Function description	
SUPERVISION → VERSION-INFO → F-CHIP	
STATUS F-CHIP (8240)	Use this function to check whether an F-CHIP is installed and which software options are available.
SYSTEM OPTION (8241)	Note! This function is not available unless the measuring device is equipped an F-CHIP. The software options available in the measuring device appear on the display.
SOFTWARE REVISION NUMBER F-CHIP (8244)	Note! The F-CHIP must be available in order to access this function. Use this function to view the software revision number of the F-CHIP.

11.2.5 Function group I/O MODULE



Function description	
SUPERVISION → VERSION-INFO → I/O MODULE	
I/O MODULE TYPE (8300)	Use this function to view the configuration of the I/O module complete with terminal numbers.
SOFTWARE REVISION NUMBER I/O MODULE (8303)	Use this function to view the software revision number of the I/O module.

11.2.6 Function groups INPUT/OUTPUT 1...4



Function description	
SUPERVISION → VERSION-INFO → I/O SUBMODULE 1...4	
SUB-IN-/OUTPUT TYP: 1 = (8320), 2 = (8340), 3 = (8360), 4 = (8380)	Use this function to view the configuration complete with terminal numbers.
SOFTWARE REVISION NUMBER SUB-I/O TYPE 1 = (8323) 2 = (8343) 3 = (8363) 4 = (8383)	Use this function to view the software revision umber of the corresponding submodule.

12 Factory settings

12.1 SI units (not for USA and Canada)

12.1.1 Low flow cut off, full scale value, pulse value – Liquid

Nominal diam. [mm]	Low flow cut off (approx. v = 0.04 m/s)		Full scale value (approx. v = 2.0 m/s)		Pulse value (approx. 2 pulse/s at 2.0 m/s)	
1	0.08	kg/h	4	kg/h	0.001	kg/p
2	0.40	kg/h	20	kg/h	0.010	kg/p
4	1.80	kg/h	90	kg/h	0.010	kg/p
8	8.00	kg/h	400	kg/h	0.100	kg/p
15	26.00	kg/h	1300	kg/h	0.100	kg/p
15 FB	72.00	kg/h	3600	kg/h	1.000	kg/p
25	72.00	kg/h	3600	kg/h	1.000	kg/p
25 FB	180.00	kg/h	9000	kg/h	1.000	kg/p
40	180.00	kg/h	9000	kg/h	1.000	kg/p
40 FB	300.00	kg/h	15000	kg/h	10.000	kg/p
50	300.00	kg/h	15000	kg/h	10.000	kg/p
50 FB	720.00	kg/h	36000	kg/h	10.000	kg/h
80	720.00	kg/h	36000	kg/h	10.000	kg/p
100	1200.00	kg/h	60000	kg/h	10.000	kg/p
150	2600.00	kg/h	130000	kg/h	100.000	kg/p
250	7200.00	kg/h	360000	kg/h	100.000	kg/p

DN 15, 25, 40, 50 "FB" = Full bore versions of Promass I

12.1.2 Low flow cut off, full scale value, pulse value – Gas

Nom. diameter [mm]	Low flow cut off (approx. v = 0.01 m/s)		Full scale value (approx. v = 2 m/s)		Pulse value (approx. 2 pulse/s at 2 m/s)	
1	0.02	kg/h	4	kg/h	0.001	kg/p
2	0.10	kg/h	20	kg/h	0.010	kg/p
4	0.45	kg/h	90	kg/h	0.010	kg/p
8	2.00	kg/h	400	kg/h	0.100	kg/p
15	6.50	kg/h	1300	kg/h	0.100	kg/p
15 FB	18.00	kg/h	3600	kg/h	1.000	kg/p
25	18.00	kg/h	3600	kg/h	1.000	kg/p
25 FB	45.00	kg/h	9000	kg/h	1.000	kg/p
40	45.00	kg/h	9000	kg/h	1.000	kg/p
40 FB	75.00	kg/h	15000	kg/h	10.000	kg/p
50	75.00	kg/h	15000	kg/h	10.000	kg/p
50 FB	180.00	kg/h	36000	kg/h	10.000	kg/p
80	180.00	kg/h	36000	kg/h	10.000	kg/p
100	300.00	kg/h	60000	kg/h	10.000	kg/p
150	650.00	kg/h	130000	kg/h	100.000	kg/p
250	1800.00	kg/h	360000	kg/h	100.000	kg/p

DN 15, 25, 40, 50 "FB" = Full bore versions Promass I

12.1.3 Language

Country	Language
Australia	English
Belgium	English
China	Chinese
Denmark	English
Germany	Deutsch
England	English
Finland	Suomi
France	Francais
Netherlands	Nederlands
Hong Kong	English
India	English
Indonesia	Bahasa Indonesia
Instruments International	English
Italy	Italiano
Japan	Japanese
Malaysia	English
Norway	Norsk
Poland	Polish
Portugal	Portuguese
Austria	Deutsch
Russia	Russian
Sweden	Svenska
Switzerland	Deutsch
Singapore	English
Spain	Espanol
South Africa	English
Thailand	English
Czech Republic	Czech
Hungary	English

12.1.4 Density, length, temperature

	Unit
Density	kg/l
Length	mm
Temperature	°C

12.2 US units (only for USA and Canada)

12.2.1 Low flow cut off, full scale value, pulse value – Liquid

Nominal diam. [mm]	Low flow cut off (approx. v = 0.04 m/s)		Full scale value (approx. v = 2.0 m/s)		Pulse value (approx. 2 pulse/s at 2.0 m/s)	
1	0.003	lb/min	0.15	lb/min	0.002	lb/p
2	0.015	lb/min	0.75	lb/min	0.020	lb/p
4	0.066	lb/min	3.30	lb/min	0.020	lb/p
8	0.300	lb/min	15.00	lb/min	0.200	lb/p
15	1.000	lb/min	50.00	lb/min	0.200	lb/p
15 FB	2.600	lb/min	130.00	lb/min	2.000	lb/p
25	2.600	lb/min	130.00	lb/min	2.000	lb/p
25 FB	6.600	lb/min	330.00	lb/min	2.000	lb/p
40	6.600	lb/min	330.00	lb/min	2.000	lb/p
40 FB	11.000	lb/min	550.00	lb/min	20.000	lb/p
50	11.000	lb/min	550.00	lb/min	20.000	lb/p
50 FB	26.000	lb/min	1300.00	lb/min	20.000	lb/min
80	26.000	lb/min	1300.00	lb/min	20.000	lb/p
100	44.000	lb/min	2200.00	lb/min	20.000	lb/p
150	95.000	lb/min	4800.00	lb/min	200.000	lb/p
250	260.000	lb/min	13000.00	lb/min	200.000	lb/p

DN 15, 25, 40, 50 "FB" = Full bore versions of Promass I

12.2.2 Low flow cut off, full scale value, pulse value – Gas

Nominal diameter [mm]	Low flow cut off (approx. v = 0.01 m/s)		Full scale value (approx. v = 2 m/s)		Pulse value (approx. 2 pulse/s at 2 m/s)	
1	0.001	lb/min	0.15	lb/min	0.002	lb/p
2	0.004	lb/min	0.75	lb/min	0.020	lb/p
4	0.046	lb/min	3.30	lb/min	0.020	lb/p
8	0.075	lb/min	15.00	lb/min	0.200	lb/p
15	0.250	lb/min	50.00	lb/min	0.200	lb/p
15 FB	0.650	lb/min	130.00	lb/min	2.000	lb/p
25	0.650	lb/min	130.00	lb/min	2.000	lb/p
25 FB	1.650	lb/min	330.00	lb/min	2.000	lb/p
40	1.650	lb/min	330.00	lb/min	2.000	lb/p
40 FB	2.750	lb/min	550.00	lb/min	20.000	lb/p
50	2.750	lb/min	550.00	lb/min	20.000	lb/p
50 FB	6.500	lb/min	1300.00	lb/min	20.000	lb/p
80	6.500	lb/min	1300.00	lb/min	20.000	lb/p
100	11.000	lb/min	2200.00	lb/min	20.000	lb/p
150	23.750	lb/min	4800.00	lb/min	200.000	lb/p
250	65.000	lb/min	13000.00	lb/min	200.000	lb/p

DN 15, 25, 40, 50 "FB" = Full bore versions Promass I

12.2.3 Language, density, length, temperature

	Unit
Language	English
Density	g/cc
Length	INCH
Temperature	°F

Index function matrix

Blocks

A = MEASURED VARIABLES	11
B = QUICK SETUP	25
C = USER INTERFACE	35
D = TOTALIZER	56
E = OUTPUT	61
F = INPUT	111
G = BASIC FUNCTION	119
H = SPECIAL FUNCTION	139
J = SUPERVISION	179

Groups

AAA = MEASURING VALUES	12
ACA = SYSTEM UNITS	17
AEA = SPECIAL UNITS	22
CAA = CONTROL	36
CCA = MAIN LINE	40
CEA = ADDITIONAL LINE	44
CGA = INFORMATION LINE	50
DAA = TOTALIZER 1	57
DAB = TOTALIZER 2	57
DAC = TOTALIZER 3	57
DJA = HANDLING TOTALIZER	60
EAA = CURRENT OUTPUT 1	62
EAB = CURRENT OUTPUT 2	62
EAC = CURRENT OUTPUT 3	62
ECA = PULSE/FREQUENCY OUTPUT 1	74
ECB = PULSE/FREQUENCY OUTPUT 2	74
EGA = RELAY OUTPUT 1	101
EGB = RELAY OUTPUT 2	101
FAA = STATUS INPUT	112
FCA = CURRENT INPUT	115
GAA = HART	120
GIA = PROCESS PARAMETER	122
GLA = SYSTEM PARAMETER	133
GNA = SENSOR DATA	135
HAA = DENSITY FUNCTIONS	141
HCA = BATCHING FUNCTION	147
HEA = ADVANCED DIAGNOSTICS	166
JAA = SYSTEM	180
JCA = VERSION INFO	185

Function groups

000 = MAIN VALUES	12
002 = ADDITIONAL VALUES	13
040 = CONFIGURATION	17
042 = ADDITIONAL CONFIGURATION	20
060 = ARBITRARY UNIT	22
200 = BASIC CONFIGURATION	36
202 = UNLOCKING/LOCKING	38
204 = OPERATION	39
220 = CONFIGURATION	40
222 = MULTIPLEX	42
240 = CONFIGURATION	44
242 = MULTIPLEX	47
260 = CONFIGURATION	50

262 = MULTIPLEX	53
300 = CONFIGURATION	57
304 = OPERATION	59
400 = CONFIGURATION	62
404 = OPERATION	72
408 = INFORMATION	73
420 = CONFIGURATION	74
430 = OPERATION	96
438 = INFORMATION	100
470 = CONFIGURATION	101
474 = OPERATION	105
478 = INFORMATION	107
500 = CONFIGURATION	112
504 = OPERATION	113
508 = INFORMATION	114
520 = CONFIGURATION	115
524 = OPERATION	117
528 = INFORMATION	118
600 = CONFIGURATION	120
604 = INFORMATION	121
640 = CONFIGURATION	122
642 = EPD PARAMETER	125
646 = REFERENCE PARAMETER	127
648 = ADJUSTMENT	129
650 = PRESSURE CORRECTION	132
660 = CONFIGURATION	133
680 = CONFIGURATION	135
684 = FLOW COEFFICIENT	136
685 = DENSITY COEFFICIENT	137
686 = ADDITIONAL COEFFICIENT	138
700 = CONFIGURATION	141
720 = CONFIGURATION	147
722 = VALVE PARAMETER	153
724 = SUPERVISION	158
726 = OPERATION	162
728 = INFORMATION	164
740 = CONFIGURATION	166
741 = ACQUISITION	167
742 = MASS FLOW	168
743 = DENSITY	169
744 = REFERENCE DENSITY	170
745 = TEMPERATURE	171
746 = TUBE DAMPING	172
747 = ELECTRODYNAMIC SENSORS	173
748 = OPERATING FREQUENCY FLUCTUATION	175
749 = TUBE DAMPING FLUCTUATION	177
800 = CONFIGURATION	180
804 = OPERATION	183
810 = DEVICE	185
820 = SENSOR	185
822 = AMPLIFIER	186
824 = F-CHIP	187
830 = I/O MODULE	187
832 = INPUT/OUTPUT 1	188
834 = INPUT/OUTPUT 2	188
836 = INPUT/OUTPUT 3	188

838 = INPUT/OUTPUT 4188

Functions 0...

0000 = MASS FLOW12
 0001 = VOLUME FLOW12
 0004 = CORRECTED VOLUME FLOW12
 0005 = DENSITY12
 0006 = REFERENCE DENSITY12
 0008 = TEMPERATURE12
 0009 = PRESSURE12
 0020 = TARGET MASS FLOW13
 0021 = % TARGET MASS FLOW13
 0022 = TARGET VOLUME FLOW13
 0023 = % TARGET VOLUME FLOW13
 0024 = CORRECTED TARGET VOLUME FLOW14
 0025 = CARRIER MASS FLOW14
 0026 = % CARRIER MASS FLOW14
 0027 = CARRIER VOLUME FLOW14
 0028 = % CARRIER VOLUME FLOW15
 0029 = CORRECTED CARRIER VOL. FLOW15
 0030 = % BLACK LIQUOR15
 0031 = ° BAUME15
 0033 = ° API15
 0034 = ° PLATO16
 0035 = ° BALLING16
 0036 = ° BRIX16
 0037 = OTHERS16
 0400 = UNIT MASS FLOW17
 0401 = UNIT MASS17
 0402 = UNIT VOLUME FLOW18
 0403 = UNIT VOLUME18
 0404 = UNIT CORRECTED VOLUME FLOW19
 0405 = UNIT CORRECTED VOLUME19
 0420 = UNIT DENSITY20
 0421 = UNIT REFERENCE DENSITY20
 0422 = UNIT TEMPERATURE21
 0424 = UNIT LENGTH21
 0426 = UNIT PRESSURE21
 0600 = TEXT ARBITRARY MASS22
 0601 = FACTOR ARBITRARY MASS22
 0602 = TEXT ARBITRARY VOLUME23
 0603 = FACTOR ARBITRARY VOLUME23
 0604 = TEXT ARBITRARY DENSITY23
 0605 = FACTOR ARBITRARY DENSITY23
 0606 = TEXT ARBITRARY CONCENTRATION24
 0607 = FACTOR ARBITRARY CONCENTRATION24

1...

1002 = QUICK SETUP COMMISSIONING25
 1003 = QUICK SETUP PULSATING FLOW25
 1004 = QUICK SETUP GAS MEASUREMENT25
 1005 = QUICK SETUP BATCHING/DOSING26
 1009 = T-DAT SAVE/LOAD26

2...

2000 = LANGUAGE36
 2002 = DISPLAY DAMPING36
 2003 = CONTRAST LCD37
 2004 = BACKLIGHT37

2020 = ACCESS CODE38
 2021 = DEFINE PRIVATE CODE38
 2022 = STATUS ACCESS38
 2023 = ACCESS CODE38
 2040 = TEST DISPLAY39
 2200 = ASSIGN40
 2201 = 100% VALUE41
 2202 = FORMAT41
 2220 = ASSIGN42
 2221 = 100% VALUE43
 2222 = FORMAT43
 2400 = ASSIGN44
 2401 = 100% VALUE45
 2402 = FORMAT46
 2403 = DISPLAY MODE46
 2420 = ASSIGN47
 2421 = 100% VALUE48
 2422 = FORMAT49
 2423 = DISPLAY MODE49
 2600 = ASSIGN50
 2601 = 100% VALUE51
 2602 = FORMAT52
 2603 = DISPLAY MODE52
 2620 = ASSIGN53
 2621 = 100% VALUE54
 2622 = FORMAT55
 2623 = DISPLAY MODE55

3...

3000 = ASSIGN57
 3001 = UNIT TOTALIZER58
 3002 = TOTALIZER MODE58
 3003 = RESET TOTALIZER58
 3040 = SUM59
 3041 = OVERFLOW59
 3800 = RESET ALL TOTALIZERS60
 3801 = FAILSAFE MODE60

4...

4000 = ASSIGN CURRENT OUTPUT62
 4001 = CURRENT SPAN64
 4002 = VALUE 0_4 mA65
 4003 = VALUE 20 mA67
 4004 = MEASURING MODE68
 4005 = TIME CONSTANT70
 4006 = FAILSAFE MODE71
 4040 = ACTUAL CURRENT72
 4041 = SIMULATION CURRENT72
 4042 = VALUE SIMULATION CURRENT72
 4080 = TERMINAL NUMBER73
 4200 = OPERATION MODE74
 4201 = ASSIGN FREQUENCY75
 4202 = START VALUE FREQUENCY76
 4203 = END VALUE FREQUENCY76
 4204 = VALUE F LOW77
 4205 = VALUE F HIGH77
 4206 = MEASURING MODE79
 4207 = OUTPUT SIGNAL81,82,83
 4208 = TIME CONSTANT84

4209 = FAILSAFE MODE	84
4211 = FAILSAFE VALUE	84
4221 = ASSIGN PULSE	85
4222 = PULSE VALUE	85
4223 = PULSE WIDTH	86
4225 = MEASURING MODE	87
4226 = OUTPUT SIGNAL	88,89,90
4227 = FAILSAFE MODE	91
4241 = ASSIGN STATUS	92,93
4242 = ON VALUE	93
4243 = SWITCH-ON DELAY	93
4244 = OFF VALUE	94
4245 = SWITCH-OFF DELAY	94
4246 = MEASURING MODE	95
4247 = TIME CONSTANT	95
4301 = ACTUAL FREQUENCY	96
4302 = SIMULATION FREQUENCY	96
4303 = VALUE SIMULATION FREQUENCY	97
4322 = SIMULATION PULSE	98
4323 = VALUE SIMULATION PULSE	98
4341 = ACTUAL STATUS	99
4342 = SIMULATION SWITCH POINT	99
4343 = VALUE SIMULATION SWITCH POINT	99
4380 = TERMINAL NUMBER	100
4700 = ASSIGN RELAY	101
4701 = ON VALUE	102
4702 = SWITCH-ON DELAY	103
4703 = OFF VALUE	103
4704 = SWITCH-OFF DELAY	103
4705 = MEASURING MODE	104
4706 = TIME CONSTANT	104
4740 = ACTUAL STATUS RELAY	105
4741 = SIMULATION SWITCH POINT	105
4742 = VALUE SIMULATION SWITCH POINT	106
4780 = TERMINAL NUMBER	107

5...

5000 = ASSIGN STATUS INPUT	112
5001 = ACTIVE LEVEL	112
5002 = MINIMUM PULSE WIDTH	112
5040 = ACTUAL STATUS INPUT	113
5041 = SIMULATION STATUS INPUT	113
5042 = VALUE SIMULATION STATUS INPUT	113
5080 = TERMINAL NUMBER	114
5200 = ASSIGN CURRENT INPUT	115
5201 = CURRENT SAPN	115
5202 = VALUE $I_{4\text{ mA}}$	115
5203 = VALUE $I_{20\text{ mA}}$	116
5204 = FAILSAFE MODE	116
5240 = ACTUAL CURRENT INPUT	117
5241 = SIMULATION CURRENT	117
5242 = VALUE SIMULATION CURRENT	117
5245 = TERMINAL NUMBER	118

6...

6000 = TAG NAME	120
6001 = TAG DESCRIPTION	120
6002 = BUS ADDRESS	120
6003 = HART PROTOCOL	120

6004 = WRITE PROTECTION	120
6040 = MANUFACTURER ID	121
6041 = DEVICE ID	121
6042 = DEVICE REVISION	121
6400 = ASSIGN LOW FLOW CUT OFF	122
6402 = ON-VALUE LOW FLOW CUT OFF	122
6403 = OFF-VALUE LOW FLOW CUT OFF	122
6404 = PRESSURE SHOCK SUPPRESSION	123
6420 = EMPTY PIPE DETECTION	125
6423 = EPD VALUE LOW	125
6424 = EPD VALUE HIGH	125
6425 = EPD RESPONSE TIME	125
6460 = CORRECTED VOLUME CALCULATION	127
6461 = FIXED REFERENCE DENSITY	127
6462 = EXPANSION COEFFICIENT	127
6463 = SQUARE EXPANSION COEFFICIENT	127
6464 = REFERENCE TEMPERATURE	128
6480 = ZEROPOINT ADJUST	129
6482 = DENSITY ADJUST MODE	130
6483 = DENSITY SETPOINT 1	130
6484 = MEASURE FLUID 1	130
6485 = DENSITY SETPOINT 2	130
6486 = MEASURE FLUID 2	130
6487 = DENSITY ADJUST	131
6488 = RESTORE ORIGINAL	131
6500 = PRESSURE MODE	132
6501 = PRESSURE	132
6600 = INSTALLATION DIRECTION SENSOR	133
6602 = DENSITY DAMPING	133
6603 = FLOW DAMPING	133
6605 = POSITIVE ZERO RETURN	133
6606 = TEMPERATURE MEASUREMENT	134
6800 = K-FACTOR	135
6803 = ZEROPOINT	135
6804 = NOMINAL DIAMETER	135
6840 = TEMPERATURE COEFFICIENT KM	136
6841 = TEMPERATURE COEFFICIENT KM 2	136
6842 = TEMPERATURE COEFFICIENT KT	136
6843 = CALIBRATION COEFFICIENT KD 1	136
6844 = CALIBRATION COEFFICIENT KD 2	136
6850 = DENSITY COEFFICIENT C 0	137
6851 = DENSITY COEFFICIENT C 1	137
6852 = DENSITY COEFFICIENT C 2	137
6853 = DENSITY COEFFICIENT C 3	137
6854 = DENSITY COEFFICIENT C 4	137
6855 = DENSITY COEFFICIENT C 5	137
6860 = MINIMAL TEMP. MEASURED	138
6861 = MAXIMAL TEMP. MEASURED	138
6862 = MINIMAL TEMP. CARRIER TUBE	138
6863 = MAXIMAL TEMP. CARRIER TUBE	138

7...

7000 = DENSITY FUNCTION	141
7001 = REFERENCE DENSITY CARRIER FLUID	141
7002 = EXP. COEF. LIN. CARR. FL.	141
7003 = EXP. COEF. SQR. CARR. FL.	142
7004 = REFERENCE DENSITY TARGET FLUID	142
7005 = EXP. COEF. LIN. TARG. FL.	142
7006 = EXP. COEF. SQR. TARG. FL.	143

7007 = LINEAR EXPANSION COEFFICIENT	143
7008 = SQUARE EXPANSION COEFFICIENT	143
7009 = REFERENCE TEMPERATURE	144
7021 = MODE	144
7022 = CONCENTRATION SELECTOR	145
7031 = CONCENTRATION NAME	145
7032 = COEFFICIENT A0	145
7033 = COEFFICIENT A1	145
7034 = COEFFICIENT A2	146
7035 = COEFFICIENT A3	146
7036 = COEFFICIENT A4	146
7037 = COEFFICIENT B1	146
7038 = COEFFICIENT B2	146
7039 = COEFFICIENT B3	146
7200 = BATCH SELECTOR	147
7201 = BATCH NAME	147
7202 = ASSIGN BATCH VARIABLE	148
7203 = BATCH QUANTITY	148
7204 = FIXED COMPENSATION QUANTITY	149
7205 = COMPENSATION MODE	149
7206 = CALCULATION MODE	151
7207 = AVERAGING DRIP	151
7208 = BATCH STAGES	152
7209 = INPUT FORMAT	152
7220 = OPEN VALVE 1	153
7221 = CLOSE VALVE 1	153
7222 = OPEN VALVE 2	154
7223 = CLOSE VALVE 2	154
7240 = MAXIMUM BATCHING TIME	158
7241 = MINIMUM BATCHING QUANTITY	159
7242 = MAXIMUM BATCHING QUANTITY	160
7243 = PROGRESS NOTE	160
7244 = MAX. FLOW	161
7260 = BATCH PROCEDURE	162
7261 = BATCH UPWARDS	162
7262 = BATCH DOWNWARDS	163
7263 = BATCH COUNTER	163
7264 = BATCH SUM	163
7265 = RESET SUM/COUNTER	163
7280 = VALVE 1 INTERNAL SWITCH POINT	164
7281 = DRIP QUANTITY	164
7282 = VALVE 1 CLOSING TIME	164
7283 = BATCHING TIME	165
7401 = REFERENCE CONDITION USER	166
7402 = SELECT REFERENCE CONDITION	166
7403 = WARNING MODE	166
7410 = ACQUISITION MODE	167
7411 = ACQUISITION PERIOD	167
7412 = ACQUISITION DO	167
7413 = RESET HISTORY	167
7420 = REFERENCE VALUE MASS FLOW	168
7421 = MASS FLOW	168
7422 = MINIMUM VALUE (MASS FLOW)	168
7423 = MAXIMUM VALUE (MASS FLOW)	168
7424 = MASS FLOW HISTORY	168
7425 = MASS FLOW DEVIATION	168
7426 = WARNING LEVEL (MASS FLOW)	168
7430 = REFERENCE VALUE DENSITY	169
7431 = DENSITY	169

7432 = MINIMUM VALUE (DENSITY)	169
7433 = MAXIMUM VALUE (DENSITY)	169
7434 = DENSITY HISTORY	169
7435 = DENSITY DEVIATION	169
7436 = WARNING LEVEL (DENSITY)	169
7440 = REFERENCE VALUE REFERENCE DENSITY	170
7441 = REFERENCE DENSITY	170
7442 = MINIMUM VALUE (REFERENCE DENSITY)	170
7443 = MAXIMUM VALUE (REFERENCE DENSITY)	170
7444 = REFERENCE DENSITY HISTORY	170
7445 = REFERENCE DENSITY DEVIATION	170
7446 = WARNING LEVEL (REFERENCE DENSITY)	170
7450 = REFERENCE VALUE TEMPERATURE	171
7451 = TEMPERATURE	171
7452 = MINIMUM VALUE (TEMPERATURE)	171
7453 = MAXIMUM VALUE (TEMPERATURE)	171
7454 = TEMPERATURE HISTORY	171
7455 = TEMPERATURE DEVIATION	171
7456 = WARNING LEVEL (TEMPERATURE)	171
7460 = REFERENCE VALUE TUBE DAMPING	172
7461 = TUBE DAMPING	172
7462 = MINIMUM VALUE (TUBE DAMPING)	172
7463 = MAXIMUM VALUE (TUBE DAMPING)	172
7464 = TUBE DAMPING HISTORY	172
7465 = TUBE DAMPING DEVIATION	172
7466 = WARNING LEVEL (TUBE DAMPING)	172
7470 = REF. VALUE EL.-DYN. SENSORS	173
7471 = ELECTRODYNAMIC SENSORS	173
7472 = MINIMUM VALUE (EL-DYN. SENSORS)	173
7473 = MAXIMUM VALUE (EL-DYN. SENSORS)	173
7474 = EL-DYN. SENSORS HISTORY	173
7475 = EL-DYN. SENSORS DEVIATION	173
7476 = WARNING LEVEL (EL-DYN. SENSORS)	174
7480 = REF. VALUE OP. FREQ. FLUCT.	175
7481 = OPERATING FREQUENCY FLUCT.	175
7482 = MINIMUM VALUE (OP. FREQ. FLUCT.)	175
7483 = MAXIMUM VALUE (OP. FREQ. FLUCT.)	175
7484 = HISTORY OPERATING FREQUENCY FLUCT.	175
7485 = DEVIATION OPERATING FREQUENCY FLUCT.	175
7486 = WARNING LEVEL	176
7490 = REF. VALUE TUBE DAMPING FLUCT.	177
7491 = TUBE DAMPING FLUCTUATION	177
7492 = MINIMUM VALUE (TUBE DAMPING FLUCT.)	177
7493 = MAXIMUM VALUE (TUBE DAMPING FLUCT.)	177
7494 = HISTORY TUBE DAMPING FLUCT.	177
7495 = DEVIATION TUBE DAMPING FLUCT.	177
7496 = WARNING LEVEL	178

8...

8000 = ASSIGN SYSTEM ERROR	180
8001 = ERROR CATEGORY	180
8002 = ASSIGN PROCESS ERROR	180
8003 = ERROR CATEGORY	181
8004 = ACKNOWLEDGE FAULTS	181
8005 = ALARM DELAY	181
8006 = REMOVE SW-OPTION	182
8007 = PERMANENT STORAGE	182
8040 = ACTUAL SYSTEM CONDITION	183
8041 = PREVIOUS SYSTEM CONDITION	183

8042 = SIMULATION FAILSAFE MODE	183
8043 = SIMULATION MEASURAND	183
8044 = VALUE SIMULATION MEASURAND	184
8046 = SYSTEM RESET	184
8048 = OPERATION HOURS	184
8100 = DEVICE SOFTWARE	186
8200 = SERIAL NUMBER	185
8201 = SENSOR TYPE	185
8205 = SW REV. NO. S-DAT	185
8222 = SW REV. NO. AMPLIFIER	186
8225 = SOFTWARE REV. NO. T-DAT	186
8226 = LANGUAGE GROUP	186
8240 = STATUS F-CHIP	187
8241 = SYSTEM OPTION	187
8244 = SW REV. NO. F-CHIP	187
8300 = I/O MODULE TYPE	187
8303 = SW-REV. NO. I/O MODULE	187
8320 = SUB-I/O TYPE	188
8323 = SW REV. SUB-I/O	188
8340 = SUB-I/O TYPE	188
8343 = SW REV. SUB-I/O	188
8360 = SUB-I/O TYPE	188
8363 = SW REV. SUB-I/O	188
8380 = SUB-I/O TYPE	188
8383 = SW REV. SUB-I/O	188

Index key words

A

Access code	38
Acknowledge faults	181
Acquisition	
Do	167
Mode	167
Period	167
Acquisition (Advanced diagnosis)	167
Active level	112
Actual	
Current (current input)	117
Current (current output)	72
Frequency	96
Actual Status	
Relay output	105
Status input	113
Switch point (pulse/frequency output)	99
Actual System condition	183
Additional configuration	20
Additional line	
Configuration	44
Multiplex	47
Additional values	13
Adjustment	
Density	131
Zero point	129
Advanced diagnostics	
Acquisition	167
Configuration	166
Density	169
Electrodynamic sensors	173
Mass flow	168
Operating frequency fluctuation	175
Reference density	170
Temperature	171
Tube damping	172
Tube damping fluctuation	177
Alarm delay	181
Amplifier (Version Info)	186
Arbitrary unit	22
Assign	
Additional line	44
Additional line (Multiplex)	47
Current input	115
Current output	62
Frequency (Pulse/Freq. output)	75
Information line	50
Information line (Multiplex)	53
Low flow cut off	122
Main line	40
Main line (Multiplex)	42
Process error	180
Pulse	85

Relay (relay output)	101
Status input	112
Status (Pulse/Freq. output)	92,93
System error	180
Totalizer	57
Assign Batch variable	148
Averaging drip	151

B

Backlight (user interface)	37
Basic Configuration (user interface)	36
Basic functions	119
Batch Counter	163
Batch Name	147
Batch Procedure	162
Batch quantity	148
Downwards	163
Upwards	162
Batch Selector	147
Batch Stages	152
Batch Sum	163
Batching function	
Configuration	147
Batching time	165
Batching/Dosing	26
Block	
Basic functions	119
Display	35
Inputs	111
Measured variables	11
Outputs	61
Quick Setup	25
Special function	139
Supervision	179
Totalizer	56
Bus address	120

C

Calculation mode	151
Calibrate	
Coefficient	
KD 1	136
KD 2	136
Carrier Mass flow	14
Carrier Volume flow	14
Close	
Valve 1	153
Valve 2	154
Coefficient	
Calibration	
KD 1	136
KD 2	136

Concentration		
A0	145	
A1	145	
A2	146	
A3	146	
A4	146	
B1	146	
B2	146	
B3	146	
Density		
C 0	137	
C 1	137	
C 2	137	
C 3	137	
C 4	137	
C 5	137	
Expansion	127	
Expansion Square	127	
Temperature		
KM	136	
KM 2	136	
KT	136	
Commissioning	25	
Compensation Mode	149	
Compensation Quantity (fixed)	149	
Concentration selection (density function)	145	
Configuration		
Additional line	44	
Advanced diagnostics	166	
Batching function	147	
Current input	115	
Current output	62	
Density functions	141	
HART	120	
Information line	50	
Main line	40	
Process parameter	122	
Pulse/Frequency output	74	
Relay output	101	
Sensor data	135	
Status input	112	
System	180	
System parameter	133	
System units	17	
Totalizer	57	
Contrast LCD	37	
Corrected Carrier volume flow	15	
Corrected Target volume flow	14	
Corrected Volume calculation	127	
Corrected volume flow	12	
Current input		
Configuration	115	
Information	118	
Operation	117	
Current output		
Configuration	62	
Information	73	
Operation	72	
Current range		
Current output	64	
D		
Damping		
Density	133	
System	133	
Define private code	38	
Density	12	
Adjustment	131	
Coefficient		
C 0	137	
C 1	137	
C 2	137	
C 3	137	
C 4	137	
C 5	137	
Damping	133	
Function	141	
Density Adjust mode	130	
Density functions		
Configuration	141	
Density (Advanced diagnosis)		
Density	169	
Deviation	169	
History	169	
Maximum	169	
Minimum	169	
Warning level	169	
Device ID	121	
Device revision	121	
Device (version-info)	185	
Display	35	
Display damping	36	
Display light	37	
Display mode		
Additional line	46	
Additional line (Multiplex)	49	
Information line	52	
Information line (Multiplex)	55	
Display test	39	
Drip quantity	164	
E		
Electrodynamic sensors (Advanced diagnosis)		
Deviation	173	
Electrodynamic sensors	173	
History	173	
Maximum	173	
Minimum	173, 175	
Warning level	174	
Empty pipe detection (EPD)	125	
End value frequency	76	
EPD		

Empty pipe detection	125	Advanced diagnostics	166
Parameter	125	Batching function	147
Response time	125,126	Current input	115
Value high	125	Current output	62
Value low	125	Density functions	141
Error category		HART	120
Process error	181	Information line	50
System error	180	Main line	40
Expansion coefficient	127	Process parameter	122
Linear	143	Pulse/Freq. output	74
Carrier fluid	141	Relay output	101
Target fluid	142	Sensor data	135
Square	143	Status input	112
Carrier fluid	142	System	180
Target fluid	143	System parameter	133
Expansion coefficient Square	127	System units	17
F		Totalizer	57
Factor		Density	
Arbitrary concentration	24	Advanced diagnostics	169
Arbitrary density	23	Density coefficient	137
Arbitrary mass	22	Device	185
Arbitrary volume	23	Electrodynamic sensors	
Factory settings		Advanced diagnostics	173
Full scale value	189	EPD parameter	125
Low flow cut off	189	F-CHIP	187
Pulse value	189	Flow coefficient	136
Failsafe mode		Information	
All totalizers	60	Batching function	164
Current input	116	Current input	118
Current output	71	Current output	73
Frequency output	84	HART	121
Pulse output	91	Pulse/Frequency output	100
Failsafe value	84	Relay output	107
F-CHIP (Version Info)	187	Status input	114
Fixed Compensation quantity	149	Input/Output	188
Fixed Reference density	127	I/O Module	187
Flow	161	Main values	12
Format		Mass flow	
Additional line	46	Advanced diagnostics	168
Additional line (Multiplex)	49	Multiplex	
Information line	52	Additional line	47
Information line (Multiplex)	55	Information line	53
Main line	41	Main line	42
Main line (Multiplex)	43	Operating frequency fluctuation	
Function group		Advanced diagnostics	175
Acquisition		Operation	
Advanced diagnostics	167	Batching function	162
Additional coefficient	138	Current input	117
Additional configuration	20	Current output	72
Additional values	13	Pulse/Frequency output	96
Adjustment	129	Relay output	105
Amplifier	186	Status input	113
Arbitrary unit	22	System	183
Basic Configuration (user interface)	36	Totalizer	59
Configuration		Operation (display)	39
Additional line	44	Pressure correction	132

Reference density		
Advanced diagnostics	170	
Reference parameter	127	
Sensor	185	
Supervision		
Batching function	158	
Temperature		
Advanced diagnostics	171	
Tube damping		
Advanced diagnostics	172	
Tube damping fluctuation		
Advanced diagnostics	177	
Unlocking/Locking (user interface)	38	
Valve parameter		
Batching function	153	
Function matrix		
Codes identifying	9	
General layout	8	
Overview	10	
G		
Gas measurement	25	
Group		
Additional line	44	
Advanced diagnostics	166	
Batching function	147	
Control (display)	36	
Current input	115	
Current output	62	
Handling Totalizer	60	
HART	120	
Information line	50	
Main line	40	
Measuring values	12	
Process parameter	122	
Pulse/Frequency output	74	
Relay output	101	
Sensor data	135	
Special units	22	
Status input	112	
System	180	
System parameter	133	
System units	17	
Version Info	185	
H		
Handling Totalizer	60	
HART		
Configuration	120	
Information	121	
HART Protocol	120	
I		
Information		
Batching function	164	
Current input	118	
Current output	73	
Pulse/Frequency output	100	
Relay output	107	
Status input	114	
Information line		
Configuration	50	
Multiplex	53	
Input format	152	
Inputs	111	
Input/Output 1...4	188	
Installation direction sensor	133	
I/O Module	187	
K		
K-Factor	135	
L		
Language		
Factory setting (country)	190	
Language group (display)	186	
Selection	36	
LCD contrast	37	
Low flow cut off		
Assign	122	
Off value	122	
On value	122	
M		
Main line		
Configuration	40	
Multiplex	42	
Main values	12	
Manufacturer ID	121	
Mass flow	12	
Mass flow (Advanced diagnosis)		
Deviation	168	
History	168	
Mass flow	168	
Maximum	168	
Minimum	168	
Reference value	168	
Warning level	168	
Maximal		
Temperature carrier tube	138	
Temperature measured	138	
Maximum	161	
Maximum Batching quantity	160	
Maximum Batching time	158	
Measure Fluid 1	130	
Measure Fluid 2	130	
Measured variables	11	
Measuring mode		
Current output	68	
Frequency (Pulse/Freq. output)	79	
Pulse output	87	
Relay output	104	
Status (Pulse/Freq. output)	95	
Measuring values	12	

Additional values	13
Main values	12
Minimal	
Temperature carrier tube	138
Temperature measured	138
Minimum Batching quantity	159
Minimum Pulse width	112
Mode (density function)	144
Multiplex	
Additional line	47
Information line	53
Main line	42
N	
Nominal diameter	135
O	
Off value	
Low flow cut off	122
Relay output	103
Status (Pulse/Freq. output)	94
On value	
Low flow cut off	122
Relay output	102
Status (Pulse/Freq. output)	93
Open	
Valve 1	153
Valve 2	154
Operating frequency fluct. (Advanced diagnosis)	
Deviation	175
History	175
Maximum	175
Minimum	175
Operating frequency fluct.	175
Warning level	176
Operation	
Basic configuration	36
Batching function	162
Current input	117
Current output	72
Display	39
Operation	39
Pulse/Frequency output	74,96
Relay output	105
Status input	113
System	183
Totalizer	59
Unlocking/Locking	38
Operation hours	184
Other (unit of concentration)	16
Output signal	
Frequency output	81
Pulse output	88,89,90
Outputs	61
Overflow	
Totalizer	59

P

Positive zero return	133
Pressure	12,132
Pressure correction	132
Pressure Mode	132
Pressure Shock suppression	123,124
Previous system condition	183
Process parameter	
Adjustment	129
Configuration	122
EPD parameter	125
Pressure correction	132
Reference parameter	127
Progress note	160
Pulsating flow	25
Pulse value	85
Pulse Width	86
Pulse/Frequency output	
Configuration	74
Information	100
Operation	96

Q

Quick Setup	25
Batching/Dosing	26
Commissioning	25
Gas measurement	25
Pulsating flow	25

R

Refer to installation direction for flow direction	133
Reference condition	
Selection	166
User	166
Reference density	12
Carrier fluid	141
Target fluid	142
Reference density (Advanced diagnosis)	
Deviation	170
History	170
Maximum	170
Minimum	170
Reference density	170
Warning level	170
Reference density (fixed)	127
Reference Temperature	128,144
Relay output	
Configuration	101
Flow direction	108
General	108
Information	107
Limit value	108
Operation	105
Switching behavior	109
Remove SW-OPTION	182

Reset		Status (Pulse/Freq. output)	93
All totalizers	60	System	
History	167	Configuration	180
System	184	Damping	133
Totalizer	58	Operation	183
Reset Sum/Counter	163	Operation hours	184
Restore original	131	Reset	184
S		System condition	
Sensor data		Actual	183
Additional coefficient	138	Previous	183
Configuration	135	System parameter	
Density coefficient	137	Configuration	133
Flow coefficient	136	System units	
Sensor type	185	Additional configuration	20
Sensor (Version info)	185	Configuration	17
Serial number sensor	185	T	
Setpoint		Tag Description	120
Density 1	130	Tag Name	120
Density 2	130	Target Mass flow	13
Simulation		Target Volume flow	13
Current (current output)	72	T-DAT Save/Load	26
Failsafe mode	183	Temperature	12
Frequency	96	Coefficient	
Measured variable	183	KM	136
Status input	113	KM 2	136
Switch point (Relay output)	105	KT	136
Simulation Pulse	98	Temperature (Advanced diagnosis)	
Software		Deviation	171
Amplifier	186	History	171
Software revision number		Maximum	171
Amplifier	186	Minimum	171
F-CHIP	187	Temperature	171
I/O Module	187	Warning level	171
S-DAT	185	Terminal number	
T-DAT	186	Current input	118
Special units		Current output	73
Arbitrary unit	22	Pulse/Frequency output	100
Start value frequency	76	Relay output	107
Status access	38	Status input	114
Status F-CHIP	187	Test display	39
Status input		Text	
Configuration	112	Arbitrary concentration	24
Information	114	Arbitrary density	23
Operation	113	Arbitrary mass	22
Store permanently	182	Arbitrary volume	23
Sum		Time constant	
Totalizer	59	Current output	70
Supervision	179	Frequency output	84
Batching function	158	Relay output	104
Switching behavior of the relay output	109	Status (Pulse/Freq. output)	95
Switch-off delay		Totalizer	56
Relay output	103	Configuration	57
Status (Pulse/Freq. output)	94	Operation	59
Switch-on delay		Totalizer Mode	58
Relay output	103	Totalizer Reset	58

Tube damping fluct. (Advanced diagnosis)	
Deviation.	177
History	177
Maximum	177
Minimum	177
Tube damping fluct.	177
Warning level.	178
Tube damping (Advanced diagnosis)	
Deviation.	172
History	172
Maximum	172
Minimum	172
Tube damping	172
Warning level	172
Type	
Input/Output 1...4	188
I/O Module.	187
Sub-input/Sub-output 1...4	188
U	
Unit	
Corrected volume	19
Corrected volume flow	19
Density	20
Length.	21
Mass	17
Mass flow	17
Pressure.	21
Reference density.	20
Temperature	21
Totalizer	58
Volume	18
Volume flow	18
Unlocking/Locking (user interface)	38
V	
Value F High.	77
Value F Low	77
Value simulation	
Current (current input)	117
Current (current output)	72
Frequency	97
Measured variable	184
Status input	113
Switch point (pulse/freq. output)	99
Switch point (Relay output)	106
Value Simulation Pulse	98
Value 0_4 mA	
Current input	115
Current output	65
Value 20 mA	
Current input	116
Current output	67
Valve parameter	
Batching function	153
Valve 1 Closing time	164
Valve 1 Internal switch point.	164

Version Info	
Amplifier	186
F-CHIP	187
Input/Output 1...4.	188
I/O Module.	187
Sensor	185
Volume flow	12

W

Warning mode.	166
Write protection	120

Z

Zero point	135
Zero Point adjust	129

Symbols

% Black liquor	15
% Carrier Mass flow.	14
% Carrier Volume flow	15
% Target Mass flow	13
% Target Volume flow	13
°Api	15
°Balling.	16
°Baume.	15
°Brix	16
°Plato	16

Numerics

100% Value	
Additional line	45
Additional line (Multiplex)	48
Information line	51
Information line (Multiplex)	54
Main line	41
Main line (Multiplex)	43

www.endress.com/worldwide

For more Endress+Hauser product please visit: www.ainstru.com
Mail: Sales@ainstru.com

Endress+Hauser 
People for Process Automation