



Level



Pressure



Flow



Temperature



Liquid
Analysis



Registration



Systems
Components



Services




Solutions

Operating Instructions

Proline Prosonic Flow 93T Portable

Portable ultrasonic flow measuring system



BA136D/06/en/04.10
71112144

Valid as of version
V 2.02.XX (device software)

Table of contents

1	Safety instructions	5	4	Wiring	31
1.1	Designated use	5	4.1	Charging the NiMH storage battery	31
1.2	Installation, commissioning and operation	5	4.2	Connecting the connecting cable	31
1.3	Operational safety	5	4.3	Cable specification for connecting cable	31
1.4	Return	6	4.4	Potential equalization	32
1.5	Notes on safety conventions and icons	6	4.5	Degree of protection	32
			4.6	Post-connection check	32
2	Identification	7	5	Operation	33
2.1	Device designation	7	5.1	Quick operation guide	33
2.1.1	Nameplate of the transmitter	7	5.2	Display and operating elements	33
2.1.2	Nameplate of the sensor	8	5.3	Brief guide to the function matrix	36
2.2	Certificates and approvals	9	5.3.1	General notes	37
2.3	Registered trademarks	9	5.3.2	Enabling the programming mode	37
			5.3.3	Disabling the programming mode	37
3	Installation	10	5.4	Error messages	38
3.1	Incoming acceptance, transport and storage	10	5.4.1	Type of error	38
3.1.1	Incoming acceptance	10	5.4.2	Error message types	38
3.1.2	Transport	10	5.4.3	Confirming error messages	39
3.1.3	Storage	10	5.5	Communication	39
3.2	Installation conditions	10	5.5.1	FieldCare	39
3.2.1	Dimensions	10			
3.2.2	Mounting location	10	6	Commissioning	40
3.2.3	Orientation	11	6.1	Function check	40
3.2.4	Inlet and outlet run	11	6.2	Switching on the measuring device	40
3.2.5	Sensor selection and arrangement	12	6.2.1	Resetting the measuring device	40
3.3	Preparatory steps prior to installation	13	6.3	Commissioning via onsite display	41
3.4	Determining the necessary installation distances	13	6.3.1	Quick Setup "Sensor Installation"	41
3.4.1	Installation distances for Prosonic Flow P	13	6.3.2	Quick Setup "Commissioning"	43
3.5	Determining values for installation distances	13	6.3.3	Quick Setup "Pulsating Flow"	44
3.5.1	Determining installation distances via local operation	13	6.4	Application-specific commissioning	47
3.5.2	Determining installation distances via Applicator	15	6.4.1	Zero point adjustment	47
3.6	Mechanical preparation	15	6.5	Using the data logger	48
3.6.1	Mounting the sensor holder	16	6.6	Data exchange with Prosonic Flow 93T	48
3.6.2	Premounting the strapping bands (metal, medium nominal diameters)	20	7	Maintenance	49
3.6.3	Premounting the strapping bands (metal, large nominal diameters)	21	7.1	General	49
3.6.4	Mounting with strapping bands (flexible)	22	7.2	Charging the device	49
3.7	Installing Prosonic Flow P (DN 15 to 65 / ½ to 2½")	23	8	Accessories	50
3.7.1	Mounting the sensor	23	9	Troubleshooting	52
3.8	Installing Prosonic Flow P (DN 50 to 4000 / 2 to 160") (Clamp On)	24	9.1	Troubleshooting instructions	52
3.8.1	Installation for measurement via one traverse	24	9.2	System error messages	52
3.8.2	Installation for measurement via two traverses	26	9.3	Process error messages	54
3.9	Installing sensor DDU18	28	9.4	Process errors without messages	55
3.10	Installing sensor DDU20 (wall thickness measurement)	29	9.5	Response of outputs to errors	56
3.10.1	Method 1	29	9.6	Spare parts	56
3.10.2	Method 2	30	9.7	Return	56
3.11	Post-installation check	30	9.8	Disposal	56
			9.9	Software history	56

10 Technical data 57

10.1	Quick technical data guide	57
10.1.1	Application	57
10.1.2	Function and system design	57
10.1.3	Input	57
10.1.4	Output	58
10.1.5	Power supply	58
10.1.6	Performance characteristics	59
10.1.7	Operating conditions: installation	60
10.1.8	Operating conditions: environment	61
10.1.9	Operating conditions: process	62
10.1.10	Mechanical construction	62
10.1.11	Human interface	63
10.1.12	Certificates and approvals	64
10.1.13	Ordering information	64
10.1.14	Documentation	64

11 Description of Device Functions 65

11.1	Function matrix	65
11.1.1	General layout of the function matrix	65
11.1.2	Codes identifying cells	66
11.2	Function matrix of Prosonic Flow 93T Portable . . .	67
11.3	Block MEASURED VARIABLES	68
11.3.1	Group MEASURING VALUES'	68
11.3.2	Group SYSTEM UNITS	69
11.3.3	Group SPECIAL UNITS	71
11.4	Block QUICK SETUP	71
11.5	Block USER INTERFACE	72
11.5.1	Group CONTROL	72
11.5.2	Group MAIN LINE	75
11.5.3	Group ADDITIONAL LINE	77
11.5.4	Group INFORMATION LINE	81
11.6	Block TOTALIZER	85
11.6.1	Group TOTALIZER (1 to 3)	85
11.6.2	Group HANDLING TOTALIZER	86
11.7	Block OUTPUTS	87
11.7.1	Group DATA LOGGER	87
11.8	Block INPUTS	88
11.8.1	Group CURRENT INPUT	88
11.9	Block BASIC FUNCTIONS	90
11.9.1	Group PROCESS PARAMETER	90
11.9.2	Group SYSTEM PARAMETER	98
11.9.3	Group SENSOR DATA	99
11.10	Block SUPERVISION	102
11.10.1	Group SYSTEM	102
11.10.2	Group VERSION INFO	104

12 Factory settings 106

12.1	SI units (not for USA and Canada)	106
12.1.1	Units of length and temperature	106
12.1.2	Language	106
12.2	US units (for USA and Canada only)	106
12.2.1	Units of length and temperature	106
12.2.2	Language	106

Index 107

1 Safety instructions

1.1 Designated use

The measuring device described in these Operating Instructions is to be used only for measuring the flow rate of liquids in closed pipes.

Examples:

- Acids, alkalis, paints, oils
- Liquid gas
- Ultrapure water with low conductivity, water, wastewater

As well as measuring the volume flow, the sound velocity of the fluid is also always measured. Different fluids can be distinguished or the fluid quality can be monitored.

The designated operation of the measuring device is battery operation without connection to the charger.

Resulting from incorrect use or from use other than that designated the operational safety of the measuring devices can be suspended. The manufacturer accepts no liability for damages being produced from this.

1.2 Installation, commissioning and operation

Note the following points:

- Installation, connection to the electricity supply, commissioning and maintenance of the device must be carried out by trained, qualified specialists authorized to perform such work by the facility's owner-operator.
The specialist must have read and understood these Operating Instructions and must follow the instructions they contain.
- The device must be operated by persons authorized and trained by the facility's owner-operator. Strict compliance with the instructions in these Operating Instructions is mandatory.
- Endress+Hauser is willing to assist in clarifying the chemical resistance properties of parts wetted by special fluids, including fluids used for cleaning.
However, small changes in temperature, concentration or the degree of contamination in the process can result in changes to the corrosion resistance properties. Therefore, Endress+Hauser cannot guarantee or accept liability for the corrosion resistance properties of wetted materials in a specific application.
The user is responsible for choosing suitable wetted materials in the process.
- The storage batteries for the device may only be charged with the charger supplied. Other equipment could cause the battery to overheat (risk of fire!).
- Invariably, local regulations governing the opening and repair of electrical devices apply.

1.3 Operational safety

Note the following points:

- The transmitter having the ingress protection IP 40 is intended for operation in dry, clean and non-hazardous environment. Mechanical stresses are to be avoided.
- The measuring device complies with the general safety requirements in accordance with EN 61010-1 and the EMC requirements of IEC/EN 61326 during storage battery operation.
- The manufacturer reserves the right to modify technical data without prior notice. Your Endress+Hauser distributor will supply you with current information and updates to these Operating Instructions.

1.4 Return

The following procedures must be carried out before a flowmeter requiring repair or calibration, for example, is returned to Endress+Hauser:

- Always enclose a duly completed "Declaration of Contamination" form.
Only then Endress+Hauser can transport, examine and repair a returned device.



Note!

You will find a preprinted "Declaration of Contamination" form at the back of this manual.

- Enclose special handling instructions if necessary, for example a safety data sheet as per EC REACH Regulation No. 1907/2006.
- Remove all residues. Pay special attention to the grooves for seals and crevices which could contain residues. This is particularly important if the substance is hazardous to health, e.g. flammable, toxic, caustic, carcinogenic, etc.



Warning!

- Do not return a measuring device if you are not absolutely certain that all traces of hazardous substances have been removed, e.g. substances which have penetrated crevices or diffused through plastic.
- Costs incurred for waste disposal or injury (burns, etc.) due to inadequate cleaning will be charged to the owner-operator.

1.5 Notes on safety conventions and icons

The devices can, however, be a source of danger if used incorrectly or for anything other than the designated use. Consequently, always pay particular attention to the safety instructions indicated in these Operating Instructions by the following icons:

The devices are designed to meet state-of-the-art safety requirements, have been tested, and left the factory in a condition in which they are safe to operate. The devices comply with the applicable standards and regulations in accordance with EN 61010-1 "Safety requirements for electrical equipment for measurement, control and laboratory use".



Warning!

"Warning" indicates an action or procedure which, if not performed correctly, can result in injury or a safety hazard. Comply strictly with the instructions and proceed with care.



Caution!

"Caution" indicates an action or procedure which, if not performed correctly, can result in incorrect operation or destruction of the device. Comply strictly with the instructions.



Note!

"Note" indicates an action or procedure which, if not performed correctly, can have an indirect effect on operation or trigger an unexpected response on the part of the device.

2 Identification

2.1 Device designation

The "Prosonic Flow 93T" flowmeter system consists of the following components:

- Prosonic Flow 93 transmitter
- Sensor:
 - Prosonic Flow P Clamp On version (DN 15 to 65 / ½ to 2½")
 - Prosonic Flow P Clamp On version (DN 50 to 4000 / 2 to 160")

The transmitter and the sensor are connected by a cable.

2.1.1 Nameplate of the transmitter




Fig. 1: Nameplate specifications for the "Prosonic Flow 93T" transmitter (example)

- 1 Order code/serial number: See the specifications on the order confirmation for the meanings of the individual letters and digits
- 2 Power supply/power consumption
- 3 Permitted ambient temperature range
- 4 Degree of protection

2.1.2 Nameplate of the sensor




Fig. 2: Nameplate specifications for the "Prosonic Flow P" sensor (example)

- A Sensor DN 50 to 300 (2 to 12") and DN 100 to 4000 (4 to 160")
- B Sensor DN 15 to 65 (1/2 to 2 1/2")
- 1 Order code/serial number: See the specifications on the order confirmation for the meanings of the individual letters and digits
- 2 Sensor type
- 3 Nominal diameter range
- 4 Max. fluid temperature
- 5 Degree of protection
- 6 Permitted ambient temperature range
- 7 Flow direction

2.2 Certificates and approvals

The devices are designed in accordance with good engineering practice to meet state-of-the-art safety requirements, have been tested, and left the factory in a condition in which they are safe to operate.

The devices comply with the applicable standards and regulations in accordance with EN 61010-1 "Safety requirements for electrical equipment for measurement, control and laboratory use" and with the EMC requirements of IEC/EN 61326.

The measuring system described in these Operating Instructions thus complies with the statutory requirements of the EC Directives. Endress+Hauser confirms successful testing of the device by affixing to it the CE mark.

The measuring system complies with the EMC requirements of the "Australian Communications and Media Authority (ACMA)".

2.3 Registered trademarks

HART®

Registered trademark of HART Communication Foundation, Austin, USA.

FieldCare®, Applicator®

Registered or registration-pending trademarks of Endress+Hauser Flowtec AG, Reinach, CH.

3 Installation

3.1 Incoming acceptance, transport and storage

3.1.1 Incoming acceptance

On receipt of the goods, check the following points:

- Check the packaging and the contents for damage.
- Check the shipment, make sure nothing is missing and that the scope of supply matches your order.

3.1.2 Transport

The devices must be transported in the container supplied when transporting them to the measuring point.

3.1.3 Storage

- Pack the measuring device in such a way as to protect it reliably against impact for storage (and transportation). The original packaging provides optimum protection.
- The storage temperature corresponds to the ambient temperature range of the transmitter, the sensors and the corresponding sensor cables (→ 61).
- The measuring device must be protected against direct sunlight during storage in order to avoid unacceptably high surface temperatures.

3.2 Installation conditions

3.2.1 Dimensions

The dimensions and lengths of the sensor and transmitter are provided in the separate "Technical Information" document on the device in question. This can be downloaded as a PDF file from www.endress.com.


A list of the "Technical Information" documents available is provided on → 64.

3.2.2 Mounting location

Correct flow measurement is possible only if a pipe is full. Entrained air or gas bubbles forming in the pipe can result in an increase in measuring errors.

For this reason avoid the following mounting locations in the pipe:

- Highest point of a pipeline. Risk of air accumulating.
- Directly upstream of a free pipe outlet in a vertical pipeline.



A0001103

Fig. 3: Mounting location

3.2.3 Orientation

Vertical

We recommend the sensor be mounted where there is upward direction of flow. With this orientation, entrained solids will sink down and gases will rise away from the sensor when the fluid is stagnant.

Horizontal

We recommend the sensors be mounted within an angle of $\pm 60^\circ$ to the horizontal (area shaded gray in the graphic). With this orientation, flow measurement is less affected by any gas or air accumulation in the upper area of the pipe or by buildup at the bottom of the pipe.




Fig. 4: Recommended orientation and recommended installation range

- A Recommended orientation with upward direction of flow
- B Recommended installation range with horizontal orientation
- C Recommended installation range max. 120°

3.2.4 Inlet and outlet run

If possible, install the sensor well clear of assemblies such as valves, T-pieces, elbows, etc. Compliance with the following inlet and outlet runs is required in order to ensure measuring accuracy.





Fig. 5: Inlet and outlet run

- 1 Valve (2/3 open)
- 2 Pump
- 3 Two pipe bends in different directions

3.2.5 Sensor selection and arrangement

The sensors can be arranged differently:

- Mounting arrangement for measurement via one traverse: the sensors are located on opposite sides of the pipe.
- Mounting arrangement for measurement via two traverses: the sensors are located on the same side of the pipe.



A0001108

Fig. 6: Sensor mounting arrangement

A Mounting arrangement for measurement via one traverse

B Mounting arrangement for measurement via two traverses

The number of traverses required depends on the sensor type, the nominal diameter and the thickness of the pipe wall. We recommend the following types of mounting:

Sensor Type	Nominal Diameter	Sensor Frequency	Sensor ID	Type of Mounting ¹⁾
Prosonic Flow P	DN 15 to 65 (½ to 2½")	6 MHz	P-CL-6F*	2 (or 1) traverses
	DN 50 to 65 (2 to 2½")	6 MHz (or 2 MHz)	P-CL-6F* P-CL-2F*	2 (or 1) traverses ²⁾
	DN 80 (3")	2 MHz	P-CL-2F*	2 traverses
	DN 100 to 300 (4 to 12")	2 MHz (or 1 MHz)	P-CL-2F* P-CL-1F*	2 traverses ³⁾
	DN 300 to 600 (12 to 24")	1 MHz (or 2 MHz)	P-CL-1F* P-CL-2F*	2 traverses ³⁾
	DN 650 to 4000 (26 to 160")	1 MHz (or 0.5 MHz)	P-CL-1F* W-CL-05F*	1 traverse ³⁾

¹⁾ The installation of clamp-on sensors is principally recommended in the 2 traverse type installation. This type of installation allows the easiest and most comfortable type of mounting and means that a system can also be mounted even if the pipe can only be accessed from one side. However, in certain applications a 1 traverse installation may be preferred. These include:

- Certain plastic pipes with wall thickness > 4 mm (0.16")
- Pipes made of composite materials such as GRP
- Lined pipes
- Applications with fluids with high acoustic damping

²⁾ If the pipe nominal diameter is small (DN 65 / 2½" and smaller), the sensor spacing with Prosonic Flow P can be too small for two traverse installation using sensor P-CL-2F*. In this case, the 1 traverse type of installation must be used.

³⁾ 0.5 MHz sensors (Prosonic Flow W) are also recommended for applications with composite material pipes such as GRP and may be recommended for certain lined pipes, pipes with wall thickness > 10 mm (0.4"), or applications with media with high acoustic damping. In addition, for these applications we principally recommend mounting the W sensors in a 1 traverse configuration.

3.3 Preparatory steps prior to installation

Depending on the conditions specific to the measuring point (e.g. Clamp On, number of traverses, fluid, etc.), a number of preparatory steps have to be taken before actually installing the sensors:

1. Determination of the values for the necessary installation distances based on the conditions specific to the measuring point. A number of methods are available for determining the values:
 - Local operation of the device
 - Applicator (software), online on the Endress+Hauser Internet site
2. Mechanical preparation of the Clamp On holders for the sensors:
 - Mount the sensor holder (DN 15 to 65 / ½ to 2½")
 - Premount the strapping bands (DN 50 to 200 / 2 to 8") or (DN 250 to 4000 / 10 to 160")

3.4 Determining the necessary installation distances

The installation distances that have to be maintained depend on:

- The type of sensor: Prosonic Flow P DN 50 to 4000 (2 to 160") or DN 15 to 65 (½ to 2½")
- The type of mounting: Clamp On with strapping band
- Number of traverses or single-path/dual-path version

3.4.1 Installation distances for Prosonic Flow P

DN 50 to 4000 (2 to 160")		DN 15 to 65 (½ to 2½")	
1 traverse	2 traverses	1 traverse	2 traverses
SENSOR DISTANCE	SENSOR DISTANCE	SENSOR DISTANCE*	
WIRE LENGTH	POSITION SENSOR	POSITION SENSOR*	

* In the SENSOR DISTANCE function, the distance is indicated in millimeters. The POSITION SENSOR function displays the values for using the mounting rail (e.g. A3).

3.5 Determining values for installation distances

3.5.1 Determining installation distances via local operation

Perform the following steps to determine the installation distances:

1. Connect and switch on the transmitter.
2. Run the "Sensor Installation" Quick Setup menu.

Connecting and switching on the transmitter




Fig. 7: Connecting and switching on the transmitter

- 1 On/off switch (press switch ≥ 3 seconds)
- 2 Charger connection (different adapters are available for the connection)


Running the "Sensor Installation" Quick Setup menu



- Note!
- If you are not familiar with the operation of the device → 33.
 - The following section only describes the steps necessary for Clamp On type of mounting within the "Sensor Installation" Quick Setup.

Running the Quick Setup for Clamp On type of mounting

1. Enter or select installation-specific values or the values specified here.
2. Read off the installation distances necessary for mounting.



Subsequent procedure

The sensors can be installed once the installation distances have been determined:

- Prosonic Flow P (DN 15 to 65 / ½ to 2½") → 23
- Prosonic Flow P (DN 50 to 4000 / 2 to 160") → 24

3.5.2 Determining installation distances via Applicator

Applicator is a software application for selecting and planning flowmeters. The installation distances required for installation can be determined without having to connect the transmitter beforehand.

Applicator is available:

- On a CD-ROM for installation on a local PC → 51.
- Via the Internet for direct online entry → www.endress.com → select country.
On the Internet site, select → Instruments → Flow → Tooling → Applicator. In the "Applicator Sizing Flow" field, select the "Start Applicator Sizing Flow online" link.

Determining installation distances for Clamp On, measuring via one traverse

Determine the installation distances required via Applicator:

- Select the fluid.
- Select the device (e.g. 93P Clamp On).
- Enter or select measuring point-specific values.
- Select the number of traverses: 1
- Read off the necessary installation distances:
 - Wire length: _____
 - Sensor distance: _____

Subsequent procedure

The mechanical preparation tasks can be performed once the installation distances have been determined → 15.

Determining installation distances for Clamp On, measuring via two traverses

Determine the installation distances required via Applicator:

- Select the fluid.
- Select the device (e.g. 93P Clamp On).
- Enter or select measuring point-specific values.
- Select the number of traverses: 2
- Read off the necessary installation distances:
 - Sensor position: _____
 - Sensor distance: _____

Subsequent procedure

The mechanical preparation tasks can be performed once the installation distances have been determined → 15

3.6 Mechanical preparation

The way in which the sensors are secured differs on account of the pipe nominal diameter and the sensor type. Depending on the type of sensor, users also have the option of securing the sensors with strapping bands or screws such that they can be later removed, or permanently fixing the sensors in place with welded bolts or welded holders.

Overview of possible ways to secure the various sensors:


Sensor	For the measuring range	Pipe nominal diameter	Secured by
P	DN 15 to 65 (½ to 2½")	DN 15 to 65 (½ to 2½")	Sensor holder → 23
P	DN 50 to 4000 (2 to 160")	DN ≤ 200 (8")	Strapping bands (metal, medium nominal diameters) → 20
		DN > 200 (8")	Strapping bands (metal, large nominal diameters) → 21
		DN 50 to 4000 (2 to 160")	Mounting with strapping bands (flexible) → 22

3.6.1 Mounting the sensor holder

- Sensor: Prosonic Flow (DN 15 to 65 / ½ to 2½")
- Sensor holder: Model 1 or 2

Model 1

1. Set the sensor distance determined (e.g. A19) on the sensor holder.
 - Release the screws of the sensor holders.
 - Position the sensor holders with the aid of the mounting rail.
 - Tighten the screws of the sensor holders again.




A0011548

Fig. 8: Setting the sensor distance with the mounting rail (value from POSITION SENSOR function)

- A Sensor distance for measurement via one traverse
 B Sensor distance for measurement via two traverses

2. Guide the sensor holder over the pipe.



A0011549

Fig. 9: Setting the sensor holder on the pipe

3. Release the screw of the retaining bracket (a) and push the retaining bracket up against the pipe.




Fig. 10: Guiding the retaining bracket onto the pipe

a Screw of retaining bracket

4. Fix the sensor holder in place by:
 - Tightening the screw of the retaining bracket (a)
 - Tightening the tensioning screw (b)



Warning!

Risk of damaging plastic or glass pipes if the screws are tightened too much! The use of a metal half-shell is recommended (on the opposite side of the tensioning screw) when working with plastic or glass pipes.




Fig. 11: Fixing the sensor holder

a Screw of retaining bracket

b Tensioning screw

Model 2

1. Set the sensor distance determined (e.g. C9) on the sensor holder.
 - Position the sensor holders with the aid of the mounting rail.




Fig. 12: Setting the sensor distance with the mounting rail (value from POSITION SENSOR function)

- A Sensor distance for measurement via one traverse
 B Sensor distance for measurement via two traverses

2. Guide the sensor holder over the pipe.




Fig. 13: Setting the sensor holder on the pipe

3. Release the quick release of the retaining bracket (a) and push the retaining bracket up against the pipe.




Fig. 14: Guiding the retaining bracket onto the pipe

a Quick release of retaining bracket

4. Fix the sensor holder in place by:
 - Tightening the quick release of the retaining bracket (a)
 - Tightening the quick release (b)




Fig. 15: Fixing the sensor holder

a Quick release of retaining bracket

b Quick release

3.6.2 Premounting the strapping bands (metal, medium nominal diameters)

When mounting on a pipe with a nominal diameter of $DN \leq 200$ (8").

Sensor: Prosonic Flow P (DN 50 to 4000 / 2 to 160")



Note!

Sensor orientation shown in the following sketches is for visual purposes only. Please apply the recommended orientation → 11.

Procedure

First strapping band

1. Fit the mounting bolt over the strapping band.
2. Wrap the strapping band around the pipe without twisting it.
3. Guide the end of the strapping band through the strapping band lock (tensioning screw is pushed up).
4. Tighten the strapping band as tight as possible by hand.
5. Set the strapping band to the desired position.
6. Push down the tensioning screw and tighten the strapping band so that it cannot slip.

Second strapping band

7. Proceed as for the first strapping band (steps 1 to 7). Only slightly tighten the second strapping band for final mounting. It must be possible to move the strapping band for final alignment.

Both strapping bands

8. Where necessary, shorten the strapping bands and trim the cut edges.



Warning!

Risk of injury. To avoid sharp edges, trim the cut edges after shortening the strapping bands.




Fig. 16: Premounting strapping bands for pipe diameters $DN \leq 200$ (8")

- 1 Mounting bolt
- 2 Strapping band
- 3 Tensioning screw

3.6.3 Premounting the strapping bands (metal, large nominal diameters)

When mounting on a pipe with a nominal diameter of $DN > 200$ (8").

Sensor: Prosonic Flow P (DN 50 to 4000 / 2 to 160")

Procedure

1. Measure the pipe circumference.
2. Shorten the strapping bands to one length (pipe circumference + 10 cm / 3.94") and trim the cut edges.



Warning!

Risk of injury. To avoid sharp edges, trim the cut edges after shortening the strapping bands.

First strapping band

3. Fit the centering plate along with the mounting bolt over the strapping band.
4. Wrap the strapping band around the pipe without twisting it.
5. Guide the end of the strapping band through the strapping band lock (tensioning screw is pushed up).
6. Tighten the strapping band as tight as possible by hand.
7. Set the strapping band to the desired position.
8. Push down the tensioning screw and tighten the strapping band so that it cannot slip.

Second strapping band

9. Proceed as for the first strapping band (steps 3 to 8). Only slightly tighten the second strapping band for final mounting. It must be possible to move the strapping band for final alignment.




Fig. 17: Premounting strapping bands for pipe diameters $DN > 200$ (8")

- 1 Centering plate with mounting bolt
- 2 Strapping band
- 3 Tensioning screw

3.6.4 Mounting with strapping bands (flexible)

For sensor Prosonic Flow P (DN 50 to 4000 / 2 to 160")



Caution!

- Each time you use the strapping bands, check that the ratchet locks and springs function safely beforehand.
- Inspect the strapping bands for damage.

Procedure

Closing the strapping band lock

1. Fit the mounting bolt onto the strapping band.
2. Guide the strapping band around the pipe making sure it is not twisted in the process and, with the ratchet lock (a) open, push the end through the slot. Pretension manually by pulling on the free end of the strapping band.



Note!

If you do not pretension the bands it is more difficult to release the strapping bands.

3. Tension continuously by moving the lever back and forth (b) until the strapping band is optimally tensioned.
4. Then push down the lever (c).




Caution!

The tensioning clamp (d) must engage on both sides!

Opening the strapping band lock

1. Pull back the lever lock (e) while simultaneously opening the lever 180° (f) until the lever lock (g) is engaged.
2. Remove the strapping band.



A0011550.

Fig. 18: Strapping band lock

- 1 Closing the strapping band lock
- 2 Opening the strapping band lock

3.7 Installing Prosonic Flow P (DN 15 to 65 / ½ to 2½")

3.7.1 Mounting the sensor

Prerequisites

- The sensor holder is already mounted → 16.
- The distance of the sensor holder is set (sensor distance) → 16.

Material

The following material is needed for mounting:

- Sensor
- Connecting cable




Note!

Prior to mounting, connect the connecting cables to the sensors.

Procedure


1. Coat the contact surfaces (1) of the sensors with an even layer of coupling fluid approx. 1 mm (0.04") thick.



A0013624


Fig. 19: Coating with coupling fluid

2. Mount as illustrated in the graphic (steps 1 to 5):



A0011552

Fig. 20: Mounting the sensors, Sensor holder: Model 1



A0013551

Fig. 21: Mounting the sensors, Sensor holder: Model 2

This completes the mounting process. The sensors can now be connected to the transmitter via the connecting cables → 31.

3.8 Installing Prosonic Flow P (DN 50 to 4000 / 2 to 160") (Clamp On)

3.8.1 Installation for measurement via one traverse

Prerequisites

- The installation distances (sensor distance and wire length) are known → 13.
- The strapping bands are already mounted → 15.

Material

The following material is needed for mounting:

- Two strapping bands incl. mounting bolts and centering plates where necessary (already mounted → 15)
- Two measuring wires, each with a cable lug and a fixer to position the strapping bands
- Two sensor holders
- Coupling fluid for an acoustic connection between the sensor and pipe
- Two sensors incl. connecting cables

Procedure

1. Prepare the two measuring wires:
 - Arrange the cable lugs and fixer such that the distance they are apart corresponds to the wire length (SL).
 - Screw the fixer onto the measuring wire.




Fig. 22: Fixer (a) and cable lugs (b) at a distance that corresponds to the wire length (SL)

2. With the first measuring wire:
 - Fit the fixer over the mounting bolt of the strapping band that is already securely mounted.
 - Run the measuring wire **clockwise** around the pipe.
 - Fit the cable lug over the mounting bolt of the strapping band that can still be moved.
3. With the second measuring wire:
 - Fit the cable lug over the mounting bolt of the strapping band that is already securely mounted.
 - Run the measuring wire **counterclockwise** around the pipe.
 - Fit the fixer over the mounting bolt of the strapping band that can still be moved.
4. Take the still movable strapping band, incl. the mounting bolt, and move it until both measuring wires are evenly tensioned and tighten the strapping band so that it cannot slip.




Fig. 23: Positioning the strapping bands (steps 2 to 4)

5. Loosen the screws of the fixers on the measuring wires and remove the measuring wires from the mounting bolt.
6. Fit the sensor holders over the individual mounting bolts and tighten securely with the retaining nut.




Fig. 24: Mounting the sensor holders

7. Coat the contact surfaces of the sensors with an even layer of coupling fluid approx. 1 mm (0.04") thick, going from the groove through the center to the opposite edge.




Fig. 25: Coating the contact surfaces of the sensor with coupling fluid

8. Insert the sensor into the sensor holder.
9. Fit the sensor cover on the sensor holder and turn until:
 - The sensor cover engages with a click.
 - The arrows (▲ / ▼ "close") are pointing towards one another.
10. Screw the connecting cable into the individual sensor.




Fig. 26: Mounting the sensor and connecting the connecting cable

This completes the mounting process. The sensors can now be connected to the transmitter via the connecting cables → 31.

3.8.2 Installation for measurement via two traverses

Prerequisites

- The installation distance (position sensor) is known → 13.
- The strapping bands are already mounted → 15.

Material

The following material is needed for mounting:

- Two strapping bands incl. mounting bolts and centering plates where necessary (already mounted → 15)
- A mounting rail to position the strapping bands
- Two mounting rail holders
- Two sensor holders
- Coupling fluid for an acoustic connection between the sensor and pipe
- Two sensors incl. connecting cables

Mounting rail and POSITION SENSOR installation distance

The mounting rail has two rows with bores. The bores in one of the rows are indicated by letters and the bores in the other row are indicated by numerical values. The value determined for the POSITION SENSOR installation distance is made up of a letter and a numerical value.

The bores that are identified by the specific letter and numerical value are used to position the strapping bands.

Procedure

1. Position the strapping bands with the aid of the mounting rail.
 - Slide the mounting rail with the bore identified by the letter from POSITION SENSOR over the mounting bolt of the strapping band that is permanently fixed in place.
 - Position the movable strapping band and slide the mounting rail with the bore identified by the numerical value from POSITION SENSOR over the mounting bolt.




Fig. 27: Determining the distance in accordance with the mounting rail (e.g. POSITION SENSOR G22)

2. Tighten the strapping band so that it cannot slip.
3. Remove the mounting rail from the mounting bolt.
4. Fit the sensor holders over the individual mounting bolts and tighten securely with the retaining nut.




Fig. 28: Mounting the sensor holders

5. Coat the contact surfaces of the sensors with an even layer of coupling fluid approx. 1 mm (0.04") thick, going from the groove through the center to the opposite edge.




Fig. 29: Coating the contact surfaces of the sensor with coupling fluid

6. Insert the sensor into the sensor holder.
7. Fit the sensor cover on the sensor holder and turn until:
 - The sensor cover engages with a click.
 - The arrows (▲ / ▼ "close") are pointing towards one another.
8. Screw the connecting cable into the individual sensor.




Fig. 30: Mounting the sensor and connecting the connecting cable

This completes the mounting process. The sensors can now be connected to the transmitter via the connecting cables → 31.

3.9 Installing sensor DDU18

1. Premount the strapping band:
 - Nominal diameters $DN \leq 200$ (8") → 20
 - Nominal diameters $DN > 200$ (8") → 21The two mounting bolts must be positioned opposite each other on either side of the pipe.
2. Fit the sensor holders over the individual mounting bolts and tighten securely with the retaining nut.
3. Coat the contact surfaces of the sensors with an even layer of coupling fluid approx. 1 mm (0.04") thick, going from the groove through the center to the opposite edge.
4. Insert the sensor into the sensor holder.
5. Fit the sensor cover on the sensor holder and turn until:
 - The sensor cover engages with a click.
 - The arrows (▲ / ▼ "close") are pointing towards one another.
6. Screw the connecting cable into the individual sensor.




Fig. 31: Steps 1 to 5, installing the sound velocity measuring sensors

3.10 Installing sensor DDU20 (wall thickness measurement)

3.10.1 Method 1

Measuring the wall thickness on pipes DN 15 to 65 ($\frac{1}{2}$ to $2\frac{1}{2}$ ") when using the sensor holder shown on → [16](#) or → [18](#).

1. Mount sensor holder per instructions → [16](#) or → [18](#).
2. Coat the contact surface (1) of the sensor with an even layer of coupling fluid approx. 1 mm (0.04") thick.




Fig. 32: Coating with coupling fluid

3. Mount sensor as illustrated in the graphic (steps 1 to 5).




Fig. 33: Mounting the sensor, Sensor holder: Model 1




Fig. 34: Mounting the sensor, Sensor holder: Model 2

4. The sensor can now be connected to the 93T transmitter via the connecting cables.



Note!

The polarity of the connections to the 93T transmitter is not important for wall thickness measurement.

If flow sensors are to be installed after the wall thickness measurement is made, be sure to clean the pipe surface once again.

3.10.2 Method 2

Measuring the wall thickness on pipes DN 50 to 4000 (2 to 160").

- 1. Coat the contact surface of the sensor with an even layer of coupling fluid approx. 1 mm (0.04") thick.
- 2. Hold the sensor by hand on the pipe for measurement. Be sure that the horizontal line on the sensor contact surface is parallel to the axis of the pipe.




Fig. 35: Measuring the wall thickness



- 3. The sensor can now be connected to the 93T transmitter via the connecting cables.

Note!
The polarity of the connections to the 93T transmitter is not important for wall thickness measurement.
If flow sensors are to be installed after the wall thickness measurement is made, be sure to clean the pipe surface once again.

3.11 Post-installation check

Perform the following checks after installing the measuring device on the pipe:

Device condition and specifications	Notes
Is the cable or the device damaged (visual inspection)?	–
Does the device correspond to specifications at the measuring point, including process temperature, ambient temperature, measuring range, etc.?	→ 61
Installation	Notes
Are the measuring point number and labeling correct (visual inspection)?	–
Process environment / process conditions	Notes
Have the inlet and outlet runs been observed?	→ 11
Is the measuring device protected against moisture and direct sunlight?	–

4 Wiring

4.1 Charging the NiMH storage battery



Warning!

- The storage battery for the device (NiMH storage batteries) may only be charged with the charger supplied. Other equipment could cause the battery to overheat.
- Compare the information on the nameplate of the charger with the local supply voltage and frequency.

To charge the storage battery, connect the charger to the connection for 12 V DC power supply of the measuring device (→  36, No. 7). It takes approx. 3.6 hours to charge the battery. Once charged, the unit operating life is approx. 8 hours.

4.2 Connecting the connecting cable



Warning!

- Only use the connecting cables supplied by Endress+Hauser.
- The measuring device only complies with the general safety requirements in accordance with EN 61010-1 and the EMC requirements of IEC/EN 61326 during storage battery operation. Disconnect the charger from the measuring device for measuring operation.

The connecting cables are available in different lengths →  50.

Connect the connecting cable to the connections CH-DN (downstream) and CH-UP (upstream) (→  36, No. 4 and 5). The connectors on the connecting cable and measuring device have the same color code.



Note!

To ensure correct measuring results, route the cable well clear of electrical machines and switching elements.




Fig. 36: Transmitter connections

- 1 On/off switch (press switch ≥ 3 seconds)
- 2 Current input connection
- 3 USB plug connection
- 4 Connecting cable connection (CH-DN, downstream)
- 5 Connecting cable connection (CH-UP, upstream)
- 6 FXA193/FXA291 modem connection
- 7 Charger connection (different adapters are available for the connection)

4.3 Cable specification for connecting cable

Information on the cable specifications →  58.

4.4 Potential equalization

No special measures are necessary for potential equalization.

4.5 Degree of protection

Information on the degree of protection →  61.

4.6 Post-connection check

Perform the following checks after completing electrical installation of the measuring device:

Device condition and specifications	Notes
Are cables or the device damaged (visual inspection)?	–
Electrical connection	Notes
Does the supply voltage match the information on the nameplate on the charger?	→  58
Is the connecting cable connected correctly?	→  31

5 Operation

5.1 Quick operation guide

You have a number of options for configuring and commissioning the device:

1. Local display (option) →  33
The local display enables you to read all of the important parameters directly at the measuring point, configure device-specific parameters in the field and commission the instrument.
2. Configuration program →  39
You can commission the device with the FieldCare operating program.

5.2 Display and operating elements

The local display enables you to read all important parameters directly at the measuring point and configure the device using the "Quick Setup" or the function matrix.

The display area consists of four lines; this is where measured values are displayed, and/or status variables (direction of flow, bar graph, etc.). You can change the assignment of display lines to different variables to suit your needs and preferences.




Fig. 37: Display and operating elements

Liquid crystal display (1)

The backlit, four-line liquid-crystal display shows measured values, dialog texts, error messages and notice messages. The display as it appears when normal measuring is in progress is known as the HOME position (operating mode).

Optical sensors for "Touch Control" (2)

2 Plus/minus keys (3)

- HOME position → Direct access to totalizer values and actual values of inputs/outputs
- Enter numerical values, select parameters
- Select different blocks, groups and function groups within the function matrix

Press the  keys simultaneously to trigger the following functions:

- Exit the function matrix step by step → HOME position
- Press and hold down the  keys for longer than 3 seconds → Return directly to HOME position
- Cancel data entry

3 Enter key (4)

- HOME position → Entry into the function matrix
- Save the numerical values you input or settings you change

Display (operating mode)

The display area consists of three lines in all; this is where measured values are displayed, and/or status variables (direction of flow, bar graph, etc.). You can change the assignment of display lines to different variables to suit your needs and preferences.

Multiplex mode:

A maximum of two different display variables can be assigned to each line. Variables multiplexed in this way alternate every 10 seconds on the display.

Error messages:

In-depth information on how system/process errors are displayed is provided on → 52 ff.




Fig. 38: Typical display for standard operating mode (HOME position)

- 1 Main line: shows main measured values, e.g. volume flow in [l/s].
- 2 Additional line: shows additional measured variables and status variables, e.g. totalizer reading No. 3 in [m3].
- 3 Information line: shows additional information on the measured variables and status variables, e.g. bar graph display of the end value achieved by the volume flow.
- 4 "Info icons" field: icons representing additional information on the measured values are shown in this field. A full overview of all the symbols and their meaning is provided on → 35.
- 5 "Measured values" field: the current measured values appear in this field.
- 6 "Unit of measure" field: the units of measure and time defined for the current measured values appear in this field.



Note!

From the HOME position, you can use the $\boxed{+/-}$ keys to open an "Info Menu" containing the following information:

- Totalizers (including overflow)
- Actual values or states of the configured inputs/outputs
- Device TAG number (user-definable).

$\boxed{+/-}$ key → Scan of individual values within the list

Esc key ($\boxed{\text{Esc}}$) → Return to HOME position

Icons

The icons which appear in the field on the left make it easier to read and recognize measured variables, device status, and error messages.

Icon	Meaning	Icon	Meaning
S	System error	P	Process errors
	Fault message (with effect on outputs)	!	Notice message (without effect on outputs)
Σ 1 to n	Totalizer 1 to n	 A0013672	Signal strength
 A0001181	Measuring mode: PULSATING FLOW	 A0001182	Measuring mode: SYMMETRY (bidirectional)
 A0001183	Measuring mode: STANDARD	 A0001184	Totalizer count mode: BALANCE (forward and backward)
 A0001185	Totalizer count mode: Forward	 A0001186	Totalizer count mode: Backward
 A0001187	Signal input (current input or status input)	 A0001188	Volume flow
 A000xxxx	Device operation active	 A0013613	Battery operation
		 A0013614	Connected to mains power

5.3 Brief guide to the function matrix



Note!

- See the general notes → 37.
- Function description → 65

1. HOME position → → Entry into the function matrix
2. Select a block (e.g. USER INTERFACE)
3. Select a group (e.g. CONTROL)
4. Select a function group (e.g. BASIC CONFIGURATION)
5. Select a function (e.g. LANGUAGE)

Change parameter / enter numerical values:

- Select or enter enable code, parameters, numerical values
- Save your entries

6. Exit the function matrix:
 - Press and hold down Esc key () for longer than 3 seconds → HOME position
 - Repeatedly press Esc key () → Return step-by-step to HOME position.




Fig. 39: Selecting functions and configuring parameters (function matrix)

A0001210

5.3.1 General notes

The Quick Setup menu (→  43) contains the default settings that are adequate for commissioning. Complex measuring operations on the other hand necessitate additional functions that you can configure as necessary and customize to suit your process parameters. The function matrix, therefore, comprises a multiplicity of additional functions which, for the sake of clarity, are arranged on a number of menu levels (blocks, groups, and function groups).

Comply with the following instructions when configuring functions:

- You select functions as described on →  36. Each cell in the function matrix is identified by a numerical or letter code on the display.
- You can switch off certain functions (OFF). If you do so, related functions in other function groups will no longer be displayed.
- Certain functions prompt you to confirm your data entries.
Press  to select "SURE [YES]" and press  to confirm. This saves your setting or starts a function, as applicable.
- Return to the HOME position is automatic if no key is pressed for 5 minutes.



Note!

- The transmitter continues to measure while data entry is in progress, i.e. the current measured values are output via the signal outputs in the normal way.
- If the power supply fails all preset and parameterized values remain safely stored in the EEPROM.



Caution!

All functions are described in detail, as is the function matrix itself on →  65.

5.3.2 Enabling the programming mode

The function matrix can be disabled. Disabling the function matrix rules out the possibility of inadvertent changes to device functions, numerical values or factory settings. A numerical code (factory setting = 80) has to be entered before settings can be changed.

If you use a code number of your choice, you exclude the possibility of unauthorized persons accessing data.

Comply with the following instructions when entering codes:

- If programming is disabled and the  operating elements are pressed in any function, a prompt for the code automatically appears on the display.
- If "0" is entered as the private code, programming is always enabled.
- The Endress+Hauser service organization can be of assistance if you mislay your personal code.



Caution!

Changing certain parameters such as all sensor characteristics, for example, influences numerous functions of the entire measuring system, particularly measuring accuracy.

There is no need to change these parameters under normal circumstances and consequently, they are protected by a special code known only to the Endress+Hauser service organization. Please contact Endress+Hauser if you have any questions.

5.3.3 Disabling the programming mode

Programming mode is disabled if you do not press an operating element within 60 seconds following automatic return to the HOME position.

You can also disable programming in the "ACCESS CODE" function by entering any number other than the customer's code.

5.4 Error messages

5.4.1 Type of error

Errors that occur during commissioning or measuring are displayed immediately. If two or more system or process errors occur, the error with the highest priority is the only one shown on the display.

The measuring system distinguishes between two types of error:

- **System error:** this group includes all device errors, for example communication errors, hardware errors, etc. (→ 52).
- **Process error:** this group includes all application errors, e.g. measuring range exceeded (→ 54).




Fig. 40: Error messages on the display (example)

- 1 Error type: P = process error, S = system error
- 2 Error message type: ⚡ = fault message, ! = notice message, (definition: → 52)
- 3 Error designation: e.g. S. V. RANGE CH1. = sound velocity of channel 1 is outside the measuring range
- 4 Error number: e.g. #492
- 5 Duration of most recent error occurrence (in hours, minutes and seconds)

5.4.2 Error message types

Users have the option of weighting system and process errors differently, by defining them as either **Fault messages** or **Notice messages**. This is specified by means of the functions in the function matrix. → 65. Serious system errors, e.g. module defects, are always identified and classed as "fault messages" by the measuring device.

Notice message (!)

- Displayed as → Exclamation mark (!), error group (S: system error, P: process error).
- The error in question has no effect on the outputs of the measuring device.

Fault message (⚡)

- Displayed as → Lightning flash (⚡), error designation (S: system error, P: process error)
- The error in question has a direct effect on the outputs.

The response of the outputs (failsafe mode) can be defined by means of functions in the function matrix (→ 56).



Note!

- Error conditions can be output via the relay outputs.
- If an error message occurs, an upper or lower signal level for the breakdown information according to NAMUR NE 43 can be output via the current output.

5.4.3 Confirming error messages

For plant and process safety reasons, the measuring device can be configured in such a way that fault messages displayed (F) not only have to be eliminated but also have to be confirmed by pressing [F]. Only then will error messages disappear from the display!

This function is enabled or disabled via the ACKNOWL. FAULTS function.



Note!

- Fault messages (F) can also be reset and confirmed via the status input.
- Notice messages (!) do not have to be confirmed. However, they remain on the display until the cause for the error has been eliminated.

5.5 Communication

5.5.1 FieldCare

FieldCare is Endress+Hauser's FDT-based plant asset management tool and allows the configuration and diagnosis of intelligent field devices. By using status information, you also have a simple but effective tool for monitoring devices. The Proline flowmeters are accessed via a service interface or via the service interface FXA193.

6 Commissioning

6.1 Function check

Make sure that all final checks have been completed before you commission your measuring point:

- Checklist for "Post-installation check" → 30
- Checklist for "Post-connection check" → 32

6.2 Switching on the measuring device




Warning!

The measuring device only complies with the general safety requirements in accordance with EN 61010-1 and the EMC requirements of IEC/EN 61326 during storage battery operation. Disconnect the charger from the measuring device for measuring operation.

The measuring device is switched on by pressing the ON/OFF switch ≥ 3 seconds (→ 31, → 36, No. 1).

The measuring system performs a number of internal test functions after power-up. During this process, the following sequence of messages appears on the local display:



Normal measuring mode commences as soon as startup completes. Various measured value and/or status variables appear on the display (HOME position).



Note!

If startup fails, an appropriate error message is displayed, depending on the cause.

6.2.1 Resetting the measuring device

The measuring device is reset by pressing the ON/OFF switch ≥ 30 seconds (→ 31, → 36, No. 1). Only the internal clock of the measuring device is reset during the reset. All the other settings remain unchanged.

6.3 Commissioning via onsite display

6.3.1 Quick Setup "Sensor Installation"

The installation distances needed to install the sensors can be determined using the Quick Setup menu → 13.




Fig. 41: Quick Setup menu "Sensor" (only via onsite display)


A0011560-en

**Note!**

- The installation distances can also be determined via the Applicator online tool →  15.
 - The display returns to the function SETUP SENSOR (1001) if you press the ESC key combination during parameter interrogation.
-
- ① Selection of the system units only influences the functions:
 - UNIT TEMPERATURE (0422)
 - UNIT LENGTH (0424)
 - UNIT VELOCITY (0425)
 - ② The necessary installation distances are determined with the CLAMP ON option.
 - ③ The INSERTION option is not supported by the Prosonic Flow 93T sensor.
 - ④ The SOUND VELOCITY LIQUID option is only needed for the DDU18 sensor.
"Save?" prompt:
 - YES = The value measured during Quick Setup is accepted in the appropriate function.
 - NO = The measurement is discarded and the original value remains.
 - ⑤ The SOUND VELOCITY PIPE option is only needed for the DDU18 sensor.
"Save?" prompt:
 - YES = The value measured during Quick Setup is accepted in the appropriate function.
 - NO = The measurement is discarded and the original value remains.
 - ⑥ The WALL THICKNESS option is only needed for the DDU20 sensor.
"Save?" prompt:
 - YES = The value measured during Quick Setup is accepted in the appropriate function.
 - NO = The measurement is discarded and the original value remains.
 - ⑦ The POSITION SENSOR function (6884) only appears if:
 - The CLAMP ON option is selected in the MEASUREMENT function (6880)
and
 - Two traverses are selected in the SENSOR CONFIGURATION function (6882)
 - ⑧ The WIRE LENGTH function (6885) only appears if:
 - The CLAMP ON option is selected in the MEASUREMENT function (6880)
and
 - One traverse is selected in the SENSOR CONFIGURATION function (6882)

6.3.2 Quick Setup "Commissioning"

All the device parameters important for standard measuring mode, as well as additional functions, can be configured easily and quickly using the Quick Setup menu.



A0011559-en

Fig. 42: Quick Setup "Commissioning"



Note!

- The display returns to the function SETUP COMMISSIONING (1002) if you press the ESC key combination during parameter interrogation.
- If you answer YES to the question regarding the "Automatic configuration of the display", the display lines are assigned as follows:
 - Main line = volume flow
 - Additional line = totalizer 1
 - Information line = operating/system condition

- ① Only units not yet configured in the current Quick Setup are offered for selection in each cycle. The volume unit is derived from the volume flow unit.
- ② The "YES" option remains visible until all the units have been configured. "NO" is the only option displayed when no further units are available.
- ③ Only outputs not yet configured in the current Quick Setup are offered for selection in each cycle.

6.3.3 Quick Setup "Pulsating Flow"

A flow that fluctuates severely, for a temporary period, occurs when using pump types that transport media in a pulsating manner, such as reciprocating pumps, peristaltic pumps and eccentric pumps. Negative flow on account of the closing volume or valve leakage can also occur with these pumps.



Note!

Execute the Quick Setup "Commissioning" before running the Quick Setup "Pulsating Flow"

→ 43.




Fig. 43: Flow characteristic of different pump types

A With high pulsating flow

B With low pulsating flow

1 1-cylinder eccentric pump

2 2-cylinder eccentric pump

3 Solenoid pump

4 Peristaltic pump, flexible connecting cable

5 Multi-cylinder reciprocating pump

High pulsating flows

By specifically configuring a number of different device functions via the "Pulsating Flow" Quick Setup, flow fluctuations over the entire flow range can be compensated for, and pulsating liquid flows can be measured correctly. The process for executing the Quick Setup menu is described in detail in the next section.



Note!

It is recommended to always run the "Pulsating Flow" Quick Setup if you are unsure of the exact flow characteristics.

Low pulsating flows


It is **not** absolutely essential to run the Quick Setup if only minor flow fluctuations occur, e.g. when using gear-type pumps, three-cylinder or multi-cylinder pumps.

In such situations, however, it is advisable to adapt the functions listed below to meet the local process conditions to achieve a stable, constant output signal. This applies, in particular, to the current output:

- Measuring system damping: "SYSTEM DAMPING" function → Increase value
- Current output damping: "TIME CONSTANT" function → Increase value

Running the "Pulsating Flow" Quick Setup

With the aid of this Quick Setup, the user is systematically guided through all the device functions that have to be adjusted and configured for measuring operation with pulsating flow. Values that are already configured, such as the measuring range, current range or full scale value, are not changed in the process!



A0011561-en

Fig. 44: "Quick Setup" menu for operation with high pulsating flow



Note!

- The display returns to the function SETUP PULSATING FLOW (1003) if you press the ESC key combination during parameter interrogation.
- This Quick Setup can either be called up directly after the "COMMISSIONING" Quick Setup, or it can be called up manually via the SETUP PULSATING FLOW function (1003).

① Only counters not yet configured in the current Quick Setup are offered for selection in each cycle.

② The "YES" option remains visible until all the counters have been configured.
"NO" is the only option displayed when no further counters are available.

Quick Setup "Pulsating Flow"		
HOME position →  → MEASURED VARIABLE (A) MEASURED VARIABLE →  → QUICK SETUP (B) QUICK SETUP → N → QS PULS. FLOW (1003)		
Function No.	Function name	Setting to be selected (P)
1003	QS PULS. FLOW.	YES
After  is pressed by way of confirmation, the Quick Setup menu calls up all the subsequent functions in succession.		



Basic settings		
2002	DISPLAY DAMPING	1 s
3002	TOTALIZER MODE (DAA)	BALANCE (totalizer 1)
3002	TOTALIZER MODE (DAB)	BALANCE (totalizer 2)
3002	TOTALIZER MODE (DAC)	BALANCE (totalizer 3)
Other settings		
8005	ALARM DELAY	0 s
6400	ASSIGN LF CUT OFF	VOLUME FLOW
6402	ON-VAL. LF CUT OFF	Recommended setting 0.4 l/s
6403	OFF-VAL. LF CUT OFF	50%
6404	PRESS. SHOCK SUPP.	0 s



Back to the HOME position → Press and hold down Esc key () for longer than three seconds. → Repeatedly press and release Esc key () → Exit the function matrix step by step		
---	--	--

6.4 Application-specific commissioning

6.4.1 Zero point adjustment

Zero point adjustment is generally not necessary!

Experience shows that the zero point adjustment is advisable only in special cases:

- To achieve highest measuring accuracy with very low flow rates.
- Under extreme process or operating conditions (e.g. very high process temperatures or very high viscosity fluids).

Preconditions for a zero point adjustment

Note the following before you perform a zero point adjustment:

- A zero point adjustment can be performed only with fluids that have no gas or solid contents.
- Zero point adjustment is performed with the measuring tube completely filled and at zero flow ($v=0$ m/s). This can be achieved, for example, with shutoff valves upstream and/or downstream of the measuring range or by using existing valves and gates (→ 47).
 - Standard operation → Valves 1 and 2 open
 - Zero point adjustment with pump pressure → Valve 1 open / valve 2 closed
 - Zero point adjustment without pump pressure → Valve 1 closed / valve 2 open



Caution!

- If the fluid is very difficult to measure (e.g. containing entrained solids or gas) it may prove impossible to obtain a stable zero point despite repeated zero point adjustments. In instances of this nature, please contact your Endress+Hauser service center.
- You can view the currently valid zero point value using the ZERO POINT function.




Fig. 45: Zero point adjustment and shutoff valves

Performing a zero point adjustment

1. Operate the system until normal operating conditions resume.
2. Stop the flow ($v = 0$ m/s).
3. Check the shutoff valves for leaks.
4. Check that operating pressure is correct.
5. Using the local display, select the "ZEROPOINT ADJUST" function in the function matrix:

HOME →  → R → BASIC FUNCTIONS
 BASIC FUNCTIONS →  → R → PROCESS PARAMETER CH1/CH2
 PROCESS PARAMETER →  → R → ADJUSTMENT
 ADJUSTMENT →  → ZEROPOINT ADJUST

6. When you press  you are automatically prompted to enter the access code if the function matrix is still disabled. Enter the code.
7. With , select the START setting and confirm with .
 Acknowledge the security prompt with YES and press  to confirm. Zero point adjustment is now started:
 - The message "ZEROPOINT ADJUST RUNNING" appears on the display for 30 to 60 seconds while adjustment is in progress.
 - If the flow in the pipe exceeds 0.1 m/s, the following error message appears on the display: ZERO ADJUST NOT POSSIBLE.
 - When the zero point adjustment completes, the "ZERO ADJUST" function reappears on the display.
8. Back to the HOME position
 - Press and hold down Esc key () for longer than three seconds.
 - Repeatedly press and release the Esc key (.

6.5 Using the data logger

Prosonic Flow has the capability to log volume flow, flow velocity, sound velocity, signal strength, signal to noise ratio, the content of the three internal totalizers, external volume flow, and the actual current of the current input. The data set is fixed and not configurable. The sampling time is configurable. The logged data are stored on an external memory unit (1 GB USB memory stick) in a CSV text format.

Logging is started from the LOGGING function found in the OUTPUTS → DATALOGGER menu when a memory stick is available. Logging is stopped in the same function or by removing the memory stick from the unit. The latter is not a recommended method due to the remote possibility corrupting the data.

6.6 Data exchange with Prosonic Flow 93T

Prosonic Flow 93T uses a text file format commonly referred to as a CSV format (**C**omma **S**eparated **V**alues) for its data exchange.

A logged data record is placed on one line. A record contains a number of fields (time stamp, measurement parameters, flow data, etc.). A delimiter – a blank space, semi-colon, comma or other character that indicates the beginning or end of a field – is used to organize the fields into columns. A separator – usually a point (.) or a comma (,) – is used to identify the location of the decimal.

Prosonic Flow 93T uses the format semicolon (;) as field delimiter and point (.) as decimal separator. Adjustments may need to be made in spreadsheet software by setting the field delimiter and decimal separator correctly prior to importing the data from the flowmeter to ensure proper visualization of the data. The adjustments required are dependant on the local settings used by the PCs and Laptops in a particular region. In general, set the field delimiter to semi-colon (;) and the decimal separator to point (.) and the logged data will be converted to a format that is compatible with the numeric settings of the local PC or Laptop.

7 Maintenance

7.1 General

The flow measuring system Prosonic Flow 93T requires no special maintenance.

Exterior cleaning

When cleaning the exterior of measuring devices, always use cleaning agents that do not attack the surface of the housing and the seals.

Coupling fluid

A coupling fluid is required to ensure the acoustic link between the sensor and the piping. This is applied to the sensor surface during commissioning. Periodic replacement of the coupling fluid is usually not required.

7.2 Charging the device

Prosonic Flow 93T is charged applying the supplied power supply type FW7362M12 or the optional DK9ZT-2 automobile cigarette lighter charging cable. Prosonic Flow 93T is supplied pre-charged, but it is recommended to charge the device before first use.

The Prosonic Flow 93T can be charged in the temperature range +5 to +45 °C (+41 to +113 °F). The charging process is monitored and protected. It will idle when the temperature at the battery pack exceeds +35 °C (+95 °F) and resume when the temperature drops below that temperature. Below +5 °C (+41 °F) and above +45 °C (+113 °F) charging is terminated. The charging time is 4 hours when starting empty. Good maintenance praxis is to charge the battery pack fully before use and optimally to discharge it fully before recharging to ensure optimal battery life.

The device will automatically stop the charging when the battery is fully charged. The charge bar will indicate 100%.

8 Accessories

Various accessories, which can be ordered separately from Endress+Hauser, are available for the transmitter and the sensor. The Endress+Hauser service organization can provide detailed information on the order codes on request.

Device-specific accessories

Accessory	Description	Order code
Sensor P (DN 15 to 65 / ½ to 2½") Clamp-on version	DN 15 to 65 (½ to 2½") ■ -40 to +100 °C (-40 to +212 °F) ■ -40 to +150 °C (-40 to +302 °F)	DK9PT - 1A DK9PT - 2A
Sensor P (DN 50 to 4000 / 2 to 160") Clamp-on version	DN 50 to 300 (2 to 12") ■ -40 to +80 °C (-40 to +176 °F) ■ -40 to +170 °C (-40 to +338 °F) DN 100 to 4000 (4 to 160") ■ -40 to +80 °C (-40 to +176 °F) ■ 0 to +170 °C (+32 to +338 °F)	DK9PT - BA DK9PT - FA DK9PT - AA DK9PT - EA
Sensor DDU18	Sensor for sound velocity measurement -40 to +80 °C (-40 to +176 °F) 0 to +170 °C (+32 to +338 °F)	50091703 50091704
Sensor DDU20	Sensor for wall thickness measurement. ■ -20 to +60 °C (-4 to +140 °F)	71112217

Measuring principle-specific accessories

Accessory	Description	Order code
Sensor holder set	■ Prosonic Flow P (DN 15 to 65 / ½ to 2½"): Sensor holder, clamp-on version ■ Prosonic Flow P (DN 50 to 4000 / 2 to 160") – Sensor holder, fixed retaining nut, clamp-on version – Sensor holder, removable retaining nut, clamp-on version	DK9SH - 2 DK9SH - A DK9SH - B
Clamp-on installation set Clamp On	■ DN < 1500 (60") (textile strapping) ■ DN ≥ 1500 (60") (textile strapping) ■ DN 50 to 300 (2 to 12"): 0 to +170 °C (+32 to +338 °F) (stainless steel strapping)	DK9ZT - D DK9ZT - E DK9ZT - B
Connecting cable	5 m (16.4 ft) sensor cable, PTFE, -40 to +170 °C (-40 to +338 °F) 10 m (32.8 ft) sensor cable, PTFE, -40 to +170 °C (-40 to +338 °F)	DK9SS - CEE DK9SS - CEF
Acoustic coupling fluid	■ Coupling fluid: 0 to +170 °C (+32 to +338 °F), standard, high temperature ■ Adhesive coupling fluid: -40 to +80 °C (-40 to +176 °F) ■ Water-soluble coupling fluid: -20 to +80 °C (-4 to +176 °F) ■ Coupling fluid DDU20: -20 to +60 °C (-4 to +140 °F) ■ Coupling fluid: -40 to +80 °C (-40 to +176 °F), standard, type MBG2000	DK9CM - 2 DK9CM - 3 DK9CM - 4 DK9CM - 6 DK9CM - 7

Service-specific accessories

Accessory	Description	Order code
Applicator	Software for selecting and planning flowmeters. The Applicator can be downloaded from the Internet or ordered on CD-ROM for installation on a local PC. Contact your Endress+Hauser representative for more information.	DXA80 – *
Fieldcheck	Tester/simulator for testing flowmeters in the field. When used in conjunction with the "FieldCare" software package, test results can be imported into a database, printed out and used for official certification. Contact your Endress+Hauser representative for more information.	50098801
FieldCare	FieldCare is Endress+Hauser's FDT-based plant asset management tool. It can configure all intelligent field units in your system and helps you manage them. By using the status information, it is also a simple but effective way of checking their status and condition.	See the product page on the Endress+Hauser website: www.endress.com
FXA193	Service interface from the measuring device to the PC for operation via FieldCare.	FXA193 – *
Communication cable	Communication cable for connecting the Prosonic Flow 93T transmitter to the FXA193 service interface.	DK9ZT – A
FXA291	Service interface from the measuring device to the PC for operation via FieldCare.	FXA291 – *
Communication cable	Communication cable for connecting the Prosonic Flow 93T transmitter to the FXA291 service interface.	DK9ZT – 8

9 Troubleshooting

9.1 Troubleshooting instructions

Always start troubleshooting with the following checklist if faults occur after commissioning or during operation. The routine takes you directly to the cause of the problem and the appropriate remedial measures.

Check the display	
Nothing shown on the display.	Check the device storage battery and charge it if necessary.
Display texts are in a foreign language.	1. Switch off the measuring device. 2. Press and hold down both the   keys and switch on the measuring device. The display text will appear in English (default) and is displayed at maximum contrast.
▼	
Error messages on display	
Errors that occur during commissioning or measuring are displayed immediately. Error messages consist of a variety of icons. The meanings of these icons are as follows: – Type of error: S = System error, P = Process error – Error message type:  = Fault message,  = Notice message – S.V. RANGE CH1 = error designation (e.g. sound velocity for channel 1 is outside the measuring range) – 03:00:05 = duration of error occurrence (in hours, minutes and seconds) – #492 = error number  Caution! ■ See the information on →  38! ■ The measuring system interprets simulations and positive zero return as system errors, but displays them as notice messages only.	
Error number: No. 001 – 399 No. 501 – 799	System error (device error) has occurred →  52
Error number: No. 401 – 499	Process error (application error) has occurred →  54
▼	
Other error (without error message)	
Some other error has occurred.	Diagnosis and rectification →  55

9.2 System error messages

Serious system errors are **always** recognized by the instrument as "Fault message" and are shown as a lightning flash () on the display! Fault messages immediately affect the inputs and outputs.



Caution!
In the event of a serious fault, a flowmeter might have to be returned to the manufacturer for repair. Important procedures must be carried out before you return a flowmeter to Endress+Hauser →  6. Always enclose a duly completed "Declaration of Contamination" form. A copy of the form can be found at the end of these Operating Instructions!



Note!
See the information or troubleshooting guide on →  52.

No.	Error message/type	Cause	Remedy (spare parts → 📄 50 ff.)
S = System error ⚡ = Fault message (with an effect on the outputs) ! = Notice message (without any effect on the outputs)			
No. # 0xx → Hardware error			
001	S: CRITICAL FAILURE ⚡: # 001	Critical device error.	Replace the amplifier board.
011	S: AMP HW EEPROM ⚡: # 011	Amplifier: Faulty EEPROM	Replace the amplifier board.
012	S: AMP SW EEPROM ⚡: # 012	Amplifier: Error when accessing data of the EEPROM.	The EEPROM data blocks in which an error occurred are displayed in the TROUBLESHOOTING function. The errors in question have to be confirmed with the Enter key; faulty parameters are then replaced by predefined standard values. 🖋️ Note! The device has to be restarted if an error occurs in the totalizer block (see also error # 111 / CHECKSUM TOTAL.).
082	S: SENS. DOWN CH1 ⚡: # 082	Connection between sensor channel 1 and transmitter interrupted.	■ Check the cable connection between the sensor and transmitter. ■ Check whether the sensor connector is inserted until the stop. ■ The sensor might be defective. ■ Incorrect sensor connected. ■ The wrong sensor was selected in the SENSOR TYPE function (No. 6881).
085	S: SENS. UP CH1 ⚡: # 085		
No. # 2xx → Error with DAT / no data reception			
261	S: COMMUNIC. I/O ⚡: # 261	No data reception between amplifier and I/O board or faulty internal data transfer.	Check BUS contacts
No. # 3xx → System range limits exceeded			
363	S: RANGE CUR.IN !: # 363	Current input: The active current value is outside the set range.	■ Change the start and end values configured. ■ Check the settings of the external sensor.
392	S: SIGNA. LOW CH1 ⚡: # 392	Attenuation of acoustic measurement section too high.	■ Check whether the coupling fluid has to be renewed. ■ The attenuation of the fluid might be too high. ■ The attenuation of the pipe might be too high. ■ Check the sensor distance (installation dimensions). ■ Reduce the number of traverses if possible.
No # 5xx → Application errors			
501	S: SW.-UPDATE ACT. !: # 501	New amplifier or communication module software version being loaded. Currently no other functions are possible.	Wait until the procedure is complete. The device will restart automatically.
502	S: UP-/DOWNLOAD ACT. !: # 502	Up- or downloading the device data via operating program. Currently no other functions are possible.	Wait until the procedure is complete.

No.	Error message/type	Cause	Remedy (spare parts → 50 ff.)
No. # 6xx → Simulation operation active			
601	S: POS. ZERO RET. !: # 601	Positive zero return active.  Caution! This notice message has the highest display priority!	Switch off positive zero return.
661	S: SIM. CURR. INP. !: # 661	Current input simulation active.	Switch off simulation.
691	S: SIM. FAILSAFE !: # 691	Simulation of failsafe mode (outputs) active.	Switch off simulation.
692	S: SIM. MEASURAND !: # 692	Simulation of a measured variable active (e.g. mass flow).	Switch off simulation.
698	S: DEV. TEST ACT. !: # 698	The measuring device is being checked on site via the test and simulation device.	–

9.3 Process error messages

Process errors can be defined as either "Fault" or "Notice" messages and can thus be weighted differently.



Note!

See the information on → 37 ff. and → 55.

Type	Error message / No.	Cause	Remedy
P = Process error ⚡ = Fault message (with an effect on the inputs/outputs) ! = Notice message (without any effect on the inputs/outputs)			
P ⚡	PIPE DATA? CH1 # 469	The internal diameter is negative.	In the "PIPE DATA" function group, check the values of the functions "OUTER DIAMETER" and "WALL THICKNESS" or "LINING THICKNESS".
P ⚡	S. V. RANGE CH1 # 492	The sound velocity in channel 1/2 is outside the search range of the transmitter.	– Check the installation dimensions. – If possible, check the sound velocity of the liquid or check the specialist literature. If the current sound velocity is outside the defined search range, the corresponding function must be changed in the LIQUID DATA function group. Detailed explanations can be found under the SOUND VELOCITY LIQUID function (6542).
P !	INTERF. CH1 # 495	The wave transmitted in the pipe may superimpose the useful signal. We recommend you alter the sensor configuration in the event of this error message.  Caution! The sensor configuration must be changed if the measuring device indicates zero flow or low flow.	In the SENSOR CONFIGURATION function (6882), change the number of traverses from 2 or 4 to 1 or 3 and mount the sensors accordingly.

9.4 Process errors without messages

Symptoms	Rectification
 Note! You may have to change or correct certain settings of the function matrix in order to rectify faults. For an explanation of the functions listed below, e.g. DISPLAY DAMPING, see → 65 ff.	
Negative flow values displayed even though the fluid is flowing forwards in the pipe.	1. Check the wiring → 31. If necessary, switch the connections for the terminals for "up" and "down". 2. Change the "INSTL. DIR. SENSOR" function accordingly.
Measured value reading fluctuates even though flow is steady.	1. Check the fluid for presence of gas bubbles. 2. "TIME CONSTANT" function (current output) → Increase value 3. "DISPLAY DAMPING" function → Increase value
The measured value display or measured value output is pulsating or fluctuating, e.g. due to reciprocating pumps, peristaltic pumps, diaphragm pumps or pumps with similar transporting characteristics.	Run the "Pulsating Flow" Quick Setup → 44. If these measures do not rectify the problem, a pulsation damper has to be installed between the pump and the flowmeter.
Measured value reading shown on display, even though the fluid is at a standstill and the measuring tube is full.	1. Check the fluid for presence of gas bubbles. 2. Activate the "LOW FLOW CUTOFF" function, i.e. enter or increase the value for the switch point.
The fault cannot be rectified or some other fault not described above has occurred. In these instances, please contact your Endress+Hauser service organization.	The following options are available for tackling problems of this nature: Request the services of an Endress+Hauser service technician If you contact our service organization to have a service technician sent out, please be ready with the following information: – Brief description of the fault – Nameplate specifications: order code and serial number Return devices to Endress+Hauser The measures listed must be carried out before you return a measuring device requiring repair or calibration to Endress+Hauser. Always enclose the duly completed "Declaration of Contamination" form with the flowmeter. You will find a preprinted blank of this form at the back of this manual.

9.5 Response of outputs to errors



Note!
The response of the totalizer (failsafe mode) can be configured by means of various functions in the function matrix.

You can use positive zero return to set the signals to their fallback value, for example when operation has to be interrupted while a pipe is being cleaned. This function has priority over all other device functions; simulations are suppressed, for example.

Error response mode of outputs and totalizers		
	Process/system error present	Positive zero return activated
 Caution! System or process errors defined as "notice messages" have no effect whatsoever on the inputs and outputs. See the information on →  38 ff.		
Totalizer	STOP The totalizers stop if a fault is present. ACTUAL VALUE The fault is ignored. The totalizers continue to count in accordance with the current flow measured value. HOLD VALUE The totalizers continue to count in accordance with the last valid flow measured value (before the fault occurred).	The totalizer stops.

9.6 Spare parts

Only accessories are available for the measuring device →  50.

9.7 Return

→  6

9.8 Disposal

Observe the regulations applicable in your country!

9.9 Software history

Date	Software version	Changes to software	Operating Instructions
04.2010	2.02.XX	No changes to software	71112144/04.10
06.2009	2.02.XX	Original software for Prosonic Flow 93T Portable	71093720/06.09

10 Technical data

10.1 Quick technical data guide

10.1.1 Application

- Measuring the flow rate of liquids in closed piping systems.
- Applications in measuring, control and regulation technology for monitoring processes.

10.1.2 Function and system design

Measuring principle	The measuring system operates on the principle of transit time difference.
Measuring system	The measuring system consists of one transmitter and two sensors. <i>Transmitter</i> Prosonic Flow 93T Portable <i>Sensor</i> ■ Prosonic Flow P Clamp On version, Nominal diameters DN 15 to 65 ($\frac{1}{2}$ to $2\frac{1}{2}$") ■ Prosonic Flow P Clamp On version, Nominal diameters DN 50 to 4000 (2 to 160") ■ Prosonic Flow DDU18 (sound velocity measurement), Nominal diameters DN 50 to 3000 (2 to 120") ■ Prosonic Flow DDU20 (wall thickness measurement), – for wall thicknesses from 2 to 50 mm ($\frac{1}{12}$ to 2") for steel pipes – for wall thicknesses from 4 to 15 mm ($\frac{1}{8}$ to $\frac{1}{2}$") for plastic pipes (only suitable for use with PTFE and PE pipes to a certain extent)

10.1.3 Input

Measured variable	Flow velocity (transit time difference proportional to flow velocity)
Measuring range	Typically $v = 0$ to 15 (0 to 50 ft/s) at the specified measuring accuracy
Operable flow range	Over 150 : 1
Input signal	<i>Current input</i> ■ Galvanically isolated ■ Passive: 0/4 to 20 mA, $R_i < 150 \Omega$, max. 30 V DC ■ Terminal voltage: min. 2 V DC to max. 30 V DC ■ Time constant selectable (0.05 to 100 s) ■ Full scale value adjustable ■ Temperature coefficient: typ. 0.002 % o.r./°C (o.r. = of reading) ■ Resolution: 0.82 μA

10.1.4 Output

Output signal

Data logger function

The device has a data logger function. The measured values can be stored in CSV format on an external USB storage device (FAT 16/FAT 32). A recording cycle of between 1 and 99999 seconds can be selected. USB storage devices with a maximum capacity greater than 2 GB should not be used. Approx. 130 bytes are needed per recording. The standard supplied USB storage device has a maximum capacity of 1 GB.

The following values are stored:

- Time (dd.mm.yyyy hh:mm:ss)
- Flow
- Sound velocity
- Flow velocity
- Signal strength
- Noise ratio
- Counter 1 to 3
- System status
- 0/4 to 20 mA current input (flow rate and active current value)

Each recording is marked with the tag name and device-specific information, such as the serial number for example.

Low flow cut off

Switch points for low flow cutoff are selectable.

Galvanic isolation

All circuits for inputs, outputs, and power supply are galvanically isolated from each other.

10.1.5 Power supply

Measuring unit electrical connection

→  31

Connecting the connecting cable

→  31

Supply voltage

Transmitter

Power unit

- 100 to 240 V AC, 47 to 63 Hz to Power Adapter (12 V DC, 2.5 A)

NiMH accumulator

- Operating time: up to 8 hours
- Charge time: approx. 3.6 hours

Sensor

Powered by the transmitter

Connecting cable (sensor/ transmitter)	Only use the connecting cables supplied by Endress+Hauser. Different versions of the connecting cables are available → 50. ■ Cable material: PTFE ■ Cable lengths: 5 m (16.4 feet), 10 m (32.8 feet) Note! To ensure correct measuring results, route the connecting cable well clear of electrical machines and switching elements.
Potential equalization	For potential equalization, no special measures are necessary.

10.1.6 Performance characteristics

Reference operating conditions	■ Fluid temperature: +20 to +30 °C ■ Ambient temperature: +22 °C ± 2 K ■ Warm-up period: 30 minutes Installation: ■ Sensors and transmitter are grounded. ■ The measuring sensors are correctly installed.
Maximum measured error	The measured error depends on a number of factors. A distinction is made between the measured error of the device (Prosonic Flow 93T = 0.5 % of the measured value) and an additional installation-specific measured error (typically 1.5 % of the measured value) that is independent of the device. The installation-specific measured error depends on the installation conditions on site, such as the nominal diameter, wall thickness, real pipe geometry, fluid, etc. The sum of the two measured errors is the measured error at the measuring point.




Fig. 46: Example of the measured error in a pipe with a nominal diameter DN > 200 (8")

a Measured error of the device (0.5 % o.r. ± 0.02 % o.f.s.)

b Measured error due to installation conditions (typically 1.5 % o.r.)

c Measured error at the measuring point: 0.5 % o.r. ± 0.02 % o.f.s. + 1.5 % o.r. = 2 % o.r. ± 0.02 % o.f.s.

Measured error at the measuring point

The measured error at the measuring point is made up of the measured error of the device (0.5 % o.r.) and the measured error resulting from the installation conditions on site. Given a flow velocity > 0.3 m/s (1 ft/s) and a Reynolds number > 10000, the following are typical error limits:

Nominal diameter	Device error limits	+	Installation-specific error limits (typical)	→	Error limits at the measuring point (typical)
DN 15 (½")	±0.5 % o.r. ± 0.05 % o.f.s.	+	±2.5 % o.r.	→	±3 % o.r. ± 0.05 % o.f.s.
DN 25 to 200 (1 to 8")	±0.5 % o.r. ± 0.05 % o.f.s.	+	±1.5 % o.r.	→	±2 % o.r. ± 0.05 % o.f.s.
> DN 200 (8")	±0.5 % o.r. ± 0.02 % o.f.s.	+	±1.5 % o.r.	→	±2 % o.r. ± 0.02 % o.f.s.

o.r. = of reading

o.f.s. = of full scale value [Prosonic P: DN 15 to 65 (½ to 2½") = 10 m/s (33 ft/s),
DN 50 to 4000 (2 to 160") = 15 m/s (50 ft/s)]

Measurement Report

If required, the device can be supplied with a factory measurement report. To certify the performance of the device, a measurement is performed under reference conditions. Here, the sensors are mounted on a pipe with a nominal diameter of DN 50 (2") or DN 100 (4") respectively.

The measurement report guarantees the following error limits of the device [at a flow velocity > 0.3 m/s (1 ft/s) and a Reynolds number > 10000]:

Nominal diameter	Guaranteed error limits of the device
DN 50 (2"), DN 100 (4")	±0.5 % o.r. ± 0.05 % o.f.s.

o.r. = of reading

o.f.s. = of full scale value [Prosonic P: DN 50 (2"), DN 100 (4") = 15 m/s (50 ft/s)]

Repeatability ±0.3 % for flow velocities > 0.3 m/s (1 ft/s)

10.1.7 Operating conditions: installation

Installation instructions *Mounting location*

→  10

Orientation

→  11

Inlet and outlet run →  11

Length of connecting cable (sensor/transmitter) The connecting cable is available in the following lengths:

- 5 m (16.4 ft)
- 10 m (32.8 ft)

10.1.8 Operating conditions: environment

Ambient temperature range	<i>Transmitter</i> 0 to +60 °C (+32 to +140 °F) <i>Prosonic Flow P sensor</i> DN 15 to 65 (½ to 2½") ■ Standard: -40 to +100 °C (-40 to +212 °F) ■ Optional: 0 to +150 °C (+32 to +302 °F) DN 50 to 4000 (2 to 160") ■ Standard: -40 to +80 °C (-40 to +176 °F) ■ Optional: 0 to +170 °C (+32 to +338 °F) <i>DDU18 sensor (accessories: sound velocity measurement)</i> ■ Standard: -40 to +80 °C (-40 to +176 °F) ■ Optional: 0 to +170 °C (+32 to +338 °F) <i>DDU20 sensor (accessories: wall thickness measurement)</i> -20 to +60 °C (-4 to +140 °F) <i>Connecting cable (sensor/transmitter)</i> -40 to +170 °C (-40 to +338 °F)
Storage temperature	The storage temperature corresponds to the ambient temperature range.
Degree of protection	<i>Transmitter</i> IP 40 <i>Sensor</i> IP 68 (NEMA 6P), connection IP 50 <i>DDU18 sensor (accessories: sound velocity measurement)</i> IP 68 (NEMA 6P), connection IP 50 <i>DDU20 sensor (accessories: wall thickness measurement)</i> IP 67 (NEMA 4X), connection IP 50
Shock and vibration resistance	According to IEC 68-2-6
Electromagnetic compatibility (EMC)	Electromagnetic compatibility (EMC requirements) according to IEC/EN 61326 "Emission to class A requirements" and NAMUR Recommendation NE 21 and NE 43.

10.1.9 Operating conditions: process

Medium temperature range	<i>Prosonic Flow P sensor</i> DN 15 to 65 (½ to 2½") ■ Standard: -40 to +100 °C (-40 to +212 °F) ■ Optional: -40 to +150 °C (-40 to +302 °F) DN 50 to 4000 (2 to 160") ■ Standard: -40 to +80 °C (-40 to +176 °F) ■ Optional: 0 to +170 °C (+32 to +338 °F) <i>DDU18 sensor (accessories: sound velocity measurement)</i> ■ Standard: -40 to +80 °C (-40 to +176 °F) ■ Optional: 0 to +170 °C (+32 to +338 °F) <i>DDU20 sensor (accessories: wall thickness measurement)</i> -10 to +60 °C (+14 to +140 °F)
Medium pressure range (nominal pressure)	No pressure limitation, however perfect measurement requires that the static fluid pressure is higher than vapor pressure.
Pressure loss	There is no pressure loss.

10.1.10 Mechanical construction

Design / dimensions	The dimensions and lengths of the sensor and transmitter are provided in the separate "Technical Information" document on the device in question. This can be downloaded as a PDF file from www.endress.com. A list of the "Technical Information" documents available is provided on →  64.
Weight	<i>Transmitter</i> 1.6 kg (3.53 lbs) <i>Sensor Prosonic Flow P</i> ■ DN 15 to 65 (½ to 2½") (incl. mounting material): 1.78 kg (3.9 lbs) ■ DN 50 to 4000 (2 to 160") (incl. mounting material): 2.8 kg (6.2 lbs) <i>Sensor (accessories)</i> ■ Prosonic Flow DDU18 (incl. mounting material): 2.4 kg (5.3 lbs) ■ Prosonic Flow DDU20 (incl. mounting material): 0.23 kg (0.5 lbs)



Note!
Weight information without packaging material.

Materials*Transmitter*

Plastic

Sensor Prosonic Flow P

DN 15 to 65 (½ to 2½")

- Sensor holder: corrosion protected aluminum, stainless steel 1.4301
- Sensor housing: stainless steel 1.4301
- Sensor contact surfaces: chemically stable plastic

DN 50 to 4000 (2 to 160")

- Sensor holder: stainless steel 1.4301
- Sensor housing: stainless steel 1.4301
- Strapping bands/bracket: textile or stainless steel 1.4301
- Sensor contact surfaces: chemically stable plastic

Sensor (accessories)

Prosonic Flow DDU18; Prosonic Flow DDU20

- Sensor holder: stainless steel 1.4301
- Sensor housing: stainless steel 1.4301
- Strapping bands/bracket: textile or stainless steel 1.4301
- Sensor contact surfaces: chemically stable plastic

Connecting cable (sensor/transmitter)

PTFE connecting cable

- Cable sheath: PTFE
- Cable connector: stainless steel

10.1.11 Human interface

Display elements

- Liquid crystal display: illuminated, four lines each with 16 characters
- Custom configuration for presenting different measured values and status variables

Operating elements

- Local operation with three optical keys
- Application specific Quick Setup menus for straightforward commissioning

Language groups

Language groups available for operation in different countries:

- Western Europe and America (WEA):
English, German, Spanish, Italian, French, Dutch and Portuguese
- Eastern Europe/Scandinavia (EES):
English, Russian, Polish, Norwegian, Finnish, Swedish and Czech
- South and Eastern Asia (SEA):
English, Japanese, Indonesian
- China (CN):
English, Chinese

You can change the language group via the FieldCare operating program.

Remote operation

Operation via FieldCare, with:

- Option of loading or saving preprogrammed measuring points
- Configuration logging
- Measured value visualization

10.1.12 Certificates and approvals

CE mark	The measuring system is in conformity with the statutory requirements of the EC Directives. Endress+Hauser confirms successful testing of the device by affixing to it the CE mark.
C-Tick mark	The measuring system is in conformity with the EMC requirements of the "Australian Communications and Media Authority (ACMA)".
Other standards and guidelines	■ EN 60529 Degrees of protection provided by enclosures (IP code). ■ EN 61010-1 Safety requirements for electrical equipment for measurement, control and laboratory use. ■ IEC/EN 61326 "Emission in accordance with Class A requirements". Electromagnetic compatibility (EMC requirements). ■ ANSI/ISA-S82.01 Safety Standard for Electrical and Electronic Test, Measuring, Controlling and Related Equipment - General Requirements. Pollution Degree 2, Installation Category II. ■ CAN/CSA-C22.2 No. 1010.1-92 Safety Requirements for Electrical Equipment for Measurement and Control and Laboratory Use. Pollution Degree 2.

10.1.13 Ordering information

The Endress+Hauser service organization can provide detailed ordering information and information on the order codes on request.

10.1.14 Documentation

- Flow measurement (FA005D/06)
- Technical Information for Prosonic Flow 93T Portable (TI085D/06)


11 Description of Device Functions

11.1 Function matrix

11.1.1 General layout of the function matrix

The function matrix consists of four levels:

Blocks -> Groups -> Function groups -> Functions



A0000961

Blocks (A, B, C, etc.)

The blocks are the highest-level grouping of the operation options for the device.

Examples of blocks available are MEASURED VARIABLES, QUICK SETUP, USER INTERFACE, TOTALIZERS, etc.

Groups (AAA, AEA, CAA, etc.)

A block consists of one or more groups. Each group represents a more detailed selection of the operation options in the higher-order block. Examples of groups available in the USER INTERFACE block are CONTROL, MAIN LINE, ADDITIONAL LINE, etc.

Functions (0000, 0001, 0002, etc.)

Each function group consists of one or more functions. The functions are used to operate and parameterize the device. Numerical values can be entered or parameters selected and saved. Examples of functions available in the BASIC CONFIGURATION function group are LANGUAGE, DISPLAY DAMPING, CONTRAST LCD, etc.

If the operating language of the device is to be changed, for example, proceed as follows:

1. Select the block USER INTERFACE.
2. Select the group CONTROL.
3. Select the function group BASIC CONFIGURATION.
4. Select the function LANGUAGE (here you can set the language required).

Function groups (000, 020, 060, etc.)

A group consists of one or more function groups. Each function group represents a more detailed selection of the operation options in the higher-order group. Examples of function groups available in the CONTROL group are BASIC CONFIGURATION, UNLOCKING/LOCKING, OPERATION, etc.

11.1.2 Codes identifying cells

Each cell (block, group, function group and function) in the function matrix has an individual, unique code.

Blocks:

The code is a letter (A, B, C, etc.).

Groups:

The code consists of three letters (AAA, ABA, BAA, etc.).

The first letter matches the block code (i.e. each group in block A has a code starting with an A _ _; the codes of the groups in block B start with a B _ _, and so on). The other two letters are for identifying the group within the respective block.

Function groups:


The code consists of three digits (000, 001, 100, etc.).

Functions:

The code consists of four digits (0000, 0001, 0201, etc.).

The first three digits are the same as the code for the function group.

The last digit in the code is a counter for the functions in the function group, incrementing from 0 to 9 (e.g. function 0005 is the sixth function in group 000).



A0001251

11.2 Function matrix of Prosonic Flow 93T Portable

Blocks	→	Groups	→	Function groups	Functions
MEASURED VARIABLES A	→	MEASURING VALUES AAA	→	MAIN VALUES CH1 000	→ 68
		SYSTEM UNITS ACA	→	CONFIGURATION 040	→ 69
				ADDITIONAL CONFIGURATION 042	→ 70
		SPECIAL UNITS AEA	→	ARBITRARY UNIT 060	→ 71
QUICK SETUP B	→		→		→ 71
USER INTERFACE C	→	CONTROL CAA	→	BASIC CONFIGURATION 200	→ 72
				UNLOCKING/LOCKING 202	→ 73
				OPERATION 204	→ 74
		MAIN LINE CCA	→	CONFIGURATION 220	→ 75
				MULTIPLEX 222	→ 76
		ADDITIONAL LINE CEA	→	CONFIGURATION 240	→ 77
				MULTIPLEX 242	→ 76
		INFORMATION LINE CGA	→	CONFIGURATION 260	→ 81
				MULTIPLEX 262	→ 83
TOTALIZER D	→	TOTALIZER 1 DAA	→	CONFIGURATION 300	→ 85
		TOTALIZER 2 DAB			
		TOTALIZER 3 DAC		OPERATION 304	→ 86
		HANDLING TOTALIZER DJA	→		→ 86
OUTPUTS E	→	DATA LOGGER ELA	→	CONFIGURATION 490	→ 87
				INFORMATION 498	→ 87
INPUTS F	→	CURRENT INPUT FCA	→	CONFIGURATION 520	→ 88
				OPERATION 524	→ 89
BASIC FUNCTIONS G	→	PROCESS PARAMETER CH1 GIA	→	CONFIGURATION 640	→ 90
				ADJUSTMENT 648	→ 92
				PIPE DATA 652	→ 92
				LIQUID DATA 654	→ 95
	→	SYSTEM PARAMETER CH1 GLA	→	CONFIGURATION 660	→ 98
		SENSOR DATA CH1 GNA	→	SENSOR PARAM. 688	→ 99
				CALIBRATION DATA 689	→ 101
SUPERVISION J	→	SYSTEM JAA	→	CONFIGURATION 800	→ 102
				OPERATION 804	→ 103
	→	VERSION INFO JCA	→	DEVICE 810	→ 104
				SENSOR 820	→ 104
				AMPLIFIER 822	→ 105
				I/O MODULE 830	→ 105
				I/O SUBMODULE 1 832	→ 105
				I/O SUBMODULE 3 834	→ 105

11.3 Block MEASURED VARIABLES

11.3.1 Group MEASURING VALUES'

Function group MAIN VALUES CH1

Functional description MEASURED VARIABLES → MEASURING VALUES → MAIN VALUES CH1	
The measuring values of channel 1 currently being measured are displayed in this function group.  Note! ■ The engineering units of all the measured variables shown here can be set in the SYSTEM UNITS group. ■ If the fluid in the pipe flows backwards, a negative sign prefixes the flow reading on the display.	
VOLUME FLOW CH1 (0001)	The volume flow currently measured appears on the display (channel 1). User interface 5-digit floating-point number, including unit and sign e.g. 5.545 dm³/min; 1.4359 kg/h; 731.63 gal/d, etc.
SOUND VELOCITY (0002)	The sound velocity currently measured in the liquid appears on the display (channel 1). User interface 5-digit fixed-point number, incl. units e.g. 1400.0 m/s, 5249.3 ft/s, etc.
FLOW VELOCITY CH1 (0003)	The flow velocity currently measured appears on the display (channel 1). User interface 5-digit floating-point number, including unit and sign e.g. 8.0000 m/s, 26.247 ft/s, etc.
SIGNAL STRENGTH CH1 (0007)	The signal strength appears on the display (channel 1). User interface 4-digit fixed-point number e.g. 80.0  Note! To ensure reliable measurement takes place, Prosonic Flow requires a signal strength of > 30.
VOLUME FLOW DEVICE 2 (0011)	The current actual value of the input current at the current input appears on the display. User interface 0.0 to 25 mA

11.3.2 Group SYSTEM UNITS

Function group CONFIGURATION

Functional description MEASURED VARIABLES → SYSTEM UNITS → CONFIGURATION	
UNIT VOLUME FLOW (0042)	Use this function to select the unit for displaying the volume flow. The unit you select here is also valid for low flow cut off. Options Metric: Cubic centimeter → cm^3/s; cm^3/min; cm^3/h; cm^3/day Cubic decimeter → dm^3/s; dm^3/min; dm^3/h; dm^3/day Cubic meter → m^3/s; m^3/min; m^3/h; m^3/day Milliliter → ml/s; ml/min; ml/h; ml/day Liter → l/s; l/min; l/h; l/day Hectoliter → hl/s; hl/min; hl/h; hl/day Megaliter → Ml/s; Ml/min; Ml/h; Ml/day US: Cubic centimeter → cc/s; cc/min; cc/h; cc/day Acre foot → af/s; af/min; af/h; af/day Cubic foot → ft^3/s; ft^3/min; ft^3/h; ft^3/day Fluid ounce → $\text{oz f}/\text{s}$; $\text{oz f}/\text{min}$; $\text{oz f}/\text{h}$; $\text{oz f}/\text{day}$ Gallon → gal/s; gal/min; gal/h; gal/day, US kgal/s; US kgal/min; US kgal/h; US kgal/day Million gallon → Mgal/s; Mgal/min; Mgal/h; Mgal/day Barrel (normal fluids: 31.5 gal/bbl) → bbl/s; bbl/min; bbl/h; bbl/day Barrel (beer: 31.0 gal/bbl) → bbl/s; bbl/min; bbl/h; bbl/day Barrel (petrochemicals: 42.0 gal/bbl) → bbl/s; bbl/min; bbl/h; bbl/day Barrel (filling tanks: 55.0 gal/bbl) → bbl/s; bbl/min; bbl/h; bbl/day Imperial: Gallon → gal/s; gal/min; gal/h; gal/day Million gallon/Mega gallon → Mgal/s; Mgal/min; Mgal/h; Mgal/day Barrel (beer: 31.0 gal/bbl) → bbl/s; bbl/min; bbl/h; bbl/day Barrel (petrochemicals: 34.97 gal/bbl) → bbl/s; bbl/min; bbl/h; bbl/day Barrel (filling tanks: 55.0 gal/bbl) → bbl/s; bbl/min; bbl/h; bbl/day Arbitrary unit (from ARB. UNIT function group →  71): ____ → ____/s; ____/min; ____/h; ____/day Factory setting l/s
UNIT VOLUME (0403)	Use this function to select the unit for displaying the volume. Options Metric: cm^3; dm^3; m^3; ml; l; hl; Ml MEGA US: cc; af; ft^3; oz f; gal; kgal; Mgal; bbl (NORMAL FLUIDS); bbl (BEER); bbl (PETROCHEMICALS), bbl (FILLING TANKS) Imperial: gal; Mgal; bbl (BEER); bbl (PETROCHEMICALS) Arbitrary unit (from ARBITRARY UNIT function group →  71): ____ Factory setting Liter  Note! The unit of the totalizers is independent of your choice here. The unit for each totalizer is selected separately for the totalizer in question.

Function group ADDITIONAL CONFIGURATION

Functional description MEASURED VARIABLES → SYSTEM UNITS → ADDITIONAL CONFIGURATION	
UNIT TEMPERATURE (0422)	Use this function to select the unit for displaying the fluid temperature. Options °C (Celsius) K (Kelvin) °F (Fahrenheit) R (Rankine) Factory setting ° C  Note! The fluid temperature is entered in the function TEMPERATURE (→ 95).
UNIT VISCOSITY (0423)	Use this function to select the unit for liquid viscosity. Options mm ² /s cSt St Factory setting mm ² /s
UNIT LENGTH (0424)	Use this function to select the unit for the measure of length. The unit you select here is valid for: ■ Nominal diameter ■ Diameter ■ Wall thickness ■ Liner thickness ■ Path length ■ Wire length ■ Sensor spacing Options MILLIMETER INCH Factory setting MILLIMETER
UNIT VELOCITY (0425)	Use this function to select the unit for displaying the velocity. The unit you select here is valid for: ■ Sound velocity ■ Flow velocity Options mm ² /s cSt St Factory setting m/s
FORMAT DATE/TIME (0429)	Use this function to select the date and time format of the calibration history. Options DD.MM.YY 24 H MM/DD/YY 12 H A/P DD.MM.YY 12 H A/P MM/DD/YY 24 H Factory setting DD.MM.YY 24 H

11.3.3 Group SPECIAL UNITS

Function group ARBITRARY UNITS

Functional description MEASURED VARIABLES → SPECIAL UNITS → ARBITRARY UNIT	
Use this function group to define an arbitrary unit for the flow rate variable.	
TEXT ARBITRARY VOLUME (0602)	Use this function to enter a text for the selectable volume (flow) unit. You define only the text, the unit of time is provided from a choice of options (s, min, h, day). User input 7-digit floating-point number Factory setting _ _ _ _ (No text) Example If your text entry is "GLAS", this text string appears on the display complete with the unit of time, e.g. "GLAS/min": GLAS = Volume (text input) GLAS / min = Volume flow as shown (on the display)
FACTOR ARBITRARY VOLUME (0603)	Use this function to define a quantity factor (without time) for the free selectable unit. The volume unit on which this factor is based is one liter. User input xxxxxxx (max. 4 characters) Valid characters are A–Z, 0–9, +, –, decimal point, white space or underscore Factory setting 1 Reference quantity Liter Example The volume of a glass is 0.5 l → 2 glasses = 1 liter User input: 2

11.4 Block QUICK SETUP

Functional description QUICK SETUP	
Description of the procedure and illustration of the subsequent Quick Setups → 41 ff.	
QUICK SETUP SENSOR INSTALLATION (1001)	Use this function to start the Setup menu for sensor installation. Options YES NO Factory setting NO
QUICK SETUP COMMISSIONING (1002)	Use this function to start the Setup menu for commissioning. Options YES NO Factory setting NO
QUICK SETUP PULSATING FLOW (1003)	Use this function to start the Setup menu for commissioning. Options YES NO Factory setting NO

11.5 Block USER INTERFACE

11.5.1 Group CONTROL

Function group BASIC CONFIGURATION

Functional description USER INTERFACE → CONTROL → BASIC CONFIGURATION	
LANGUAGE (2000)	Use this function to select the language for all texts, parameters and messages shown on the local display.  Note! The displayed options depend on the available language group shown in the LANGUAGE GROUP (8226) function. Language groups Language groups WEST EU / USA ENGLISH DEUTSCH FRANCAIS ESPANOL ITALIANO NEDERLANDS PORTUGESE Language groups EAST EU / SCAND. ENGLISH NORSK SVENSKA SUOMI POLISH CZECH RUSSIAN Language group ASIA ENGLISH BAHASA INDONESIA JAPANESE (syllabary) Language group CHINESE CHINESE ENGLISH Factory setting Country-dependent (→  106)  Note! ■ If you press the  keys simultaneously during startup, the language defaults to "ENGLISH". ■ You can change the language group via the operating program "FieldCare".
DISPLAY DAMPING (2002)	Use this function to enter a time constant defining how the display reacts to severely fluctuating flow variables, either very quickly (enter a low time constant) or with damping (enter a high time constant). User input 0 to 100 seconds Factory setting 1 s  Note! Setting the time constant to zero seconds switches off damping.

Functional description USER INTERFACE → CONTROL → BASIC CONFIGURATION	
CONTRAST LCD (2003)	Use this function to optimize display contrast to suit local operating conditions. User input 10 to 100% Factory setting 50%
BACKLIGHT (2004)	Use this function to optimize the backlight to suit local operating conditions. User input 10 to 100% Factory setting 50%
SHUT BACKLIGHT (2005)	Use this function to specify the conditions to automatically switch off background lighting. Options 30 sec. 1 min. 5 min. Always ON Factory setting Always ON

Function group UNLOCKING/LOCKING

Functional description USER INTERFACE → CONTROL → UNLOCKING/LOCKING	
ACCESS CODE (2020)	All data of the measuring system are protected against inadvertent change. Programming is disabled and the settings cannot be changed until a code is entered in this function. If you press the  keys in any function, the measuring system automatically goes to this function and the prompt to enter the code appears on the display (when programming is disabled). You can enable programming by entering your personal code (factory setting = 93). User input 0 to 9999 (max. 4-digit number) Factory setting Max. 4-digit number: 0 to 9999  Note! ■ The programming levels are disabled if you do not press a key within 60 seconds following automatic return to the HOME position. ■ You can also disable programming in this function by entering any number (other than the defined private code). ■ The Endress+Hauser service organization can be of assistance if you mislay your personal code.


Functional description USER INTERFACE → CONTROL → UNLOCKING/LOCKING	
DEFINE PRIVATE CODE (2021)	Use this function to enter a personal code number for enabling programming. User input 0 to 9999 (max. 4-digit number) Factory setting 93  Note! ■ Programming is always enabled with the code "0". ■ Programming has to be enabled before this code can be changed. When programming is disabled this function is not available, thus preventing others from accessing your personal code.
STATUS ACCESS (2022)	Use this function to check the access status for the function matrix. User interface ACCESS CUSTOMER (parameterization possible) LOCKED (parameterization disabled) Factory setting 50%
ACCESS CODE COUNTER (2023)	The number of times the private or service code was entered to access the device appears on the display. User interface Integer (delivery status: 0)

Function group OPERATION

Functional description USER INTERFACE → CONTROL → OPERATION	
TEST DISPLAY (2040)	Use this function to test the operability of the local display and its pixels. Options YES NO Factory setting OFF Test sequence: 1. Start the test by selecting ON. 2. All pixels of the main line, additional line and information line are darkened for minimum 0.75 seconds. 3. Main line, additional line and information line show an "8" in each field for minimum 0.75 seconds. 4. Main line, additional line and information line show a "0" in each field for minimum 0.75 seconds. 5. Main line, additional line and information line show nothing (blank display) for minimum 0.75 seconds. When the test completes the local display returns to its initial state and the setting changes to OFF.

11.5.2 Group MAIN LINE

Function group CONFIGURATION

Functional description USER INTERFACE → MAIN LINE → CONFIGURATION	
1 = Main line 2 = Additional line 3 = Information line	
ASSIGN (2200)	Use this function to define the display value assigned to the main line (the top line of the local display) during normal measuring operation. Options OFF VOLUME FLOW (CH1) VOLUME FLOW IN % (CH1) SOUND VELOCITY (CH1) SIGNAL STRENGTH (CH1) FLOW VELOCITY (CH1) TOTALIZER (1 to 3) ACTUAL CURRENT INPUT Factory setting VOLUME FLOW (CH1)
100% VALUE (2201)	 Note! This function is not available unless VOLUME FLOW IN % was selected in the ASSIGN function (2200). Use this function to define the flow value to be shown on the display as the 100% value. User input 5-digit floating-point number Factory setting 10 l/s
FORMAT (2202)	Use this function to define the maximum number of places after the decimal point displayed for the reading in the main line. Options XXXXX. - XXXX.X - XXX.XX - XX.XXX - X.XXXX Factory setting X.XXXX  Note! ■ Note that this setting only affects the reading as it appears on the display, it has no influence on the accuracy of the system's calculations. ■ The places after the decimal point as computed by the measuring device cannot always be displayed, depending on this setting and the engineering unit. In such instances an arrow appears on the display between the measuring value and the engineering unit (e.g. 1.2→ m3/h), indicating that the measuring system is computing with more decimal places than can be shown on the display.


A0001253

Function group MULTIPLEX

Functional description USER INTERFACE → MAIN LINE → MULTIPLEX	
ASSIGN (2220)	Use this function to define a second reading to be displayed in the main line alternately (every 10 seconds) with the reading defined in the function ASSIGN (2200). Options OFF VOLUME FLOW (CH1) VOLUME FLOW IN % (CH1) SOUND VELOCITY (CH1) SIGNAL STRENGTH (CH1) FLOW VELOCITY (CH1) TOTALIZER (1 to 3) ACTUAL CURRENT INPUT Factory setting OFF
100% VALUE (2221)	 Note! This function is not available unless VOLUME FLOW IN % was selected in the ASSIGN function (2220). Use this function to define the flow value to be shown on the display as the 100% value. User input 5-digit floating-point number Factory setting Depends on nominal diameter and country, [value] / [dm³ to m³ or US-gal to US-Mgal] Corresponds to the factory setting for the full scale value (→  106).
FORMAT (2222)	Use this function to define the maximum number of places after the decimal point displayed for the reading in the main line. Options XXXXX. - XXXX.X - XXX.XX - XX.XXX -X.XXXX Factory setting X.XXXX  Note! ■ Note that this setting only affects the reading as it appears on the display, it has no influence on the accuracy of the system's calculations. ■ The places after the decimal point as computed by the measuring device cannot always be displayed, depending on this setting and the engineering unit. In such instances an arrow appears on the display between the measuring value and the engineering unit (e.g. 1.2→ m³/h), indicating that the measuring system is computing with more decimal places than can be shown on the display.

11.5.3 Group ADDITIONAL LINE

Function group CONFIGURATION

Functional description USER INTERFACE → ADDITIONAL LINE → CONFIGURATION	
1 = Main line 2 = Additional line 3 = Information line  A0001253	
ASSIGN (2400)	Use this function to define the display value assigned to the additional line (the middle line of the local display) during normal measuring operation. Options OFF VOLUME FLOW (CH1) VOLUME FLOW IN % (CH1) SOUND VELOCITY (CH1) SIGNAL STRENGTH (CH1) FLOW VELOCITY (CH1) VOLUME FLOW BARGRAPH IN % (CH1) SIGNAL BARGRAPH IN % (CH1) TOTALIZER (1 to 3) ACTUAL CURRENT INPUT Factory setting TOTALIZER 1
100% VALUE (2401)	 Note! This function is not available unless VOLUME FLOW IN % was selected in the ASSIGN function (2400). ■ VOLUME FLOW IN % (CH1) ■ VOLUME FLOW BARGRAPH IN % (CH1) ■ SIGNAL BARGRAPH IN % (CH1) Use this function to define the flow value to be shown on the display as the 100% value. User input 5-digit floating-point number Factory setting Depends on nominal diameter and country, [value] / [dm³ to m³ or US-gal to US-Mgal] Corresponds to the factory setting for the full scale value (→  106).

Functional description USER INTERFACE → ADDITIONAL LINE → CONFIGURATION	
FORMAT (2402)	 Note! This function is not available unless a number was selected in the function ASSIGN (2400). Use this function to define the maximum number of places after the decimal point displayed for the reading in the additional line. Options XXXXX. - XXXX.X - XXX.XX - XX.XXX -X.XXXX Factory setting X.XXXX  Note! ■ Note that this setting only affects the reading as it appears on the display, it has no influence on the accuracy of the system's calculations. ■ The places after the decimal point as computed by the measuring device cannot always be displayed, depending on this setting and the engineering unit. In such instances an arrow appears on the display between the measuring value and the engineering unit (e.g. 1.2→ m3/h), indicating that the measuring system is computing with more decimal places than can be shown on the display.
DISPLAY MODE (2403)	 Note! This function is only available if VOLUME FLOW BARGRAPH IN % or SIGNAL BARGRAPH IN % was selected in the function ASSIGN (2400). Use this function to define the format of the bar graph. Options STANDARD (Simple bar graph with 25 / 50 / 75% gradations and integrated sign).  A0001258 SYMMETRY (Symmetrical bar graph for positive and negative directions of flow, with -50 / 0 / +50% gradations and integrated sign).  A0001259 Factory setting STANDARD


Function group MULTIPLEX

Functional description USER INTERFACE → ADDITIONAL LINE → MULTIPLEX	
ASSIGN (2420)	Use this function to define a second reading to be displayed in the main line alternately (every 10 seconds) with the reading defined in the function ASSIGN (2400). Options OFF VOLUME FLOW (CH1) VOLUME FLOW IN % (CH1) SOUND VELOCITY (CH1) SIGNAL STRENGTH (CH1) FLOW VELOCITY (CH1) VOLUME FLOW BARGRAPH IN % (CH1) SIGNAL BARGRAPH IN % (CH1) TOTALIZER (1 to 3) ACTUAL CURRENT INPUT Factory setting OFF  Note! Multiplex mode is suspended as soon as a fault / notice message is generated. The message in question appears on the display. ■ Fault message (identified by a lightning icon): – If ON was selected in the function ACKNOWLEDGE FAULTS (8004), multiplex mode is resumed as soon as the fault has been acknowledged and is no longer active. – If OFF was selected in the function ACKNOWLEDGE FAULTS (8004), multiplex mode is resumed as soon as the fault is no longer active. ■ Notice message (identified by an exclamation mark): – Multiplex mode is resumed as soon as the notice message is no longer active. If a channel is not visible, it does not appear in the options. Channels can be displayed or hidden by means of the function MEASUREMENT (6880).
100% VALUE (2421)	 Note! This function is not available unless VOLUME FLOW IN % was selected in the ASSIGN function (2420). ■ VOLUME FLOW IN % (CH1) ■ VOLUME FLOW BARGRAPH IN % (CH1) ■ SIGNAL BARGRAPH IN % (CH1) Use this function to define the flow value to be shown on the display as the 100% value. User input 5-digit floating-point number Factory setting Depends on nominal diameter and country, [value] / [dm³ to m³ or US-gal to US-Mgal] Corresponds to the factory setting for the full scale value (→  106).

Functional description USER INTERFACE → ADDITIONAL LINE → MULTIPLEX	
FORMAT (2422)	 Note! This function is not available unless a number was selected in the function ASSIGN (2420). Use this function to define the maximum number of places after the decimal point displayed for the reading in the main line. Options XXXXX. - XXXX.X - XXX.XX - XX.XXX -X.XXXX Factory setting X.XXXX  Note! ■ Note that this setting only affects the reading as it appears on the display, it has no influence on the accuracy of the system's calculations. ■ The places after the decimal point as computed by the measuring device cannot always be displayed, depending on this setting and the engineering unit. In such instances an arrow appears on the display between the measuring value and the engineering unit (e.g. 1.2 →m3/h), indicating that the measuring system is computing with more decimal places than can be shown on the display.
DISPLAY MODE (2423)	 Note! This function is only available if VOLUME FLOW BARGRAPH IN % or SIGNAL BARGRAPH IN % was selected in the function ASSIGN (2420). Use this function to define the format of the bar graph. Options STANDARD (Simple bar graph with 25 / 50 / 75% gradations and integrated sign). +25 +50 +75 % A0001258 SYMMETRY (Symmetrical bar graph for positive and negative directions of flow, with -50 / 0 / +50% gradations and integrated sign). -50 0 +50 % A0001259 Factory setting STANDARD

11.5.4 Group INFORMATION LINE

Function group CONFIGURATION

Functional description USER INTERFACE → INFORMATION LINE → CONFIGURATION	
1 = Main line 2 = Additional line 3 = Information line  A0001253	
ASSIGN (2600)	Use this function to define the display value assigned to the additional line (the bottom line of the local display) during normal measuring operation. Options OFF VOLUME FLOW (CH1) VOLUME FLOW IN % (CH1) SOUND VELOCITY (CH1) SIGNAL STRENGTH (CH1) FLOW VELOCITY (CH1) VOLUME FLOW BARGRAPH IN % (CH1) SIGNAL BARGRAPH IN % (CH1) TOTALIZER (1 to 3) OPERATING/SYSTEM CONDITIONS FLOW DIRECTION ACCUMULATOR CHARGE ACTUAL CURRENT INPUT Factory setting ACCUMULATOR CHARGE
100% VALUE (2601)	 Note! This function is not available unless VOLUME FLOW IN % was selected in the ASSIGN function (2600). ■ VOLUME FLOW IN % (CH1) ■ VOLUME FLOW BARGRAPH IN % (CH1) ■ SIGNAL BARGRAPH IN % (CH1) Use this function to define the flow value to be shown on the display as the 100% value. User input 5-digit floating-point number Factory setting Depends on nominal diameter and country, [value] / [dm³ to m³ or US-gal to US-Mgal] Corresponds to the factory setting for the full scale value (→  106).

Functional description	
USER INTERFACE → INFORMATION LINE → CONFIGURATION	
FORMAT (2602)	 Note! This function is not available unless a number was selected in the function ASSIGN (2600). Use this function to define the maximum number of places after the decimal point displayed for the reading in the additional line. Options XXXXX. - XXXX.X - XXX.XX - XX.XXX -X.XXXX Factory setting X.XXXX  Note! Note that this setting only affects the reading as it appears on the display, it has no influence on the accuracy of the system's calculations. The places after the decimal point as computed by the measuring device cannot always be displayed, depending on this setting and the engineering unit. In such instances an arrow appears on the display between the measuring value and the engineering unit (e.g. 1.2→ m3/h), indicating that the measuring system is computing with more decimal places than can be shown on the display.
DISPLAY MODE (2603)	 Note! This function is only available if VOLUME FLOW BARGRAPH IN % or SIGNAL BARGRAPH IN % was selected in the function ASSIGN (2600). Use this function to define the format of the bar graph. Options STANDARD (Simple bar graph with 25 / 50 / 75% gradations and integrated sign). +25 +50 +75 % A0001258 SYMMETRY (Symmetrical bar graph for positive and negative directions of flow, with -50 / 0 / +50% gradations and integrated sign). -50 - +50 % A0001259 Factory setting STANDARD

Function group MULTIPLEX

Functional description USER INTERFACE → INFORMATION LINE → MULTIPLEX	
ASSIGN (2620)	Use this function to define a second reading to be displayed in the main line alternately (every 10 seconds) with the reading defined in the function ASSIGN (2600). Options OFF VOLUME FLOW (CH1) VOLUME FLOW IN % (CH1) SOUND VELOCITY (CH1) SIGNAL STRENGTH (CH1) FLOW VELOCITY (CH1) VOLUME FLOW BARGRAPH IN % (CH1) SIGNAL BARGRAPH IN % (CH1) TOTALIZER (1 to 3) OPERATING/SYSTEM CONDITIONS FLOW DIRECTION ACTUAL CURRENT INPUT Factory setting OFF  Note! Multiplex mode is suspended as soon as a fault / notice message is generated. The message in question appears on the display. ■ Fault message (identified by a lightning icon): – If ON was selected in the function ACKNOWLEDGE FAULTS (8004), multiplex mode is resumed as soon as the fault has been acknowledged and is no longer active. – If OFF was selected in the function ACKNOWLEDGE FAULTS (8004), multiplex mode is resumed as soon as the fault is no longer active. ■ Notice message (identified by an exclamation mark): – Multiplex mode is resumed as soon as the notice message is no longer active. If a channel is not visible, it does not appear in the options. Channels can be displayed or hidden by means of the function MEASUREMENT (6880).
100% VALUE (2621)	 Note! This function is not available unless VOLUME FLOW IN % was selected in the ASSIGN function (2620). ■ VOLUME FLOW IN % (CH1) ■ VOLUME FLOW BARGRAPH IN % (CH1) ■ SIGNAL BARGRAPH IN % (CH1) Use this function to define the flow value to be shown on the display as the 100% value. User input 5-digit floating-point number Factory setting Depends on nominal diameter and country, [value] / [dm³ to m³ or US-gal to US-Mgal] Corresponds to the factory setting for the full scale value (→  106).

Functional description USER INTERFACE → INFORMATION LINE → MULTIPLEX	
FORMAT (2622)	 Note! This function is not available unless a number was selected in the function ASSIGN (2620). Use this function to define the maximum number of places after the decimal point displayed for the reading in the main line. Options XXXXX. - XXXX.X - XXX.XX - XX.XXX -X.XXXX Factory setting X.XXXX  Note! ■ Note that this setting only affects the reading as it appears on the display, it has no influence on the accuracy of the system's calculations. ■ The places after the decimal point as computed by the measuring device cannot always be displayed, depending on this setting and the engineering unit. In such instances an arrow appears on the display between the measuring value and the engineering unit (e.g. 1.2→ m3/h), indicating that the measuring system is computing with more decimal places than can be shown on the display.
DISPLAY MODE (2623)	 Note! This function is only available if VOLUME FLOW BARGRAPH IN % or SIGNAL BARGRAPH IN % was selected in the function ASSIGN (2620). Use this function to define the format of the bar graph. Options STANDARD (Simple bar graph with 25 / 50 / 75% gradations and integrated sign). +25 +50 +75 % A0001258 SYMMETRY (Symmetrical bar graph for positive and negative directions of flow, with -50 / 0 / +50% gradations and integrated sign). -50 0 +50 % A0001259 Factory setting STANDARD

11.6 Block TOTALIZER

11.6.1 Group TOTALIZER (1 to 3)

Function group CONFIGURATION

Functional description TOTALIZER → TOTALIZER → CONFIGURATION	
ASSIGN (3000)	Use this function to assign a measured variable to the totalizer in question. Options OFF VOLUME FLOW (CH1) Factory setting VOLUME FLOW (CH1)  Note! - The totalizer is reset to 0 as soon as the selection is changed. - If you select OFF in the function group CONFIGURATION of the totalizer in question, only the ASSIGN (3000) function remains visible.
UNIT TOTALIZER (3001)	Use this function to define the unit for the totalizer's measured variable, as selected beforehand. Options Metric: cm³; dm³; m³; ml; l; hl; Ml US: cc; af; ft³; oz f; gal; Mgal; bbl (normal fluids); bbl (beer); bbl (petrochemicals); bbl (filling tanks) Imperial: gal; Mgal; bbl (beer); bbl (petrochemicals) Arbitrary unit (from ARBITRARY UNIT function group →  71): ----- Factory setting m³
TOTALIZER MODE (3002)	Use this function to define how the flow components are to be totaled by the totalizer in question. Options BALANCE Positive and negative flow components. The positive and negative flow components are balanced. In other words, net flow in the flow direction is registered. FORWARD Positive flow components only REVERSE Negative flow components only Factory setting Totalizer 1 = BALANCE Totalizer 2 = FORWARD Totalizer 3 = REVERSE
RESET TOTALIZER (3003)	Use this function to reset the sum and the overflow of the totalizer in question to zero. Options NO YES Factory setting NO

Function group OPERATION

Functional description TOTALIZER → TOTALIZER → OPERATION	
SUM (3040)	Use this function to view the total for the particular totalizer's measured variable aggregated since measuring commenced. The value can be positive or negative, depending on the setting selected in the "TOTALIZER MODE" function (3002), and the direction of flow. User interface max. 7-digit floating-point number, including sign and unit (e.g. 15467.04 m3)  Note! Multiplex mode is suspended as soon as a fault / notice message is generated. The message in question appears on the display. ■ The effect of the setting in the "TOTALIZER MODE" function (→  85) is as follows: – If the setting is "BALANCE", the totalizer balances flow in the positive and negative directions. – If the setting is "POSITIVE", the totalizer registers only flow in the positive direction. – If the setting is "NEGATIVE", the totalizer registers only flow in the negative direction. ■ The totalizer's response to faults is defined in the "FAILSAFE ALL TOTALIZERS" function (3801) (→  85).
OVERFLOW (3041)	Use this function to view the totaled overflow for the particular totalizer aggregated since measuring commenced. Total flow quantity is represented by a floating-point number consisting of max. 7 digits. You can use this function to view higher numerical values (>9,999,999) as overflows. The effective quantity is thus the total of OVERFLOW plus the value returned by the SUM function. Example Reading for 2 overflows: $2 \cdot 10^7 \text{ dm}^3$ (= 20,000,000 dm³) The value displayed in the function SUM = 196,845.7 dm³ Effective total quantity = 20,196,845.7 dm³ User interface Integer with exponent, including sign and unit, e.g. 2 107 dm3

11.6.2 Group HANDLING TOTALIZER

Functional description TOTALIZER → HANDLING TOTALIZER	
RESET ALL TOTALIZERS (3800)	Use this function to reset the totals (including all overflows) of the totalizers (1 to 3) to "zero" (= RESET). Options NO YES Factory setting NO
FAILSAFE ALL TOTALIZERS (3801)	Use this function to define the common response of all totalizers (1 to 3) in case of error. Options STOP The totalizers stop if a fault is present. ACTUAL VALUE The totalizer continues to count based on the current flow measuring value. The fault is ignored. HOLD VALUE The totalizer continues to count the flow is based on the last valid flow value (before the fault occurred). Factory setting STOP

11.7 Block OUTPUTS

11.7.1 Group DATA LOGGER

Function group CONFIGURATION

Functional description OUTPUTS → DATA LOGGER → CONFIGURATION	
TAG NAME (4900)	Use this function to enter a tag name for the data records (header) to be recorded.  Note! After recording, the tag name is saved in the amplifier of the measuring device. The name should be changed accordingly if the measuring point is changed. User input max. 8-character text, permitted characters are: A–Z, 0–9, +, –, punctuation marks Factory setting ----- (No text)
LOGGING (4901)	Use this function to start or stop logging data to the USB stick. Options OFF ON Factory setting OFF
SYSTEM DATE/TIME (4902)	Use this function to enter the current date and the current time. User input ■ Day range: 00 to 99 ■ Month range: 00 to 31 ■ Year range: 00 to 12 ■ Meridiem range A or P
LOGGING CYCLE (4903)	Use this function to specify the intervals between the data logging cycles. User input Integers, 1 to 99999 s Factory setting 10 s
DELETE LOG FILES (4904)	Use this function to clear the entire contents of the USB stick. Options NO YES Security options NO YES Factory setting NO

Function group INFORMATION

Functional description OUTPUTS → DATA LOGGER → INFORMATION	
LOGGING TIME (4981)	Use this function to display the time that has elapsed for logging data onto the USB stick. User interface HH:MM:SS Factory setting 00:00:00

11.8 Block INPUTS

11.8.1 Group CURRENT INPUT

Function group CONFIGURATION

Functional description INPUTS → CURRENT INPUT → CONFIGURATION	
ASSIGN (5200)	Use this function to assign a process variable to the current input. Options VOLUME FLOW DEVICE 2 OFF Factory setting OFF
CURRENT SPAN (5201)	Use this function to define the current span. The selection specifies the operational range and the lower and upper signal on alarm. Options 0–20 mA 4–20 mA 4–20 mA NAMUR 4–20 mA US 0–20 mA (25 mA) 4–20 mA (25 mA) Factory setting 4–20 mA NAMUR Current range / operational range (measuring information) 0–20 mA / 0 to 20.5 mA 4–20 mA / 4 to 20.5 mA 4–20 mA NAMUR / 3.8 to 20.5 mA 4–20 mA US / 3.9 to 20.8 mA 0–20 mA (25 mA) / 0 to 24 mA 4–20 mA (25 mA) / 4 to 24 mA
VALUE 0–4 mA (5202)	Use this function to assign the 0/4 mA current a value. Options 5-digit floating-point number Factory setting 0 m³/h
VALUE 20 mA (5203)	Use this function to assign the 20 mA current a value. Options 5-digit floating-point number Factory setting 10 l/s
ERROR VALUE (5204)	Use this function to enter a defined error value for the process variable in question.  Note! If the current value is outside the selected range (see CURRENT SPAN function, (5201)), the process variable is set to the "error value" defined here and a corresponding notice message "RANGE CUR. IN (# 363)" is generated. User input 5-digit floating-point number Factory setting 0 l/s


Function group OPERATION


Functional description INPUTS → CURRENT INPUT → OPERATION	
ACTUAL CURRENT INPUT (5240)	Use this function to display the actual value of the input current. User interface 0.0 to 25 mA
SIMULATION CURRENT INPUT (5241)	Use this function to activate simulation of the current input. Options OFF ON Factory setting OFF  Note! ■ Active simulation is indicated by the notice message "SIM. CURR. INP. 1" (# 661). ■ The value output for the simulation at the current input is specified in the VALUE SIMULATION CURRENT INPUT function (5242). ■ The measuring device continues to measure while simulation is in progress, i.e. the current measuring values are output correctly via the other outputs and the display.  Caution! The setting is not saved if the power supply fails.
VALUE SIMULATION CURRENT INPUT (5242)	 Note! This function is not available unless the SIMULATION CURRENT INPUT function (5241) is switched on. Use this function to define a freely selectable value (e.g. 12 mA) to be simulated at the current input. This value is used to test downstream devices and the measuring device itself. User input 0.00 to 25.00 mA Factory setting 0.00 mA or 4 mA (depending on the setting in function 5201)  Caution! The setting is not saved if the power supply fails.

11.9 Block BASIC FUNCTIONS

11.9.1 Group PROCESS PARAMETER

Function group CONFIGURATION

Functional description BASIC FUNCTION → PROCESS PARAMETER → CONFIGURATION	
ASSIGN LOW FLOW CUT OFF (6400)	Use this function to assign the switch point for low flow cut off rate suppression. Options OFF VOLUME FLOW Factory setting VOLUME FLOW
ON-VALUE LOW FLOW CUT OFF (6401)	Use this function to assign a value to the switch-on point for low flow cut off. Low flow cut off is active if the value entered is not equal to 0. The sign of the flow value is highlighted on the display to indicate that low flow cut off is active. User input 5-digit floating-point number  Note! The appropriate unit is taken from the function UNIT VOLUME FLOW (0402) (→ 69). Factory setting 0 l/s
OFF-VALUE LOW FLOW CUT OFF (6403)	Use this function to enter the switch-off (b) point for low flow cut off. Enter the switch-off point as a positive hysteresis (H) from the switch-on point (a). User input Integer 0 to 100% Factory setting 50%  A0001245 Q = Flow [volume/time] a = ON-VALUE LF CUT OFF (6402) = 200 dm ³ /h b = OFF-VALUE LF CUT OFF (6403) = 10% c = Low flow cut off active 1 = Low flow cut off is switched on at 200 dm ³ /h 2 = Low flow cut off is switched off at 220 dm ³ /h t = Time

Functional description	
BASIC FUNCTION → PROCESS PARAMETER → CONFIGURATION	
PRESSURE SHOCK SUPPRESSION (6404)	The closure of a valve can cause brief but severe movements of the fluid in the piping system, movements which the measuring system registers. The pulses totaled in this way result in a totalizer reading error, particularly in the case of batching processes. For this reason, the measuring device is equipped with pressure shock suppression (= short-term signal suppression) which can eliminate system-related "disruptions".  Note! Note that pressure shock suppression cannot be used unless the low flow cut off is active, (see function ON-VALUE LF CUT OFF, →  90). Use this function to define the time span for active pressure shock suppression. Activation of the pressure shock suppression Pressure shock suppression is activated after the flow falls below the switch-on point of the low flow cut off (see point 1 in graphic). While pressure shock suppression is active, the following conditions apply: ■ Current output → outputs the current corresponding to zero flow. ■ Pulse/Freq.-output → outputs the frequency corresponding to zero flow. ■ Flow reading on display = → 0. ■ Totalizer reading → the totalizers are pegged at the last correct value. Deactivation of the pressure shock suppression The pressure shock suppression is deactivated after the time interval, set in this function, has passed (see point 2 in graphic). Factory setting l/s  Note! The actual flow value is displayed and output when the time interval for the pressure shock suppression has passed and the flow exceeds the switch-off point of the low flow cut off (see point 3 in graphic).  A0001285-en User input max. 4-digit number, incl. unit: 0.00 to 100.0 s Factory setting l/s

Function group ADJUSTMENT

Functional description BASIC FUNCTION → PROCESS PARAMETER → ADJUSTMENT	
ZERO POINT ADJUSTMENT (6480)	Use this function to start zero point adjustment.  Note! For information on how to perform a zero point adjustment, see →  47. Options CANCEL START Factory setting CANCEL

Function group PIPE DATA

Functional description BASIC FUNCTION → PROCESS PARAMETER → PIPE DATA	
PIPE STANDARD (6520)	Use this function to select a pipe standard. Options OTHERS DIN: PN10, PN16, 28610, 28614, 28615, 28619 ANSI: SCHEDULE 40, SCHEDULE 80 AWWA: CLASS 50, CLASS 53, CLASS 55  Note! The selection specifies the values for the following functions: ■ PIPE MATERIAL(6522) ■ SOUND VELOCITY PIPE(6524) ■ LINER MATERIAL(6528) If you edit these functions the pipe standard will be reset to the option OTHERS. Factory setting DIN PN10
NOMINAL DIAMETER (6521)	 Note! This function does not appear if the option OTHERS was selected in the function PIPE STANDARD (6520). Use this function to select the nominal diameter of the pipe. Options OTHERS DN: 25/1", 40/1½", 50/2", 80/3", 100/4", 150/6", 200/8", 250/10", 300/12", 400/16", 450/18", 500/20", 600/24", 700/28", 750/30", 800/32", 900/36", 1000/40", 1200/48", 1400/54", 1500/60", 1600/64", 1800/72", 2000/80"  Note! The selection specifies the values for the following functions: ■ CIRCUMFERENCE(6525) ■ PIPE DIAMETER(6526) ■ WALL THICKNESS(6527) If you edit these functions the pipe standard will be reset to the option OTHERS and the function NOMINAL DIAMETER (6521) does not appear. Factory setting 80/3"


Functional description BASIC FUNCTION → PROCESS PARAMETER → PIPE DATA	
PIPE MATERIAL (6522)	This function displays the pipe material determined via the value entered in the function PIPE STANDARD (6520). If you edit the predetermined value the pipe standard will be reset to the option OTHERS and the function NOMINAL DIAMETER (6521) does not appear. If a pipe standard was not available for selection and the selection OTHER was made in the function PIPE STANDARD (6520) the pipe material must be entered here. Options CARBON STEEL, DUCTILE IRON, STAINLESS STEEL, SS ANSI 304, SS ANSI 316, SS ANSI 347, SS ANSI 410, SS ANSI 430, ALLOY C, PVC, PE, LDPE, HDPE, GRP, PVDF, PA, PP, PTFE, GLASS PYREX, ASBESTOS CEMENT, OTHER Factory setting STAINLESS STEEL
REFERENCE VALUE (6523)	Use this function to enter the thickness of the reference component (e.g. flange) as the basis for measuring the sound velocity of the pipe.  Note! This function does not appear unless the option SOUND VELOCITY PIPE was selected in the function MEASUREMENT (6880, →  99). User input 5-digit floating-point number, [unit] Factory setting 5 mm
SOUND VELOCITY PIPE (6524)	This function displays the sound velocity in the pipe determined via the value entered in the function PIPE STANDARD (6520). If you edit the predetermined value the pipe standard will be reset to the option OTHERS and the function NOMINAL DIAMETER (6521) does not appear. If a pipe standard was not available for selection and the selection OTHER was made in the function PIPE STANDARD (6520) the sound velocity must be entered here. Measuring the sound velocity in the pipe If the sound velocity in the pipe is unknown, it can be measured. To do so, select the option SOUND VELOCITY PIPE in the function MEASUREMENT (6880, →  99). The sound velocity in the pipe is measured by calling up the function SOUND VELOCITY PIPE (6524). The measured sound velocity, the signal strength and a bar graph appear on the local display. The measurement is valid if 100% is achieved in the bar graph. If you confirm the function with the  key, the SAVE prompt appears. To accept the measured sound velocity, select the option YES by means of the  or  key.  Note! ■ To measure the sound velocity, you require the ultrasonic sensors "DDU18" which you can order as an accessory from Endress+Hauser. ■ A reference value is used as a basis for measuring the sound velocity. This reference value can be edited (see REFERENCE VALUE function, 6523). User input Fixed-point number 800 to 6500 m/s Factory setting 3120 m/s

Functional description BASIC FUNCTION → PROCESS PARAMETER → PIPE DATA	
CIRCUMFERENCE (6525)	This function displays the outer circumference of the pipe determined via the value entered in the function NOMINAL DIAMETER (6521). If you edit the predetermined value the pipe standard will be reset to the option OTHERS and the function NOMINAL DIAMETER (6521) does not appear. If a nominal diameter was not available for selection and the selection OTHER was made in the function NOMINAL DIAMETER (6521) the outer circumference must be entered here. User input Fixed-point number 31.4 to 15708.0 mm Factory setting 279.3 mm
PIPE DIAMETER (6526)	This function displays the outer diameter of the pipe determined via the value entered in the function NOMINAL DIAMETER (6521). If you edit the predetermined value the pipe standard will be reset to the option OTHERS and the function NOMINAL DIAMETER (6521) does not appear. If a nominal diameter was not available for selection and the selection OTHER was made in the function NOMINAL DIAMETER (6521) the outer diameter must be entered here. User input Fixed-point number 10.0 to 5000.0 mm Factory setting 88.9 mm
WALL THICKNESS (6527)	This function displays the thickness of the pipe walls determined via the value entered in the function NOMINAL DIAMETER (6521). If you edit the predetermined value the pipe standard will be reset to the option OTHERS and the function NOMINAL DIAMETER (6521) does not appear. If a nominal diameter was not available for selection and the selection OTHER was made in the function NOMINAL DIAMETER (6521) the thickness of the pipe wall must be entered here. Measuring the wall thickness If the wall thickness is unknown, it can be measured. To do so, select the option WALL THICKNESS in the function MEASUREMENT (6880, → 99). The wall thickness is measured by calling up the function WALL THICKNESS (6527). The measured wall thickness, the signal strength and a bar graph appear on the local display. The measurement is valid if 100% is achieved in the bar graph. If you confirm the function with the  key, the SAVE prompt appears. To accept the measured wall thickness, select the option YES by means of the  or  key.  Note! To measure the wall thickness, you require the ultrasonic sensors "DDU20" which you can order as an accessory from Endress+Hauser. User input Fixed-point number 0.1 to 100.0 mm Factory setting 3.2 mm

Functional description BASIC FUNCTION → PROCESS PARAMETER → PIPE DATA	
LINER MATERIAL (6528)	This function displays the liner material of the pipe determined via the value entered in the function PIPE STANDARD (6520). If you edit the predetermined value the pipe standard will be reset to the option OTHERS and the function NOMINAL DIAMETER (6521) does not appear. If a pipe standard was not available for selection and the selection OTHERS was made in the function PIPE STANDARD (6520) the liner material must be specified here. Options LINER NONE MORTAR TAR EPOXY OTHERS Factory setting LINER NONE
SOUND VELOCITY LINER (6529)	 Note! This function does not appear if the option LINER NONE was selected in the function LINER MATERIAL (6528). This function displays the sound velocity of the liner determined via the value entered in the function LINER MATERIAL (6528). If you edit the predetermined value the liner material will be reset to the option OTHERS. If a liner material was not available for selection and the selection OTHER was made in the function LINER MATERIAL (6528) the sound velocity of the liner must be entered here. User input Fixed-point number 800 to 6500 m/s Factory setting Depending on the selection in the function LINER MATERIAL (6528)
LINER THICKNESS (6528)	 Note! This function does not appear if the option LINER NONE was selected in the function LINER MATERIAL (6528). Use this function to enter the thickness of the liner. User input Fixed-point number 0.1 to 100.0 mm Factory setting 0 mm

Function group LIQUID DATA

Functional description BASIC FUNCTIONS → PROCESS PARAMETER → LIQUID DATA	
LIQUID (6540)	Use this function to select the liquid in the pipe. Options WATER, SEA WATER, DISTILLED WATER, AMMONIA, ALCOHOL, BENZENE, BROMIDE, ETHANOL, GLYCOL, KEROSENE, MILK, METHANOL, TOLUOL, LUBRICATING OIL, FUEL OIL, PETROL, OTHER  Note! The selection specifies the values for the sound velocity and viscosity. If OTHER is selected, these must be entered via the SOUND VELOCITY LIQUID (6542) and VISCOSITY (6543) functions. Factory setting Water

Functional description	
BASIC FUNCTIONS → PROCESS PARAMETER → LIQUID DATA	
TEMPERATURE (6541)	Use this function to enter the process temperature of the liquid. Via the sound velocity, the value influences the determination of the sensor distance. Enter the process temperature at normal operating conditions to achieve an optimum configuration of the measuring system. User input Fixed-point number -273.15 to 726.85 °C (0 to 1000 K) Factory setting 20 °C
SOUND VELOCITY LIQUID (6542)	This function displays the sound velocity of the liquid. This is determined by the values entered in the LIQUID (6540) and TEMPERATURE (6541) functions. If you edit the predetermined value the function LIQUID (6540) will be set to the option OTHERS. The sound velocity of the liquid has to be entered if the liquid is not available for selection in the function LIQUID (6540) and the OTHERS option was selected. Measuring the sound velocity of the liquid If the sound velocity of the liquid is unknown, it can be measured. To do so, select the option SOUND VELOCITY LIQUID in the function MEASUREMENT (6880, → 99). The sound velocity in the liquid is measured by calling up the function SOUND VELOCITY LIQUID (6542). The result of the measurement appears on the local display. If you confirm the function with the  key, the SAVE prompt appears. To accept the measured sound velocity, select the option YES by means of the  or  key.  Note! To measure the sound velocity, you require the ultrasonic sensors "DDU18" which you can order as an accessory from Endress+Hauser. Transmitter search range: The measuring device searches for the measuring signal within a defined sound velocity range. You specify the search range in the SOUND VELOCITY NEGATIVE (6545) and SOUND VELOCITY POSITIVE (6546) functions. An error message is displayed if the sound velocity of the liquid exceeds the search range.  Note! We recommend you select a smaller search range in the event of unfavorable signal conditions (signal strength < 50%).  A0001246 1. Sound velocity of the liquid 2. Lower search range: is specified in the SOUND VELOCITY NEGATIVE (6545) function 3. Upper search range: is specified in the SOUND VELOCITY POSITIVE (6546) function User input Fixed-point number 400 to 3000 m/s Factory setting 1485 m/s

Functional description BASIC FUNCTIONS → PROCESS PARAMETER → LIQUID DATA	
VISCOSITY (6543)	This function displays the viscosity of the liquid. This is determined via the values entered in the LIQUID (6540) and TEMPERATURE (6541) functions. If you edit the predetermined value the function LIQUID (6540) will be set to the option OTHERS. The viscosity has to be entered if the liquid is not available for selection in the function LIQUID (6540) and the OTHERS option was selected. User input Fixed-point number 0.0 to 5000.0 mm²/s Factory setting 1 mm²/s
SOUND VELOCITY NEGATIVE (6545)	Use this function to specify the lower search range for the sound velocity of the liquid. User input Fixed-point number 0 to 1000 m/s Factory setting 500 m/s  Note! Please refer to the explanations in the function SOUND VELOCITY LIQUID (6542).
SOUND VELOCITY POSITIVE (6546)	Use this function to specify the upper search range for the sound velocity of the liquid. User input Fixed-point number 0 to 1000 m/s Factory setting 300 m/s  Note! Please refer to the explanations in the function SOUND VELOCITY LIQUID (6542).

11.9.2 Group SYSTEM PARAMETER

Function group CONFIGURATION

Functional description BASIC FUNCTION → SYSTEM PARAMETER → CONFIGURATION	
INSTALLATION DIRECTION SENSOR (6600)	Use this function to reverse the sign of the flow quantity, if necessary. Options NORMAL INVERSE Factory setting NORMAL
FLOW DAMPING (6603)	The system damping acts on all functions and outputs of the measuring device. Use this function to set the filter depth of the digital filter. This reduces the sensitivity of the measuring signal to interference peaks (e.g. high solids content, gas bubbles in the fluid, etc.). The system reaction time increases with the filter setting. User input 0 to 100 s Factory setting 0 s
POSITIVE ZERO RETURN (6605)	Use this function to interrupt evaluation of measured variables. This is necessary when a piping system is being cleaned, for example. This setting acts on all function and outputs of the measuring device. Options OFF ON → Signal output is set to the "ZERO FLOW" value. Factory setting OFF

11.9.3 Group SENSOR DATA

Function group SENSOR PARAMETER

Functional description BASIC FUNCTION → SENSOR DATA → SENSOR PARAMETER	
MEASUREMENT (6880)	Use this function to select the measuring method or the type of mounting. Options OFF CLAMP ON INSERTION (is not supported by the measuring device) SOUND VELOCITY LIQUID SOUND VELOCITY PIPE WALL THICKNESS Factory setting CLAMP ON
SENSOR TYPE (6681)	 Note! This function is only available if the OFF setting was not selected in the function MEASUREMENT. Use this function to select the sensor type. Options W-CL-05F-L-B ¹⁾ W-CL-1F-L-B ¹⁾ W-CL-2F-L-B ¹⁾ P-CL-05F-L-B ¹⁾ P-CL-1F-L-B ¹⁾ P-CL-2F-L-B ¹⁾ U-CL-2F-L-A ¹⁾ P-CL-6F-L-D ¹⁾ P-CL-6F-M-D ¹⁾ P-CL-05F-M-B ¹⁾ P-CL-1F-M-B ¹⁾ P-CL-2F-M-B ¹⁾ W-IN-1F-L-B ²⁾ P-CL-1S-L-B ³⁾ P-CL-1S-M-B ³⁾ P-CL-4W-L-B ⁴⁾ Factory setting W-CL-2F-L-B ■ ¹⁾ This option is not available unless CLAMP ON was selected in the function MEASUREMENT. ■ ²⁾ This option is not available unless INSERTION was selected in the function MEASUREMENT. ■ ³⁾ This option is not available unless SOUND VELOCITY LIQUID was selected in the function MEASUREMENT. ■ ⁴⁾ This option is not available unless SOUND VELOCITY PIPE or WALL THICKNESS was selected in the function MEASUREMENT.

Functional description BASIC FUNCTION → SENSOR DATA → SENSOR PARAMETER	
SENSOR CONFIGURATION (6882)	Use this function to select the configuration for the ultrasonic sensors, e.g. the number of traverses (in the Clamp On version).  Note! This function is not available unless one of the following options was selected in the function MEASUREMENT (6880): ■ CLAMP ON ■ SOUND VELOCITY LIQUID ■ INSERTION (is not supported by the measuring device) Options NO. TRAVERSE: 1 ¹⁾ NO. TRAVERSE: 2 ²⁾ SINGLE PATH ³⁾ (is not supported by the measuring device) DUAL PATH ³⁾ (is not supported by the measuring device) Factory setting NO. TRAVERSE: 2 ■ ¹⁾ This option is not available unless CLAMP ON or SOUND VELOCITY LIQUID was selected in the function MEASUREMENT. ■ ²⁾ This option is not available unless CLAMP ON was selected in the function MEASUREMENT. ■ ³⁾ This option is not available unless INSERTION was selected in the function MEASUREMENT.  Note! The setting "NO. TRAVERSE: 2" is required for sensors with a nominal diameter range from DN15 to DN 65.
CABLE LENGTH (6882)	Use this function to select the length of the sensor cable. Options LENGTH 5 m/15 feet LENGTH 10 m/30 feet Factory setting LENGTH 5 m/15 feet
POSITION SENSOR (6884)	Use this function to view the position of both sensors on the rail. User interface 5-digit number combination
WIRE LENGTH (6885)	The wire length for assembling the sensors at the correct distance apart appears on the display. User interface max. 5-digit number, including unit (e.g. 200 mm)
SENSOR DISTANCE (6886)	The distance between sensor 1 and sensor 2 as a length measurement appears on the display. User interface max. 5-digit number, including unit (e.g. 200 mm)
ARC LENGTH (6887)	The arc length on the pipe appears on the display. User interface max. 5-digit number, including unit (e.g. 200 mm)
PATH LENGTH (6888)	The path length appears on the display. User interface max. 5-digit number, including unit (e.g. 200 mm)

Function group CALIBRATION DATA

Functional description BASIC FUNCTIONS → SENSOR DATA → CALIBRATION DATA	
P-FACTOR (6890)	This function displays the p-factor. The p-factor indicates the influence of the velocity distribution of the flow profile inside the pipe; it is dependent on the Reynolds number. The p-factor varies in the range 0.75 to 0.95. If the displayed value ranges between 0.75 and 0.94 the measurement will have a reduced linearity.
ZERO POINT (6891)	Use this function to call up or manually change the zero point correction currently being used. User input 5-digit floating-point number, including unit and sign (e.g. +10.0 ns)
CORRECTION FACTOR (6893)	Use this function to enter a correction factor at the client's site. User input 5-digit floating-point number Factory setting 1.0000 (= no correction)
DEVIATION SENSOR DISTANCE (6894)	 Note! This option is not available unless INSERTION was selected in the function MEASUREMENT (6880). (is not supported by the measuring device) Use this function to enter a deviation value for the sensor distance. User input 5-digit floating-point number, including unit and sign (e.g. +2.0000 mm) Factory setting 0 mm
DEVIATION ARC LENGTH (6895)	 Note! This function is not available unless INSERTION was set in the function MEASUREMENT (6880) and the DUAL PATH option was selected in the function SENSOR CONFIGURATION (6882). Use this function to enter a deviation value for the arc length. User input 5-digit floating-point number, including unit and sign (e.g. +2.0000 mm) Factory setting 0 mm
DEVIATION PATH LENGTH (6896)	 Note! This option is not available unless INSERTION was selected in the function MEASUREMENT (6880). (is not supported by the measuring device) Use this function to enter a deviation value for the path length. User input 5-digit floating-point number, including unit and sign (e.g. +2.0000 mm) Factory setting 0 mm

11.10 Block SUPERVISION

11.10.1 Group SYSTEM

Function group CONFIGURATION

Functional description SUPERVISION → SYSTEM → CONFIGURATION	
ASSIGN SYSTEM ERROR (8000)	Use this function to view all system errors and the associated error categories (fault message or notice message). If you select a single system error you can change its error category. User interface CANCEL List of system errors with an icon preceding each entry.  Note! ■ Press the  key twice to call up the function ERROR CATEGORY (8001). ■ Use the  key combination or select "CANCEL" in the system error list to exit the function. ■ A list of possible system errors is provided on →  52.
ERROR CATEGORY (8001)	Use this function to define whether a system error triggers a notice message or a fault message. If you select "FAULT MESSAGES", all outputs respond to an error in accordance with their defined error response patterns. Options NOTICE MESSAGES (display only) FAULT MESSAGES (outputs and display)  Note! Press the  key twice to call up the function ASSIGN SYSTEM ERROR (8000).
ASSIGN PROCESS ERROR (8002)	Use this function to view all process errors and the associated error categories (fault message or notice message). If you select a single process error you can change its error category. User interface CANCEL List of process errors with an icon preceding each entry.  Note! ■ Press the  key twice to call up the function ERROR CATEGORY (8003). ■ Use the  key combination or select "CANCEL" in the system error list to exit the function. ■ A list of possible process errors is provided on →  54.
ERROR CATEGORY (8003)	Use this function to define whether a process error triggers a notice message or a fault message. If you select "FAULT MESSAGES", all outputs respond to an error in accordance with their defined error response patterns. Options NOTICE MESSAGES (display only) FAULT MESSAGES (outputs and display)  Note! Press the  key twice to call up the function ASSIGN PROCESS ERROR (8002).

Functional description SUPERVISION → SYSTEM → CONFIGURATION	
ACKNOWLEDGE FAULT (8004)	Use this function to define the measuring device's response to fault messages. Options OFF The measuring device resumes normal operation when the fault is rectified. The fault message disappears automatically. ON The measuring device resumes normal operation when the fault is rectified. The fault message has to be acknowledged by pressing the  key on the local display. Factory setting OFF
ALARM DELAY (8005)	Use this function to specify a time period for suppressing the appearance of fault or notice messages. Depending on the setting and the type of error, this suppression acts on: ■ Display ■ Relay output ■ Current output ■ Frequency output User input 0 to 100 s (in steps of one second) Factory setting 0 s  Caution! If this function is activated, error and notice messages are delayed by the time corresponding to the setting before being forwarded to the higher-order controller (process controller, etc.). It is therefore imperative to check in advance in order to make sure whether a delay of this nature could affect the safety requirements of the process. If error and notice messages cannot be suppressed, a value of 0 seconds must be entered here.

Function group OPERATION

Functional description SUPERVISION → SYSTEM → OPERATION	
ACTUAL SYSTEM CONDITION (8040)	Use this function to check the present system condition. User interface "SYSTEM OK" or the fault / notice message with the highest priority.
PREVIOUS SYSTEM CONDITIONS (8041)	Use this function to view the fifteen most recent error and notice messages since measuring last started. User interface The last 15 fault/notice messages appear on the display.
SIMULATION FAILSAFE MODE (8042)	Use this function to set all inputs, outputs and totalizers to their defined failsafe modes, in order to check whether they respond correctly. During this time, the words "SIMULATION FAILSAFE MODE" appear on the display. Options ON OFF FAILURE (CH1) Factory setting OFF

Functional description SUPERVISION → SYSTEM → OPERATION	
SIMULATION MEASURAND (8043)	 Note! This function is available in the SYSTEM group. Use this function to set all inputs, outputs and totalizers to their defined flow-response modes, in order to check whether they respond correctly. During this time, the words "SIMULATION MEASURAND" appear on the display. Options OFF VOLUME FLOW (CH1) SOUND VELOCITY (CH1) Factory setting OFF  Caution! ■ The measuring device cannot be used for measuring while this simulation is in progress. ■ The setting is not saved if the power supply fails.
VALUE SIMULATION MEASURAND (8044)	 Note! ■ This function is available in the SYSTEM group. ■ The function is not visible unless the function SIMULATION MEASURAND (8043) is active. Use this function to specify a selectable value (e.g. 12 m³/s). This is used to test the associated functions in the device itself and downstream signal loops. User input 5-digit floating-point number, [unit] Factory setting 0 [unit]  Caution! ■ The setting is not saved if the power supply fails. ■ The appropriate unit is taken from the function group SYSTEM UNITS (ACA) (→  69).
SYSTEM RESET (8046)	Use this function to perform a reset of the measuring system. Options NO RESTART SYSTEM (restart without interrupting power supply) Factory setting NO

11.10.2 Group VERSION INFO

Function group DEVICE

Functional description SUPERVISION → VERSION INFO → DEVICE	
DEVICE SOFTWARE (8100)	Displays the current device software version.

Function group SENSOR

Functional description SUPERVISION → VERSION INFO → SENSOR	
SERIAL NUMBER (8200)	Use this function to view the current serial number of the sensor.

Function group AMPLIFIER

Functional description SUPERVISION → VERSION INFO → AMPLIFIER	
SOFTWARE REVISION NUMBER AMPLIFIER (8222)	Use this function to view the software revision number of the amplifier.
LANGUAGE GROUP (8226)	Use this function to view the language group.  Note! ■ You can change the language group via the operating program "FieldCare". ■ The following language groups are available: – WEST EU / USA – EAST EU / SCAND. – ASIA – CHINA

Function group I/O MODULE

Functional description SUPERVISION → VERSION INFO → I/O MODULE	
I/O MODULE TYPE (8300)	Use this function to view the configuration of the I/O module.
SOFTWARE REVISION NUMBER I/O MODULE (8303)	Use this function to view the software revision number of the I/O module.

Function group I/O SUBMODULE 1

Functional description SUPERVISION → VERSION INFO → I/O SUBMODULE 1	
SUB I/O TYPE (8320)	Use this function to view the configuration of I/O submodule 1 (current input).
SOFTWARE REVISION NUMBER SUB I/O TYPE (8323)	Use this function to view the software revision number of I/O submodule 1.

Function group I/O SUBMODULE 2

Functional description SUPERVISION → VERSION INFO → I/O SUBMODULE 2	
SUB I/O TYPE (8340)	Use this function to view the configuration of I/O submodule 2 (data logger).
SOFTWARE REVISION NUMBER SUB I/O TYPE (8343)	Use this function to view the software revision number of I/O submodule 2.

12 Factory settings

12.1 SI units (not for USA and Canada)

12.1.1 Units of length and temperature

	Unit
Temperature	° C
Length	mm

12.1.2 Language

Country	Language	Country	Language
Australia	English	Norway	Norsk
Belgium	English	Austria	Deutsch
Denmark	English	Poland	Polski
Germany	Deutsch	Portugal	Portugues
England	English	Sweden	Svenska
Finland	Suomi	Switzerland	Deutsch
France	Francais	Singapore	English
The Netherlands	Nederlands	Spain	Espanol
Hong Kong	English	South Africa	English
India	English	Thailand	English
Italy	Italiano	Czech Republic	Cesky
Luxembourg	Francais	Hungary	English
Malaysia	English	Other countries	English

12.2 US units (for USA and Canada only)

12.2.1 Units of length and temperature

	Unit
Temperature	°F
Length	Inch

12.2.2 Language

	Language
USA	English
Canada	English

Index

A

Access code (2020)	73
Access code counter (2023)	74
Accessories	50
Acknowledge fault (8004)	103
Actual current input (5240)	89
Actual system condition (8040)	103
Additional configuration (function group)	70
Additional line	
100% value (2401)	77
Assign (2400)	77
Configuration	77
Display mode (2403)	78
Format (2402)	78
Additional line (Multiplex)	
100% value (2421)	79
Assign (2420)	79
Display mode (2423)	80
Format (2422)	80
Adjustment (function group)	92
Alarm delay (8005)	103
Ambient temperature range	61
Amplifier (function group)	105
Applications	5, 57
Applicator (selection and configuration software)	51
Approvals	9, 64
Arbitrary unit	
Function group	71
Arbitrary units (function group)	71
Arc length (6887)	100
Assign (3000)	85
Assign (5200)	88
Assign low flow cut off (6400)	90
Assign process error (8002)	102
Assign system error (8000)	102

B

Backlight (2004)	73
Basic configuration (function group)	72
Basic functions (block)	90
Battery charging	49
Block	
Basic functions	90
Inputs	88
Measured variables	68
Outputs	87
Quick Setup	71
Supervision	102
Totalizer	85
User interface	72

C

Cable length (6882)	100
Calibration data (function group)	101
CE mark (Declaration of Conformity)	9
Certificates	9, 64

Circumference (6525)	94
Cleaning	49
Commissioning	
Quick Setup "Pulsating Flow"	44
Configuration	
Additional line	77
Current input)	88
Data logger	87
Information line	81
Main line	75
Process parameter	90
Supervision	102
System parameter	98
System units	69
Totalizer)	85
Connecting cable	59
Contrast LCD (2003)	73
Control (group)	72
Correction factor (6893)	101
Coupling fluid	49
C-Tick mark	9
Current output (group)	88
Current span (5201)	88

D

Data logger	58
Data logger (data exchange)	48
Data logger (group)	87
DDU18 sound velocity sensor	28
DDU20 wall thickness sensor	29
Declaration of Conformity (CE mark)	9
Define private code (2021)	74
Degree of protection	61
Delete log files (4904)	87
Designated use	5
Deviation arc length (6895)	101
Deviation path length (6896)	101
Deviation sensor distance (6894)	101
Device (function group)	104
Device designation	7
Device software (8100)	104
Display	63
Display and operating elements	33
Display damping (2002)	72
Display elements	63
Disposal	56

E

Electrical connection	
Potential equalization	32
Electromagnetic compatibility (EMC)	61
Error category (8001)	102
Error category (8003)	102
Error messages	
Confirming error messages	38
Process error (application error)	54
Error types (system and process errors)	38

Error value (5204)	88
Exterior cleaning	49

F

Factor arbitrary volume (0603)	71
Failsafe all totalizers (3801)	86
Failsafe mode of inputs/outputs	56
FieldCare	39, 51
Fieldcheck (tester and simulator)	51
Flow damping (6603)	98
Flow velocity CH1 (0003)	68
Format date/time (0429)	70
Function	57
Function check	40
Function group	
Additional configuration	70
Adjustment	92
Amplifier	105
Arbitrary unit	71
Basic configuration	72
Calibration data	101
Configuration	69, 75, 85, 87–88, 90
Configuration (information line)	81
Configuration (supervision)	102
Configuration (system parameter)	98
Device	104
I/O module	105
I/O submodule 1	105
I/O submodule 2	105
Information	87
Liquid data	95
Main values CH1	68
Multiplex	76
Multiplex (additional line)	79
Multiplex (information line)	83
Operation	74, 86, 89, 103
Pipe data	92
Sensor	104
Sensor parameter	99
Unlocking/locking	73
Function matrix	
Brief guide	36
Description	65
Overview	67
FXA193	51
FXA291	51

G

Galvanic isolation	58
Group	
Additional line	77
Current output	88
Data logger	87
Handling totalizer	86
Information line	81
Main line	75
Measuring values	68
Operation	72
Process parameter	90

Sensor data	99
Special units	71
System	102
System parameter	98
System units	69
Totalizer	85
Version info.	104

H

Handling totalizer (group)	86
Hazardous substances	6
HOME position (display operating mode)	33

I

I/O module (function group)	105
I/O submodule 1 (8320)	105
I/O submodule 2 (8340)	105
I/O_module type (8300)	105
Incoming acceptance	10
Information (function group)	87
Information line	
100% value (2601)	81
Assign (2600)	81
Display mode (2603)	82
Format (2602)	82
Information line (Multiplex)	
100% value (2621)	83
Assign (2620)	83
Display mode (2623)	84
Format (2622)	84
Input	57
Input signal	57
Inputs (block)	88
Installation conditions	
Dimensions	10
Inlet and outlet run	11
Mounting location	10
Installation direction sensor (6600)	98

L

Language (2000)	72
Language group (8226)	105
Language groups	63
Length of connecting cable	60
Liner material (6528)	95
Liner thickness (6528)	95
Liquid (6540)	95
Liquid data (process parameter group)	95
Logging (4901)	87
Logging cycle (4903)	87
Logging time (4981)	87
Low flow cut off	58

M

Main line	
100% value (2201)	75
Assign (2200)	75
Configuration	75
Format (2202)	75

Main line (Multiplex)	
100% value (2221)	76
Assign (2220)	76
Format (2222)	76
Materials	63
Maximum measured error	59
Measured variable	57
Measured variables (block)	68
Measurement (6880)	99
Measuring principle	57
Measuring range	57
Measuring system	7, 57
Measuring unit electrical connection	58
Measuring values (group)	68
Mechanical construction	62
Medium pressure range (nominal pressure)	62
Medium temperature range	62

N

Nameplate	
Sensor	8
Transmitter	7
NiMH accumulator	
Charging	31
Technical data	58
Nominal diameter (6521)	92

O

Off-value low flow cut off (6403)	90
On-value low flow cut off (6401)	90
Operable flow range	57
Operating conditions	
Environment	61
Installation	60
Operating elements	63
Operation	
Display and operating elements	33
FieldCare	39
Function matrix	36
Operational safety	5
Order code	
Accessories	50
Transmitter	7–8
Ordering information	64
Output signal	58
Outputs (block)	87
Overflow (3041)	86

P

Path length (6888)	100
Performance characteristics	59
P-factor (6890)	101
Pipe data (function group)	92
Pipe diameter (6526)	94
Pipe material (6522)	93
Pipe standard (6520)	92
Position sensor (6884)	100
Positive zero return (6605)	98
Post-installation check (checklist)	30
Potential equalization	32, 59

Pressure loss	62
Pressure shock suppression (6404)	91
Previous system conditions (8041)	103
Process error messages	54
Process errors	
Definition	38
Process errors without messages	55
Process parameter (group)	90
Programming mode	
Disabling	37
Enabling	37
Pulsating flow	44
Pump types, pulsating flow	44

Q

Quick Setup

Commissioning	43
Function QS sensor installation (1001)	71
Pulsating flow	44
QS function commissioning (1002)	71
QS function pulsating flow (1003)	71
Sensor installation	41

R

Reference value (6523)	93
Registered trademarks	9
Remote operation	63
Repair	6
Reset all totalizers (3800)	86
Reset totalizer (3003)	85
Returning devices	6

S

Safety icons	6
Safety instructions	5
Sensor	57
Sensor (function group)	104
Sensor configuration (6882)	100
Sensor distance (6886)	100
Sensor parameter	
Function group	99
Sensor type (6681)	99
Serial number	7–8
Serial number (8200)	104
Service interface FXA193	51
Serviceinterface FXA291	51
Shock resistance	61
Shut backlight (2005)	73
Signal strength (0007)	68
Simulation	
Current input (5241)	89
Failsafe mode (8042)	103
Measurand (8043)	104
Software	
Amplifier display	40
Software revision number	
Amplifier (8222)	105
I/O module (8303)	105
I/O submodule 1	105
I/O submodule 2	105

Sound velocity			
Display (0002)	68		
Liquid (6542)	96		
Negative (6545)	97		
Pipe (6524)	93		
Positive (6546)	97		
Sound velocity liner (6529)	95		
Sound velocity sensor DDU18	28		
Special units (group)	71		
Standards, guidelines	64		
Status access (2022)	74		
Storage	10		
Storage temperature	61		
Sum (3040)	86		
Supervision (block)	102		
Supply voltage	58		
System (group)	102		
System date/time (4902)	87		
System design	57		
System error			
Definition	38		
System parameter (group)	98		
System reset (8046)	104		
System units (group)	69		
T			
Tag name (4900)	87		
Technical data	57		
Temperature (6541)	96		
Temperature ranges			
Ambient temperature range	61		
Medium temperature	62		
Storage temperature	61		
Test display (2040)	74		
Text arbitrary volume (0602)	71		
Totalizer (block)	85		
Totalizer (group)	85		
Totalizer mode (3002)	85		
Transmitter	57		
Electrical connection	31, 40		
Troubleshooting and remedy	52		
U			
Unit			
Length (0424)	70		
Temperature (0422)	70		
Velocity (0425)	70		
Viscosity (0423)	70		
Volume (0403)	69		
Volume flow (0042)	69		
Unit totalizer (3001)	85		
Unlocking/locking (function group)	73		
User interface	63		
V			
Value 0–4 mA (5202)	88		
Value 20 mA (5203)	88		
Value simulation current input (5242)	89		
Value simulation measurand (8044)	104		
Version info (group)	104		
Vibration resistance	61		
Vibrations, shock and vibration resistance	61		
Viscosity (6543)	97		
Volume flow CH1 (0001)	68		
Volume flow device 2 (0011)	68		
W			
Wall thickness (6527)	94		
Wall thickness sensor DDU19	29		
Weight	62		
Wire length (6885)	100		
Z			
Zero point (6891)	101		
Zero point adjustment	47		
Zero point adjustment (6480)	92		

Declaration of Hazardous Material and De-Contamination Erklärung zur Kontamination und Reinigung

RA No.

Please reference the Return Authorization Number (RA#), obtained from Endress+Hauser, on all paperwork and mark the RA# clearly on the outside of the box. If this procedure is not followed, it may result in the refusal of the package at our facility.
Bitte geben Sie die von E+H mitgeteilte Rücklieferungsnummer (RA#) auf allen Lieferpapieren an und vermerken Sie diese auch außen auf der Verpackung. Nichtbeachtung dieser Anweisung führt zur Ablehnung ihrer Lieferung.

Because of legal regulations and for the safety of our employees and operating equipment, we need the "Declaration of Hazardous Material and De-Contamination", with your signature, before your order can be handled. Please make absolutely sure to attach it to the outside of the packaging.

Aufgrund der gesetzlichen Vorschriften und zum Schutz unserer Mitarbeiter und Betriebseinrichtungen, benötigen wir die unterschriebene "Erklärung zur Kontamination und Reinigung", bevor Ihr Auftrag bearbeitet werden kann. Bringen Sie diese unbedingt außen an der Verpackung an.

Type of instrument / sensor

Geräte-/Sensortyp

Serial number

Seriennummer

☐ Used as SIL device in a Safety Instrumented System / Einsatz als SIL Gerät in Schutzeinrichtungen

Process data / Prozessdaten

Temperature / Temperatur _____ [°F] _____ [°C]

Pressure / Druck _____ [psi] _____ [Pa]

Conductivity / Leitfähigkeit _____ [µS/cm]

Viscosity / Viskosität _____ [cp] _____ [mm²/s]

Medium and warnings

Warnhinweise zum Medium



	Medium /concentration Medium /Konzentration	Identification CAS No.	flammable entzündlich	toxic giftig	corrosive ätzend	harmful/ irritant gesundheits- schädlich/ reizend	other * sonstiges *	harmless unbedenklich
Process medium								
Medium im Prozess								
Medium for process cleaning								
Medium zur Prozessreinigung								
Returned part cleaned with								
Medium zur Endreinigung								

* explosive; oxidising; dangerous for the environment; biological risk; radioactive

* explosiv; brandfördernd; umweltgefährlich; biogefährlich; radioaktiv

Please tick should one of the above be applicable, include safety data sheet and, if necessary, special handling instructions.

Zutreffendes ankreuzen; trifft einer der Warnhinweise zu, Sicherheitsdatenblatt und ggf. spezielle Handhabungsvorschriften beilegen.

Description of failure / Fehlerbeschreibung

Company data / Angaben zum Absender

Company / Firma	Phone number of contact person / Telefon-Nr. Ansprechpartner:
Address / Adresse	Fax / E-Mail
	Your order No. / Ihre Auftragsnr.

"We hereby certify that this declaration is filled out truthfully and completely to the best of our knowledge. We further certify that the returned parts have been carefully cleaned. To the best of our knowledge they are free of any residues in dangerous quantities."

"Wir bestätigen, die vorliegende Erklärung nach unserem besten Wissen wahrheitsgetreu und vollständig ausgefüllt zu haben. Wir bestätigen weiter, dass die zurückgesandten Teile sorgfältig gereinigt wurden und nach unserem besten Wissen frei von Rückständen in gefährlichen Mengen sind."

For more Endress+Hauser product please visit: www.ainstru.com
Mail: Sales@ainstru.com

www.endress.com/worldwide

Endress+Hauser 
People for Process Automation
