


PROline Prosonic Flow 93 FOUNDATION Fieldbus Ultrasonic Flow Measuring System

Description of Device Functions



Operation

PROline Prosonic Flow 93

FOUNDATION Fieldbus

- **with local operation:** **see Page 5**
- **with FOUNDATION Fieldbus:** **see Page 85**

Registered trademarks

FOUNDATION Fieldbus™

Registered trademark of Fieldbus FOUNDATION, Austin, USA

S-DAT™, T-DAT™, F-CHIP™, FieldTool™, FieldCheck™, Applicator™

Registered trademarks of Endress+Hauser Flowtec AG, Reinach, Switzerland

Contents (local operation)

1	Notes on using this manual	7
1.1	Using the table of contents to locate a function description	7
1.2	Using the graphic of the function matrix to locate a function description	7
1.3	Using the index of the function matrix to locate a function description	7
2	Function matrix	8
2.1	General layout of the function matrix	8
2.1.1	Blocks (A, B, C, etc.)	8
2.1.2	Groups (AAA, AEA, CAA, etc.)	8
2.1.3	Function groups (000, 020, 060, etc.)	8
2.1.4	Functions (0000, 0001, 0002, etc.)	8
2.1.5	Codes identifying cells	9
2.2	Function matrix Prosonic Flow 93 FOUNDATION Fieldbus	10
3	Block MEASURED VARIABLES	11
3.1	Group MEASURED VALUES	12
3.1.1	Function group: MAIN VALUES CH1	12
3.1.2	Function group: MAIN VALUES CH2	13
3.1.3	Function group: CALCULATED MAIN VALUES	14
3.2	Group SYSTEM UNITS	15
3.2.1	Function group: CONFIGURATION	15
3.2.2	Function group: ADDITIONAL CONFIGURATION	17
4	Block QUICK SETUP	19
4.0.1	Sensor Quick Setup	20
4.0.2	Commissioning Quick Setup	22
5	Block USER INTERFACE	23
5.1	Group CONTROL	24
5.1.1	Function group: BASIC CONFIGURATION	24
5.1.2	Function group: UNLOCKING/LOCKING	26
5.1.3	Function group: OPERATION	27
5.2	Group MAIN LINE	28
5.2.1	Function group: CONFIGURATION	28
5.2.2	Function group: MULTIPLEX	30
5.3	Group ADDITIONAL LINE	32
5.3.1	Function group: CONFIGURATION	32
5.3.2	Function group: MULTIPLEX	35
5.4	Group INFORMATION LINE	38
5.4.1	Function group: CONFIGURATION	38
5.4.2	Function group: MULTIPLEX	41
6	Block TOTALIZERS	44
6.1	Group TOTALIZER (1...3)	45
6.1.1	Function group: CONFIGURATION	45
6.1.2	Function group: OPERATION	47
6.2	Group HANDLING TOTALIZERS	48

7	Block BASIC FUNCTION	49
7.1	Group FOUNDATION FIELDBUS	50
7.1.1	Function group: CONFIGURATION	50
7.1.2	Function group: FUNCTION BLOCKS	51
7.1.3	Function group: INFORMATION	52
7.2	Group PROCESS PARAMETER (CH1...CH2)	53
7.2.1	Function group: CONFIGURATION	53
7.2.2	Function group: ADJUSTMENT	55
7.2.3	Function group: PIPE DATA	56
7.2.4	Function group: LIQUID DATA	60
7.3	Group SYSTEM PARAMETER (CH1...CH2)	62
7.3.1	Function group: CONFIGURATION	62
7.4	Group SENSOR DATA (CH1...CH2)	63
7.4.1	Function group: SENSOR PARAMETER	63
7.4.2	Function group: CALIBRATION DATA	67
8	Block SUPERVISION	69
8.1	Group SYSTEM	70
8.1.1	Function group: CONFIGURATION	70
8.1.2	Function group: OPERATION	71
8.2	Group SYSTEM CH2	73
8.2.1	Function group: OPERATION	73
8.3	Group VERSION-INFO	74
8.3.1	Function group: SENSOR	74
8.3.2	Function group: AMPLIFIER	74
8.3.3	Function group: F-CHIP	75
8.3.4	Function group: I/O MODULE	75
9	Factory settings	76
9.1	SI units (not for USA and Canada)	76
9.1.1	Low flow cut off, totalizer	76
9.1.2	Language	76
9.1.3	Length, temperature	76
9.2	US units (only for USA and Canada)	77
9.2.1	Low flow cut off, totalizer	77
9.2.2	Language, length, temperature	77
10	Index (function matrix)	79
11	Index (local operation)	81

1 Notes on using this manual

There are various ways of locating the description of a function of your choice in the manual:

1.1 Using the table of contents to locate a function description

The designations of all the cells in the function matrix are listed in the table of contents. You can use these unambiguous designations, (such as MEASURED VARIABLES, USER INTERFACE, TOTALIZERS, etc.), to choose whichever functions are applicable to a particular set of conditions. The page references show you exactly where to find the detailed descriptions of the functions in question. The table of contents is on Page 5.

1.2 Using the graphic of the function matrix to locate a function description

This step-by-step, top-down approach starts with the blocks, the highest level of the matrix, and works down through the matrix to the description of the function you need:

1. All blocks available, and their related groups are illustrated on Page 10. Select the block (or the group within the block) which you need for your application and use the page reference to locate the information corresponding to the next level.
2. The page in question contains a graphic showing of the block with all its subordinate groups, function groups and functions. Select the function which you need for your application and use the page reference to locate the detailed function description.

1.3 Using the index of the function matrix to locate a function description

Each “cell” in the function matrix (blocks, groups, function groups, functions) has a unique identifier in the form of a code consisting of one or three letters or a three- or four-digit number. The code identifying a selected “cell” appears at the top right on the local display.




Fig. 1: Codes of the function groups and functions on the local display

The function-matrix index lists the codes for all the available “cells” in alphabetic and consecutive order, complete with the page references for the corresponding functions.


The index to the function matrix is on Page 79.

2 Function matrix

2.1 General layout of the function matrix

The function matrix consists of four levels:

Blocks → Groups → Function groups → Functions



F06-x3xxxxx-13-xx-xx-xx-000

2.1.1 Blocks (A, B, C, etc.)

The blocks are the highest-level grouping of the operation options for the measuring device. Examples of blocks available are MEASURED VARIABLES, USER INTERFACE, TOTALIZERS etc.

2.1.2 Groups (AAA, AEA, CAA, etc.)

A block consists of one or more groups. Each group represents a more detailed selection of the operation options in the higher-order block.

The groups in the “USER INTERFACE” Block, for example, include: CONTROL, MAIN LINE, ADDITIONAL LINE etc.

2.1.3 Function groups (000, 020, 060, etc.)

A group consists of one or more function groups. Each function group represents a more detailed selection of the operation options in the higher-order group. The function groups in the “CONTROL” group, for example, include: BASIC CONFIGURATION, UNLOCKING/LOCKING, OPERATION etc.

2.1.4 Functions (0000, 0001, 0002, etc.)

Each function group consists of one or more functions. The functions are used to operate and configure the measuring device. Numerical values can be entered or parameters selected and saved.

The functions in the “BASIC CONFIGURATION” function group, for example, include: LANGUAGE, DISPLAY DAMPING, CONTRAST LCD etc.

To change the operating language of the device, for example, you must proceed as follows:

1. Select the “USER INTERFACE” Block.
2. Select the “CONTROL” group.
3. Select the “BASIC CONFIGURATION” function group.
4. Select the “LANGUAGE” function
(the language required is selected here).

2.1.5 Codes identifying cells

Each cell (block, group, function group and function) in the function matrix has an individual, unique code.

Blocks:

The code is a letter (A, B, C, etc.)

Groups:

The code consists of three letters (AAA, ABA, BAA, etc.).

The first letter matches the block code, (i.e. each group in block A has a code starting with an "A", in other words A _ _; the codes of the groups in block B start with a "B", in other words B _ _, and so on). The other two letters are for identifying the group within the respective block.

Function groups:


The code consists of three digits (000, 001, 100, etc.).

Functions:

The code consists of four digits (0000, 0001, 0201, etc.).


The first three digits are the same as the code for the function group.

The last digit in the code is a counter for the functions in the function group, incrementing from 0 to 9 (e.g. function 0005 is the sixth function in group 000).




2.2 Function matrix

Prosonic Flow 93 FOUNDATION Fieldbus



3 Block MEASURED VARIABLES




3.1 Group MEASURED VALUES

3.1.1 Function group: MAIN VALUES CH1




Function description	
MEASURED VARIABLES → MEASURED VALUES → MAIN VALUES CH1	
Use this function group to display the channel 1 measured values currently measured.  Note! - The engineering units of all the measured variables shown here can be set in the "SYSTEM UNITS" group. - If the fluid in the pipe flows backwards, a negative sign prefixes the flow reading on the display.	
VOLUME FLOW CH1 (0001)	Displays the volume flow currently measured, (channel 1). Display: 5-digit floating-point number, including unit and sign (e.g. 5.5445 dm³/min; 1.4359 m³/h; -731.63 gal/d; etc.)
SOUND VELOCITY CH1 (0002)	Displays the sound velocity currently measured in the liquid (channel 1). Display: 5-digit fixed-point number, incl. units (e.g. 1400.0 m/s, 5249.3 ft/s)
FLOW VELOCITY CH1 (0003)	Displays the flow velocity currently measured (channel 1). Display: 5-digit floating-point number, including unit and sign (e.g. 8.0000 m/s, 26.247 ft/s)
SIGNAL STRENGTH CH1 (0007)	Displays the signal strength (channel 1). Display: 4-digit fixed-point number (e.g. 80.0)  Note! To ensure reliable measurement takes place, Prosonic Flow requires a signal strength of > 30.

3.1.2 Function group: MAIN VALUES CH2



Function description	
MEASURED VARIABLES → MEASURED VALUES → MAIN VALUES CH2	
Use this function group to display the channel 2 measured values currently measured.  Note! - The engineering units of all the measured variables shown here can be set in the “SYSTEM UNITS” group. - If the fluid in the pipe flows backwards, a negative sign prefixes the flow reading on the display.	
VOLUME FLOW CH2 (0061)	Displays the volume flow currently measured, (channel 2). Display: 5-digit floating-point number, including unit and sign (e.g. 5.5445 dm³/min; 1.4359 m³/h; -731.63 gal/d; etc.)
SOUND VELOCITY CH2 (0062)	Displays the sound velocity currently measured in the liquid, (channel 2). Display: 5-digit fixed-point number, incl. units (e.g. 1400.0 m/s, 5249.3 ft/s)
FLOW VELOCITY CH2 (0063)	Displays the flow velocity currently measured, (channel 2). Display: 5-digit floating-point number, including unit and sign (e.g. 8.0000 m/s, 26.247 ft/s)
SIGNAL STRENGTH CH2 (0067)	Displays the signal strength, (channel 2). Display: 4-digit fixed-point number (e.g. 80.0)  Note! To ensure reliable measurement takes place, Prosonic Flow requires a signal strength of > 30.


3.1.3 Function group: CALCULATED MAIN VALUES



Function description	
MEASURED VARIABLES → MEASURED VALUES → CALCULATED MAIN VALUES	
Displays the calculated measured values. The measured values of both channels are used when calculating the values.  Note! - The engineering units of all the measured variables shown here can be set in the "SYSTEM UNITS" group. - If the fluid in the pipe flows backwards, a negative sign prefixes the flow reading on the display.	
VOLUME FLOW AVERAGE (0083)	Displays the calculated average volume flow. Calculated from: $(\text{VOLUME FLOW CH1} + \text{VOLUME FLOW CH2}) / 2$ Display: 5-digit floating-point number, including unit and sign (e.g. 5.5445 dm³/min; 1.4359 m³/h; -731.63 gal/d; etc.)
VOLUME FLOW SUM (0084)	Displays the calculated total volume flow. Calculated from: $\text{VOLUME FLOW CH1} + \text{VOLUME FLOW CH2}$ Display: 5-digit floating-point number, including unit and sign (e.g. 5.5445 dm³/min; 1.4359 m³/h; -731.63 gal/d; etc.)
VOLUME FLOW DIFFERENCE (0085)	Displays the calculated difference between the volume flows. Calculated from: $\text{VOLUME FLOW CH1} - \text{VOLUME FLOW CH2}$ Display: 5-digit floating-point number, including unit and sign (e.g. 5.5445 dm³/min; 1.4359 m³/h; -731.63 gal/d; etc.)
SOUND VELOCITY AVERAGE (0086)	Displays the average sound velocity calculated. Calculated from: $(\text{SOUND VELOCITY CH1} + \text{SOUND VELOCITY CH2}) / 2$ Display: 5-digit fixed-point number, incl. units (e.g. 1400.0 m/s, 5249.3 ft/s)
FLOW VELOCITY AVERAGE (0087)	Displays the average flow velocity calculated. Calculated from: $(\text{FLOW VELOCITY CH1} + \text{FLOW VELOCITY CH2}) / 2$ Display: 5-digit floating-point number, including unit and sign (e.g. 8.0000 m/s, 26.247 ft/s)

3.2 Group SYSTEM UNITS


3.2.1 Function group: CONFIGURATION



Function description	
MEASURED VARIABLES → SYSTEM UNITS → CONFIGURATION	
Use this function group to select the units for the measured variables.  Note! The units selected here have no effect on the FOUNDATION Fieldbus. They are only used for the local display and for assigned instrument functions.	
UNIT VOLUME FLOW (0402)	Use this function to select the unit for displaying the volume flow. The unit you select here is also valid for: • Simulation • Low flow cut off Options:  Note! The following units of time (...) can be selected: s = second, m = minute, h = hour, d = day <i>Metric:</i> Cubic centimetre → cm³/... Cubic decimetre → dm³/... Cubic metre → m³/... Millilitre → ml/... Litre → l/... Hectolitre → hl/... Megalitre → Ml/... MEGA <i>US:</i> Cubic centimetre→ cc/... Acre foot → af/... Cubic foot → ft³/... Fluid ounce → oz f/... Gallon → US gal/... Million gallon → US Mgal/... Barrel (normal fluids: 31.5 gal/bbl) → US bbl/... NORM. Barrel (beer: 31.0 gal/bbl) → US bbl/... BEER Barrel (petrochemicals: 42.0 gal/bbl) → US bbl/... PETR. Barrel (filling tanks: 55.0 gal/bbl) → US bbl/... TANK <i>Imperial:</i> Gallon → imp. gal/... Mega gallon → imp. Mgal/... Barrel (beer: 36.0 gal/bbl) → imp. bbl/... BEER Barrel (petrochemicals: 34.97 gal/bbl) → imp. bbl/... PETR. Factory setting: Depends on country (dm³/m...m³/h or US gal/m...US Mgal/d)

Function description	
MEASURED VARIABLES → SYSTEM UNITS → CONFIGURATION	
UNIT VOLUME (0403)	Use this function to select the unit for displaying the volume. Options: <i>Metric:</i> Cubic centimetre → cm³ Cubic decimetre → dm³ Cubic metre → m³ Millilitre → ml Litre → l Hectolitre → hl Megalitre → MI MEGA <i>US:</i> Cubic centimetre → cc Acre foot → af Cubic foot → ft³ Fluid ounce → oz f Gallon → US gal Million gallon → US Mgal Barrel (normal fluids: 31.5 gal/bbl) → US bbl NORM.FL. Barrel (beer: 31.0 gal/bbl) → US bbl BEER Barrel (petrochemicals: 42.0 gal/bbl) → US bbl PETROCH. Barrel (filling tanks: 55.0 gal/bbl) → US bbl TANK <i>Imperial:</i> Gallon → imp. gal Mega gallon → imp. Mgal Barrel (beer: 36.0 gal/bbl) → imp. bbl BEER Barrel (petrochemicals: 34.97 gal/bbl) → imp. bbl PETROCH. Factory setting: Depends on country (dm³...m³ or US gal...US Mgal), corresponds to the totalizer unit factory setting, (see Page 76 ff.).  Note! The unit of the totalizers is independent of your choice here. The unit for each totalizer is selected separately for the totalizer in question.


3.2.2 Funktion group: ADDITIONAL CONFIGURATION



Function description	
MEASURED VARIABLES → SYSTEM UNITS → ADDITIONAL CONFIGURATION	
Note! The units selected here have no effect on the FOUNDATION Fieldbus. They are only used for the local display and for assigned instrument functions.	
UNIT TEMPERATURE (0422)	Use this function to select the unit for displaying the liquid temperature. Note! The fluid temperature is entered in the TEMPERATURE function, (see Page 60). Options: °C (Celsius) K (Kelvin) °F (Fahrenheit) R (Rankine) Factory setting: Depends on country (°C or °F), see factory setting Page 76 ff.
UNIT VISCOSITY (0423)	Use this function to select the unit for fluid viscosity. Note! The viscosity is entered in the VISCOSITY function, (see Page 61). Options: mm²/s cSt St Factory setting: mm²/s
UNIT LENGTH (0424)	Use this function to select the unit for the measure of length. The unit you select here is valid for: - Nominal diameter - Diameter - Wall thickness - Liner thickness - Path length - Wire length - Sensor distance Options: MILLIMETER INCH Factory setting: Depends on country (MILLIMETER or INCH), see factory setting Page 76 ff.


Function description	
MEASURED VARIABLES → SYSTEM UNITS → ADDITIONAL CONFIGURATION	
UNIT VELOCITY (0425)	Use this function to select the unit for the velocity. The unit selected is valid for the sound and flow velocity. Options: m/s ft/s Factory setting: m/s

4 Block QUICK SETUP



Function description	
QUICK SETUP	
SETUP SENSOR (1001)	Use this function to start the Quick Setup menu for mounting the ultrasonic sensors. Options: YES NO Factory setting: NO  Note! You will find a flowchart of the Quick Setup SENSOR menu on Page 20. Further information on Quick Setups is provided in the related Operating Instructions for Prosonic Flow 93 FOUNDATION Fieldbus, (BA078D/06/en/).
QUICK SETUP COMMISSIONING (1002)	Use this function to start the Quick Setup for commissioning. Options: YES NO Factory setting: NO  Note! You will find a flowchart of the COMMISSIONING Quick Setup menu on Page 22. Further information on Quick Setups is provided in the related Operating Instructions for Prosonic Flow 93 FOUNDATION Fieldbus, (BA078D/06/en/).
T-DAT SAVE/LOAD (1009)	Use this function to save the parameter settings / configuration of the transmitter in a transmitter DAT (T-DAT), or to load the parameter settings from the T-DAT into the EEPROM (manual security function). Application examples: • After commissioning, the current measuring point parameters can be saved to the T-DAT as a backup. • If the transmitter is replaced for some reason, the data from the T-DAT can be loaded into the new transmitter (EEPROM). Options: CANCEL SAVE (from EEPROM to T-DAT) LOAD (from the T-DAT into EEPROM) Factory setting: CANCEL  Note! If the power supply fails, the totalizer readings are automatically saved to the EEPROM.

4.0.1 Sensor Quick Setup




F06-93xxxxx-19-xx-xx-efr-002

**Note!**

- The display returns to the SETUP SENSOR (1001) cell if you press the ESC key combination during parameter interrogation.
- See numbers in the illustration of the Quick Setup sensor menu:
 - ① The choice of units only affects the UNIT LENGTH (0424) and UNIT VELOCITY (0425) functions.
 - ② If a channel is selected for which a Quick Setup has already been carried out beforehand, the previous values are overwritten.
 - ③ All options are offered for selection in each cycle. Any settings which may already have been made in a cycle are overwritten.
 - ④ Option “YES”: The value measured during the Quick Setup is applied to the function in question. Option “NO”: The measurement is rejected and the original value is retained.
 - ⑤ The SENSOR POSITION (6884) function does not appear unless CLAMP ON is set in the MEASUREMENT function and the number of traverses in the SENSOR CONFIGURATION (6882) function is 2 or 4.
 - ⑥ The WIRE LENGTH (6885) function does not appear unless CLAMP ON is set in the MEASUREMENT function and the number of traverses in the SENSOR CONFIGURATION (6882) function is 1 or 3.
 - ⑦ The ARC LENGTH (6887) function does not appear unless “INSERTION” is set in the MEASUREMENT function and “DUAL PATH” was selected in the SENSOR CONFIGURATION (6882) function.


4.0.2 Commissioning Quick Setup



Note!

- The display returns to the QUICK SETUP COMMISSIONING (1002) cell if you press the ESC key combination during parameter interrogation.
- See numbers in the illustration of the Quick Setup sensor menu:
 - ① Only the units not yet configured in the current Quick Setup are offered for selection in each cycle. The unit for volume is derived from the volume flow unit.
 - ② The "YES" option remains visible until all the units have been configured. "NO" is the only option displayed when no further units are available.
- The system units selected via the Quick Setup are only valid for display on the local display and for the parameters in the Transducer Blocks. They have no effect on the process variables which are transmitted via the FOUNDATION Fieldbus.

5 Block USER INTERFACE




5.1 Group CONTROL

5.1.1 Function group: BASIC CONFIGURATION

USER INTERFACE C	⇒	CONTROL CAA	⇒	BASIC CONFIGURATION 200
Function description USER INTERFACE → CONTROL → BASIC CONFIGURATION				
LANGUAGE (2000)	Use this function to select the language for all texts, parameters and messages shown on the local display. Options: ENGLISH DEUTSCH FRANCAIS ESPANOL ITALIANO NEDERLANDS DANSK NORSK SVENSKA SUOMI BAHASA INDONESIA JAPANESE (syllabary) Factory setting: Depends on country, see factory setting Page 76 ff.  Note! If you press the  keys at startup, the language defaults to "ENGLISH".			
DISPLAY DAMPING (2002)	Use this function to enter a time constant defining how the display reacts to severely fluctuating flow variables, either very quickly (enter a low time constant) or with damping (enter a high time constant). User input: 0...100 seconds Factory setting: 1 s  Note! Setting the time constant to 0 seconds switches off damping.			
CONTRAST LCD (2003)	Use this function to optimise display contrast to suit local operating conditions. User input: 10...100% Factory setting: 50%			


Function description	
USER INTERFACE → CONTROL → BASIC CONFIGURATION	
X-LINE CALCULATED MAIN VALUES (2004)	Use this function to indicate which “calculated main value” from the measured values of both channels is displayed. “CALCULATED VOLUME FLOW” must be selected in the ASSIGN line function, (function 2200 for the main line, function 2400 for the additional line, function 2600 for the information line), so that the value appears in the line required.  Note! This function does not appear if “OFF” was selected on at least one channel in the MEASUREMENT (6880) function. Options: (CH1 + CH2) / 2 CH1 + CH2 CH1 - CH2 Factory setting: (CH1 + CH2) / 2

5.1.2 Function group: UNLOCKING/LOCKING



Function description	
USER INTERFACE → CONTROL → UNLOCKING/LOCKING	
ACCESS CODE (2020)	All data of the measuring system are protected against inadvertent change. Programming is disabled and the settings cannot be changed until a code is entered in this function. If you press the  or  keys in any function, the measuring system automatically goes to this function and the prompt to enter the code appears on the display (when programming is disabled). You can enable programming by entering your private code (factory setting = 93, see the DEFINE PRIVATE CODE function). User input: Max. 4-digit number: 0...9999  Note! • The programming levels are disabled if you do not press a key within 60 seconds following automatic return to the HOME position. • You can also disable programming in this function by entering any number (other than the defined private code). • The Endress+Hauser service organisation can be of assistance if you mislay your personal code. • Access to programming is only valid for local operation in this function. If functions or parameters are to be changed via the FOUNDATION Fieldbus, programming must be enabled separately in the "Un/Locking - Access Code" parameter (Transducer Blocks).
DEFINE PRIVATE CODE (2021)	Use this function to enter a personal code for enabling programming. User input: 0...9999 (max. 4-digit number) Factory setting: 93  Note! • Programming is always enabled with the code "0". • Programming has to be enabled before this code can be changed. When programming is disabled this function is not available, thus preventing others from accessing your personal code. • The code entered here is also valid for operation with the FF configuration programme.
STATUS ACCESS (2022)	Use this function to check the access status for the function matrix (local display). Display: ACCESS CUSTOMER (parameters can be modified) LOCKED (parameters cannot be modified)


5.1.3 Function group: OPERATION




Function description	
USER INTERFACE → CONTROL → OPERATION	
TEST DISPLAY (2040)	Use this function to test the operability of the local display and its pixels. Options: OFF ON Factory setting: OFF Test sequence: 1. Start the test by selecting ON. 2. All pixels of the main line, additional line and information line are darkened for minimum 0.75 seconds. 3. Main line, additional line and information line show an "8" in each field for minimum 0.75 seconds. 4. Main line, additional line and information line show a "0" in each field for minimum 0.75 seconds. 5. Main line, additional line and information line show nothing (blank display) for minimum 0.75 seconds. When the test completes the local display returns to its initial state and the setting changes to "OFF."

5.2 Group MAIN LINE


5.2.1 Function group: CONFIGURATION



Function description	
USER INTERFACE → MAIN LINE → CONFIGURATION	
F06-x3xxxxx-07-03-xx-xx-000  A = main line, B = additional line, C = information line	
ASSIGN (2200)	Use this function to define the display value assigned to the main line (the top line of the local display) during normal measuring operation. Options: OFF VOLUME FLOW CH1 VOLUME FLOW CH2 CALCULATED VOLUME FLOW VOLUME FLOW % CH1 VOLUME FLOW % CH2 CALCULATED VOLUME FLOW % SOUND VELOCITY CH1 SOUND VELOCITY CH2 SOUND VELOCITY AVERAGE SIGNAL STRENGTH CH1 SIGNAL STRENGTH CH2 FLOW VELOCITY CH1 FLOW VELOCITY CH2 FLOW VELOCITY AVERAGE TOTALIZER 1 TOTALIZER 2 TOTALIZER 3 AI 1 - OUT VALUE AI 2 - OUT VALUE AI 3 - OUT VALUE AI 4 - OUT VALUE AI 5 - OUT VALUE AI 6 - OUT VALUE AI 7 - OUT VALUE AI 8 - OUT VALUE PID - IN VALUE (controlled variable) PID - CAS IN VALUE (remote setpoint value) PID - OUT VALUE (manipulated variable) Factory setting: VOLUME FLOW CH1  Note! If a channel is not visible, it does not appear in the options. The channels can be displayed or hidden by means of the MEASUREMENT (6880) function.

Function description	
USER INTERFACE → MAIN LINE → CONFIGURATION	
100% VALUE (2201)	 Note! This function is not available unless one of the following options was selected in the ASSIGN (2200) function: • VOLUME FLOW % CH1 • VOLUME FLOW % CH2 • CALCULATED VOLUME FLOW % Use this function to define the flow value to be shown on the display as the 100% value. User input: 5-digit floating-point number Factory setting: Depends on country, [value] / [dm³...m³ or US-gal...US-Mgal]
FORMAT (2202)	Use this function to define the maximum number of places after the decimal point displayed for the reading in the main line. Options: XXXXX. - XXXX.X - XXX.XX - XX.XXX -X.XXXX Factory setting: X.XXXX  Note! • Note that this setting only affects the reading as it appears on the display, it has no influence on the accuracy of the system's calculations. • The places after the decimal point as computed by the measuring device cannot always be displayed, depending on this setting and the engineering unit. In these instances an arrow appears on the display between the measured value and the engineering unit, (e.g. 1.2 → m³/h), indicating that the measuring system is computing with more decimal places than can be shown on the display.

5.2.2 Function group: MULTIPLEX





Function description	
USER INTERFACE → MAIN LINE → MULTIPLEX	
ASSIGN (2220)	Use this function to define the second reading to be displayed in the main line alternately (every 10 seconds) with the value defined in the ASSIGN (2200) function. Options: OFF VOLUME FLOW CH1 VOLUME FLOW CH2 CALCULATED VOLUME FLOW VOLUME FLOW % CH1 VOLUME FLOW % CH2 CALCULATED VOLUME FLOW % SOUND VELOCITY CH1 SOUND VELOCITY CH2 SOUND VELOCITY AVERAGE SIGNAL STRENGTH CH1 SIGNAL STRENGTH CH2 FLOW VELOCITY CH1 FLOW VELOCITY CH2 FLOW VELOCITY AVERAGE TOTALIZER 1 TOTALIZER 2 TOTALIZER 3 AI 1 - OUT VALUE AI 2 - OUT VALUE AI 3 - OUT VALUE AI 4 - OUT VALUE AI 5 - OUT VALUE AI 6 - OUT VALUE AI 7 - OUT VALUE AI 8 - OUT VALUE PID - IN VALUE (controlled variable) PID - CAS IN VALUE (remote setpoint value) PID - OUT VALUE (manipulated variable) Factory setting: OFF  Note! If a channel is not visible, it does not appear in the options. The channels can be displayed or hidden by means of the MEASUREMENT (6880) function.

Function description	
USER INTERFACE → MAIN LINE → MULTIPLEX	
100% VALUE (2221)	 Note! This function is not available unless one of the following options was selected in the ASSIGN (2220) function: • VOLUME FLOW % CH1 • VOLUME FLOW % CH2 • CALCULATED VOLUME FLOW % Use this function to define the flow value to be shown on the display as the 100% value. User input: 5-digit floating-point number Factory setting: Depends on country, [value] / [dm³...m³ or US-gal...US-Mgal]
FORMAT (2222)	Use this function to define the maximum number of places after the decimal point for the second value displayed in the main line. Options: XXXXX. - XXXX.X - XXX.XX - XX.XXX -X.XXXX Factory setting: X.XXXX  Note! • Note that this setting only affects the reading as it appears on the display, it has no influence on the accuracy of the system's calculations. • The places after the decimal point as computed by the measuring device cannot always be displayed, depending on this setting and the engineering unit. In these instances an arrow appears on the display between the measured value and the engineering unit, (e.g. 1.2 → m³/h), indicating that the measuring system is computing with more decimal places than can be shown on the display.

5.3 Group ADDITIONAL LINE

5.3.1 Function group: CONFIGURATION




Function description	
USER INTERFACE → ADDITIONAL LINE → CONFIGURATION	
F06-x3xxxxx-07-03-xx-xx-000  A = main line, B = additional line, C = information line	
ASSIGN (2400)	Use this function to define the display value assigned to the additional line (the middle line of the local display) during normal measuring operation. Options: OFF VOLUME FLOW CH1 VOLUME FLOW CH2 CALCULATED VOLUME FLOW VOLUME FLOW % CH1 VOLUME FLOW % CH2 CALCULATED VOLUME FLOW % SOUND VELOCITY CH1 SOUND VELOCITY CH2 SOUND VELOCITY AVERAGE SIGNAL STRENGTH CH1 SIGNAL STRENGTH CH2 FLOW VELOCITY CH1 FLOW VELOCITY CH2 FLOW VELOCITY AVERAGE VOLUME FLOW BARGRAPH % CH1 VOLUME FLOW BARGRAPH % CH2 CALCULATED VOLUME FLOW BARGRAPH % SIGNAL STRENGTH BARGRAPH CH1 SIGNAL STRENGTH BARGRAPH CH2 TOTALIZER 1 TOTALIZER 2 TOTALIZER 3 FLOW DIRECTION CH1 FLOW DIRECTION CH2 CALCULATED FLOW DIRECTION AI 1 - OUT VALUE AI 2 - OUT VALUE AI 3 - OUT VALUE AI 4 - OUT VALUE AI 5 - OUT VALUE AI 6 - OUT VALUE AI 7 - OUT VALUE AI 8 - OUT VALUE (Continued on next page)

Function description	
USER INTERFACE → ADDITIONAL LINE → CONFIGURATION	
Contd: ASSIGN (2400)	Options (contd.): PID - IN VALUE (controlled variable) PID - CAS IN VALUE (remote setpoint value) PID - OUT VALUE (manipulated variable) DEVICE PD-TAG (tag name) Factory setting: TOTALIZER 1  Note! If a channel is not visible, it does not appear in the options. The channels can be displayed or hidden by means of the MEASUREMENT (6880) function.
100% VALUE (2401)	 Note! This function is not available unless one of the following options was selected in the ASSIGN (2400) function: • VOLUME FLOW % CH1 • VOLUME FLOW % CH2 • CALCULATED VOLUME FLOW % • VOLUME FLOW BARGRAPH % CH1 • VOLUME FLOW BARGRAPH % CH2 • CALCULATED VOLUME FLOW BARGRAPH % Use this function to define the flow value to be shown on the display as the 100% value. User input: 5-digit floating-point number Factory setting: Depends on country, [value] / [dm³...m³ or US-gal...US-Mgal]
FORMAT (2402)	 Note! This function is not available unless a numerical option was selected in the ASSIGN (2400) function. Use this function to define the maximum number of places after the decimal point displayed for the reading in the additional line. Options: XXXXX. - XXXX.X - XXX.XX - XX.XXX -X.XXXX Factory setting: X.XXXX  Note! • Note that this setting only affects the reading as it appears on the display, it has no influence on the accuracy of the system's calculations. • The places after the decimal point as computed by the measuring device cannot always be displayed, depending on this setting and the engineering unit. In these instances an arrow appears on the display between the measured value and the engineering unit, (e.g. 1.2 → m³/h), indicating that the measuring system is computing with more decimal places than can be shown on the display.

Function description	
USER INTERFACE → ADDITIONAL LINE → CONFIGURATION	
DISPLAY MODE (2403)	Note! This function is not available unless one of the following options was selected in the ASSIGN (2400) function: - VOLUME FLOW BARGRAPH % CH1 - VOLUME FLOW BARGRAPH % CH2 - CALCULATED VOLUME FLOW BARGRAPH % - SIGNAL STRENGTH BARGRAPH CH1 - SIGNAL STRENGTH BARGRAPH CH2 Use this function to define the format of the bar graph. Options: STANDARD (Simple bar graph with 25 / 50 / 75% gradations and integrated sign). +25+50+75% F-x3xxxx-20-xx-xx-xx-000 SYMMETRY (Symmetrical bar graph for positive and negative directions of flow with -50 / 0 / +50% gradations and integrated sign). -50+50% F-x3xxxx-20-xx-xx-xx-001 Factory setting: STANDARD

5.3.2 Function group: MULTIPLEX




Function description	
USER INTERFACE → ADDITIONAL LINE → MULTIPLEX	
ASSIGN (2420)	Use this function to define the second reading to be displayed in the additional line alternately (every 10 seconds) with the value defined in the ASSIGN (2400) function. Options: OFF VOLUME FLOW CH1 VOLUME FLOW CH2 CALCULATED VOLUME FLOW VOLUME FLOW % CH1 VOLUME FLOW % CH2 CALCULATED VOLUME FLOW % SOUND VELOCITY CH1 SOUND VELOCITY CH2 SOUND VELOCITY AVERAGE SIGNAL STRENGTH CH1 SIGNAL STRENGTH CH2 FLOW VELOCITY CH1 FLOW VELOCITY CH2 FLOW VELOCITY AVERAGE VOLUME FLOW BARGRAPH % CH1 VOLUME FLOW BARGRAPH % CH2 CALCULATED VOLUME FLOW BARGRAPH % SIGNAL STRENGTH BARGRAPH CH1 SIGNAL STRENGTH BARGRAPH CH2 TOTALIZER 1 TOTALIZER 2 TOTALIZER 3 FLOW DIRECTION CH1 FLOW DIRECTION CH2 CALCULATED FLOW DIRECTION AI 1 - OUT VALUE AI 2 - OUT VALUE AI 3 - OUT VALUE AI 4 - OUT VALUE AI 5 - OUT VALUE AI 6 - OUT VALUE AI 7 - OUT VALUE AI 8 - OUT VALUE PID - IN VALUE (controlled variable) PID - CAS IN VALUE (remote setpoint value) PID - OUT VALUE (manipulated variable) DEVICE PD-TAG (tag name) Factory setting: OFF (Continued on next page)


Function description USER INTERFACE → ADDITIONAL LINE → MULTIPLEX	
Contd: ASSIGN (2420)	 Note! Multiplex mode is suspended as soon as a fault/notice message is generated. The appropriate error message appears on the display: • Fault message (identified by a lightning icon): Multiplex mode is resumed as soon as the fault is no longer active. • Notice message (identified by an exclamation mark): Multiplex mode is resumed as soon as the notice message is no longer active. If a channel is not visible, it does not appear in the options. The channels can be displayed or hidden by means of the MEASUREMENT (6880) function.
100% VALUE (2421)	 Note! This function is not available unless one of the following options was selected in the ASSIGN (2420) function: • VOLUME FLOW % CH1 • VOLUME FLOW % CH2 • CALCULATED VOLUME FLOW % • VOLUME FLOW BARGRAPH % CH1 • VOLUME FLOW BARGRAPH % CH2 • CALCULATED VOLUME FLOW BARGRAPH % Use this function to define the flow value to be shown on the display as the 100% value. User input: 5-digit floating-point number Factory setting: Depends on country, [value] / [dm³...m³ or US-gal...US-Mgal]
FORMAT (2422)	 Note! This function is not available unless a numerical option was selected in the ASSIGN (2420) function. Use this function to define the maximum number of places after the decimal point for the second value displayed in the additional line. Options: XXXXX. - XXXX.X - XXX.XX - XX.XXX -X.XXXX Factory setting: X.XXXX  Note! • Note that this setting only affects the reading as it appears on the display, it has no influence on the accuracy of the system's calculations. • The places after the decimal point as computed by the measuring device cannot always be displayed, depending on this setting and the engineering unit. In these instances an arrow appears on the display between the measured value and the engineering unit, (e.g. 1.2 → m³/h), indicating that the measuring system is computing with more decimal places than can be shown on the display.

Function description	
USER INTERFACE → ADDITIONAL LINE → MULTIPLEX	
DISPLAY MODE (2423)	Note! This function is not available unless one of the following options was selected in the ASSIGN (2420) function: - VOLUME FLOW BARGRAPH % CH1 - VOLUME FLOW BARGRAPH % CH2 - CALCULATED VOLUME FLOW BARGRAPH % - SIGNAL STRENGTH BARGRAPH CH1 - SIGNAL STRENGTH BARGRAPH CH2 Use this function to define the format of the bar graph. Options: STANDARD (Simple bar graph with 25 / 50 / 75% gradations and integrated sign). +25+50+75% F-x3xxxxx-20-xx-xx-xx-000 SYMMETRY (Symmetrical bar graph for positive and negative directions of flow with -50 / 0 / +50% gradations and integrated sign). -50+50% F-x3xxxxx-20-xx-xx-xx-001 Factory setting: STANDARD

5.4 Group INFORMATION LINE

5.4.1 Function group: CONFIGURATION




Function description	
USER INTERFACE → INFORMATION LINE → CONFIGURATION	
F06-x3xxxxx-07-03-xx-xx-000  A = main line, B = additional line, C = information line	
ASSIGN (2600)	Use this function to define the display value assigned to the information line (the bottom line of the local display) during normal measuring operation. Options: OFF VOLUME FLOW CH1 VOLUME FLOW CH2 CALCULATED VOLUME FLOW VOLUME FLOW % CH1 VOLUME FLOW % CH2 CALCULATED VOLUME FLOW % SOUND VELOCITY CH1 SOUND VELOCITY CH2 SOUND VELOCITY AVERAGE SIGNAL STRENGTH CH1 SIGNAL STRENGTH CH2 FLOW VELOCITY CH1 FLOW VELOCITY CH2 FLOW VELOCITY AVERAGE VOLUME FLOW BARGRAPH % CH1 VOLUME FLOW BARGRAPH % CH2 CALCULATED VOLUME FLOW BARGRAPH % SIGNAL STRENGTH BARGRAPH CH1 SIGNAL STRENGTH BARGRAPH CH2 TOTALIZER 1 TOTALIZER 2 TOTALIZER 3 OPERATING/SYSTEM CONDITIONS FLOW DIRECTION CH1 FLOW DIRECTION CH2 CALCULATED FLOW DIRECTION (Continued on next page)

Function description	
USER INTERFACE → INFORMATION LINE → CONFIGURATION	
ASSIGN (2600) (contd.)	Options (contd.): AI 1 - OUT VALUE AI 2 - OUT VALUE AI 3 - OUT VALUE AI 4 - OUT VALUE AI 5 - OUT VALUE AI 6 - OUT VALUE AI 7 - OUT VALUE AI 8 - OUT VALUE PID - IN VALUE (controlled variable) PID - CAS IN VALUE (remote setpoint value) PID - OUT VALUE (manipulated variable) DEVICE PD-TAG (tag name) Factory setting: OPERATING/SYSTEM CONDITIONS  Note! If a channel is not visible, it does not appear in the options. The channels can be displayed or hidden by means of the MEASUREMENT (6880) function.
100% VALUE (2601)	 Note! This function is not available unless one of the following options was selected in the ASSIGN (2600) function: • VOLUME FLOW % CH1 • VOLUME FLOW % CH2 • CALCULATED VOLUME FLOW % • VOLUME FLOW BARGRAPH % CH1 • VOLUME FLOW BARGRAPH % CH2 • CALCULATED VOLUME FLOW BARGRAPH % Use this function to define the flow value to be shown on the display as the 100% value. User input: 5-digit floating-point number Factory setting: Depends on country, [value] / [dm³...m³ or US-gal...US-Mgal]
FORMAT (2602)	 Note! This function is not available unless a numerical option was selected in the ASSIGN (2600) function. Use this function to define the maximum number of places after the decimal point displayed for the reading in the information line. Options: XXXXX. - XXXX.X - XXX.XX - XX.XXX -X.XXXX Factory setting: X.XXXX  Note! • Note that this setting only affects the reading as it appears on the display, it has no influence on the accuracy of the system's calculations. • The places after the decimal point as computed by the measuring device cannot always be displayed, depending on this setting and the engineering unit. In these instances an arrow appears on the display between the measured value and the engineering unit, (e.g. 1.2 → m³/h), indicating that the measuring system is computing with more decimal places than can be shown on the display.

Function description	
USER INTERFACE → INFORMATION LINE → CONFIGURATION	
DISPLAY MODE (2603)	Note! This function is not available unless one of the following options was selected in the ASSIGN (2600) function: - VOLUME FLOW BARGRAPH % CH1 - VOLUME FLOW BARGRAPH % CH2 - CALCULATED VOLUME FLOW BARGRAPH % - SIGNAL STRENGTH BARGRAPH CH1 - SIGNAL STRENGTH BARGRAPH CH2 Use this function to define the format of the bar graph. Options: STANDARD (Simple bar graph with 25 / 50 / 75% gradations and integrated sign). +25+50+75% F-x3xxxx-20-xx-xx-xx-000 SYMMETRY (Symmetrical bar graph for positive and negative directions of flow with -50 / 0 / +50% gradations and integrated sign). -50+50% F-x3xxxx-20-xx-xx-xx-001 Factory setting: STANDARD

5.4.2 Function group: MULTIPLEX



Function description	
USER INTERFACE → INFORMATION LINE → MULTIPLEX	
ASSIGN (2620)	Use this function to define the second reading to be displayed in the information line alternately (every 10 seconds) with the value defined in the ASSIGN (2600) function. Options: OFF VOLUME FLOW CH1 VOLUME FLOW CH2 CALCULATED VOLUME FLOW VOLUME FLOW % CH1 VOLUME FLOW % CH2 CALCULATED VOLUME FLOW % SOUND VELOCITY CH1 SOUND VELOCITY CH2 SOUND VELOCITY AVERAGE SIGNAL STRENGTH CH1 SIGNAL STRENGTH CH2 FLOW VELOCITY CH1 FLOW VELOCITY CH2 FLOW VELOCITY AVERAGE VOLUME FLOW BARGRAPH % CH1 VOLUME FLOW BARGRAPH % CH2 CALCULATED VOLUME FLOW BARGRAPH % SIGNAL STRENGTH BARGRAPH CH1 SIGNAL STRENGTH BARGRAPH CH2 TOTALIZER 1 TOTALIZER 2 TOTALIZER 3 OPERATING/SYSTEM CONDITIONS FLOW DIRECTION CH1 FLOW DIRECTION CH2 CALCULATED FLOW DIRECTION AI 1 - OUT VALUE AI 2 - OUT VALUE AI 3 - OUT VALUE AI 4 - OUT VALUE AI 5 - OUT VALUE AI 6 - OUT VALUE AI 7 - OUT VALUE AI 8 - OUT VALUE PID - IN VALUE (controlled variable) PID - CAS IN VALUE (remote setpoint value) PID - OUT VALUE (manipulated variable) DEVICE PD-TAG (tag name) Factory setting: OFF (Continued on next page)

Function description USER INTERFACE → INFORMATION LINE → MULTIPLEX	
Contd: ASSIGN (2620)	 Note! Multiplex mode is suspended as soon as a fault/notice message is generated. The appropriate error message appears on the display: • Fault message (identified by a lightning icon): Multiplex mode is resumed as soon as the fault is no longer active. • Notice message (identified by an exclamation mark): Multiplex mode is resumed as soon as the notice message is no longer active. If a channel is not visible, it does not appear in the options. The channels can be displayed or hidden by means of the MEASUREMENT (6880) function.
100% VALUE (2621)	 Note! This function is not available unless one of the following options was selected in the ASSIGN (2620) function: • VOLUME FLOW % CH1 • VOLUME FLOW % CH2 • CALCULATED VOLUME FLOW % • VOLUME FLOW BARGRAPH % CH1 • VOLUME FLOW BARGRAPH % CH2 • CALCULATED VOLUME FLOW BARGRAPH % Use this function to define the flow value to be shown on the display as the 100% value. User input: 5-digit floating-point number Factory setting: Depends on country, [value] / [dm³...m³ or US-gal...US-Mgal]
FORMAT (2622)	 Note! This function is not available unless a numerical option was selected in the ASSIGN (2620) function. Use this function to define the maximum number of places after the decimal point for the second value displayed in the information line. Options: XXXXX. - XXXX.X - XXX.XX - XX.XXX -X.XXXX Factory setting: X.XXXX  Note! • Note that this setting only affects the reading as it appears on the display, it has no influence on the accuracy of the system's calculations. • The places after the decimal point as computed by the measuring device cannot always be displayed, depending on this setting and the engineering unit. In these instances an arrow appears on the display between the measured value and the engineering unit, (e.g. 1.2 → m³/h), , indicating that the measuring system is computing with more decimal places than can be shown on the display.


Function description	
USER INTERFACE → INFORMATION LINE → MULTIPLEX	
DISPLAY MODE (2623)	Note! This function is not available unless one of the following options was selected in the ASSIGN (2620) function: - VOLUME FLOW BARGRAPH % CH1 - VOLUME FLOW BARGRAPH % CH2 - CALCULATED VOLUME FLOW BARGRAPH % - SIGNAL STRENGTH BARGRAPH CH1 - SIGNAL STRENGTH BARGRAPH CH2 Use this function to define the format of the bar graph. Options: STANDARD (Simple bar graph with 25 / 50 / 75% gradations and integrated sign). +25+50+75% F-x3xxxx-20-xx-xx-xx-000 SYMMETRY (Symmetrical bar graph for positive and negative directions of flow with -50 / 0 / +50% gradations and integrated sign). -50+50% F-x3xxxx-20-xx-xx-xx-001 Factory setting: STANDARD

6 Block TOTALIZERS

Block	Groups	Function groups	Functions
TOTALIZERS D	TOTALIZER 1 (DAA) P. 45 ⇕⇕	⇕	CONFIGURA- TION (300) P. 45 ⇕⇕
		⇕	ASSIGN (3000) P. 45 ⇕
		⇕	UNIT TOTALIZER (3001) P. 46 ⇕
		⇕	TOTALIZER MODE (3002) P. 46 ⇕
	TOTALIZER 2 (DAB) P. 45 ⇕⇕	⇕	CONFIGURA- TION (300) P. 45 ⇕⇕
		⇕	ASSIGN (3000) P. 45 ⇕
		⇕	UNIT TOTALIZER (3001) P. 46 ⇕
		⇕	TOTALIZER MODE (3002) P. 46 ⇕
	TOTALIZER 3 (DAC) P. 45 ⇕⇕	⇕	CONFIGURA- TION (300) P. 45 ⇕⇕
		⇕	ASSIGN (3000) P. 45 ⇕
⇕		UNIT TOTALIZER (3001) P. 46 ⇕	
⇕		TOTALIZER MODE (3002) P. 46 ⇕	
HANDLING TOTALIZERS (DJA) P. 48 ⇕⇕	⇕	RESET ALL TOTALIZERS (3800) P. 48 ⇕	
	⇕	FAILSAFE MODE (3801) P. 48	

6.1 Group TOTALIZER (1...3)


6.1.1 Function group: CONFIGURATION



Function description	
TOTALIZERS → TOTALIZER (1...3) → CONFIGURATION	
The function descriptions below apply to totalizers 1...3; the totalizers are independently configurable.	
ASSIGN (3000)	Use this function to assign a measured variable to the totalizer. Options: OFF VOLUME FLOW CH1 VOLUME FLOW CH2 VOLUME FLOW AVERAGE VOLUME FLOW SUM VOLUME FLOW DIFFERENCE Factory setting: VOLUME FLOW CH1 Note! - The totalizer in question is reset to “0” as soon as the selection is changed. - If you select “OFF”, this function (ASSIGN) is the only function shown in this function group.


Function description	
TOTALIZERS → TOTALIZER (1...3) → CONFIGURATION	
UNIT TOTALIZER (3001)	Use this function to define the unit for the totalizer's measured variable, as selected beforehand. Options: <i>Metric:</i> Cubic centimetre → cm³ Cubic decimetre → dm³ Cubic metre → m³ Millilitre → ml Litre → l Hectolitre → hl Megalitre → Ml MEGA <i>US:</i> Cubic centimetre → cc Acre foot → af Cubic foot → ft³ Fluid ounce → oz f Gallon → US gal Million gallon → US Mgal Barrel (normal fluids: 31.5 gal/bbl) → US bbl NORM.FL. Barrel (beer: 31.0 gal/bbl) → US bbl BEER Barrel (petrochemicals: 42.0 gal/bbl) → US bbl PETROCH. Barrel (filling tanks: 55.0 gal/bbl) → US bbl TANK <i>Imperial:</i> Gallon → imp. gal Mega gallon → imp. Mgal Barrel (beer: 36.0 gal/bbl) → imp. bbl BEER Barrel (petrochemicals: 34.97 gal/bbl) → imp. bbl PETROCH. Factory setting: Depends on country (dm³...m³ or US gal...US Mgal), corresponds to the totalizer unit factory setting (see Page 76 ff.).  Note! The unit selected here has no effect on the FOUNDATION Fieldbus. It is only used for the local display and for assigned instrument functions.
TOTALIZER MODE (3002)	Use this function to define how the flow components are to be totalled by the totalizer. Options: BALANCE → Positive and negative flow components. (The positive and negative flow components are balanced. In other words, net flow in the flow direction is registered.) FORWARD → Positive flow components only. REVERSE → Negative flow components only. Factory setting: Totalizer 1 = BALANCE Totalizer 2 = FORWARD Totalizer 3 = REVERSE
RESET TOTALIZER (3003)	Use this function to reset the sum and the overflow of the totalizer to "0". Options: NO YES Factory setting: NO

6.1.2 Function group: OPERATION



Function description	
TOTALIZERS → TOTALIZER (1...3) → OPERATION	
The function descriptions below apply to totalizers 1...3; the totalizers are independently configurable.	
SUM (3040)	Use this function to view the total for the totalizer's measured variable aggregated since measuring commenced. This value can be positive or negative, depending on the setting selected in the TOTALIZER MODE (3002) function and the direction of flow. Display: Max. 7-digit floating-point number, including sign and unit (e.g. 15467.04 m³) Note! • The effect of the setting in the TOTALIZER MODE function (see Page 46) is as follows: – If the setting is "BALANCE", the totalizer balances flow in the positive and negative directions. – If the setting is "FORWARD", the totalizer registers only flow in the positive direction. – If the setting is "REVERSE", the totalizer registers only flow in the negative direction. • The totalizers' response to faults is defined in the FAILSAFE MODE (3801) function, (see Page 48).
OVERFLOW (3041)	Use this function to view the overflow for the totalizer in question, aggregated since measuring commenced. Total flow quantity is represented by a floating-point number consisting of max. 7 digits. You can use this function to view higher numerical values (>9,999,999) as overflows. The effective quantity is thus the total of the OVERFLOW plus the value returned by the SUM function. Example: Reading for 2 overflows: 2 · 10⁷ kg (= 20,000,000 kg). The value returned by the SUM function = 196,845.7 kg Effective total quantity = 20,196,845.7 kg Display: Integer with exponent, including sign and unit, e.g. 2 · 10⁷ kg

6.2 Group HANDLING TOTALIZERS



Function description	
TOTALIZERS → HANDLING TOTALIZERS → Handling totalizer functions	
RESET ALL TOTALIZERS (3800)	Use this function to reset the totals (including all overflows) of the totalizers (1...3) to "0" (= RESET). Options: NO YES Factory setting: NO
FAILSAFE MODE (3801)	Use this function to define the common response of all totalizers (1...3) to error. Options: STOP The totalizer is paused until the fault is rectified. ACTUAL VALUE The totalizers continue to count based on the current measured flow value. The fault is ignored. HOLD VALUE The totalizer continues to count the flow is based on the last valid flow value (before the fault occurred). Factory setting: STOP

7 Block BASIC FUNCTION

Block	Groups	Function groups	Functions														
BASIC FUNCTION G	FOUNDATION FIELD BUS (GGA) P. 50	⇕⇕	⇕	CONFIGURATI ON (620) P. 50	⇕	WRITE PROTECT (6200) P. 50	⇕	SIMULATION (6201) P. 50	DEVICE PD-TAG (6203) P. 50								
			⇕⇕	⇕⇕	⇕⇕	⇕⇕											
			FUNCTION BLOCKS (622) P. 51	⇕	BLOCK SELECTION (6220) P. 51	⇕	OUT VALUE (6221) P. 51	PID_IN VALUE (6222) P. 51	CASCADE IN (6223) P. 51								
		⇕⇕	⇕⇕	⇕	INFORMATION (624) P. 52	⇕	MANUFACT. ID (6240) P. 52	⇕	DEVICE TYPE (6241) P. 52	SERIAL NUMBER (6242) P. 52	DEVICE REVISION (6243) P. 52	DD REVISION (6244) P. 52					
				⇕⇕													
				⇕⇕	⇕⇕												
	PROCESS PARAM. CH1 (GIA) P. 53	⇕⇕	⇕⇕	⇕	CONFIGURATI ON (640) P. 53			⇕	ASSIGN LF CUT OFF (6400) P. 53	⇕	ON-VALUE LF CUT OFF (6402) P. 53	OFF-VALUE LF CUT OFF (6403) P. 53	PRESS. SHOCK SUPPR. (6404) P. 54				
				⇕⇕	ZEROPOINT ADJUSTMENT (6480)			⇕	⇕⇕	⇕⇕	⇕⇕						
				ADJUSTMENT (648) P. 55	⇕												
	PROCESS PARAM. CH2 (GIB) P. 53	⇕⇕	⇕⇕	⇕	PIPE DATA (652) P. 56	⇕	PIPE STANDARD (6520) P. 56	⇕	NOMINAL DIAMETER (6521) P. 57	PIPE MATERIAL (6522) P. 57	REFERENCE VALUE (6523) P. 58	SOUND VELOC. PIPE (6524) P. 58	PIPE CIRCUM. (6525) P. 58	PIPE DIAMETER (6526) P. 58	WALL THICKNESS (6527) P. 59	LINER MATERIAL (6528) P. 59	SOUND VELOC. LINER (6529) P. 59
⇕⇕				⇕⇕	⇕	⇕⇕	⇕⇕	⇕⇕	⇕⇕	⇕⇕	⇕⇕	⇕⇕	⇕⇕	⇕⇕	⇕⇕		
⇕⇕				⇕⇕	⇕	⇕⇕	⇕⇕	⇕⇕	⇕⇕	⇕⇕	⇕⇕	⇕⇕	⇕⇕	⇕⇕	⇕⇕		
		⇕⇕	⇕⇕			⇕⇕	LIQUID DATA (654) P. 60	⇕	TEMP. (6541) P. 60	SOUND VELOC. LIQ. (6542) P. 61	VISCOSITY (6543) P. 61	MIN. S-VEL. LIQ. (6545) P. 61	MAX. S-VEL. LIQ. (6546) P. 61				
			⇕⇕	⇕⇕	⇕	⇕⇕	⇕⇕	⇕⇕	⇕⇕	⇕⇕	⇕⇕	⇕⇕	⇕⇕	⇕⇕	⇕⇕		
			⇕⇕	⇕⇕	⇕	⇕⇕	⇕⇕	⇕⇕	⇕⇕	⇕⇕	⇕⇕	⇕⇕	⇕⇕	⇕⇕	⇕⇕		
	SYSTEM PARAM. CH1 (GLA) P. 62	⇕⇕	⇕⇕	⇕	CONFIGURA- TION (660) P. 62	⇕	INSTALL. DIR. SENSOR (6600) P. 62	⇕	FLOW DAMPING (6603) P. 62	POSITIVE ZERO RETURN (6605) P. 62							
				⇕⇕	⇕⇕	⇕	⇕⇕	⇕⇕									
				⇕⇕	⇕⇕	⇕	⇕⇕	⇕⇕									
	SYSTEM PARAM. CH2 (GLB.) P. 62	⇕⇕	⇕⇕	⇕⇕			⇕⇕	MEASURE- MENT (6880) P. 63	⇕	SENSOR CONFIG. (6882) P. 65	CABLE LENGTH (6883) P. 65	SENSOR POSITION (6884) P. 65	WIRE LENGTH (6885) P. 66	SENSOR DISTANCE (6886) P. 66	ARC LENGTH (6887) P. 66	PATH LENGTH (6888) P. 66	
				⇕⇕	⇕⇕	⇕	⇕⇕	⇕⇕	⇕⇕	⇕⇕	⇕⇕	⇕⇕	⇕⇕	⇕⇕	⇕⇕	⇕⇕	
				⇕⇕	⇕⇕	⇕	⇕⇕	⇕⇕	⇕⇕	⇕⇕	⇕⇕	⇕⇕	⇕⇕	⇕⇕	⇕⇕	⇕⇕	
	SENSOR DATA CH1 (GNA) P. 62	⇕⇕	⇕⇕	⇕	SENSOR PARAMETER (688) P. 63	⇕	CALIBRATION FACTOR (6890) P. 67	⇕	ZERO POINT (6891) P. 67	CORRECTION FACTOR (6893) P. 67	DEV. SENSOR DIST. (6894) P. 67	DEV. ARC LENGTH (6895) P. 68	DEV. PATH LENGTH (6896) P. 68				
⇕⇕				⇕⇕	⇕	⇕⇕	⇕⇕	⇕⇕	⇕⇕	⇕⇕	⇕⇕	⇕⇕	⇕⇕	⇕⇕			
⇕⇕				⇕⇕	⇕	⇕⇕	⇕⇕	⇕⇕	⇕⇕	⇕⇕	⇕⇕	⇕⇕	⇕⇕	⇕⇕			
SENSOR DATA CH2 (GNB) P. 62	⇕⇕	⇕⇕	⇕	CALIBRATION DATA (689) P. 67	⇕	CALIBRATION FACTOR (6890) P. 67	⇕	ZERO POINT (6891) P. 67	CORRECTION FACTOR (6893) P. 67	DEV. SENSOR DIST. (6894) P. 67	DEV. ARC LENGTH (6895) P. 68	DEV. PATH LENGTH (6896) P. 68					
			⇕⇕	⇕⇕	⇕	⇕⇕	⇕⇕	⇕⇕	⇕⇕	⇕⇕	⇕⇕	⇕⇕	⇕⇕	⇕⇕			
			⇕⇕	⇕⇕	⇕	⇕⇕	⇕⇕	⇕⇕	⇕⇕	⇕⇕	⇕⇕	⇕⇕	⇕⇕	⇕⇕			


7.1 Group FOUNDATION FIELDBUS

7.1.1 Function group: CONFIGURATION

BASIC FUNCTION	G	⇒	FOUNDATION FIELDBUS	GGA	⇒	CONFIGURATION	620
-----------------------	----------	---	----------------------------	------------	---	----------------------	------------


Function description BASIC FUNCTION → FOUNDATION FIELDBUS → CONFIGURATION	
WRITE PROTECT (6200)	Use this function to check whether the device parameters can be accessed via the FOUNDATION Fieldbus. Display: OFF Access to device parameters via FOUNDATION Fieldbus possible ON Access to device parameters via FOUNDATION Fieldbus not possible Factory setting: OFF  Note! Hardware write protection is enabled and disabled by means of a jumper on the I/O board, (see also Operating Instructions for Prosonic Flow 93 FOUNDATION Fieldbus BA078D/06/en/).
SIMULATION (6201)	Use this function to check whether a simulation in the Analog Input or Discrete Output function block is possible. Display: OFF Simulation in the Analog Input and Discrete Output function block is not possible. ON Simulation in the Analog Input and Discrete Output function block is possible. Factory setting: ON  Note! • The simulation mode is activated and deactivated by means of a jumper on the I/O board, (see also Operating Instructions for Prosonic Flow 93 FOUNDATION Fieldbus BA078D/06/en/). • The status of the simulation mode is also shown in the "BLOCK_ERR" parameter of the Resource Block, (see Page 92).
DEVICE PD-TAG (6203)	Use this function to enter a tag name for the measuring device. User input: Max. 32-character text, permissible: A-Z, 0-9, +, -, punctuation marks Factory setting: E+H_PROSONIC_FLOW_93_XXXXXXXXXX (XXXXXXXXXX = serial number)

7.1.2 Function group: FUNCTION BLOCKS



Function description	
BASIC FUNCTION → FOUNDATION FIELDBUS → FUNCTION BLOCKS	
BLOCK SELECTION (6220)	Use this function to select a function block whose value and status is shown in the subsequent functions. Options: ANALOG INPUT 1 ANALOG INPUT 2 ANALOG INPUT 3 ANALOG INPUT 4 ANALOG INPUT 5 ANALOG INPUT 6 ANALOG INPUT 7 ANALOG INPUT 8 PID Factory setting: ANALOG INPUT 1
OUT VALUE (6221)	Displays the output value OUT, incl. unit and status, of the Analog Input or PID function block selected in the BLOCK SELECTION (6220) function.
PID_IN VALUE (6222)	 Note! This function is not available unless "PID" was selected in the BLOCK SELECTION (6220) function. Display: Displays the controlled variable IN, incl. unit and status, of the PID function block.
CASCADE IN (6223)	 Note! This function is not available unless "PID" was selected in the BLOCK SELECTION (6220) function. Display: Displays the analog setpoint value, incl. unit and status, taken over from an external function block.


7.1.3 Function group: INFORMATION





Function description	
BASIC FUNCTION → FOUNDATION FIELDBUS → OPERATION	
MANUFACTURER ID (6240)	Displays the manufacturer ID. Display: 452B48 (hex) for Endress+Hauser
DEVICE TYPE (6241)	Displays the device type. Display: 1059 (hex) for Prosonic Flow 93 FOUNDATION Fieldbus
SERIAL NUMBER (6242)	Displays the serial number of the device. Display: 11-digit designation (number, letters)
DEVICE REVISION (6243)	Displays the revision number of the device.  Note! This display can be used to check whether the correct system files (DD = Device Description) are being used for linking into the host system. The system files can be downloaded free of charge from the Internet, (www.endress.com). Example: DEVICE REVISION (6243) function displays → 01 DD REVISION (6244) function displays → 01 Device description (DD) files required → 0101.sym and 0101.ffa
DD REVISION (6244)	Displays the revision number of the device description.  Note! This display can be used to check whether the correct system files (DD = Device Description) are being used for linking into the host system. The system files can be downloaded free of charge from the Internet, (www.endress.com). Example: DEVICE REVISION (6243) function displays → 01 DD REVISION (6244) function displays → 01 Device description (DD) files required → 0101.sym and 0101.ffa

7.2 Group PROCESS PARAMETER (CH1...CH2)


7.2.1 Function group: CONFIGURATION



Function description	
BASIC FUNCTION → PROCESS PARAMETER (CH1...CH2) → CONFIGURATION	
ASSIGN LOW FLOW CUT OFF (6400)	Use this function to assign the switching point for low flow cut off in a technical engineering unit. Options: OFF VOLUME FLOW Factory setting: VOLUME FLOW
ON-VALUE LOW FLOW CUT OFF (6402)	Use this function to assign a value to the switch-on point for low flow cut off. Low flow cut off is active if the value entered is not equal to 0. The sign of the flow value is highlighted on the display to indicate that low flow cut off is active. User input: 5-digit floating-point number Factory setting: Depends on country, [value] / [dm³...m³ or US-gal...US-Mgal] Corresponds to the factory setting for the low flow cut off, (see Page 76 ff.).  Note! The appropriate unit is taken from the UNIT VOLUME FLOW (0402) function, (see Page 15).
OFF-VALUE LOW FLOW CUT OFF (6403)	Entry of the switch-off point (b) for low flow cut off. Enter the switch-off point as a positive hysteresis (H) from the switch-on point (a). User input: Integer 0...100% Factory setting: 50% Example:  Q = Flow [volume/time] t = Time a = ON-VALUE LOW FLOW CUT OFF (6402) = 200 dm³/h b = OFF-VALUE LOW FLOW CUT OFF (6403) = 10% c = Low flow cut off active 1 = Low flow cut off is switched on at 200 dm³/h 2 = Low flow cut off is switched off at 220 dm³/h


Function description	
BASIC FUNCTION → PROCESS PARAMETER (CH1...CH2) → CONFIGURATION	
PRESSURE SHOCK SUPPRESSION (6404)	The closure of a valve can cause brief but severe movements of the liquid in the piping system, movements which the measuring system registers. The pulses totalled in this way result in a totalizer reading error, particularly in the case of batching processes. For this reason, the measuring device is equipped with pressure shock suppression (= short-term signal suppression) which can eliminate system-related "disruptions".  Note! Pressure shock suppression cannot be used unless the low flow cut off is active, (see ON-VALUE LOW FLOW CUT OFF function on Page 53). Use this function to define the time span for active pressure shock suppression. Activation of the pressure shock suppression Pressure shock suppression is activated after the flow falls below the switch-on point of the low flow cut off, (see point 1 in graphic). While pressure shock suppression is active, the following conditions apply: • Output value OUT of the AI Blocks → Flow value "0" • Flow reading on display → 0. • Totalizer reading → The totalizers are pegged at the last valid value. Deactivation of the pressure shock suppression The pressure shock suppression is deactivated after the time interval, set in this function, has passed (see point 2 in graphic).  Note! The current flow value is only processed and displayed again once the time interval for the pressure shock suppression has elapsed and the flow exceeds the switch-off point for low flow cut off, (see point 3 in graphic).  User input: Max. 4-digit number, incl. unit: 0.00...100.0 s Factory setting: 0.00 s

7.2.2 Function group: ADJUSTMENT



Function description	
BASIC FUNCTION → PROCESS PARAMETER (CH1...CH2) → ADJUSTMENT	
ZEROPOINT ADJUSTMENT (6480)	This function enables a zero point adjustment to be automatically carried out. The new zero point determined by the measuring system is adopted by the ZERO POINT function, (see Page 67). User input: CANCEL START Factory setting: CANCEL  Caution! Before carrying this out, please refer to the Operating Instructions for Prosonic Flow 93 FOUNDATION Fieldbus (BA078D/06/en), for a detailed description of the procedure for zero point adjustment.  Note! • Programming is locked during zero point adjustment The message "ZERO ADJUST RUNNING" appears on the display. • If the zero point adjustment is not possible (e.g. if $v > 0.1$ m/s) or has been cancelled, the alarm "ZERO ADJUST NOT POSSIBLE" appears on the display. This error is relayed to downstream function blocks or higher-level process control systems via the FOUNDATION Fieldbus by means of the status "UNCERTAIN" for the output value OUT (AI Block).

7.2.3 Function group: PIPE DATA




Function description	
BASIC FUNCTION → PROCESS PARAMETER (CH1...CH2) → PIPE DATA	
PIPE STANDARD (6520)	Use this function to select a standard pipe. Options: OTHERS DIN PN10 DIN PN16 DIN 28610 DIN 28614 DIN 28615 DIN 28619 ANSI SCHEDULE 40 ANSI SCHEDULE 80 AWWA CLASS 50 AWWA CLASS 53 AWWA CLASS 55 Factory setting: DIN PN10

Function description	
BASIC FUNCTION → PROCESS PARAMETER (CH1...CH2) → PIPE DATA	
NOMINAL DIAMETER (6521)	Use this function to select the nominal diameter of the pipe. Options: OTHERS DN 25/1" DN 40/1½" DN 50/2" DN 80/3" DN 100/4" DN 150/6" DN 200/8" DN 250/10" DN 300/12" DN 400/16" DN 450/18" DN 500/20" DN 600/24" DN 700/28" DN 750/30" DN 800/32" DN 900/36" DN 1000/40" DN 1200/48" DN 1400/54" DN 1500/60" DN 1600/64" DN 1800/72" DN 2000/80" Factory setting: DN 80/3"
PIPE MATERIAL (6522)	Use this function to select the pipe material. Options: CARBON STEEL CAST IRON STAINLESS STEEL SS ANSI 304 SS ANSI 316 SS ANSI 347 SS ANSI 410 SS ANSI 430 HASTELLOY C PVC PE LDPE HDPE GRP PVDF PA PP PTFE GLASS PYREX ASBESTOS CEMENT OTHERS Factory setting: STAINLESS STEEL

Function description	
BASIC FUNCTION → PROCESS PARAMETER (CH1...CH2) → PIPE DATA	
REFERENCE VALUE (6523)	 Note! This function does not appear unless "SOUND VELOCITY PIPE" was selected in the MEASUREMENT function (6880, Page 63). Use this function to enter the thickness of the reference component (e.g. flange) as the basis for measuring the sound velocity of the pipe. User input: 5-digit floating-point number, [unit] Factory setting: 5 mm
SOUND VELOCITY PIPE (6524)	Use this function to enter the sound velocity in the pipe. Measuring the sound velocity in the pipe If the sound velocity in the pipe is not known, it can be measured. To do so, "SOUND VELOCITY PIPE" must be set in the MEASUREMENT function (6880, Page 63). The sound velocity in the pipe is measured by calling up the SOUND VELOCITY PIPE (6524) function. The measured sound velocity, the signal strength and a bar graph appear on the local display. The measurement is valid if 100% is achieved in the bar graph. If you confirm the function with the  key, the SAVE prompt appears. To accept the measured sound velocity, select the option "YES" by means of the  or  key.  Note! A reference value is used as a basis for measuring the sound velocity. This reference value can be edited, (see Page 58). User input: Fixed-point number 800...6500 m/s Factory setting: 3120 m/s
PIPE CIRCUMFERENCE (6525)	Use this function to enter the circumference of the pipe. User input: Fixed-point number 31.4...15708.0 mm Factory setting: 279.3 mm
PIPE DIAMETER (6526)	Use this function to enter the diameter of the pipe. User input: Fixed-point number 10.0...5000.0 mm Factory setting: 88.9 mm

Function description	
BASIC FUNCTION → PROCESS PARAMETER (CH1...CH2) → PIPE DATA	
WALL THICKNESS (6527)	Use this function to enter the thickness of the pipe walls. Measuring the wall thickness If the wall thickness is not known, it can be measured. To do so, "WALL THICKNESS" must be set in the MEASUREMENT function (6880, Page 63). The wall thickness is measured by calling up the WALL THICKNESS (6527) function. The measured wall thickness, the signal strength and a bar graph appear on the local display. The measurement is valid if 100% is achieved in the bar graph. If you confirm the function with the  key, the SAVE prompt appears. To accept the measured wall thickness, select the option "YES" by means of the  or  key. User input: Fixed-point number 0.1...100.0 mm Factory setting: 3.2 mm
LINER MATERIAL (6528)	Use this function to select the liner material of the pipe. Options: NO LINER MORTAR RUBBER TAR EPOXY OTHERS Factory setting: NO LINER
SOUND VELOCITY LINER (6529)	 Note! This function does not appear unless a liner was selected in the LINER MATERIAL (6528) function. Use this function to enter the sound velocity of the liner. User input: Fixed-point number 800...6500 m/s Factory setting: Depends on the setting selected in the LINER MATERIAL (6528) function
LINER THICKNESS (6530)	 Note! This function does not appear unless a liner was selected in the LINER MATERIAL (6528) function. Use this function to enter the thickness of the liner. User input: Fixed-point number 0.1...100.0 mm Factory setting: 0 mm

7.2.4 Function group: LIQUID DATA




Function description	
BASIC FUNCTION → PROCESS PARAMETER (CH1...CH2) → LIQUID DATA	
LIQUID (6540)	Use this function to select the liquid in the pipe. Options: WATER SEA WATER DISTILLED WATER AMMONIA ALCOHOL BENZENE BROMIDE ETHANOL GLYCOL KEROSENE MILK METHANOL TOLUOL LUBE OIL FUEL OIL PETROL OTHERS Factory setting: WATER
TEMPERATURE (6541)	Use this function to enter the temperature of the liquid. User input: Fixed-point number -273.15...726.85 °C (0...1000 K) Factory setting: 20 °C

Function description	
BASIC FUNCTION → PROCESS PARAMETER (CH1...CH2) → LIQUID DATA	
SOUND VELOCITY LIQUID (6542)	Use this function to enter the sound velocity of the liquid. Measuring the sound velocity of the liquid If the sound velocity of the liquid is not known, it can be measured. To do so, "SOUND VELOCITY LIQUID" must be set in the MEASUREMENT function (6880, Page 63). The sound velocity of the liquid is measured by calling up the SOUND VELOCITY LIQUID (6542) function. The measured sound velocity appears on the local display. If you confirm the function with the  key, the SAVE prompt appears. To accept the measured sound velocity, select the option "YES" by means of the  or  key. User input: Fixed-point number 400...3000 m/s Factory setting: 1487 m/s
VISCOSITY (6543)	Use this function to enter the viscosity of the liquid. User input: Fixed-point number 0.0...5000.0 mm²/s Factory setting: 1 mm²/s
MINIMUM SOUND VELOCITY LIQUID (6545)	Use this function to enter the minimum sound velocity of the liquid. User input: Fixed-point number 400...3000 m/s Factory setting: 800 m/s
MAXIMUM SOUND VELOCITY LIQUID (6546)	Use this function to enter the maximum sound velocity of the liquid. User input: Fixed-point number 400...3000 m/s Factory setting: 1800 m/s

7.3 Group SYSTEM PARAMETER (CH1...CH2)


7.3.1 Function group: CONFIGURATION



Function description	
BASIC FUNCTION → SYSTEM PARAMETER CH1 → CONFIGURATION	
INSTALLATION DIRECTION SENSOR (6600)	Use this function to reverse the sign of the flow rate variable, if necessary. Options: NORMAL (flow as indicated by the arrow) INVERSE (flow opposite to direction indicated by the arrow) Factory setting: NORMAL
FLOW DAMPING (6603)	 Note! The damping acts on all instrument functions and FOUNDATION Fieldbus outputs of the measuring device. Use this function to set the filter depth of the digital filter. This reduces the sensitivity of the measuring signal to interference peaks (e.g. high solids content, gas bubbles in the fluid, etc.). The measuring system reaction time increases with the filter setting. User input: 0 ...100 s Factory setting: 0 s
POSITIVE ZERO RETURN (6605)	Use this function to interrupt evaluation of measured variables. This is necessary when a piping system is being cleaned, for example. The selection only has an effect on the volume flow and the totalizer as well as the corresponding instrument functions and outputs of the FOUNDATION Fieldbus interface. Options: OFF ON → The flow value is set to "0". Factory setting: OFF  Note! An active positive zero return is relayed to downstream function blocks or higher-level process control systems via the FOUNDATION Fieldbus by means of the status "UNCERTAIN" for the output value OUT (AI Block).

7.4 Group SENSOR DATA (CH1...CH2)

7.4.1 Function group: SENSOR PARAMETER




Function description	
BASIC FUNCTION → SENSOR DATA (CH1...CH2) → SENSOR PARAMETER	
MEASUREMENT (6880)	Options: OFF CLAMP ON INSERTION SOUND VELOCITY LIQUID SOUND VELOCITY PIPE WALL THICKNESS Factory setting for channel 1: CLAMP ON Factory setting for channel 2: OFF

Function description	
BASIC FUNCTION → SENSOR DATA (CH1...CH2) → SENSOR PARAMETER	
SENSOR TYPE (6881)	 Note! This function is only available if "OFF" was not selected in the MEASUREMENT function (6880, see Page 63). Use this function to select a sensor type. The options in this function depend on the measurement method selected in the MEASUREMENT function (6880, see Page 63). Options: (if "CLAMP ON" was selected in the MEASUREMENT function) W-CL-05F-L-B W-CL-1F-L-B W-CL-2F-L-B P-CL-05F-L-B P-CL-1F-L-B P-CL-2F-L-B P-CL-05F-M-B P-CL-1F-M-B P-CL-2F-M-B U-CL-2F-L-A Options: (if "INSERTION" was selected in the MEASUREMENT function) W-IN-1F-L-B Options: (if "SOUND VELOCITY LIQUID" was selected in the MEASUREMENT function) P-CL-1S-L-B P-CL-1S-M-B Options: (if "SOUND VELOCITY PIPE" or "WALL THICKNESS" was selected in the MEASUREMENT function) P-CL-4W-L-B Factory setting: W-CL-2F-L-B

Function description	
BASIC FUNCTION → SENSOR DATA (CH1...CH2) → SENSOR PARAMETER	
SENSOR CONFIGURATION (6882)	 Note! This function is not available unless one of the following options was selected in the MEASUREMENT function (6880): • CLAMP ON • SOUND VELOCITY LIQUID • INSERTION Use this function to select the configuration for the ultrasonic sensors, e.g. the number of traverses (in the Clamp On version) or whether single-path or dual-path configuration is present (in the Insertion version). The options in this function depend on the measurement method selected in the MEASUREMENT function (6880, see Page 63). Options: (if "CLAMP ON" was selected in the MEASUREMENT function) NO. TRAVERSE: 1 NO. TRAVERSE: 2 NO. TRAVERSE: 3 NO. TRAVERSE: 4 Options: (if "SOUND VELOCITY LIQUID" was selected in the MEASUREMENT function) NO. TRAVERSE: 1 NO. TRAVERSE: 3 Options: (if "INSERTION" was selected in the MEASUREMENT function) SINGLE PATH DUAL PATH Factory setting: NO. TRAVERSE: 2
CABLE LENGTH (6883)	Use this function to select the length of the sensor cable. Options: LENGTH 5m/15 feet LENGTH 10m/30 feet LENGTH 15m/45 feet LENGTH 30m/90 feet Factory setting: LENGTH 5m/15 feet
SENSOR POSITION (6884)	 Note! This function is not available unless "CLAMP ON" is set in the MEASUREMENT function (6880, see Page 63), and the number of traverses selected in the SENSOR CONFIGURATION function (6882) is 2 or 4. Use this function to view the position of both sensors on the rail. Display: 5-digit number combination

Function description	
BASIC FUNCTION → SENSOR DATA (CH1...CH2) → SENSOR PARAMETER	
WIRE LENGTH (6885)	 Note! This function is not available unless "CLAMP ON" is set in the MEASUREMENT function (6880, see Page 63), and the number of traverses selected in the SENSOR CONFIGURATION function (6882, see Page 65) is 1 or 3. Displays the wire length for mounting the sensors at the correct distance. Display: Max. 5-digit number, including unit (e.g. 200 mm)
SENSOR DISTANCE (6886)	Displays the distance between sensor 1 and sensor 2 as a length measurement. Display: Max. 5-digit number, including unit (e.g. 200 mm)
ARC LENGTH (6887)	 Note! This function is not available unless "INSERTION" is set in the MEASUREMENT function (6880, see Page 63), and "DUAL PATH" was selected in the SENSOR CONFIGURATION function (6882, see Page 65). Displays the arc length on the pipe. Display: Max. 5-digit number, including unit (e.g. 200 mm)
PATH LENGTH (6888)	 Note! This function is not available unless "INSERTION" is selected in the MEASUREMENT function (6880, see Page 63). Displays the path length. Display: Max. 5-digit number, including unit (e.g. 200 mm)


7.4.2 Function group: CALIBRATION DATA



Function description	
BASIC FUNCTION → SENSOR DATA (CH1...CH2) → CALIBRATION DATA	
CALIBRATION FACTOR (6890)	Displays the current calibration factor for the sensors.
ZERO POINT (6891)	Use this function to call up or manually change the zero point correction currently being used. User input: 5-digit floating-point number, including unit and sign (e.g. +10.0 ns)
CORRECTION FACTOR (6893)	Use this function to enter a correction factor at the client's site. User input: 5-digit floating-point number Factory setting: 1.0000 (= no correction)
DEVIATION SENSOR DISTANCE (6894)	 Note! This function is not available unless "INSERTION" is selected in the MEASUREMENT function (6880, see Page 63). Use this function to enter a deviation value for the sensor distance. User input: 5-digit floating-point number, including unit and sign (e.g. +2.0000 mm) Factory setting: 0 mm

Function description	
BASIC FUNCTION → SENSOR DATA (CH1...CH2) → CALIBRATION DATA	
DEVIATION ARC LENGTH (6895)	 Note! This function is not available unless "INSERTION" is set in the MEASUREMENT function (6880, see Page 63) and "DUAL PATH" was selected in the SENSOR CONFIGURATION function (6882, see Page 65). Use this function to enter a deviation value for the arc length. User input: 5-digit floating-point number, including unit and sign (e.g. +2.0000 mm) Factory setting: 0 mm
DEVIATION PATH LENGTH (6896)	 Note! This function is not available unless "INSERTION" is selected in the MEASUREMENT function (6880, see Page 63). Use this function to enter a deviation value for the path length. User input: 5-digit floating-point number, including unit and sign (e.g. +2.0000 mm) Factory setting: 0 mm

8 Block SUPERVISION




8.1 Group SYSTEM

8.1.1 Function group: CONFIGURATION

SUPERVISION	J	⇒	SYSTEM	JAA	⇒	CONFIGURATION	800
Function description							
SUPERVISION → SYSTEM → CONFIGURATION							
ALARM DELAY (8005)		Use this function to specify a time period for suppressing the appearance of fault or notice messages. Depending on the setting and the type of fault, this suppression acts on: • Display • Output values (AI Blocks) FF interface User input: 0...100 s (in steps of one second) Factory setting: 0 s  Caution! If this function is activated, error and notice messages are delayed by the time corresponding to the setting before being forwarded to the higher-level controller (process controller, etc.). It is therefore imperative to check in advance whether a delay of this nature could affect the safety requirements of the process. If fault and notice messages may not be suppressed, a value of 0 seconds must be entered here.					

8.1.2 Function group: OPERATION




Function description	
SUPERVISION → SYSTEM → OPERATION	
CURRENT SYSTEM CONDITION (8040)	Use this function to check the current system condition.  Note! All error messages are described in detail in the Operating Instructions for PROline Prosonic Flow 93 FOUNDATION Fieldbus, BA 078D/06/en. Display: "SYSTEM OK" or the fault/notice message with the highest priority.
PREVIOUS SYSTEM CONDITIONS (8041)	Use this function to view the fifteen most recent fault and notice messages since measuring last started. Display: The last 15 fault/notice messages appear on the display.
SIMULATION FAILSAFE MODE (8042)	Use this function to set all totalizers to their defined failsafe modes, in order to check whether they respond correctly. During this time, the words "SIMULATION FAILSAFE MODE" appear on the display. Options: ON OFF Factory setting: OFF  Note! Active simulation is relayed to downstream function blocks or higher-level process control systems via the FOUNDATION Fieldbus by means of the status "UNCERTAIN" for the output value OUT (AI Block).
SIMULATION MEASURAND (8043)	Use this function to activate the simulation of a measured variable. The simulation value is determined in the VALUE SIMULATION MEASURAND (8044) function. When simulation is active, the message "SIMULATION MEASURAND" appears on the local display. Options: OFF VOLUME FLOW CH1 SOUND VELOCITY CH1 Factory setting: OFF  Caution! • The measuring device cannot be used for measuring while this simulation is in progress. • The setting is not saved if the power supply fails.  Note! • Active simulation is relayed to downstream function blocks or higher-level process control systems via the FOUNDATION Fieldbus by means of the status "UNCERTAIN" for the output value OUT (AI Block). • The simulation is independent of the position of the jumper for the simulation mode on the I/O board.

Function description SUPERVISION → SYSTEM → OPERATION	
VALUE SIMULATION MEASURAND (8044)	 Note! This function is not displayed unless the SIMULATION MEASURAND (8043) function is active. Use this function to specify a selectable value, (e.g. 12 m³/s). This is used to test the associated functions in the flowmeter itself and downstream FOUNDATION Fieldbus function blocks. User input: 5-digit floating-point number, [unit] Factory setting: 0 [unit]  Caution! • The setting is not saved if the power supply fails. • The appropriate unit is taken from the SYSTEM UNITS function group, (ACA, see Page 15).
SYSTEM RESET (8046)	Use this function to perform a reset of the measuring system. Options: NO RESTART SYSTEM (restart without interrupting power supply) Factory setting: NO
TROUBLESHOOTING (8047)	Use this function to rectify errors in the EEPROM. The EEPROM is divided into a number of blocks. Only blocks in which a fault has occurred are shown. For fault elimination, select the block in question and acknowledge by pressing the  key.  Caution! When you clear an error in a block, the parameters of the block you select are reset to their factory settings. Options: CANCEL "Faulty block"

8.2 Group SYSTEM CH2


8.2.1 Function group: OPERATION



Function description	
SUPERVISION → SYSTEM CH2 → OPERATION	
SIMULATION MEASURAND (8043)	Use this function to activate the simulation of a measured variable. The simulation value is determined in the VALUE SIMULATION MEASURAND (8044) function. When simulation is active, the message "SIMULATION MEASURAND" appears on the local display. Options: OFF VOLUME FLOW CH2 SOUND VELOCITY CH2 Factory setting: OFF Caution! - The measuring device cannot be used for measuring while this simulation is in progress. - The setting is not saved if the power supply fails. Note! - Active simulation is relayed to downstream function blocks or higher-level process control systems via the FOUNDATION Fieldbus by means of the status "UNCERTAIN" for the output value OUT (AI Block). - The simulation is independent of the position of the jumper for the simulation mode on the I/O board.
VALUE SIMULATION MEASURAND (8044)	Note! This function is not displayed unless the SIMULATION MEASURAND (8043) function is active. Use this function to specify a selectable value, (e.g. 12 m³/s). This is used to test the associated functions in the flowmeter itself and downstream FOUNDATION Fieldbus function blocks. User input: 5-digit floating-point number, [unit] Factory setting: 0 [unit] Caution! - The setting is not saved if the power supply fails. - The appropriate unit is taken from the SYSTEM UNITS function group, (ACA, see Page 15).


8.3 Group VERSION-INFO

8.3.1 Function group: SENSOR




Function description	
SUPERVISION → VERSION-INFO → SENSOR	
SERIAL NUMBER (8200)	Displays the serial number of the sensor.

8.3.2 Function group: AMPLIFIER




Function description	
SUPERVISION → VERSION-INFO → AMPLIFIER	
SOFTWARE REVISION NUMBER AMPLIFIER (8222)	Displays the software revision number of the amplifier.
SOFTWARE REVISION NUMBER T-DAT (8225)	Displays the software revision number of the software used to create the content of the T-DAT.

8.3.3 Function group: F-CHIP



Function description	
SUPERVISION → VERSION-INFO → F-CHIP	
STATUS F-CHIP (8240)	Use this function to check whether an F-CHIP is installed and which software options are available.

8.3.4 Function group: I/O MODULE



Function description	
SUPERVISION → VERSION-INFO → I/O MODULE	
I/O MODULE TYPE (8300)	Displays the configuration of the I/O module complete with terminal numbers.
SOFTWARE REVISION NUMBER I/O MODULE (8303)	Displays the software revision number of the I/O module.

9 Factory settings

9.1 SI units (not for USA and Canada)

9.1.1 Low flow cut off, totalizer

Nominal diameter		Low flow cut off / flow unit		Totalizer unit
[mm]	[inch]	(approx. $v = 0.04 \text{ m/s}$)	Volume	Volume
80	3"	12	dm^3/min	dm^3

9.1.2 Language

Country	Language
Australia	English
Austria	Deutsch
Belgium	Francais
Denmark	Dansk
England	English
Finland	Suomi
France	Francais
Germany	Deutsch
Holland	Nederlands
Hong Kong	English
India	English
International Instruments	English
Italy	Italiano
Japan	Japanese
Malaysia	English
Norway	Norsk
Singapore	English
South Africa	English
Spain	Espanol
Sweden	Svenska
Switzerland	Deutsch
Thailand	English
Hungary	English

9.1.3 Length, temperature

	Unit
Length	mm
Temperature	$^{\circ}\text{C}$

9.2 US units (only for USA and Canada)

9.2.1 Low flow cut off, totalizer

Nominal diameter		Low flow cut off / flow unit		Totalizer unit
[inch]	[mm]	(approx. v = 0.04 m/s)	Volume	Volume
3"	80	2.5	gal/min	gal

9.2.2 Language, length, temperature

	Unit
Language	English
Length	Inch
Temperature	°F

10 Index (function matrix)

Blöcke

A = MEASURED VARIABLES	11
B = QUICK SETUP	19
C = USER INTERFACE	23
D = TOTALIZER	44
G = BASIC FUNCTION	49
J = SUPERVISION	69

Gruppen

AAA = MEASURED VALUES	12
ACA = SYSTEM UNITS	15
CAA = CONTROL	24
CCA = MAIN LINE	28
CEA = ADDITIONAL LINE	32
CGA = INFORMATION LINE	38
DAA = TOTALIZER 1	45
DAB = TOTALIZER 2	45
DAC = TOTALIZER 3	45
DJA = HANDLING TOTALIZER	48
GGA = FOUNDATION FIELDBUS	50
GIA = PROCESS PARAMETER CH1	53
GIB = PROCESS PARAMETER CH2	53
GLA = SYSTEM PARAMETER CH1	62
GLB = SYSTEM PARAMETER CH2	62
GNA = SENSOR DATA CH1	63
GNB = SENSOR DATA CH2	63
JAA = SYSTEM	70
JAB = SYSTEM CH2	73
JCA = VERSION INFO	74

Funktionsgruppen

000 = MAIN VALUES CH1	12
006 = MAIN VALUES CH2	13
008 = CALCULATED MAIN VALUES	14
040 = CONFIGURATION	15
042 = ADDITIONAL CONFIGURATION	17
200 = BASIC CONFIGURATION	24
202 = UNLOCKING/LOCKING	26
204 = OPERATION	27
220 = CONFIGURATION	28
222 = MULTIPLEX	30
240 = CONFIGURATION	32
242 = MULTIPLEX	35
260 = CONFIGURATION	38
262 = MULTIPLEX	41
300 = CONFIGURATION	45
304 = OPERATION	47
620 = CONFIGURATION	50
622 = FUNCTION BLOCKS	51
624 = INFORMATION	52
640 = CONFIGURATION	53
648 = ADJUSTMENT	55
652 = PIPE DATA	56
654 = LIQUID DATA	60
660 = CONFIGURATION	62
688 = SENSOR PARAMETER	63
689 = CALIBRATION DATA	67

800 = CONFIGURATION	70
804 = OPERATION	71
804 = OPERATION (CH2)	73
820 = SENSOR	74
822 = AMPLIFIER	74
824 = F-CHIP	75
830 = I/O MODULE	75

Funktionen 0...

0001 = VOLUME FLOW CH1	12
0002 = SOUND VELOCITY CH1	12
0003 = FLOW VELOCITY CH1	12
0007 = SIGNAL STRENGTH CH1	12
0061 = VOLUME FLOW CH2	13
0062 = SOUND VELOCITY CH2	13
0063 = FLOW VELOCITY CH2	13
0067 = SIGNAL STRENGTH CH2	13
0083 = VOLUME FLOW AVERAGE	14
0084 = VOLUME FLOW SUM	14
0085 = VOLUME FLOW DIFFERENCE	14
0086 = SOUND VELOCITY AVERAGE	14
0087 = FLOW VELOCITY AVERAGE	14
0402 = UNIT VOLUME FLOW	15
0403 = UNIT VOLUME	16
0422 = UNIT TEMPERATURE	17
0423 = UNIT VISCOSITY	17
0424 = UNIT LENGTH	17
0425 = UNIT VELOCITY	18

1...

1001 = QUICK SETUP SENSOR	19
1002 = QUICK SETUP COMMISSIONING	19
1009 = T DAT SAVE/LOAD	19

2...

2000 = LANGUAGE	24
2002 = DISPLAY DAMPING	24
2003 = CONTRAST LCD	24
2004 = X-LINE CALCULATED MAIN VALUES	25
2020 = ACCESS CODE	26
2021 = DEFINE PRIVATE CODE	26
2022 = STATUS ACCESS	26
2040 = TEST DISPLAY	27
2200 = ASSIGN	28
2201 = 100% VALUE	29
2202 = FORMAT	29
2220 = ASSIGN	30
2221 = 100% VALUE	31
2222 = FORMAT	31
2400 = ASSIGN	32
2401 = 100% VALUE	33
2402 = FORMAT	33
2403 = DISPLAY MODE	34
2420 = ASSIGN	35
2421 = 100% VALUE	36

2... (continued)

2422 = FORMAT	36
2423 = DISPLAY MODE	37
2600 = ASSIGN	38
2601 = 100% VALUE	39
2602 = FORMAT	39
2603 = DISPLAY MODE	40
2620 = ASSIGN	41
2621 = 100% VALUE	42
2622 = FORMAT	42
2623 = DISPLAY MODE	43

3...

3000 = ASSIGN	45
3001 = UNIT TOTALIZER	46
3002 = TOTALIZER MODE	46
3003 = RESET TOTALIZER	46
3040 = SUM	47
3041 = OVERFLOW	47
3800 = RESET ALL TOTALIZERS	48
3801 = FAILSAFE MODE	48

6...

6200 = WRITE PROTECTION	50
6201 = SIMULATION	50
6203 = DEVICE PD-TAG	50
6220 = BLOCK SELECTION	51
6221 = OUT VALUE	51
6222 = PID_IN VALUE	51
6223 = CASCADE IN	51
6240 = MANUFACTURER ID	52
6241 = DEVICE TYPE	52
6242 = SERIAL NUMBER	52
6243 = DEVICE REVISION	52
6244 = DD REVISION	52
6400 = ASSIGN LOW FLOW CUT OFF	53
6402 = ON-VALUE LOW FLOW CUT OFF	53
6403 = OFF-VALUE LOW FLOW CUT OFF	53
6404 = PRESSURE SHOCK SUPPRESSION	54
6480 = ZEROPOINT ADJUSTMENT	55
6520 = PIPE STANDARD	56
6521 = NOMINAL DIAMETER	57
6522 = PIPE MATERIAL	57
6523 = REFERENCE VALUE	58
6525 = PIPE CIRCUMFERENCE	58
6526 = PIPE DIAMETER	58
6527 = WALL THICKNESS	59
6528 = LINER MATERIAL	59
6529 = SOUND VELOCITY LINER	59
6530 = LINER THICKNESS	59
6540 = LIQUID	60
6541 = TEMPERATURE	60
6542 = SOUND VELOCITY LIQUID	61
6543 = VISCOSITY	61
6545 = MINIMUM SOUND VELOCITY LIQUID	61
6546 = MAXIMUM SOUND VELOCITY LIQUID	61

6600 = INSTALLATION DIRECTION SENSOR	62
6603 = FLOW DAMPING	62
6605 = POSITIVE ZERO RETURN	62
6880 = MEASUREMENT	63
6881 = SENSOR TYPE	64
6882 = SENSOR CONFIGURATION	65
6883 = CABLE LENGTH	65
6884 = SENSOR POSITION	65
6885 = WIRE LENGTH	66
6886 = SENSOR DISTANCE	66
6887 = ARC LENGTH	66
6888 = PATH LENGTH	66
6890 = K-FACTOR	67
6891 = ZERO POINT	67
6893 = CORRECTION FACTOR	67
6894 = DEVIATION SENSOR DISTANCE	67
6895 = DEVIATION ARC LENGTH	68
6896 = DEVIATION PATH LENGTH	68
6524 = SOUND VELOCITY PIPE	58

8...

8005 = ALARM DELAY	70
8040 = ACTUAL SYSTEM CONDITION	71
8041 = PREVIOUS SYSTEM CONDITIONS	71
8042 = SIMULATION FAILSAFE MODE	71
8043 = SIMULATION MEASURAND (CH1)	71
8043 = SIMULATION MEASURAND (CH2)	73
8044 = VALUE SIMULATION MEASURAND (CH1)	72
8044 = VALUE SIMULATION MEASURAND (CH2)	73
8046 = SYSTEM RESET	72
8047 = TROUBLESHOOTING	72
8200 = SERIAL NUMBER	74
8222 = SOFTWARE REVISION NUMBER AMPLIFIER	74
8225 = SOFTWARE REVISION NUMBER T-DAT	74
8240 = STATUS F-CHIP	75
8300 = I/O MODULE TYPE	75
8303 = SOFTWARE REVISION NUMBER I/O MODULE	75

11 Index (local operation)

A

Actual system conditions	71
Additional	
Configuration	17
Line	32
Adjustment, zero point	55
Alarm delay	70
Arc length	66
Assign	
Additional line	32
Additional line, multiplex	35
Information line	38
Information line, multiplex	41
Low flow cut off	53
Main line	28
Main line, multiplex	30
Totalizer	45
Average	
Flow velocity	14
Sound velocity	14
Average volume flow	14

B

Basic configuration	24
Block	
Basic function	49
Measured variables	11
Quick Setup	19
Supervision	69
Totalizer	44
User interface	23
Block selection	51

C

Cable length	65
Calculated main values	14
Calibration data	67
Cascade in	51
Code	
Access	26
Private	26
Configuration	
Additional line	32
FOUNDATION Fieldbus	50
Information line	38
Main line	28
Process parameter	53
System	70
System parameter	62
System units	15
Totalizer	45
Contrast LCD	24
Correction factor	67

D

Damping	
Display	24
Flow	62
DD revision	52
Define private code	26
Deviation	
Arc length	68
Path length	68

Sensor distance	67
Device	
PD-TAG	50
Revision	52
Type	52
Display	
Damping	24
Test	27
Display mode	
Additional line	34
Additional line, multiplex	37
Information line	40
Information line, multiplex	43

F

Factory settings	
SI units	76
US units	77
Failsafe mode	48
F-CHIP status	75
Flow damping	62
Flow velocity	
Average	14
CH1	12
CH2	13
Format	
Additional line	33
Additional line, multiplex	36
Information line	39
Information line, multiplex	42
Main line	29
Main line, multiplex	31
FOUNDATION Fieldbus	50
Function blocks	51
Function group	
Additional configuration (system units)	17
Adjustment (process parameter)	55
Amplifier (version info)	74
Basic configuration (user interface)	24
Calculated main values (measured values)	14
Calibration data (sensor data)	67
Configuration (additional line)	32
Configuration (FOUNDATION Fieldbus)	50
Configuration (information line)	38
Configuration (main line)	28
Configuration (process parameter)	53
Configuration (system parameter)	62
Configuration (system units)	15
Configuration (system)	70
Configuration (totalizer)	45
F-Chip (version info)	75
Function blocks (FOUNDATION Fieldbus)	51
Information (FOUNDATION Fieldbus)	52
I/O module (version info)	75
Liquid data (process parameter)	60
Main values CH1 (measured values)	12
Main values CH2 (measured values)	13
Multiplex (additional line)	35
Multiplex (information line)	41
Multiplex (main line)	30
Operation (system CH2)	73

F (continued "Function group")

Operation (system)	71
Operation (totalizer)	47
Operation (user interface)	27
Pipe data (process parameter)	56
Sensor parameter (sensor data)	63
Sensor (version info)	74
Unlocking/locking (user interface)	26
Function matrix	
Code	9
General layout	8
Overview	10

G

Group

Additional line	32
FOUNDATION Fieldbus	50
Handling totalizer	48
Information line	38
Main line	28
Measured values	12
Operation	24
Process parameter (CH1...CH2)	53
Sensor data (CH1...CH2)	63
System	70
System CH2	73
System parameter (CH1...CH2)	62
System units	15
Totalizer (1...3)	45
Version info	74

I

Information line	38
Information (FOUNDATION Fieldbus)	52
Installation direction sensor	62
I/O module type	75

K

K-Factor	67
--------------------	----

L

Language	24
LCD contrast	24
Length	
Arc	66
Cable	65
Path	66
Wire	66
Liner	
Material	59
Thickness	59
Liquid	60
Liquid data	60
Locating function descriptions	7
Low flow cut off	
Assign	53
Off-value	53
On-value	53

M

Main line	28
Main values	
CH1	12
CH2	13
Manufacturer ID	52

Matrix

Basic function	49
Blocks/groups	10
Measured variables	11
Quick Setup	19
Supervision	69
Totalizer	44
User interface	23
Maximum liquid sound velocity	61
Measured values	12
Measurement	63
Minimum liquid sound velocity	61
Multiplex	
Additional line	35
Information line	41
Main line	30

N

Nominal diameter	57
----------------------------	----

O

Off-value low flow cut off	53
On-value low flow cut off	53
Operation	24
System	71
System CH2	73
Totalizer	47
User interface	27
Out value	51
Overflow	47

P

Path length	66
PID in value	51
Pipe	
Circumference	58
Data	56
Diameter	58
Material	57
Positive zero return	62
Pressure shock suppression	54
Previous system conditions	71
Process parameter	53

Q

Quick Setup	
Commissioning	19
Sensor	19

R

Reference value	58
Reset	
System	72
Totalizer (individual)	46
Totalizers (all)	48
Revision	
DD	52
Device	52

S

Sensor	
Configuration	65
Data	63
Distance	66
Installation direction	62
Parameter	63
Position	65
Serial number	74
Type	64
Sensor configuration	65
Sensor data	63
Sensor position	65
Serial number	52
Sensor	74
Signal strength	
CH1	12
CH2	13
Simulation	50
Failsafe mode	71
Measurand value (CH1)	72
Measurand value (CH2)	73
Measurand (CH1)	71
Measurand (CH2)	73
Software revision number	
Amplifier	74
I/O module	75
T-DAT	74
Sound velocity	
Average	14
CH1	12
CH2	13
Liner	59
Liquid	61
Maximum (liquid)	61
Minimum (liquid)	61
Pipe	58
Standard pipe	56
Status access	26
Status F-CHIP	75
Sum	47
Supervision	69
System	
Conditions	
Actual	71
Previous	71
Parameter	62
Reset	72
Units	15

T

T-DAT save/load	19
Temperature (liquid)	60
Test display	27
Totalizer	44
Assign	45
Failsafe mode	48
Handling	48
Mode	46
Overflow	47
Reset	46
Sum	47
Totalizer mode	46
Unit	46
Troubleshooting	72

U

Unit	
Length	17
Temperature	17
Totalizer	46
Velocity	18
Viscosity	17
Volume	16
Volume flow	15
Unlocking/locking	26
Using this manual	7

V

Value simulation measurand	
CH1	72
CH2	73
Version info	74
Amplifier	74
F-Chip	75
I/O module	75
Sensor	74
Viscosity	61
Volume flow	
Average	14
CH1	12
CH2	13
Difference	14
Sum	14
Unit	15

W

Wall thickness	59
Wire length	66
Write protection	50

X

X-line calculated main values	25
-------------------------------	----

Z

Zero point	67
Zero point adjustment	55

Numerics

100% value	
Additional line	33
Additional line, multiplex	36
Information line	39
Information line, multiplex	42
Main line	29
Main line, multiplex	31

Contents (FOUNDATION Fieldbus)

1	Operation via FOUNDATION Fieldbus	87
1.1	Block model	87
2	Resource Block	89
2.1	Selecting the operating mode	89
2.2	Block status	89
2.3	Write protection and simulation	90
2.4	Alarm detection and processing	90
2.5	Resource Block parameters	91
3	Transducer Blocks (transmission blocks)	100
3.1	Overview	100
3.2	Signal processing	102
3.3	Block output values	103
3.4	Selecting the operating mode	104
3.5	Alarm detection and processing	104
3.6	Diagnosis	105
3.7	Access to manufacturer-specific parameters	105
3.8	FOUNDATION Fieldbus parameters of the Transducer Blocks	106
3.9	Overview of Transducer Blocks with E+H parameters	109
3.10	E+H parameters of the Transducer Blocks: "TRANSDUCER_CH1" (flow channel 1) and "TRANSDUCER_CH2" (flow channel 2)	109
3.11	E+H parameters: Transducer Block "TRANSDUCER_DISP" (display)	129
3.12	E+H parameters: Transducer Block "TRANSDUCER_TOT" (totalizer)	148
3.13	E+H parameters: Transducer Block "TRANSDUCER_DIAG" (diagnosis)	156
3.14	E+H parameters: Transducer Block "TRANSDUCER_SERV" (service)	159
4	Analog Input function block	160
4.1	Signal processing	160
4.2	Selecting the operating mode	162
4.3	Selecting the process variable	162
4.4	Linearisation types	163
4.5	Selecting the units	163
4.6	Status of the output value OUT	164
4.7	Simulation of input/output	164
4.8	Diagnosis	165
4.9	Rescaling the input value	165
5	Discrete Output function block	181
5.1	Signal processing	181
5.2	Selecting the operating mode	182
5.3	Security behaviour	182
5.4	Assignment: DO function block/Transducer Blocks	182
5.5	Values for the CAS_IN_D, RCAS_IN_D, OUT_D, and SP_D parameters	182

6	PID function block (PID controller)	191
6.1	Signal processing	191
6.2	PID function block equation	192
6.3	Selecting the operating mode	193
6.4	Setpoint value specification	193
6.5	Damping	193
6.6	Limit values	194
6.7	Alarm detection and processing	194
6.8	Example: Basic PID control	195
6.9	Example of configuration	196
6.10	Parameters of the PID function block	197
7	Index (FOUNDATION Fieldbus)	219

1 Operation via FOUNDATION Fieldbus

1.1 Block model

In the FOUNDATION Fieldbus all the device parameters are categorised according to their functional properties and task and are generally assigned to three different blocks. A block may be regarded as a container in which parameters and the associated functionalities are contained.

A FOUNDATION Fieldbus device has the following block types:

- A Resource Block (device block)
The Resource Block contains all the device-specific characteristics of the device.
- One or several Transducer Blocks (transmission block)
The Transducer Block contains all the measuring and device-specific parameters of the device. The measuring principles, (e.g. flow, temperature, etc.), are depicted in the Transducer Blocks in accordance with the FOUNDATION Fieldbus Specification.
- One or more function blocks
Function blocks contain the automation functions of the device.
We distinguish between different function blocks, e.g. Analog Input function block, Analog Output function block, PID function block (PID controller) etc. Each of these function blocks is used to process different application functions.

Different automation tasks can be realised depending on the arrangement and connection of the individual function blocks. A field device may comprise further function blocks e.g. several Analog Input function blocks if more than one process variable is available from the field device.

Prosonic Flow 93 FOUNDATION Fieldbus has the following blocks:

- One Resource Block, see Page 89
- Six Transducer Blocks, see Page 100.
- Ten function blocks consisting of:
 - Eight Analog Input function blocks, see Page 167.
 - One Discrete Output, see Page 184.
 - One PID function block (PID controller), see Page 197.




Fig. 1: PROline Prosonic Flow 93 FOUNDATION Fieldbus block model

The sensor signal is first prepared in the measuring block, namely the Transducer Block "TRANSDUCER_CH1" (base index 1200, flow channel 1) or "TRANSDUCER_CH2" (base index 1300, flow channel 2).

The process variables are then passed to the Analog Input function blocks for technical processing, (e.g. scaling, limit value processing).

The totalizer values 1 – 3 are derived from the volume flow measured variable in the Transducer Block "TRANSDUCER_TOT" (base index 1550, totalizer).

These are then also available as process variables at the Transducer Block output.

All the important parameters for configuring the local display, (e.g. UI language, display values etc.), can be configured via the Transducer Block "TRANSDUCER_DISP" (base index 1500, display).

The Transducer Block "TRANSDUCER_DIAG" (base index 1600, diagnosis) contains all the important parameters for diagnosis and device maintenance which can be used to call up the device status or reasons for error messages, for example.

The Transducer Block "TRANSDUCER_SERV" (base index 1650, service) contains all the parameters required for servicing. As these parameters affect the accuracy and functionality of the device, changes may only be made by E+H service technicians.

The process variables go through the complete algorithm of the Analog Input function block and are available to other function blocks, e.g. the PID Block, as an output value for connecting the desired application function.

By means of the Discrete Output function block (DO), various actions and functions in PROline Prosonic Flow 93 FOUNDATION Fieldbus can be initiated or controlled via the FOUNDATION Fieldbus, such as resetting the totalizers, for example.

2 Resource Block

A Resource Block contains all the data which uniquely identify and characterise the field device. It is an electronic version of a nameplate on the field device. Parameters of the Resource Block include device type, device name, manufacturer ID, serial number, etc.

A further task of the Resource Block is the management of overall parameters and functions that have an influence on the execution of the remaining blocks in the field device. The Resource Block is thus the central unit that also checks the device status and thereby influences or controls the operability of the other blocks and thus also of the device. Since the Resource Block has no block input and block output data, it cannot be linked with other blocks.

The most important functions and parameters of the Resource Block are listed below; you will find an overview of all the parameters available from Page 89 onwards.

2.1 Selecting the operating mode

The operating mode is set by means of the MODE_BLK parameter group, (see Page 95). The Resource Block supports the following operating modes:

- AUTO (automatic mode)
- OOS (out of service)



Note!

The OOS operating mode is also displayed via the BLOCK_ERR parameter, (see Page 92). In the OOS operating mode, you can access all the write parameters without restriction if write protection is not enabled, (see Page 90).

2.2 Block status

The current operating status of the Resource Block is displayed in the RS_STATE parameter, (see Page 96).

The Resource Block can take on the following states:

- STANDBY The Resource Block is in the OOS operating mode. Execution of the remaining blocks is not possible.
- ONLINE LINKING The connections configured between the function blocks have not yet been linked.
- ONLINE Normal operating status, the Resource Block is in the AUTO (automatic) operating mode. The configured connections between the function blocks have been made.

2.3 Write protection and simulation

Write protection of the device parameters and simulation in the Analog Input and Discrete Output function block can be enabled or disabled via jumpers on the FOUNDATION Fieldbus I/O board, (see Operating Instructions for PROline Prosonic Flow 93 FOUNDATION Fieldbus, BA078D/06/en, Section 5.4).

The WRITE_LOCK parameter (see Page 98) shows the status of the hardware write protection. The following statuses are possible:

- LOCKED = Device data **cannot** be modified via the FOUNDATION Fieldbus.
- NOT LOCKED = Device data can be modified via the FOUNDATION Fieldbus.

The BLOCK_ERR parameter (see Page 92) indicates whether a simulation is possible in the Analog Input and Discrete Output function block.

- SIMULATION ACTIVE = Simulation possible via the SIMULATE parameter in the Analog Input function block and via the SIMULATE_D parameter in the Discrete Output function block.

2.4 Alarm detection and processing

Process alarms provide information on particular block statuses and block events. The status of the process alarms is communicated to the fieldbus host system via the BLOCK_ALM parameter, (see Page 91). The ACK_OPTION parameter (see Page 91) specifies whether an alarm must be acknowledged via the fieldbus host system.

The following process alarms are generated by the Resource Block:

Block process alarms

The following block process alarms of the Resource Block are shown via the BLOCK_ALM parameter, (see Page 91):

- OUT OF SERVICE
- SIMULATION ACTIVE

Write protection process alarm

If write protection is disabled on the FOUNDATION Fieldbus I/O board, the alarm priority specified in the WRITE_PRI parameter (see Page 98) is checked prior to communicating the change of status to the fieldbus host system. The alarm priority specifies the action taken in the event of an active write protection alarm WRITE_ALM (see Page 97).



Note!

- If the option of a process alarm has **not** been enabled in the ACK_OPTION parameter (see Page 91) this process alarm must only be acknowledged in the BLOCK_ALM parameter (see Page 91).
- The ALARM_SUM parameter (see Page 91) shows the current status of all the process alarms.

2.5 Resource Block parameters

The following table lists both the FOUNDATION Fieldbus parameters and the Endress+Hauser-specific parameters, (from Page 99), of the Resource Block:

Resource Block / base index 258		
Parameter	Write access with operating mode (MODE_BLK)	Description
<i>FOUNDATION Fieldbus parameters</i>		
ACK_OPTION	AUTO - OOS	This parameter is used to specify whether a process alarm must be acknowledged at the time of alarm detection by the fieldbus host system. If this option is enabled the process alarm is acknowledged automatically. Options: DISC ALM Write protection no longer exists and thus the data can be accessed. BLOCK ALM Block alarm Factory setting: The option is not enabled for any alarm, the alarms must be acknowledged.
ALARM_SUM	AUTO - OOS	Displays the current status of the process alarms in the Resource Block. Display: DISC ALM Write protection no longer exists and thus the data can be accessed. BLOCK ALM Block alarm  Note! In addition, the process alarms can also be disabled in this parameter group.
ALERT_KEY	AUTO - OOS	Entry of the identification number of the plant unit. This information can be used by the fieldbus host system for sorting alarms and events. User input: 1...255 Factory setting: 0
BLOCK_ALM	AUTO - OOS	Displays the current block status with information on pending configuration, hardware or system errors, including details of the alarm time (date, time) when the error occurred. The block alarm is triggered in the event of the following block errors: • SIMULATION ACTIVE • OUT OF SERVICE  Note! If the option of the alarm has not been enabled in the ACK_OPTION parameter, the alarm can only be acknowledged via this parameter.

Resource Block / base index 258		
Parameter	Write access with operating mode (MODE_BLK)	Description
BLOCK_ERR	read only	Displays the active block error. Display: SIMULATION ACTIVE Simulation possible in the Analog Input function block via the SIMULATE parameter and in the Discrete Output function block via the SIMULATE_D parameter, (see also settings for simulation mode in the Operating Instructions for PROline Prosonic Flow 93 FOUNDATION Fieldbus, BA078D/06/en, Section 5.4). OUT OF SERVICE The block has the status "Out of Service".
CLR_FSTATE	AUTO - OOS	This parameter can be used to manually disable the security behaviour of the Discrete Output function block. Options: UNINITIALIZED OFF CLEAR (security behaviour disabled)  Note! The security behaviour of the Discrete Output function block can be manually enabled via the SET_FSTATE parameter, (see Page 96).
CONFIRM_TIME	AUTO - OOS	Specifies the confirmation time for the event report. The event report is sent to the fieldbus host system again if the device does not receive confirmation within this time. Factory setting: 640000 $\frac{1}{32}$ ms
CYCLE_SEL	AUTO - OOS	For selecting and displaying the block execution method used by the fieldbus host system.  Note! The block execution method is selected by the fieldbus host system.
CYCLE_TYPE	read only	Displays the block execution methods supported by the device. Display: SCHEDULED (timed block execution method) BLOCK EXECUTION (sequential block execution method)
DD_RESOURCE	read only	Displays the reference source for the device description (DD). Display: No display  Note! If there is no DD in the device then nothing is displayed.

Resource Block / base index 258		
Parameter	Write access with operating mode (MODE_BLK)	Description
DD_REV	read only	Displays the revision number of the device description.  Note! This display can be used to check whether the correct system files (DD = Device Description) are being used for linking into the host system. The system files can be downloaded free of charge from the Internet, (www.endress.com). Example: DD_REV parameter displays → 01 DEV_REV parameter displays → 01 Device description (DD) files required → 0101.sym and 0101.ffo
DEV_REV	read only	Displays the revision number of the device.  Note! This display can be used to check whether the correct system files (DD = Device Description) are being used for linking into the host system. The system files can be downloaded free of charge from the Internet, (www.endress.com). Example: DD_REV parameter displays → 01 DEV_REV parameter displays → 01 Device description (DD) files required → 0101.sym and 0101.ffo
DEV_TYPE	read only	Displays the device type in decimal numerical format. Display: 4158 (1059 hex) for Prosonic Flow 93 FOUNDATION Fieldbus
FAULT_STATE	read only	Current status display of the security behaviour of the Discrete Output function block. Display: UNINITIALIZED CLEAR (security behaviour not active) ACTIVE (security behaviour active)
FEATURES	read only	Displays the additional options supported by the device. Display: REPORTS Event report is sent. FAULTSTATE The security behaviour of the Discrete Output function block is supported, (see CLR_FSTATE and SET_FSTATE parameters). HARD W LOCK Hardware write protection

Resource Block / base index 258		
Parameter	Write access with operating mode (MODE_BLK)	Description
FEATURES_SEL	AUTO - OOS	For selecting the additional options of the device. Options: UNICODE (is not supported) REPORTS Event report is sent. The fieldbus host system must acknowledge receipt of the event report. FAULTSTATE (is not supported) The security behaviour of the Discrete Output function block is supported, (see CLR_FSTATE and SET_FSTATE parameters). SOFT W LOCK (is not supported) HARD W LOCK HW write protection, this option has no effect. OUT READ BACK (is not supported) DIRECT WRITE (is not supported)
FREE_TIME	read only	Displays the free system time (in percent) available for execution of further function blocks.  Note! Since the function blocks of PROline Prosonic Flow 93 FF are permanently configured, this parameter always displays the value 0%.
FREE_SPACE	read only	Displays the free system memory (in percent) available for execution of further function blocks.  Note! Since the function blocks of PROline Prosonic Flow 93 FF are permanently configured, this parameter always displays the value 0%.
GRANT_DENY	AUTO - OOS	Releases or restricts the access authorisation of a fieldbus host system to the field device.  Note! This parameter is not evaluated.
HARD_TYPES	read only	Displays the input signal type for the function blocks, (Analog Input and Discrete Output function blocks). Display: SCALAR INPUT (scalable analog input value) DISCRETE OUTPUT
ITK_VER	read only	Displays the revision state of the Interoperability Test Kits (ITK). Display: 4
LIM_NOTIFY	AUTO - OOS	This parameter is used to specify the number of event reports that can exist unconfirmed at the same time. Options: 0...24 Factory setting: 24

Resource Block / base index 258		
Parameter	Write access with operating mode (MODE_BLK)	Description
MANUFAC_ID	read only	Displays the manufacturer's ID number. Display: 452B48 (hex) for Endress+Hauser
MAX_NOTIFY	read only	Displays the maximum number of event reports supported by the device that can exist unconfirmed at the same time. Display: 24
MEMORY_SIZE	read only	Displays the available configuration memory in Kbytes.  Note! This parameter is not supported.
MIN_CYCLE_T	read only	Displays the shortest block execution time which is supported by PROline Prosonic Flow 93 FOUNDATION Fieldbus. Display: $1600 \frac{1}{32}$ ms (≈ 50 ms)
MODE_BLK	AUTO - OOS	Displays the current (Actual) and desired (Target) operating mode of the Resource Block, the permitted modes (Permitted) supported by the Resource Block and the normal operating mode (Normal). Display: AUTO (automatic mode) In this operating mode, the execution of the remaining blocks (Transducer Blocks, AI, DO and PID function blocks) is enabled. OOS, Out of Service The block has the status "Out of Service". In this operating mode, the execution of the remaining blocks (Transducer Blocks, AI, DO and PID function blocks) is blocked. These blocks cannot be set to AUTO mode.  Note! The current operating status of the Resource Block is also shown via the RS_STATE parameter, (see Page 96).
NV_CYCLE_T	read only	Displays the time interval for which the dynamic device parameters are stored in the non-volatile memory. The time interval displayed relates to storage of the following dynamic device parameters: • OUT • PV • FIELD_VAL  Note! Since PROline Prosonic Flow 93 FF does not store the dynamic device parameter in the non-volatile memory, this parameter always displays the value $0 \frac{1}{32}$ ms.

Resource Block / base index 258		
Parameter	Write access with operating mode (MODE_BLK)	Description
RESTART	AUTO - OOS	This parameter is used to reset the field device in various ways. Options: UNINITIALIZED RUN Normal operating status. RESOURCE (is not supported) DEFAULTS The FF standard parameters and the connections of the function blocks are reset to the specified default values. PROCESSOR Warm start of device, processor restart.
RS_STATE	read only	Displays the current operating status of the Resource Block. Display: STANDBY The Resource Block is in the OOS operating mode. Execution of the remaining blocks is not possible. ONLINE LINKING The connections configured between the function blocks have not yet been linked. ONLINE Normal operating status, the Resource Block is in the AUTO operating mode. The configured connections between the function blocks have been made.
SET_FSTATE	AUTO - OOS	This parameter can be used to manually enable the security behaviour of the Discrete Output function block. Options: UNINITIALIZED OFF SET (security behaviour enabled)  Note! The security behaviour of the Discrete Output function block can be manually disabled via the CLR_FSTATE parameter, (see Page 92).
SHED_RCAS	AUTO - OOS	Specifies the monitoring time for checking the connection between the fieldbus host system and the PID function block in the RCAS operating mode. On expiry of the monitoring time, the PID function block switches from the RCAS operating mode to the operating mode selected in the SHED_OPT parameter, (see Page 214). Factory setting: 640000 $\frac{1}{32}$ ms

Resource Block / base index 258		
Parameter	Write access with operating mode (MODE_BLK)	Description
SHED_ROUT	AUTO - OOS	Specifies the monitoring time for checking the connection between the fieldbus host system and the PID function block in the ROUT operating mode. On expiry of the monitoring time, the PID function block switches from the ROUT operating mode to the operating mode selected in the SHED_OPT parameter, (see Page 214). Factory setting: 640000 $\frac{1}{32}$ ms
STRATEGY	AUTO - OOS	Parameter for grouping and thus faster evaluation of blocks. Grouping is carried out by entering the same numerical value in the STRATEGY parameter of each individual block. Factory setting: 0  Note! These data are neither checked nor processed by the Resource Block.
ST_REV	read only	Displays the revision status of the static data.  Note! The revision status is incremented on each modification of static data.
TAG_DESC	AUTO - OOS	Entry of a user-specific text of max. 32 characters for unique identification and assignment of the block. Factory setting: " _ _ _ _ _ " no text
TEST_RW	AUTO - OOS	 Note! This parameter is required only for the FF-conformance test and is not significant in normal operation.
UPDATE_EVT	read only	Displays whether static block data have been modified, including date and time.
WRITE_ALM	AUTO - OOS	Displays the status of the write protection alarm.  Note! • The alarm is triggered if the write protection is disabled. • If the option of the alarm has not been enabled in the ACK_OPTION parameter, the alarm can only be acknowledged via this parameter.

Resource Block / base index 258		
Parameter	Write access with operating mode (MODE_BLK)	Description
WRITE_LOCK	read only	Displays the status of the hardware write protection. Display: UNINITIALIZED LOCKED It is not possible to write to the device via the FOUNDATION Fieldbus. NOT LOCKED Device data can be modified via the FOUNDATION Fieldbus.  Note! For information on hardware write protection configuration, see the Operating Instructions for PROline Prosonic Flow 93 FOUNDATION Fieldbus, BA078D/06/en, Section 5.4.
WRITE_PRI	AUTO - OOS	Specifies the action taken in the event of a write protection alarm, (WRITE_ALM parameter, see Page 97). User input: 0 The write protection alarm is not evaluated. 1 No report to the fieldbus host system in the event of a write protection alarm. 2 Reserved for block alarms. 3-7 The write protection alarm is output with the appropriate priority (3 = low priority, 7 = high priority) to the fieldbus host system as a user notice. 8-15 The write protection alarm is output with the appropriate priority (8 = low priority, 15 = high priority) to the fieldbus host system as a critical alarm. Factory setting: 0

Resource Block / base index 258		
Parameter	Write access with operating mode (MODE_BLK)	Description
<i>Endress+Hauser parameters (manufacturer-specific)</i>		
Sensor - Serial Number	read only	Displays the sensor serial number.
Amplifier - HW-Revision No.	read only	Displays the hardware revision number of the amplifier.
Amplifier - HW-Identification	read only	Displays the hardware ID number of the amplifier.
Amplifier - SW-Revision No.	read only	Displays the software revision number of the amplifier.
Amplifier - SW-Identification	read only	Displays the software ID number of the amplifier.
Amplifier - Production-No.	read only	Displays the production number of the amplifier.
Amplifier - SW-Revision No. T-DAT	read only	Displays the software revision number of the software used to create the content of the T-DAT.
I/O Module - Type	read only	Displays the I/O module type.
I/O Module - HW-Revision No.	read only	Displays the hardware revision number of the I/O module.
I/O Module - HW-Identification	read only	Displays the hardware ID number of the I/O module.
I/O Module - SW-Revision No.	read only	Displays the software revision number of the I/O module.
I/O Module - SW-Identification	read only	Displays the software ID number of the I/O module.
I/O Module - Production-No.	read only	Displays the production number of the I/O module.

3 Transducer Blocks (transmission blocks)

3.1 Overview

PROline Prosonic Flow 93 FOUNDATION Fieldbus's Transducer Blocks contain all the measuring and device-specific parameters of the flowmeter. The settings directly connected with flow measurement or the application are made here. They form the interface between sensor-specific measured value preprocessing and the Analog Input function blocks required for automation.

The Transducer Blocks allow you to influence the input and output values of the function blocks. The parameters of a Transducer Block include information on the sensor type, sensor configuration, physical units, calibration, damping, diagnosis, etc. as well as the device-specific parameters.

The device-specific parameters and functions of PROline Prosonic Flow 93 FOUNDATION Fieldbus are divided among several Transducer Blocks which cover different tasks. The Figure 2 on Page 101 shows the internal structure of the various Transducer Blocks:

TRANSDUCER_CH1 (flow channel 1) / base index 1200:

All flow-specific parameters and functions, (such as adjustment functions, sensor data etc.), for the first channel are located in this block → Page 109.

TRANSDUCER_CH2 (flow channel 2) / base index 1300:

All flow-specific parameters and functions, (such as adjustment functions, sensor data etc.), for the second channel are located in this block → Page 109.

TRANSDUCER_DISP (display) / base index 1500:

All parameters for configuring the local display are located in this block → Page 129.

TRANSDUCER_TOT (totalizer) / base index 1550:

All parameters for configuring the totalizers are located in this block → Page 148.

TRANSDUCER_DIAG (diagnosis) / base index 1600:

All parameters for system diagnosis, (such as current system status etc.), are located in this block → Page 156.

TRANSDUCER_SERV (service) / base index 1650:

All parameters for servicing are located in this block → Page 159.




Fig. 2: Structure and function of the individual Transducer Blocks

3.2 Signal processing

The Transducer Blocks TRANSDUCER_CH1 (flow channel 1, base index 1200) and TRANSDUCER_CH2 (flow channel 2, base index 1300) receive several signal variables as input values from the sensor, (sound velocity, flow velocity). Other process variables are derived from these signal variables, (see Section 3.3 Block output values). The input signals are prepared for measuring via the amplifier.

The "Simulation - Value Measurand" parameter (see Page 128) allows you to specify a simulation value for the Transducer Block TRANSDUCER_CH1 (base index 1200) or TRANSDUCER_CH2 (base index 1300) in order to test assigned parameters in the device and subsequent function blocks.

A low flow cut off allows you to hide measurement inaccuracies in the low flow range. The "Low Flow Cut Off - On Value" parameter (see Page 114) allows you to define a limit value.

If the measured flow value undershoots this limit value, the output value of "0" is output. In addition, the "System Param. - Positive Zero Return" parameter (see Page 113) allows you to switch the measured value to "0". This is necessary when the piping system is being cleaned, for example.

The Transducer Blocks TRANSDUCER_CH1 (flow channel 1, base index 1200) and TRANSDUCER_CH2 (flow channel 2, base index 1300) make the following process variables available to the downstream function blocks.

- Volume flow channel 1 and volume flow channel 2
- Sound velocity channel 1 and sound velocity channel 2
- Flow velocity channel 1 and flow velocity channel 2
- Signal strength channel 1 and signal strength channel 2

If the device operates in two-channel mode, the following calculated process variables are also made available:

- Average volume flow
- Volume flow sum
- Volume flow difference
- Average sound velocity
- Average flow velocity

A process variable (e.g. volume flow channel 1, etc.) can be assigned to each individual totalizer in the Transducer Block TRANSDUCER_TOT (totalizer, base index 1550). The totalizers are also configured here. In this way, for example, all totalizers can be reset simultaneously by means of the "Totalizer Handling - Reset All" parameter.

You will find an overview of all the block output values on Page 103.

The Transducer Block TRANSDUCER_DIAG (diagnosis, base index 1600) contains all the parameters necessary for the diagnosis and maintenance of the device. For example, the "Diagnosis - Actual System Condition" parameter (see Page 156) displays the current system status or detailed information on the cause of an error if an error occurs.

If the device is equipped with a local display, various display parameters, such as the UI language, contrast etc., can be configured via the Transducer Block TRANSDUCER_DISP (display, base index 1500).



Note!

The Transducer Blocks TRANSDUCER_DIAG (diagnosis, base index 1600) and TRANSDUCER_DISP (display, base index 1500) do not have any output values, i.e. they only have an effect on the device itself.

The most important functions and parameters of the Transducer Block are listed below. An overview of all the parameters available is provided from Page 106 onwards.

3.3 Block output values

The Transducer Blocks make the following output values (process variables) available to the downstream Analog Input function blocks:

- Transducer Block TRANSDUCER_CH1 (flow channel 1, base index 1200):
 - Volume flow channel 1
 - Sound velocity channel 1
 - Flow velocity channel 1
 - Signal strength channel 1
- Transducer Block TRANSDUCER_CH2 (flow channel 2, base index 1300):
 - Volume flow channel 2
 - Sound velocity channel 2
 - Flow velocity channel 2
 - Signal strength channel 2
- Transducer Block TRANSDUCER_CH1 and TRANSDUCER_CH2:
 - Average volume flow
 - Volume flow sum
 - Volume flow difference
 - Average sound velocity
 - Average flow velocity
- Transducer Block TRANSDUCER_TOT (flow channel 2, base index 1550):
 - Totalizer 1
 - Totalizer 2
 - Totalizer 3
- The Transducer Blocks TRANSDUCER_DISP (display, base index 1500), TRANSDUCER_DIAG (diagnosis, base index 1600) and TRANSDUCER_SERV (service, base index 1650) do not have any output values.

The CHANNEL parameter in the Analog Input function block, (see Page 171), is used to assign the process variable which is read into and processed in the downstream Analog Input function block.

The Transducer Block(s) in question must be in AUTO (automatic) mode for the process variable to be processed correctly in the downstream Analog Input function block.

Transducer Block:	Base index	Operating mode	Process variable:	Parameter CHANNEL (AI fct. block)
TRANSDUCER_CH1	1200	AUTO	Volume flow channel 1	2
			Sound velocity channel 1	21
			Flow velocity channel 1	23
			Signal strength channel 1	30
TRANSDUCER_CH2	1300	AUTO	Volume flow channel 2	20
			Sound velocity channel 2	22
			Flow velocity channel 2	24
			Signal strength channel 2	31
TRANSDUCER_CH1 + TRANSDUCER CH2	1200 + 1300	AUTO	Average volume flow	25
		AUTO	Volume flow sum	26
			Volume flow difference	27
			Average sound velocity	28
			Average flow velocity	29
TRANSDUCER_TOT	1550	AUTO	Totalizer 1	7
			Totalizer 2	8
			Totalizer 3	9

3.4 Selecting the operating mode

The operating mode is set by means of the MODE_BLK parameter group, (see Page 107). The Transducer Blocks support the following operating modes:

- AUTO (automatic mode)
- OOS (out of service).



Note!

- The OOS operating mode is also displayed via the BLOCK_ERR parameter, (see Page 107). In the OOS operating mode, you can access all the write parameters without restriction if write protection is not enabled and the release code is entered, ("Un-/Locking - Access Code" parameter).
- The following applies to the Transducer Blocks TRANSDUCER_CH1 (flow channel 1, base index 1200), TRANSDUCER_CH2 (flow channel 2, base index 1300) and TRANSDUCER_TOT (totalizer, base index 1550):
 - In the "OOS" operating mode, the process variables are updated but the status of the OUT output value of the downstream Analog Input function block changes to "BAD".
 - The Transducer Block(s) in question must be in AUTO (automatic) mode for the process variable to be processed correctly in the downstream Analog Input function block.
- Please refer to the Operating Instructions for PROline Prosonic Flow 93 FOUNDATION Fieldbus, BA078D/06/en, if problems arise when configuring the function blocks.

3.5 Alarm detection and processing

The Transducer Blocks do not generate any process alarms. The status of the process variables is evaluated in the downstream Analog Input function blocks.

A process alarm is generated if the Analog Input function block receives an input value which cannot be evaluated from the Transducer Blocks TRANSDUCER_CH1 (flow channel 1, base index 1200), TRANSDUCER_CH2 (flow channel 2, base index 1300) or TRANSDUCER_TOT (totalizer, base index 1550). This process alarm is displayed in the BLOCK_ERR parameter of the Analog Input function block, (BLOCK_ERR = Input Failure).

The BLOCK_ERR parameter (see Page 107) of the Transducer Block TRANSDUCER_DIAG (base index 1600) displays the device error that produced the input value that could not be evaluated and thus triggered the process alarm in the Analog Input function block.

Detailed information on the current device status and any pending errors is shown in the Transducer Block TRANSDUCER_DIAG (base index 1600) in the "Diagnosis - Actual System Condition" parameter, (see Page 156).

More information on eliminating errors can be found in the Operating Instructions for PROline Prosonic Flow 93 FOUNDATION Fieldbus, BA078D/06/en.

3.6 Diagnosis

The status of the device is displayed via the BLOCK_ERR (see Page 107) and "Transducer Error" (see Page 108) parameters (specified in the FOUNDATION Fieldbus Specification) of the Transducer Block TRANSDUCER_DIAG (diagnosis, base index 1600).



Note!

Although these parameters are available in other Transducer Blocks, the correct values are only displayed in the Transducer Block TRANSDUCER_DIAG (diagnosis, base index 1600).

Detailed information on the current device status and any pending errors is shown in the Transducer Block TRANSDUCER_DIAG (base index 1600) in the "Diagnosis - Actual System Condition" parameter, (see Page 156). More information on eliminating errors can be found in the Operating Instructions for PROline Prosonic Flow 93 FOUNDATION Fieldbus, BA 078D/06/en.

3.7 Access to manufacturer-specific parameters

To access the manufacturer-specific parameters, the following requirements must be met:

1. Hardware write protection must be disabled (see Operating Instructions for PROline Prosonic Flow 93 FOUNDATION Fieldbus, BA078D/06/en, Section 5.4).
2. The correct code must be entered in the "Un/Locking - Access Code" parameter, (see Page 109).

3.8 FOUNDATION Fieldbus parameters of the Transducer Blocks

The following table provides you with a description of all the specified FOUNDATION Fieldbus parameters of the Transducer Blocks. The E+H-specific parameters are explained from Page 109 onwards.

FOUNDATION Fieldbus parameters (Transducer Blocks, transmission blocks)		
Parameter	Write access with operating mode (MODE_BLK)	Description
ST_REV	read only	Displays the revision status of the static data.  Note! The revision status parameter is incremented on each modification of static data.
TAG_DESC	AUTO - OOS	Entry of a user-specific text of max. 32 characters for unique identification and assignment of the block. Factory setting: (____) no text
STRATEGY	AUTO - OOS	Parameter for grouping and thus faster evaluation of blocks. Grouping is carried out by entering the same numerical value in the STRATEGY parameter of each individual block. Factory setting: 0  Note! These data are neither checked nor processed by the Transducer Blocks.
ALERT_KEY	AUTO - OOS	Entry of the identification number of the plant unit. This information can be used by the fieldbus host system for sorting alarms and events. User input: 1...255 Factory setting: 0

FOUNDATION Fieldbus parameters (Transducer Blocks, transmission blocks)		
Parameter	Write access with operating mode (MODE_BLK)	Description
MODE_BLK	AUTO - OOS	Displays the current (Actual) and desired (Target) operating mode of the relevant Transducer Block, the permitted modes (Permitted) supported by the Transducer Block in question and the normal operating mode (Normal). Display: AUTO OOS  Note! The Transducer Blocks support the following operating modes: • AUTO (automatic mode): The block is executed. • OOS (out of service): The block has the status "Out of Service". In the "OOS" operating mode, the process variables are updated but the status of the OUT output value (of the downstream Analog Input function block) changes to "BAD".
BLOCK_ERR	read only	Displays the active block error.  Note! This parameter is available in all Transducer Blocks. However, the block errors (apart from "OUT OF SERVICE") are only displayed via the BLOCK_ERR parameter of the Transducer Block TRANSDUCER_DIAG (diagnosis, base index 1600). Display: OUT OF SERVICE The block is in the "Out of Service" operating mode. SIMULATION ACTIVE Simulation is active via the "Simulation - Measurand" parameter (see Page 128) in the Transducer Block TRANSDUCER_CH1 (flow channel 1, base index 1200) or TRANSDUCER_CH2 (flow channel 2, base index 1300). DEVICE NEEDS MAINTENANCE NOW The device needs to be checked since an active device error is pending. The cause of the error can be viewed in detail via the "Diagnosis - Actual System Condition" parameter in the Transducer Block TRANSDUCER_DIAG (diagnosis, base index 1600), (see Page 156).
UPDATE_EVT	AUTO - OOS	Displays whether static block data have been modified, including date and time.

FOUNDATION Fieldbus parameters (Transducer Blocks, transmission blocks)		
Parameter	Write access with operating mode (MODE_BLK)	Description
BLOCK_ALM	AUTO - OOS	Displays the current block status with information on pending configuration, hardware or system errors, including details of the alarm time (date, time) when the error occurred.  Note! - In addition, the active block alarm can be acknowledged in this parameter group. - PROline Prosonic Flow 93 FF does not use this parameter to display a process alarm since these are generated in the BLOCK_ALM parameter of the Analog Input function block, (see Page 169).
Transducer Type	read only	Displays the Transducer Block type. Display: Standard flow with calibration
Transducer Error	read only	Displays the active device error.  Note! This parameter is available in all Transducer Blocks. However, the device errors (apart from "No Error") are only displayed via the BLOCK_ERR parameter of the Transducer Block TRANSDUCER_DIAG (diagnosis, base index 1600). Possible display: - No Error (normal state) - Electronis Failure - Data Integrity Error - Mechanical Error - Configuration Error - General Error  Note! - Display of the device error is standardised. Precise information on the pending error is available via the manufacturer-specific error display which can be read in the "Diagnosis - Actual System Condition" parameter in the Transducer Block TRANSDUCER_DIAG (diagnosis, base index 1600). - A precise error description as well as notes on fault elimination can be found in the Operating Instructions for PROline Prosonic Flow 93 FF, BA 078D/06/en.

3.9 Overview of Transducer Blocks with E+H parameters

Here you can find all the E+H-specific parameters of the Transducer Blocks:

- TRANSDUCER_CH1 (flow channel 1) → Page 109
- TRANSDUCER_CH2 (flow channel 2) → Page 109
- TRANSDUCER_DISP (display) → Page 129
- TRANSDUCER_TOT (totalizer) → Page 148
- TRANSDUCER_DIAG (diagnosis) → Page 156
- TRANSDUCER_SERV for servicing purposes only - is not explained here.

3.10 E+H parameters of the Transducer Blocks: “TRANSDUCER_CH1” (flow channel 1) and “TRANSDUCER_CH2” (flow channel 2)

The following table lists all the E+H-specific parameters of the Transducer Blocks “TRANSDUCER_CH1” (flow channel 1) and “TRANSDUCER_CH2” (flow channel 2). The conditions which have to be met before changing these parameters are provided on Page 105.


“TRANSDUCER_CH1” and “TRANSDUCER_CH2” (E+H parameters) / Base index 1200 and 1300		
Parameter	Write access with operating mode (MODE_BLK)	Description
 Note! A description of the FOUNDATION Fieldbus parameters of this block is provided on Page 106.		
Un-/Locking - Access Code	AUTO - OOS	All data of the measuring system are protected against inadvertent change. Only when the code has been entered in this parameter can the manufacturer-specific parameters (E+H parameters) be programmed and the device configuration modified. You can enable programming by entering: • Code 93 (factory setting) • Personal code (see Page 129) User input: Max. 4-digit number (0...9999)  Note! • If write protection is enabled, access to the manufacturer-specific parameters is blocked even if the right code is entered. (More detailed information on write protection is provided in the Operating Instructions for PROline Prosonic Flow 93 FOUNDATION Fieldbus, BA078D/06/en, Section 5.4). • You can disable programming again by entering any number (other than the access code) in this parameter. • The E+H service organisation can be of assistance if you mislay your personal code. • The entry made here does not affect the local display. Therefore programming via the function matrix must be enabled separately.
Un-/Locking - Access Status	read only	Displays the current status of access to the manufacturer-specific parameters of the device. Display: • LOCKED (parameters cannot be modified) • ACCESS CUSTOMER (parameters can be modified)

“TRANSDUCER_CH1” and “TRANSDUCER_CH2” (E+H parameters) / Base index 1200 and 1300		
Parameter	Write access with operating mode (MODE_BLK)	Description
System Value - Volume Flow	read only	Displays the current volume flow. The volume flow is made available to the downstream Analog Input function blocks as a process variable.  Note! The unit is selected and displayed in the “System Unit - Volume Flow” parameter.
System Unit - Volume Flow	AUTO - OOS	For selecting the unit required for the volume flow. The unit you select here is also valid for: • Switch points (limit value, flow direction) • Low flow cut off Options:  Note! The following units of time can be selected: s = second, m = minute, h = hour, d = day <i>Metric:</i> Cubic centimetre → cm³/... Cubic decimetre → dm³/... Cubic metre → m³/... Millilitre → ml/... Litre → l/... Hectolitre → hl/... Megalitre → Ml/... MEGA <i>US:</i> Cubic centimetre → cc/... Acre foot → af/... Cubic foot → ft³/... Fluid ounce → oz f/... Gallon → US gal/... Million gallon → US Mgal/... Barrel (normal fluids: 31.5 gal/bbl) → US bbl/... NORM. Barrel (beer: 31.0 gal/bbl) → US bbl/... BEER Barrel (petrochemicals: 42.0 gal/bbl) → US bbl/... PETR. Barrel (filling tanks: 55.0 gal/bbl) → US bbl/... TANK <i>Imperial:</i> Gallon → imp. gal/... Mega gallon → imp. Mgal/... Barrel (beer: 36.0 gal/bbl) → imp. bbl/... BEER Barrel (petrochemicals: 34.97 gal/bbl) → imp. bbl/... PETR. Factory setting: Depends on country (dm³/m...m³/h or US gal/m...US Mgal/d)  Note! The unit selected here has no effect on the desired volume unit which should be transmitted via the FF interface. This setting is made separately via the appropriate Analog Input function block in the XD_SCALE parameter group, (see Page 180).


“TRANSDUCER_CH1” and “TRANSDUCER_CH2” (E+H parameters) / Base index 1200 and 1300		
Parameter	Write access with operating mode (MODE_BLK)	Description
System Value - Sound Velocity	read only	Displays the current sound velocity. The sound velocity is made available to the downstream Analog Input function blocks as a process variable.  Note! The unit is selected and displayed in the “System Unit - Sound Velocity” parameter.
System Unit - Sound Velocity	AUTO - OOS	For selecting the unit for the sound velocity. Options: m/s ft/s Factory setting: m/s
System Value - Flow Velocity	read only	Displays the current flow velocity. The flow velocity is made available to the downstream Analog Input function blocks as a process variable.  Note! The unit is selected and displayed in the “System Unit - Flow Velocity” parameter.
System Unit - Flow Velocity	AUTO - OOS	For selecting the unit for the flow velocity. Options: m/s ft/s Factory setting: m/s
System Value - Signal Strength	read only	Displays the current signal strength. The signal strength is made available to the downstream Analog Input function blocks as a process variable.
System Unit - Temperature	AUTO - OOS	For selecting the unit for the fluid temperature. Options: °C (Celsius) K (Kelvin) °F (Fahrenheit) R (Rankine) Factory setting: Depends on country (°C or °F), see factory setting Page 76 ff.

“TRANSDUCER_CH1” and “TRANSDUCER_CH2” (E+H parameters) / Base index 1200 and 1300		
Parameter	Write access with operating mode (MODE_BLK)	Description
System Unit - Viscosity	AUTO - OOS	For selecting the unit for the viscosity of the fluid. Options: mm²/s cSt St Factory setting: mm²/s
System Unit - Length	AUTO - OOS	For selecting the unit for the measure of length. The unit you select here is valid for: • Nominal diameter • Diameter • Wall thickness • Liner thickness • Path length • Wire length • Sensor distance Options: MILLIMETER INCH Factory setting: Depends on country (MILLIMETER or INCH), see factory setting Page 76 ff..
System Param. - Installation Direction Sensor	AUTO - OOS	This parameter can be used to reverse the sign of the flow rate variable, if necessary. Options: NORMAL (FORWARD) INVERSE (REVERSE) Factory setting: NORMAL (FORWARD)
System Param. - Flow Damping	AUTO - OOS	 Note! System damping acts on all functions of the measuring device. Specifies the filter depth of the digital filter. This reduces the sensitivity of the measuring signal to interference peaks (e.g. high solids content, gas bubbles in the fluid, etc.). The measuring system reaction time increases with the filter setting. The damping acts on all parameters and all downstream function blocks. User input: 0...100 s Factory setting: 0 s

“TRANSDUCER_CH1” and “TRANSDUCER_CH2” (E+H parameters) / Base index 1200 and 1300		
Parameter	Write access with operating mode (MODE_BLK)	Description
System Param. - Positive Zero Return	AUTO - OOS	This parameter can be used to interrupt evaluation of measured variables. This is necessary when a piping system is being cleaned, for example. The setting acts on all parameters and calculations of the measuring device. Options: OFF (signal output not interrupted) ON (signal output is set to the value “0”) Factory setting: OFF  Note! • When positive zero return is active, a flow value of “0” is output via the output value OUT (AI Block). • Active positive zero return is relayed to downstream function blocks or higher-level process control systems by means of the status “UNCERTAIN” for the output value OUT (AI Block). • Positive zero return can be also be controlled using cyclic data transmission via the Discrete Output function block, (see DO function block Page 181).
Adjustment - Adjust Zeropoint	AUTO - OOS	This parameter can be used to start zero point adjustment automatically. The new zero point determined by the measuring system is adopted by the “Calibration Data - Zero Point” parameter, (see Page 126). Options: CANCEL START Factory setting: CANCEL  Caution! Before carrying this out, please refer to the Operating Instructions for <i>PROline Prosonic Flow 93 FOUNDATION Fieldbus</i>, (BA078D/06/en), for a detailed description of the procedure for zero point adjustment.

“TRANSDUCER_CH1” and “TRANSDUCER_CH2” (E+H parameters) / Base index 1200 and 1300		
Parameter	Write access with operating mode (MODE_BLK)	Description
Low Flow Cut Off - Assign	AUTO - OOS	Use this function to assign the switch point for the low flow cut off. Options: OFF VOLUME FLOW Factory setting: OFF
Low Flow Cut Off - On Value	AUTO - OOS	Specifies the switch-on point of the low flow cut off. Low flow cut off is active if the setting is a value not equal to "0". User input: 5-digit floating-point number Factory setting: 0.0000  Note! - A flow value of "0" is output via the output value OUT (AI Block) when the low flow cut off responds. In addition, the status changes to UNCERTAIN. - The unit used is displayed in the "Low Flow Cut Off - Unit" parameter and determined in the "System Unit - Volume Flow" parameter, (see Page 110).
Low Flow Cut Off - Unit	read only	Displays the unit for the low flow cut off.  Note! The unit for the low flow cut off is determined by means of the "System Unit - Volume Flow" parameter, (see Page 110).
Low Flow Cut Off - Off Value	AUTO - OOS	Specifies the switch-off point of the low flow cut off. Enter the switch-off point as a positive hysteresis from the switch-on point. User input: 0...100% Factory setting: 50% Example: Low Flow Cut Off Assign = VOLUME FLOW Low Flow Cut Off Off-Value = 50% Low Flow Cut Off On-Value = 10 Low Flow Cut Off Unit = l/s This results in an off-value of 15 l/s $(10 \text{ l/s} + [10 \text{ l/s} \cdot 0.5] = 15 \text{ l/s})$. 

F06-53xFFxx-05-xx-xx-en-000

“TRANSDUCER_CH1” and “TRANSDUCER_CH2” (E+H parameters) / Base index 1200 and 1300		
Parameter	Write access with operating mode (MODE_BLK)	Description
Pressure Shock Suppression	AUTO - OOS	The closure of a valve can cause brief but severe movements of the liquid in the piping system, movements which the measuring system registers. The pulses totalled in this way result in a totalizer reading error, particularly in the case of batching processes. For this reason, the measuring device is equipped with pressure shock suppression (= short-term signal suppression) which can eliminate system-related “disruptions”.  Note! Pressure shock suppression cannot be used unless the low flow cut off is active, (see "Low Flow Cut Off - On Value" parameter, Page 114). Use this parameter to define the time span for active pressure shock suppression. Activation of the pressure shock suppression Pressure shock suppression is activated after the flow falls below the switch-on point of the low flow cut off, (see point 1 in graphic). While pressure shock suppression is active, the following conditions apply: • Output value OUT of the AI Blocks → Flow value “0” • Flow reading on display → 0. • Totalizer reading → The totalizers are pegged at the last valid value. Deactivation of the pressure shock suppression The pressure shock suppression is deactivated once the time interval set in this parameter has elapsed, (see point 2 in graphic).  Note! The current flow value is only processed and displayed again once the time interval for the pressure shock suppression has elapsed and the flow exceeds the switch-off point for low flow cut off, (see point 3 in graphic).  User input: Max. 4-digit number, incl. unit: 0.00...100.0 s Factory setting: 0.00 s

“TRANSDUCER_CH1” and “TRANSDUCER_CH2” (E+H parameters) / Base index 1200 and 1300		
Parameter	Write access with operating mode (MODE_BLK)	Description
Pipe Data - Pipe Standard	AUTO - OOS	For selecting the standard pipe. Options: OTHERS DIN PN10 DIN PN16 DIN 28610 DIN 28614 DIN 28615 DIN 28619 ANSI SCHEDULE 40 ANSI SCHEDULE 80 AWWA CLASS 50 AWWA CLASS 53 AWWA CLASS 55 Factory setting: DIN PN10
Pipe Data - Nominal Diameter	AUTO - OOS	For selecting the nominal diameter of the pipe. Options: OTHERS DN 25/1IN DN 40/1½IN DN 50/2IN DN 80/3IN DN 100/4IN DN 150/6IN DN 200/8IN DN 250/10IN DN 300/12IN DN 400/16IN DN 450/18IN DN 500/20IN DN 600/24IN DN 700/28IN DN 750/30IN DN 800/32IN DN 900/36IN DN 1000/40IN DN 1200/48IN DN 1400/54IN DN 1500/60IN DN 1600/64IN DN 1800/72IN DN 2000/80IN Factory setting: DN 80/3IN
Pipe Data - Unit Nominal Diameter	read only	Displays the unit used in the “Pipe Data - Nominal Diameter” unit.  Note! The unit is selected in the “System Unit - Length” parameter, see Page 112.

“TRANSDUCER_CH1” and “TRANSDUCER_CH2” (E+H parameters) / Base index 1200 and 1300		
Parameter	Write access with operating mode (MODE_BLK)	Description
Pipe Data - Pipe Material	AUTO - OOS	For selecting the pipe material. Options: CARBON STEEL DUCTILE IRON STAINLESS STEEL SS ANSI 304 SS ANSI 316 SS ANSI 347 SS ANSI 410 SS ANSI 430 HASTELLOY C PVC PE LDPE HDPE GRP PVDF PA PP PTFE GLASS PYREX ASBESTOS CEMENT OTHERS Factory setting: STAINLESS STEEL
Pipe Data - Reference Value	AUTO - OOS	 Note! This parameter is not active unless “Sound Vel. Pipe” was selected in the “Sensor Param. - Measurement” parameter, (see Page 122). Entry of the thickness of the reference component (e.g. flange) which serves as the basis for measuring the sound velocity of the pipes, (see Page 118). User input: 5-digit floating-point number Factory setting: 5 (mm)  Note! The unit used is displayed in the “Pipe Data - Unit Reference Value” parameter.
Pipe Data - Unit Reference Value	read only	Displays the unit for the thickness of the reference component.  Note! The unit is selected in the “System Unit - Length” parameter, see Page 112.

“TRANSDUCER_CH1” and “TRANSDUCER_CH2” (E+H parameters) / Base index 1200 and 1300		
Parameter	Write access with operating mode (MODE_BLK)	Description
Pipe Data - Sound Velocity Pipe	AUTO - OOS	Entry of the sound velocity in the pipe. Measuring the sound velocity in the pipe Measurement can be carried out via: • The local display (“Sensor” Quick Setup), see Page 19. • The configuration and service software FieldTool.  Note! A reference value is used as a basis for measuring the sound velocity. This reference value can be edited, (see Page 117). User input: Fixed-point number 800...6500 (m/s) Factory setting: 3120 (m/s)  Note! The unit used is displayed in the “Pipe Data - Unit Sound Velocity Pipe” parameter.
Pipe Data - Unit Sound Velocity Pipe	read only	Displays the unit for the sound velocity in the pipe.  Note! The unit is selected in the “System Unit - Sound Velocity” parameter, see Page 111.
Pipe Data - Circumference	AUTO - OOS	Entry of the pipe circumference. User input: Fixed-point number 31.4...15708.0 (mm) Factory setting: 279.3 (mm)  Note! The unit used is displayed in the “Pipe Data - Unit Circumference” parameter.
Pipe Data - Unit Circumference	read only	Displays the unit for the pipe circumference.  Note! The unit is selected in the “System Unit - Length” parameter, see Page 112.
Pipe Data - Pipe Diameter	AUTO - OOS	Entry of the pipe diameter. User input: Fixed-point number 10.0...5000.0 (mm) Factory setting: 88.9 (mm)  Note! The unit used is displayed in the “Pipe Data - Unit Pipe Diameter” parameter.

“TRANSDUCER_CH1” and “TRANSDUCER_CH2” (E+H parameters) / Base index 1200 and 1300		
Parameter	Write access with operating mode (MODE_BLK)	Description
Pipe Data - Unit Pipe Diameter	read only	Displays the unit for the pipe circumference.  Note! The unit is selected in the “System Unit - Length” parameter, see Page 112.
Pipe Data - Wall Thickness	AUTO - OOS	Entry of the pipe wall thickness. Measuring the wall thickness Measurement can be carried out via: • The local display (“Sensor” Quick Setup), see Page 19. • The configuration and service software FieldTool. User input: Fixed-point number 0.1...100.0 (mm) Factory setting: 3.2 (mm)  Note! The unit used is displayed in the “Pipe Data - Unit Wall Thickness” parameter.
Pipe Data - Unit Wall Thickness	read only	Displays the unit for the thickness of the pipe wall.  Note! The unit is selected in the “System Unit - Length” parameter, see Page 112.
Pipe Data - Liner Material	AUTO - OOS	For selecting the material with which the pipe is lined. Options: LINER NONE MORTAR RUBBER TAR EPOXY OTHERS Factory setting: LINER NONE
Pipe Data - Sound Velocity Liner	AUTO - OOS	 Note! This parameter is not active unless a liner was selected in the “Pipe Data - Liner Material” parameter. Entry of the sound velocity of the liner. User input: Fixed-point number 800...6500 Factory setting: Depends on the setting selected in the “Pipe Data - Liner Material” parameter.  Note! The unit used is displayed in the “Pipe Data - Unit Sound Velocity Liner” parameter.

“TRANSDUCER_CH1” and “TRANSDUCER_CH2” (E+H parameters) / Base index 1200 and 1300		
Parameter	Write access with operating mode (MODE_BLK)	Description
Pipe Data - Unit Sound Velocity Liner	read only	Displays the unit for the sound velocity of the liner.  Note! The unit is selected in the “System Unit - Sound Velocity” parameter, see Page 111.
Pipe Data - Liner Thickness	AUTO - OOS	 Note! This parameter is not active unless a liner was selected in the “Pipe Data - Liner Material” parameter. Entry of the thickness of the liner. User input: Fixed-point number 0.1...100.0 Factory setting: 0  Note! The unit used is displayed in the “Pipe Data - Unit Liner Thickness” parameter.
Pipe Data - Unit Liner Thickness	read only	Displays the unit for the liner thickness selected in the “Pipe Data - Liner Thickness” parameter.  Note! The unit is selected in the “System Unit - Length” parameter, see Page 112.
Liquid Data - Liquid	AUTO - OOS	For selecting the liquid in the pipe. Options: WATER SEAWATER DEST. WATER (distilled water) AMMONIA ALCOHOL BENZENE BROMIDE ETHANOL GLYCOL KEROSENE MILK METHANOL TOLUOL LUBE OIL FUEL OIL PETROL OTHERS Factory setting: WATER

“TRANSDUCER_CH1” and “TRANSDUCER_CH2” (E+H parameters) / Base index 1200 and 1300		
Parameter	Write access with operating mode (MODE_BLK)	Description
Liquid Data - Temperature	AUTO - OOS	Entry of the liquid temperature. User input: Fixed-point number -273.15...726.85 °C (0...1000 K) Factory setting: 20  Note! The unit used is displayed in the “Liquid Data - Unit Temperature” parameter.
Liquid Data - Unit Temperature	read only	Displays the unit for the liquid temperature selected in the “Liquid Data - Temperature” parameter.  Note! The unit is selected in the “System Unit - Temperature” parameter, see Page 111.
Liquid Data - Sound Velocity Liquid	AUTO - OOS	Entry of the sound velocity of the liquid. Measuring the sound velocity of the liquid Measurement can be carried out via: • The local display (“Sensor” Quick Setup), see Page 19. • The configuration and service software FieldTool. User input: Fixed-point number 400...3000 Factory setting: 1487  Note! The unit used is displayed in the “Liquid Data - Unit Sound Velocity Liquid” parameter.
Liquid Data - Unit Sound Velocity Liquid	read only	Displays the unit for the liquid sound velocity selected in the “Liquid Data - Sound Velocity Liquid” parameter.  Note! The unit is selected in the “System Unit - Sound Velocity” parameter, see Page 111.
Liquid Data - Min. Sound Velocity Liquid	AUTO - OOS	Entry of the minimum sound velocity of the liquid. User input: Fixed-point number 400...3000 Factory setting: 800  Note! The unit used is displayed in the “Liquid Data - Unit Min. Sound Velocity Liquid” parameter.

“TRANSDUCER_CH1” and “TRANSDUCER_CH2” (E+H parameters) / Base index 1200 and 1300		
Parameter	Write access with operating mode (MODE_BLK)	Description
Liquid Data - Unit Min. Sound Velocity Liquid	read only	Displays the unit for the minimum liquid sound velocity selected in the “Liquid Data - Min. Sound Velocity Liquid” parameter.  Note! The unit is selected in the “System Unit - Sound Velocity” parameter, see Page 111.
Liquid Data - Max. Sound Velocity Liquid	AUTO - OOS	Entry of the maximum sound velocity of the liquid. User input: Fixed-point number 400...3000 Factory setting: 1800  Note! The unit used is displayed in the “Liquid Data - Unit Max. Sound Velocity Liquid” parameter.
Liquid Data - Unit Max. Sound Velocity Liquid	read only	Displays the unit for the maximum liquid sound velocity selected in the “Liquid Data - Max. Sound Velocity Liquid” parameter.  Note! The unit is selected in the “System Unit - Sound Velocity” parameter, see Page 111.
Sensor Param. - Measurement	AUTO - OOS	For selecting which measurement method should be used. Options: OFF CLAMP ON INSERTION Factory setting for channel 1: CLAMP ON Factory setting for channel 2: OFF  Caution! Although the following options also appear in this parameter, they can only be selected by means of the local display (see Page 63) or the configuration and service software FieldTool: • SOUND VEL. LIQUID (liquid sound velocity) • SOUND VEL. PIPE (pipe sound velocity) • WALL THICKNESS

“TRANSDUCER_CH1” and “TRANSDUCER_CH2” (E+H parameters) / Base index 1200 and 1300		
Parameter	Write access with operating mode (MODE_BLK)	Description
Sensor Param. - Sensor Type	AUTO - OOS	 Note! This parameter is only active if "OFF" was not selected in the "Sensor Param. - Measurement" parameter. Sensor type selection. The options in this parameter depend on the measurement method selected in the "Sensor Param. - Measurement" parameter, (see Page 122). Options: (if "CLAMP ON" was selected in the "Sensor Param. - Measurement" parameter) W-CL-05F-L-B W-CL-1F-L-B W-CL-2F-L-B P-CL-05F-L-B P-CL-1F-L-B P-CL-2F-L-B P-CL-05F-M-B P-CL-1F-M-B P-CL-2F-M-B U-CL-2F-L-A Options: (if "INSERTION" was selected in the "Sensor Param. - Measurement" parameter) W-IN-1F-L-B Factory setting: W-CL-2F-L-B  Caution! Although the following options also appear in this parameter, they can only be selected by means of the local display (see Page 64) or the configuration and service software FieldTool: • P-CL-1S-L-B • P-CL-1S-M-B • P-CL-4W-L-B

“TRANSDUCER_CH1” and “TRANSDUCER_CH2” (E+H parameters) / Base index 1200 and 1300		
Parameter	Write access with operating mode (MODE_BLK)	Description
Sensor Param. - Sensor Configuration	AUTO - OOS	 Note! This parameter is not active unless one of the following options was selected in the “Sensor Param. - Measurement” parameter. • CLAMP ON • INSERTION Use this parameter to select the configuration for the ultrasonic sensors, e.g. the number of traverses (in the Clamp On version) or whether single-path or dual-path configuration is present (in the Insertion version) The options in this parameter depend on the measurement method selected in the “Sensor Param. - Measurement” parameter, (see Page 122). Options: (if “CLAMP ON” was selected in the “Sensor Param. - Measurement” parameter) NO. TRAVERSE: 1 NO. TRAVERSE: 2 NO. TRAVERSE: 3 NO. TRAVERSE: 4 Options: (if “INSERTION” was selected in the “Sensor Param. - Measurement” parameter) SINGLE PATH DUAL PATH Factory setting: NO. TRAVERSE: 2
Sensor Param. - Cable Length	AUTO - OOS	For selecting the length of the sensor cable. Options: LEN. 5m/15 feet LEN. 10m/30 feet LEN. 15m/45 feet LEN. 30m/90 feet Factory setting: LEN. 5m/15 feet
Sensor Param. - Position Sensor	read only	 Note! This parameter is not active unless “CLAMP ON” was selected in the “Sensor Param. - Measurement” parameter and the number of traverses in the “Sensor Param. - Sensor Configuration” parameter is 2 or 4. Displays the position of both sensors on the rail. Display: 5-digit number combination

“TRANSDUCER_CH1” and “TRANSDUCER_CH2” (E+H parameters) / Base index 1200 and 1300		
Parameter	Write access with operating mode (MODE_BLK)	Description
Sensor Param. - Wire Length	read only	 Note! This parameter is not active unless "CLAMP ON" was selected in the "Sensor Param. - Measurement" parameter and the number of traverses in the "Sensor Param. - Sensor Configuration" parameter is 1 or 3. Displays the wire length for mounting the sensors at the correct distance. Display: Max. 5-digit number  Note! The unit used is displayed in the "Sensor Param. - Unit Wire Length" parameter.
Sensor Param. - Unit Wire Length	read only	Displays the unit used for the display in the "Sensor Param. - Wire Length" parameter.  Note! The unit is selected in the "System Unit - Length" parameter, see Page 112.
Sensor Param. - Sensor Distance	read only	Displays the distance between sensor 1 and sensor 2 as a length measurement. Display: Max. 5-digit number  Note! The unit used is displayed in the "Sensor Param. - Unit Sensor Distance" parameter.
Sensor Param. - Unit Sensor Distance	read only	Displays the unit used for the display in the "Sensor Param. - Sensor Distance" parameter.  Note! The unit is selected in the "System Unit - Length" parameter, see Page 112.
Sensor Param. - ARC Length	read only	 Note! This parameter is not active unless "INSERTION" was selected in the "Sensor Param. - Measurement" parameter and "DUAL PATH" was selected in the "Sensor Param. - Sensor Configuration" parameter. Displays the arc length on the pipe. Display: Max. 5-digit number  Note! The unit used is displayed in the "Sensor Param. - Unit ARC Length" parameter.

“TRANSDUCER_CH1” and “TRANSDUCER_CH2” (E+H parameters) / Base index 1200 and 1300		
Parameter	Write access with operating mode (MODE_BLK)	Description
Sensor Param. - Unit ARC Length	read only	Displays the unit used for the display in the “Sensor Param. - ARC Length” parameter.  Note! The unit is selected in the “System Unit - Length” parameter, see Page 112.
Sensor Param. - Path Length	read only	 Note! This parameter is not active unless "INSERTION" was selected in the “Sensor Param. - Measurement” parameter. Displays the path length. Display: Max. 5-digit number  Note! The unit used is displayed in the “Sensor Param. - Unit Path Length” parameter.
Sensor Param. - Unit Path Length	read only	Displays the unit used for the display in the “Sensor Param. - Path Length” parameter.  Note! The unit is selected in the “System Unit - Length” parameter, see Page 112.
Calibration Data - Calibration Factor	read only	Displays the current calibration factor for the sensors.
Calibration Data - Zero Point	AUTO - OOS	For displaying or manually changing the value for the zero point correction currently used. User input: 5-digit floating-point number, including unit and sign (e.g. +10.0 ns)
Calibration Data - Correction Factor	AUTO - OOS	Entry of a correction factor defined by the customer. User input: 5-digit floating-point number
Calibration Data - Deviation Sensor Distance	AUTO - OOS	 Note! This parameter is not active unless "INSERTION" was selected in the “Sensor Param. - Measurement” parameter. Entry of the sensor distance deviation. User input: 5-digit floating-point number Factory setting: 0  Note! The unit used is displayed in the “Calibration Data - Unit Deviation Sensor Distance” parameter.

“TRANSDUCER_CH1” and “TRANSDUCER_CH2” (E+H parameters) / Base index 1200 and 1300		
Parameter	Write access with operating mode (MODE_BLK)	Description
Calibration Data - Unit Deviation Sensor Distance	read only	Displays the unit used for the entry in the “Calibration Data - Deviation Sensor Distance” parameter.  Note! The unit is selected in the “System Unit - Length” parameter, see Page 112.
Calibration Data - Deviation ARC Length	AUTO - OOS	 Note! This parameter is not active unless "INSERTION" was selected in the “Sensor Param. - Measurement” parameter and "DUAL PATH" was selected in the “Sensor Param. - Sensor Configuration” parameter. Entry of the arc length deviation. User input: 5-digit floating-point number Factory setting: 0  Note! The unit used is displayed in the “Calibration Data - Unit Deviation ARC Length” parameter.
Calibration Data - Unit Deviation ARC Length	read only	Displays the unit used for the entry in the “Calibration Data - Deviation ARC Length” parameter.  Note! The unit is selected in the “System Unit - Length” parameter, see Page 112.
Calibration Data - Deviation Path Length	AUTO - OOS	 Note! This parameter is not active unless "INSERTION" was selected in the “Sensor Param. - Measurement” parameter. Entry of the path length deviation. User input: 5-digit floating-point number Factory setting: 0  Note! The unit used is displayed in the “Calibration Data - Unit Deviation Path Length” parameter.
Calibration Data - Unit Deviation Path Length	read only	Displays the unit used for the entry in the “Calibration Data - Deviation Path Length” parameter.  Note! The unit is selected in the “System Unit - Length” parameter, see Page 112.

“TRANSDUCER_CH1” and “TRANSDUCER_CH2” (E+H parameters) / Base index 1200 and 1300		
Parameter	Write access with operating mode (MODE_BLK)	Description
Simulation - Measurand	AUTO - OOS	For activating the simulation for the volume flow. Options: OFF VOLUME FLOW Factory setting: OFF  Caution! • The measuring device cannot be used for measuring while this simulation is in progress. • The simulation functions independently of the position of the relevant jumpers on the I/O board, (see Operating Instructions for PROline Prosonic Flow 93 FOUNDATION Fieldbus, BA078D/06/en, Section 5.4). • The setting is not saved if the power supply fails.  Note! Active simulation is relayed to downstream function blocks or higher-level process control systems by means of the status “UNCERTAIN” for the output value OUT (AI Block).
Simulation - Value Measurand	AUTO - OOS	This parameter can be used to specify a selectable value (e.g. 12 m³/s). This is used to test the assigned parameters in the flowmeter itself and downstream function blocks. User input: 5-digit floating-point number Factory setting: 0  Note! The unit used is displayed in the “Simulation - Unit” parameter.  Caution! The setting is not saved if the power supply fails.
Simulation - Unit	read only	Displays the unit used in the “Simulation - Value Measurand” parameter.  Note! The unit is taken from the “System Unit - Volume Flow” parameter, (see Page 110).
Amp. Device Family	read only	This parameter is only used in the event of servicing.


3.11 E+H parameters: Transducer Block “TRANSDUCER_DISP” (display)

The following table lists all the E+H-specific parameters of the Transducer Block “TRANSDUCER_DISP” (display). The conditions which have to be met before changing these parameters are provided on Page 105.

“TRANSDUCER_DISP” (E+H parameters) / base index 1500		
Parameter	Write access with operating mode (MODE_BLK)	Description
 Note! A description of the FOUNDATION Fieldbus parameters of this block is provided on Page 106.		
Un-/Locking - Access Code	AUTO - OOS	All data of the measuring system are protected against inadvertent change. Only when the code has been entered in this parameter can the manufacturer-specific parameters (E+H parameters) be programmed and the device configuration modified. You can enable programming by entering: • Code 93 (factory setting) • Personal code (see Page 129) User input: Max. 4-digit number (0...9999)  Note! • If write protection is enabled, access to the manufacturer-specific parameters is blocked even if the right code is entered. (More detailed information on write protection is provided in the Operating Instructions for PROline Prosonic Flow 93 FOUNDATION Fieldbus, BA078D/06/en, Section 5.4). • You can disable programming again by entering any number (other than the access code) in this parameter. • The E+H service organisation can be of assistance if you mislay your personal code. • The entry made here does not affect the local display. Therefore programming via the function matrix must be enabled separately.
Un-/Locking - Access Status	read only	Displays the current status of access to the manufacturer-specific parameters of the device. Display: • LOCKED (parameters cannot be modified) • ACCESS CUSTOMER (parameters can be modified)
Un-/Locking - Define Private Code	AUTO - OOS	Entry of a personal code with which the configuration can be enabled. This applies both to manufacturer-specific parameters in the Transducer Blocks and also to operation via local display. User input: 0...9999 (max. 4-digit number) Factory setting: 93  Note! • Programming is always enabled with the code “0”. • Configuration has to be enabled before this code can be changed.

“TRANSDUCER_DISP” (E+H parameters) / base index 1500		
Parameter	Write access with operating mode (MODE_BLK)	Description
Configuration - Language	AUTO - OOS	Use this parameter to select the language for all texts, parameters and messages shown on the local display. Options: ENGLISH DEUTSCH FRANCAIS ESPANOL ITALIANO NEDERLANDS DANSK NORSK SVENSKA SUOMI BAHASA INDONESIA JAPANESE (syllabary) Factory setting: Depends on country, see factory setting on Page 76 ff.
Configuration- Display Damping	AUTO - OOS	Use this parameter to enter a time constant defining how the display reacts to severely fluctuating flow variables, either very quickly (enter a low time constant) or with damping (enter a high time constant). User input: 0...100 seconds Factory setting: 1 s  Note! Setting the time constant to "0" seconds switches off damping.
Configuration - Contrast LCD	AUTO - OOS	Use this function to optimise display contrast to suit local operating conditions. User input: 10...100% Factory setting: 50%


“TRANSDUCER_DISP” (E+H parameters) / base index 1500		
Parameter	Write access with operating mode (MODE_BLK)	Description
Configuration - Xline Calculated	AUTO - OOS	Use this parameter to indicate which “calculated main value” from the measured values of both channels is displayed. “CALC. VOLUME FLOW” must be selected in one of the following parameters so that the value appears in the line desired: • “Main Line - Assign” parameter for display in the main line • “Add. Line - Assign” parameter for display in the additional line • “Info Line - Assign” parameter for display in the information line  Note! This parameter is not active if “OFF” was selected on one channel in the “Sensor Param. - Measurement” parameter, (see Page 122). Options: (CH1 + CH2) / 2 CH1 + CH2 CH1 - CH2 Factory setting: (CH1 + CH2) / 2
Operation - Test Display	AUTO - OOS	Use this parameter to test the operability of the local display and its pixels. Options: OFF ON Factory setting: OFF Test sequence: 1. Start the test by selecting ON. 2. All pixels of the main line, additional line and information line are darkened for minimum 0.75 seconds. 3. Main line, additional line and information line show an “8” in each field for minimum 0.75 seconds. 4. Main line, additional line and information line show a “0” in each field for minimum 0.75 seconds. 5. Main line, additional line and information line show nothing (blank display) for minimum 0.75 seconds. When the test is completed, the display returns to its initial state. Parameter → OFF.

“TRANSDUCER_DISP” (E+H parameters) / base index 1500		
Parameter	Write access with operating mode (MODE_BLK)	Description
A = Main line, B = Additional line, C = Information line  F-x3xxxx-07-05-xx-xx-000		
Main Line - Assign	AUTO - OOS	Use this parameter to define the display value assigned to the main line (the top line of the local display) during normal measuring operation. Options: OFF VOLUME FLOW CH1 VOLUME FLOW CH2 CALC. VOLUME FLOW VOLUME FLOW % CH1 VOLUME FLOW % CH2 CALC. VOLUME FLOW % SOUND VELOCITY CH1 SOUND VELOCITY CH2 SOUND VELOCITY AVG. SIGNAL STRENGTH CH1 SIGNAL STRENGTH CH2 FLOW VELOCITY CH1 FLOW VELOCITY CH2 FLOW VELOCITY AVG. TOTALIZER 1 TOTALIZER 2 TOTALIZER 3 AI 1 - OUT VALUE AI 2 - OUT VALUE AI 3 - OUT VALUE AI 4 - OUT VALUE AI 5 - OUT VALUE AI 6 - OUT VALUE AI 7 - OUT VALUE AI 8 - OUT VALUE PID - IN VALUE (controlled variable) PID - CAS IN VALUE (remote setpoint value) PID - OUT VALUE (manipulated variable) Factory setting: VOLUME FLOW CH1

“TRANSDUCER_DISP” (E+H parameters) / base index 1500		
Parameter	Write access with operating mode (MODE_BLK)	Description
Main Line - 100%-Value	AUTO - OOS	 Note! The input is not active unless one of the following was selected in the "Main Line - Assign" parameter: • VOLUME FLOW % CH1 • VOLUME FLOW % CH2 • CALC. VOLUME FLOW % Use this parameter to define the flow value to be shown on the display as the 100% value. User input: 5-digit floating-point number Factory setting: Depends on country, [value] / [dm³...m³ or US-gal...US-Mgal]  Note! The unit is taken from the “System Unit - Volume Flow” parameter, (see Page 110).
Main Line - Format	AUTO - OOS	Use this parameter to define the maximum number of places after the decimal point displayed for the reading in the main line. Options: XXXXX. – XXXX.X – XXX.XX – XX.XXX – X.XXXX Factory setting: X.XXXX  Note! • Note that this setting only affects the reading as it appears on the display, it has no influence on the accuracy of the system's calculations. • The places after the decimal point as computed by the measuring device cannot always be displayed, depending on this setting and the engineering unit. In these instances an arrow appears on the display between the measured value and the engineering unit, (e.g. 1.2 → dm³/s), indicating that the measuring system is computing with more decimal places than can be shown on the display.

“TRANSDUCER_DISP” (E+H parameters) / base index 1500		
Parameter	Write access with operating mode (MODE_BLK)	Description
Main Line Multiplex - Assign	AUTO - OOS	Use this parameter to define the second reading to be displayed in the main line alternately (every 10 seconds) with the value defined in the "User Interface Main Line - Assign" parameter. Options: OFF VOLUME FLOW CH1 VOLUME FLOW CH2 CALC. VOLUME FLOW VOLUME FLOW % CH1 VOLUME FLOW % CH2 CALC. VOLUME FLOW % SOUND VELOCITY CH1 SOUND VELOCITY CH2 SOUND VELOCITY AVG. SIGNAL STRENGTH CH1 SIGNAL STRENGTH CH2 FLOW VELOCITY CH1 FLOW VELOCITY CH2 FLOW VELOCITY AVG. TOTALIZER 1 TOTALIZER 2 TOTALIZER 3 AI 1 - OUT VALUE AI 2 - OUT VALUE AI 3 - OUT VALUE AI 4 - OUT VALUE AI 5 - OUT VALUE AI 6 - OUT VALUE AI 7 - OUT VALUE AI 8 - OUT VALUE PID - IN VALUE (controlled variable) PID - CAS IN VALUE (remote setpoint value) PID - OUT VALUE (manipulated variable) Factory setting: OFF
Main Line Multiplex - 100%-Value	AUTO - OOS	 Note! The input is not active unless one of the following was selected in the "Main - Multiplex Line Assign" parameter: • VOLUME FLOW % CH1 • VOLUME FLOW % CH2 • CALC. VOLUME FLOW % Use this parameter to define the flow value to be shown on the display as the 100% value. User input: 5-digit floating-point number Factory setting: Depends on country, [value] / [dm³...m³ or US-gal...US-Mgal]  Note! The unit is taken from the "System Unit - Volume Flow" parameter, (see Page 110).

“TRANSDUCER_DISP” (E+H parameters) / base index 1500		
Parameter	Write access with operating mode (MODE_BLK)	Description
Main Line Multiplex - Format	AUTO - OOS	Use this parameter to define the maximum number of places after the decimal point for the second value displayed in the main line. Options: XXXXX. – XXXX.X – XXX.XX – XX.XXX – X.XXXX Factory setting: X.XXXX  Note! • Note that this setting only affects the reading as it appears on the display, it has no influence on the accuracy of the system's calculations. • The places after the decimal point as computed by the measuring device cannot always be displayed, depending on this setting and the engineering unit. In these instances an arrow appears on the display between the measured value and the engineering unit, (e.g. 1.2 → dm³/s), indicating that the measuring system is computing with more decimal places than can be shown on the display.

“TRANSDUCER_DISP” (E+H parameters) / base index 1500		
Parameter	Write access with operating mode (MODE_BLK)	Description
A = Main line, B = Additional line, C = Information line  F-x3xxxx-07-05-xx-xx-000		
Add. Line - Assign	AUTO - OOS	Use this parameter to define the display value assigned to the additional line (the middle line of the local display) during normal measuring operation. Options: OFF VOLUME FLOW CH1 VOLUME FLOW CH2 CALC. VOLUME FLOW VOLUME FLOW % CH1 VOLUME FLOW % CH2 CALC. VOLUME FLOW % SOUND VELOCITY CH1 SOUND VELOCITY CH2 SOUND VELOCITY AVG. SIGNAL STRENGTH CH1 SIGNAL STRENGTH CH2 FLOW VELOCITY CH1 FLOW VELOCITY CH2 FLOW VELOCITY AVG. VOLUME FLOW BARGRAPH % CH1 VOLUME FLOW BARGRAPH % CH2 CALC. VOLUME FLOW BARGRAPH % SIGNAL BARGRAPH CH1 SIGNAL BARGRAPH CH2 TOTALIZER 1 TOTALIZER 2 TOTALIZER 3 FLOW DIRECTION CH1 FLOW DIRECTION CH2 CALC. FLOW DIRECTION AI 1 - OUT VALUE AI 2 - OUT VALUE AI 3 - OUT VALUE AI 4 - OUT VALUE AI 5 - OUT VALUE AI 6 - OUT VALUE AI 7 - OUT VALUE AI 8 - OUT VALUE PID - IN VALUE (controlled variable) PID - CAS IN VALUE (remote setpoint value) PID - OUT VALUE (manipulated variable) DEVICE PD-TAG (tag name) Factory setting: TOTALIZER 1


“TRANSDUCER_DISP” (E+H parameters) / base index 1500		
Parameter	Write access with operating mode (MODE_BLK)	Description
Add. Line - 100%-Value	AUTO - OOS	 Note! The input is not active unless one of the following was selected in the "Add. Line - Assign" parameter: • VOLUME FLOW % CH1 • VOLUME FLOW % CH2 • CALC. VOLUME FLOW % • VOLUME FLOW BARGRAPH % CH1 • VOLUME FLOW BARGRAPH % CH2 • CALC. VOLUME FLOW BARGRAPH % Use this parameter to define the flow value to be shown on the display as the 100% value. User input: 5-digit floating-point number Factory setting: Depends on country, [value] / [dm³...m³ or US-gal...US-Mgal]  Note! The unit is taken from the "System Unit - Volume Flow" parameter, (see Page 110).
Add. Line - Format	AUTO - OOS	 Note! Selection is not active unless a numerical option was selected in the "Add. Line - Assign" parameter. Use this parameter to define the maximum number of places after the decimal point displayed for the reading in the additional line. Options: XXXXX. – XXXX.X – XXX.XX – XX.XXX – X.XXXX Factory setting: X.XXXX  Note! • Note that this setting only affects the reading as it appears on the display, it has no influence on the accuracy of the system's calculations. • The places after the decimal point as computed by the measuring device cannot always be displayed, depending on this setting and the engineering unit. In these instances an arrow appears on the display between the measured value and the engineering unit, (e.g. 1.2 → dm³/s), indicating that the measuring system is computing with more decimal places than can be shown on the display.

“TRANSDUCER_DISP” (E+H parameters) / base index 1500		
Parameter	Write access with operating mode (MODE_BLK)	Description
Add. Line - Display Mode	AUTO - OOS	Note! Selection is not active unless one of the following was selected in the "Add. Line - Assign" parameter: VOLUME FLOW BARGRAPH % CH1 VOLUME FLOW BARGRAPH % CH2 CALC. VOLUME FLOW BARGRAPH % SIGNAL BARGRAPH CH1 SIGNAL BARGRAPH CH2 Use this parameter to define the format of the bar graph. Options: STANDARD Simple bar graph with 25 / 50 / 75% gradations and integrated sign. +25+50+75% F-x3xxxx-20-xx-xx-xx-000 SYMMETRY Symmetrical bar graph for positive and negative directions of flow with -50 / 0 / +50% gradations and integrated sign. -50+50% F-x3xxxx-20-xx-xx-xx-001 Factory setting: STANDARD

“TRANSDUCER_DISP” (E+H parameters) / base index 1500		
Parameter	Write access with operating mode (MODE_BLK)	Description
Add. Line Multiplex - Assign	AUTO - OOS	Use this parameter to define the second reading to be displayed in the additional line alternately (every 10 seconds) with the value defined in the "User Interface Add. Line - Assign" parameter. Options: OFF VOLUME FLOW CH1 VOLUME FLOW CH2 CALC. VOLUME FLOW VOLUME FLOW % CH1 VOLUME FLOW % CH2 CALC. VOLUME FLOW % SOUND VELOCITY CH1 SOUND VELOCITY CH2 SOUND VELOCITY AVG. SIGNAL STRENGTH CH1 SIGNAL STRENGTH CH2 FLOW VELOCITY CH1 FLOW VELOCITY CH2 FLOW VELOCITY AVG. VOLUME FLOW BARGRAPH % CH1 VOLUME FLOW BARGRAPH % CH2 CALC. VOLUME FLOW BARGRAPH % SIGNAL BARGRAPH CH1 SIGNAL BARGRAPH CH2 TOTALIZER 1 TOTALIZER 2 TOTALIZER 3 FLOW DIRECTION CH1 FLOW DIRECTION CH2 CALC. FLOW DIRECTION AI 1 - OUT VALUE AI 2 - OUT VALUE AI 3 - OUT VALUE AI 4 - OUT VALUE AI 5 - OUT VALUE AI 6 - OUT VALUE AI 7 - OUT VALUE AI 8 - OUT VALUE PID - IN VALUE (controlled variable) PID - CAS IN VALUE (remote setpoint value) PID - OUT VALUE (manipulated variable) DEVICE PD-TAG (tag name) Factory setting: OFF  Note! Multiplex mode is suspended as soon as a fault/notice message is generated. The appropriate error message appears on the display: • Fault message (identified by a lightning icon): Multiplex mode is resumed as soon as the fault is no longer active. • Notice message (identified by an exclamation mark): Multiplex mode is resumed as soon as the notice message is no longer active.

“TRANSDUCER_DISP” (E+H parameters) / base index 1500		
Parameter	Write access with operating mode (MODE_BLK)	Description
Add. Line Multiplex - 100%-Value	AUTO - OOS	 Note! The input is not active unless one of the following was selected in the "Add. Line - Multiplex Assign" parameter: • VOLUME FLOW % CH1 • VOLUME FLOW % CH2 • CALC. VOLUME FLOW % • VOLUME FLOW BARGRAPH % CH1 • VOLUME FLOW BARGRAPH % CH2 • CALC. VOLUME FLOW BARGRAPH % Use this parameter to define the flow value to be shown on the display as the 100% value. User input: 5-digit floating-point number Factory setting: Depends on country, [value] / [dm³...m³ or US-gal...US-Mgal]  Note! The unit is taken from the "System Unit - Volume Flow" parameter, (see Page 110).
Add. Line Multiplex - Format	AUTO - OOS	 Note! Selection is not active unless a numerical option was selected in the "Add. Line - Multiplex Assign" parameter. Use this parameter to define the maximum number of places after the decimal point displayed for the reading in the additional line. Options: XXXXX. – XXXX.X – XXX.XX – XX.XXX – X.XXXX Factory setting: X.XXXX  Note! • Note that this setting only affects the reading as it appears on the display, it has no influence on the accuracy of the system's calculations. • The places after the decimal point as computed by the measuring device cannot always be displayed, depending on this setting and the engineering unit. In these instances an arrow appears on the display between the measured value and the engineering unit, (e.g. 1.2 → dm³/s), indicating that the measuring system is computing with more decimal places than can be shown on the display.

“TRANSDUCER_DISP” (E+H parameters) / base index 1500		
Parameter	Write access with operating mode (MODE_BLK)	Description
Add. Line Multiplex - Display Mode	AUTO - OOS	Note! Selection is not active unless one of the following was selected in the "Add. Line - Multiplex Assign" parameter: - VOLUME FLOW BARGRAPH % CH1 - VOLUME FLOW BARGRAPH % CH2 - CALC. VOLUME FLOW BARGRAPH % - SIGNAL BARGRAPH CH1 - SIGNAL BARGRAPH CH2 Use this parameter to define the format of the bar graph. Options: STANDARD Simple bar graph with 25 / 50 / 75% gradations and integrated sign. +25 +50 +75 % F-x3xxxxx-20-xx-xx-xx-000 SYMMETRY Symmetrical bar graph for positive and negative directions of flow with -50 / 0 / +50% gradations and integrated sign. -50 +50 % F-x3xxxxx-20-xx-xx-xx-001 Factory setting: STANDARD

“TRANSDUCER_DISP” (E+H parameters) / base index 1500		
Parameter	Write access with operating mode (MODE_BLK)	Description
A = Main line, B = Additional line, C = Information line  F-x3xxxx-07-05-xx-xx-000		
Info Line - Assign	AUTO - OOS	Use this parameter to define the display value assigned to the information line (the bottom line of the local display) during normal measuring operation. Options: OFF VOLUME FLOW CH1 VOLUME FLOW CH2 CALC. VOLUME FLOW VOLUME FLOW % CH1 VOLUME FLOW % CH2 CALC. VOLUME FLOW % SOUND VELOCITY CH1 SOUND VELOCITY CH2 SOUND VELOCITY AVG. SIGNAL STRENGTH CH1 SIGNAL STRENGTH CH2 FLOW VELOCITY CH1 FLOW VELOCITY CH2 FLOW VELOCITY AVG. VOLUME FLOW BARGRAPH % CH1 VOLUME FLOW BARGRAPH % CH2 CALC. VOLUME FLOW BARGRAPH % SIGNAL BARGRAPH CH1 SIGNAL BARGRAPH CH2 TOTALIZER 1 TOTALIZER 2 TOTALIZER 3 OPERATING/SYSTEM CONDITIONS FLOW DIRECTION CH1 FLOW DIRECTION CH2 CALC. FLOW DIRECTION AI 1 - OUT VALUE AI 2 - OUT VALUE AI 3 - OUT VALUE AI 4 - OUT VALUE AI 5 - OUT VALUE AI 6 - OUT VALUE AI 7 - OUT VALUE AI 8 - OUT VALUE PID - IN VALUE (controlled variable) PID - CAS IN VALUE (remote setpoint value) PID - OUT VALUE (manipulated variable) DEVICE PD-TAG (tag name) Factory setting: OPERATING/SYSTEM CONDITIONS

“TRANSDUCER_DISP” (E+H parameters) / base index 1500		
Parameter	Write access with operating mode (MODE_BLK)	Description
Info Line - 100%-Value	AUTO - OOS	 Note! The input is not active unless one of the following was selected in the "Info Line - Assign" parameter: • VOLUME FLOW % CH1 • VOLUME FLOW % CH2 • CALC. VOLUME FLOW % • VOLUME FLOW BARGRAPH % CH1 • VOLUME FLOW BARGRAPH % CH2 • CALC. VOLUME FLOW BARGRAPH % Use this parameter to define the flow value to be shown on the display as the 100% value. User input: 5-digit floating-point number Factory setting: Depends on country, [value] / [dm³...m³ or US-gal...US-Mgal]  Note! The unit is taken from the "System Unit - Volume Flow" parameter, (see Page 110).
Info Line - Format	AUTO - OOS	 Note! Selection is not active unless a numerical option was selected in the "Info Line - Assign" parameter. Use this parameter to define the maximum number of places after the decimal point displayed for the reading in the additional line. Options: XXXXX. – XXXX.X – XXX.XX – XX.XXX – X.XXXX Factory setting: X.XXXX  Note! • Note that this setting only affects the reading as it appears on the display, it has no influence on the accuracy of the system's calculations. • The places after the decimal point as computed by the measuring device cannot always be displayed, depending on this setting and the engineering unit. In these instances an arrow appears on the display between the measured value and the engineering unit, (e.g. 1.2 → dm³/s), indicating that the measuring system is computing with more decimal places than can be shown on the display.

“TRANSDUCER_DISP” (E+H parameters) / base index 1500		
Parameter	Write access with operating mode (MODE_BLK)	Description
Info Line - Display Mode	AUTO - OOS	Note! Selection is not active unless one of the following was selected in the "Info Line - Assign" parameter: VOLUME FLOW BARGRAPH % CH1 VOLUME FLOW BARGRAPH % CH2 CALC. VOLUME FLOW BARGRAPH % SIGNAL BARGRAPH CH1 SIGNAL BARGRAPH CH2 Use this parameter to define the format of the bar graph. Options: STANDARD Simple bar graph with 25 / 50 / 75% gradations and integrated sign. +25+50+75% F-x3xxxx-20-xx-xx-xx-000 SYMMETRY Symmetrical bar graph for positive and negative directions of flow with -50 / 0 / +50% gradations and integrated sign. -50+50% F-x3xxxx-20-xx-xx-xx-001 Factory setting: STANDARD

“TRANSDUCER_DISP” (E+H parameters) / base index 1500		
Parameter	Write access with operating mode (MODE_BLK)	Description
Info Line Multiplex - Assign	AUTO - OOS	Use this parameter to define the second reading to be displayed in the information line alternately (every 10 seconds) with the value defined in the "Info. Line - Assign" parameter. Options: OFF VOLUME FLOW CH1 VOLUME FLOW CH2 CALC. VOLUME FLOW VOLUME FLOW % CH1 VOLUME FLOW % CH2 CALC. VOLUME FLOW % SOUND VELOCITY CH1 SOUND VELOCITY CH2 SOUND VELOCITY AVG. SIGNAL STRENGTH CH1 SIGNAL STRENGTH CH2 FLOW VELOCITY CH1 FLOW VELOCITY CH2 FLOW VELOCITY AVG. VOLUME FLOW BARGRAPH % CH1 VOLUME FLOW BARGRAPH % CH2 CALC. VOLUME FLOW BARGRAPH % SIGNAL BARGRAPH CH1 SIGNAL BARGRAPH CH2 TOTALIZER 1 TOTALIZER 2 TOTALIZER 3 OPERATING/SYSTEM CONDITIONS FLOW DIRECTION CH1 FLOW DIRECTION CH2 CALC. FLOW DIRECTION AI 1 - OUT VALUE AI 2 - OUT VALUE AI 3 - OUT VALUE AI 4 - OUT VALUE AI 5 - OUT VALUE AI 6 - OUT VALUE AI 7 - OUT VALUE AI 8 - OUT VALUE PID - IN VALUE (controlled variable) PID - CAS IN VALUE (remote setpoint value) PID - OUT VALUE (manipulated variable) DEVICE PD-TAG (tag name) Factory setting: OFF  Note! Multiplex mode is suspended as soon as a fault/notice message is generated. The appropriate error message appears on the display: • Fault message (identified by a lightning icon): Multiplex mode is resumed as soon as the fault is no longer active. • Notice message (identified by an exclamation mark): Multiplex mode is resumed as soon as the notice message is no longer active.

“TRANSDUCER_DISP” (E+H parameters) / base index 1500		
Parameter	Write access with operating mode (MODE_BLK)	Description
Info Line Multiplex - 100%-Value	AUTO - OOS	 Note! The input is not active unless one of the following was selected in the "Info Line - Multiplex Assign" parameter: • VOLUME FLOW % CH1 • VOLUME FLOW % CH2 • CALC. VOLUME FLOW % • VOLUME FLOW BARGRAPH % CH1 • VOLUME FLOW BARGRAPH % CH2 • CALC. VOLUME FLOW BARGRAPH % Use this parameter to define the flow value to be shown on the display as the 100% value. User input: 5-digit floating-point number Factory setting: Depends on country, [value] / [dm³...m³ or US-gal...US-Mgal]  Note! The unit is taken from the "System Unit - Volume Flow" parameter, (see Page 110).
Info Line Multiplex - Format	AUTO - OOS	 Note! Selection is not active unless a numerical option was selected in the "Info Line - Multiplex Assign" parameter. Use this parameter to define the maximum number of places after the decimal point for the second value displayed in the information line. Options: XXXXX. — XXXX.X — XXX.XX — XX.XXX — X.XXXX Factory setting: X.XXXX  Note! • Note that this setting only affects the reading as it appears on the display, it has no influence on the accuracy of the system's calculations. • The places after the decimal point as computed by the measuring device cannot always be displayed, depending on this setting and the engineering unit. In these instances an arrow appears on the display between the measured value and the engineering unit, (e.g. 1.2 → dm³/s), indicating that the measuring system is computing with more decimal places than can be shown on the display.

“TRANSDUCER_DISP” (E+H parameters) / base index 1500		
Parameter	Write access with operating mode (MODE_BLK)	Description
Info Line Multiplex - Display Mode	AUTO - OOS	 Note! Selection is not active unless one of the following was selected in the "Info Line - Multiplex Assign" parameter: • VOLUME FLOW BARGRAPH % CH1 • VOLUME FLOW BARGRAPH % CH2 • CALC. VOLUME FLOW BARGRAPH % • SIGNAL BARGRAPH CH1 • SIGNAL BARGRAPH CH2 Use this parameter to define the format of the bar graph. Options: STANDARD Simple bar graph with 25 / 50 / 75% gradations and integrated sign.  F-x3xxxxx-20-xx-xx-xx-000 SYMMETRY Symmetrical bar graph for positive and negative directions of flow with -50 / 0 / +50% gradations and integrated sign.  F-x3xxxxx-20-xx-xx-xx-001 Factory setting: STANDARD
Amp. Device Family	read only	This parameter is only used in the event of servicing.

3.12 E+H parameters: Transducer Block “TRANSDUCER_TOT” (totalizer)

The following table lists all the E+H-specific parameters of the Transducer Block “TRANSDUCER_TOT” (totalizer). The conditions which have to be met before changing these parameters are provided on Page 105.

“TRANSDUCER_TOT” (E+H parameters) / base index 1550		
Parameter	Write access with operating mode (MODE_BLK)	Description
 Note! A description of the FOUNDATION Fieldbus parameters of this block is provided on Page 106.		
Un-/Locking - Access Code	AUTO - OOS	All data of the measuring system are protected against inadvertent change. Only when the code has been entered in this parameter can the manufacturer-specific parameters (E+H parameters) be programmed and the device configuration modified. You can enable programming by entering: • Code 93 (factory setting) • Personal code (see Page 129) User input: Max. 4-digit number (0...9999)  Note! • If write protection is enabled, access to the manufacturer-specific parameters is blocked even if the right code is entered. (More detailed information on write protection is provided in the Operating Instructions for PROline Prosonic Flow 93 FOUNDATION Fieldbus, BA078D/06/en, Section 5.4). • You can disable programming again by entering any number (other than the access code) in this parameter. • The E+H service organisation can be of assistance if you mislay your personal code. • The entry made here does not affect the local display. Therefore programming via the function matrix must be enabled separately.
Un-/Locking - Access Status	read only	Displays the current status of access to the manufacturer-specific parameters of the device. Display: • LOCKED (parameters cannot be modified) • ACCESS CUSTOMER (parameters can be modified)

“TRANSDUCER_TOT” (E+H parameters) / base index 1550		
Parameter	Write access with operating mode (MODE_BLK)	Description
Totalizer 1 - System Value	AUTO - OOS	Use this parameter to view the total for the totalizer's measured variable aggregated since measuring commenced. This value can be positive or negative, depending on the setting selected in the "Totalizer 1 - Mode" parameter (see Page 150) and the direction of flow.  Note! - The effect of the setting in the "Totalizer 1 - Mode" parameter (see Page 150) is as follows: - If the setting is "BALANCE", the totalizer balances flow in the positive and negative directions. - If the setting is "FORWARD", the totalizer registers only flow in the positive direction. - If the setting is "REVERSE", the totalizer registers only flow in the negative direction. - The totalizers' response to faults is defined in the "Totalizer Handling - Failsafe All" parameter, (see Page 155).
Totalizer 1 - System Unit	AUTO - OOS	Use this parameter to define the unit for the measured variable selected for the totalizer. Options: <i>Metric:</i> Cubic centimetre → cm³ Cubic decimetre → dm³ Cubic metre → m³ Millilitre → ml Litre → l Hectolitre → hl Megalitre → Ml MEGA <i>US:</i> Cubic centimetre → cc Acre foot → af Cubic foot → ft³ Fluid ounce → oz f Gallon → US gal Million gallon → US Mgal Barrel (normal fluids: 31.5 gal/bbl) → US bbl NORM.FL. Barrel (beer: 31.0 gal/bbl) → US bbl BEER Barrel (petrochemicals: 42.0 gal/bbl) → US bbl PETROCH. Barrel (filling tanks: 55.0 gal/bbl) → US bbl TANK <i>Imperial:</i> Gallon → imp. gal Mega gallon → imp. Mgal Barrel (beer: 36.0 gal/bbl) → imp. bbl BEER Barrel (petrochemicals: 34.97 gal/bbl) → imp. bbl PETROCH. Factory setting: Depends on country (dm³...m³ or US gal...US Mgal), corresponds to the totalizer unit factory setting, (see Page 76 ff.).  Note! The unit selected here has no effect on the desired volume unit which should be transmitted via the FF interface. This setting is made separately via the appropriate AI Block in the XD_SCALE parameter group, (see Page 180).

“TRANSDUCER_TOT” (E+H parameters) / base index 1550		
Parameter	Write access with operating mode (MODE_BLK)	Description
Totalizer 1 - Assign	AUTO - OOS	For assigning a measured variable to the totalizer. Options: OFF VOLUME FLOW CH1 VOLUME FLOW CH2 VOLUME FLOW AVERAGE VOLUME FLOW SUM VOLUME FLOW DIFF. Factory setting: VOLUME FLOW CH1  Note! The totalizer is reset to “0” as soon as the selection is changed.
Totalizer 1 - Mode	AUTO - OOS	Use this parameter to define how the flow components are to be totalled by the totalizer. Options: BALANCE Positive and negative flow components. The positive and negative flow components are balanced. In other words, net flow in the flow direction is registered. FORWARD Positive flow components only REVERSE Negative flow components only Factory setting: BALANCE
Totalizer 1 - Reset	AUTO - OOS	Resets totalizer 1 (“Totalizer 1 - System Value” parameter, see Page 149) to zero. Options: NO YES Factory setting: NO  Note! Resetting of the totalizer can be also be controlled or initiated using cyclic data transmission via the Discrete Output function block, (see Page 181).

“TRANSDUCER_TOT” (E+H parameters) / base index 1550		
Parameter	Write access with operating mode (MODE_BLK)	Description
Totalizer 2 - System Value	AUTO - OOS	Use this parameter to view the total for the totalizer's measured variable aggregated since measuring commenced. This value can be positive or negative, depending on the setting selected in the "Totalizer 2 - Mode" parameter (see Page 152) and the direction of flow.  Note! - The effect of the setting in the "Totalizer 2 - Mode" parameter (see Page 152) is as follows: - If the setting is "BALANCE", the totalizer balances flow in the positive and negative directions. - If the setting is "FORWARD", the totalizer registers only flow in the positive direction. - If the setting is "REVERSE", the totalizer registers only flow in the negative direction. - The totalizers' response to faults is defined in the "Totalizer Handling - Failsafe All" parameter, (see Page 155).
Totalizer 2 - System Unit	AUTO - OOS	Use this parameter to define the unit for the measured variable selected for the totalizer. Options: <i>Metric:</i> Cubic centimetre → cm³ Cubic decimetre → dm³ Cubic metre → m³ Millilitre → ml Litre → l Hectolitre → hl Megalitre → Ml MEGA <i>US:</i> Cubic centimetre → cc Acre foot → af Cubic foot → ft³ Fluid ounce → oz f Gallon → US gal Million gallon → US Mgal Barrel (normal fluids: 31.5 gal/bbl) → US bbl NORM.FL. Barrel (beer: 31.0 gal/bbl) → US bbl BEER Barrel (petrochemicals: 42.0 gal/bbl) → US bbl PETROCH. Barrel (filling tanks: 55.0 gal/bbl) → US bbl TANK <i>Imperial:</i> Gallon → imp. gal Mega gallon → imp. Mgal Barrel (beer: 36.0 gal/bbl) → imp. bbl BEER Barrel (petrochemicals: 34.97 gal/bbl) → imp. bbl PETROCH. Factory setting: Depends on country (dm³...m³ or US gal...US Mgal), corresponds to the totalizer unit factory setting, (see Page 76 ff.).  Note! The unit selected here has no effect on the desired volume unit which should be transmitted via the FF interface. This setting is made separately via the appropriate AI Block in the XD_SCALE parameter group, (see Page 180).

“TRANSDUCER_TOT” (E+H parameters) / base index 1550		
Parameter	Write access with operating mode (MODE_BLK)	Description
Totalizer 2 - Assign	AUTO - OOS	For assigning a measured variable to the totalizer. Options: OFF VOLUME FLOW CH1 VOLUME FLOW CH2 VOLUME FLOW AVERAGE VOLUME FLOW SUM VOLUME FLOW DIFF. Factory setting: VOLUME FLOW CH1  Note! The totalizer is reset to “0” as soon as the selection is changed.
Totalizer 2 - Mode	AUTO - OOS	Use this parameter to define how the flow components are to be totalled by the totalizer. Options: BALANCE Positive and negative flow components. The positive and negative flow components are balanced. In other words, net flow in the flow direction is registered. FORWARD Positive flow components only REVERSE Negative flow components only Factory setting: FORWARD
Totalizer 2 - Reset	AUTO - OOS	Resets totalizer 2 (“Totalizer 2 - System Value” parameter, see Page 151) to zero. Options: NO YES Factory setting: NO  Note! Resetting of the totalizer can be also be controlled or initiated using cyclic data transmission via the Discrete Output function block, (see Page 181).

“TRANSDUCER_TOT” (E+H parameters) / base index 1550		
Parameter	Write access with operating mode (MODE_BLK)	Description
Totalizer 3 - System Value	AUTO - OOS	Use this parameter to view the total for the totalizer's measured variable aggregated since measuring commenced. This value can be positive or negative, depending on the setting selected in the "Totalizer 3 - Mode" parameter (see Page 154) and the direction of flow.  Note! - The effect of the setting in the "Totalizer 3 - Mode" parameter (see Page 154) is as follows: - If the setting is "BALANCE", the totalizer balances flow in the positive and negative directions. - If the setting is "FORWARD", the totalizer registers only flow in the positive direction. - If the setting is "REVERSE", the totalizer registers only flow in the negative direction. - The totalizers' response to faults is defined in the "Totalizer Handling - Failsafe All" parameter, (see Page 155).
Totalizer 3 - System Unit	AUTO - OOS	Use this parameter to define the unit for the measured variable selected for the totalizer. Options: <i>Metric:</i> Cubic centimetre → cm³ Cubic decimetre → dm³ Cubic metre → m³ Millilitre → ml Litre → l Hectolitre → hl Megalitre → Ml MEGA <i>US:</i> Cubic centimetre → cc Acre foot → af Cubic foot → ft³ Fluid ounce → oz f Gallon → US gal Million gallon → US Mgal Barrel (normal fluids: 31.5 gal/bbl) → US bbl NORM.FL. Barrel (beer: 31.0 gal/bbl) → US bbl BEER Barrel (petrochemicals: 42.0 gal/bbl) → US bbl PETROCH. Barrel (filling tanks: 55.0 gal/bbl) → US bbl TANK <i>Imperial:</i> Gallon → imp. gal Mega gallon → imp. Mgal Barrel (beer: 36.0 gal/bbl) → imp. bbl BEER Barrel (petrochemicals: 34.97 gal/bbl) → imp. bbl PETROCH. Factory setting: Depends on country (dm³...m³ or US gal...US Mgal), corresponds to the totalizer unit factory setting, (see Page 76 ff.).  Note! The unit selected here has no effect on the desired volume unit which should be transmitted via the FF interface. This setting is made separately via the appropriate AI Block in the XD_SCALE parameter group, (see Page 180).

“TRANSDUCER_TOT” (E+H parameters) / base index 1550		
Parameter	Write access with operating mode (MODE_BLK)	Description
Totalizer 3 - Assign	AUTO - OOS	For assigning a measured variable to the totalizer. Options: OFF VOLUME FLOW CH1 VOLUME FLOW CH2 VOLUME FLOW AVERAGE VOLUME FLOW SUM VOLUME FLOW DIFF. Factory setting: VOLUME FLOW CH1  Note! The totalizer is reset to “0” as soon as the selection is changed.
Totalizer 3 - Mode	AUTO - OOS	Use this parameter to define how the flow components are to be totalled by the totalizer. Options: BALANCE Positive and negative flow components. The positive and negative flow components are balanced. In other words, net flow in the flow direction is registered. FORWARD Positive flow components only REVERSE Negative flow components only Factory setting: REVERSE
Totalizer 3 - Reset	AUTO - OOS	Resets totalizer 3 (“Totalizer 3 - System Value” parameter, see Page 153) to zero. Options: NO YES Factory setting: NO  Note! Resetting of the totalizer can be also be controlled or initiated using cyclic data transmission via the Discrete Output function block, (see Page 181).

“TRANSDUCER_TOT” (E+H parameters) / base index 1550		
Parameter	Write access with operating mode (MODE_BLK)	Description
Totalizer Handling - Reset All	AUTO - OOS	Resets totalizers 1–3 (“Totalizer x - System Value” parameter) to zero simultaneously. Options: NO YES Factory setting: NO  Note! Resetting of the totalizers can be also be controlled or initiated using cyclic data transmission via the Discrete Output function block, (see Page 181).
Totalizers Handling - Failsafe All	AUTO - OOS	Use this parameter to define the common response of all totalizers (1...3) to error. Options: STOP The totalizer is paused until the fault is rectified. ACTUAL VALUE The totalizers continue to count based on the current measured flow value. The fault is ignored. HOLD VALUE The totalizer continues to count the flow is based on the last valid flow value (before the fault occurred). Factory setting: STOP
Amp. Device Family	read only	This parameter is only used in the event of servicing.

3.13 E+H parameters: Transducer Block “TRANSDUCER_DIAG” (diagnosis)

The following table lists all the E+H-specific parameters of the Transducer Block “TRANSDUCER_DIAG” (diagnosis). The conditions which have to be met before changing these parameters are provided on Page 105.

“TRANSDUCER_DIAG” (E+H parameters) / base index 1600		
Parameter	Write access with operating mode (MODE_BLK)	Description
 Note! A description of the FOUNDATION Fieldbus parameters of this block is provided on Page 106.		
Diagnosis - Actual System Condition	read only	Displays the current system status.  Note! A precise error description as well as notes on fault elimination can be found in the Operating Instructions for PROline Prosonic Flow 93 FOUNDATION Fieldbus, BA078D/06/en, Section 9.
Diagnosis - Previous System Condition	read only	Displays the last error messages that occurred.
Un-/Locking - Access Code	AUTO - OOS	All data of the measuring system are protected against inadvertent change. Only when the code has been entered in this parameter can the manufacturer-specific parameters (E+H parameters) be programmed and the device configuration modified. You can enable programming by entering: • Code 93 (factory setting) • Personal code (see Page 129) User input: Max. 4-digit number (0...9999)  Note! • If write protection is enabled, access to the manufacturer-specific parameters is blocked even if the right code is entered. (More detailed information on write protection is provided in the Operating Instructions for PROline Prosonic Flow 93 FOUNDATION Fieldbus, BA078D/06/en, Section 5.4). • You can disable programming again by entering any number (other than the access code) in this parameter. • The E+H service organisation can be of assistance if you mislay your personal code. • The entry made here does not affect the local display. Therefore programming via the function matrix must be enabled separately.
Un-/Locking - Access Status	read only	Displays the current status of access to the manufacturer-specific parameters of the device. Display: • LOCKED (parameters cannot be modified) • ACCESS CUSTOMER (parameters can be modified)

"TRANSDUCER_DIAG" (E+H parameters) / base index 1600		
Parameter	Write access with operating mode (MODE_BLK)	Description
System - Alarm Delay	AUTO - OOS	Use this parameter to define a time span for which the criteria for an error have to be satisfied without interruption before an error or notice message is generated.  Note! Depending on the setting and type of error, this alarm delay acts on both the display and the output values of the FOUNDATION Fieldbus. User input: 0...100 s (in steps of one second) Factory setting: 0 s  Caution! If this parameter is used, error and notice messages are delayed by the time corresponding to the setting before being forwarded to downstream function blocks or the fieldbus host system. It is therefore imperative to check in advance whether a delay of this nature could affect the safety requirements of the process. If fault and notice messages may not be suppressed, a value of 0 seconds must be entered here.
System - Simulation Failsafe Mode	AUTO - OOS	Use this function to set the totalizers to their defined failsafe modes, in order to check whether they respond correctly. The totalizers' response to faults is defined via the "Totalizer Handling - Failsafe All" parameter, (see Page 155).  Note! With regard to the fieldbus, an active simulation is relayed to downstream function blocks or higher-level process control systems by means of the status "UNCERTAIN" for the output value OUT (AI Block). Options: OFF ON Factory setting: OFF
System - Reset	AUTO - OOS	Use this parameter to perform a reset of the measuring system. Options: NO RESTART SYSTEM (restart without interrupting power supply) ORIGINAL TRANSMITTER DATA Factory setting: NO

“TRANSDUCER_DIAG” (E+H parameters) / base index 1600		
Parameter	Write access with operating mode (MODE_BLK)	Description
System - Trouble-shooting	AUTO - OOS	Use this parameter to rectify errors in the EEPROM. The EEPROM is divided into a number of blocks. For fault elimination, select the block in question and acknowledge the error.  Caution! When you clear an error in a block, the parameters of the block you select are reset to their factory settings. Options: CANCEL MEASURED VALUES SYSTEM UNITS DENSITY PARAMETERS QUICK SETUP USER INTERFACE TOTALIZER COMMUNICATION PROCESS PARAMETER SYSTEM PARAMETER SENSOR DATA BATCH FUNCTION ADVANCED DIAGNOSIS AMPLIFIER PARAMETERS SUPERVISION VERSION INFO SERVICE & ANALYSIS PRODUCTION INFO FILTER PARAMETER Factory setting: CANCEL
System - Operation Time	read	Displays the entire operation time (in seconds) since the flowmeter was commissioned.
T-DAT Save/ Load	AUTO - OOS	Use this parameter to save the parameter settings / configuration of the transmitter in a transmitter DAT (T-DAT), or to load the parameter settings from the T-DAT into the EEPROM. Application examples: • After commissioning, the current measuring point parameters can be saved to the T-DAT as a backup. • If the transmitter is replaced for some reason, the data from the T-DAT can be loaded into the new transmitter (EEPROM). Options: CANCEL SAVE (from EEPROM to T-DAT) LOAD (from T-DAT to EEPROM) Factory setting: CANCEL  Note! If the power supply fails, the totalizer readings are automatically saved to the EEPROM.
Amp. Device Family	read only	This parameter is only used in the event of servicing.


3.14 E+H parameters: Transducer Block “TRANSDUCER_SERV” (service)

The Transducer Block “TRANSDUCER_SERV” (base index 1650, service) contains all the parameters required for servicing. As these parameters affect the accuracy and functionality of the device, changes may only be made by E+H service technicians. The parameters of the “TRANSDUCER_SERV” Transducer Block are not explained in these Operating Instructions.

4 Analog Input function block

In the Analog Input function block (AI function block), the process variables from the Transducer Blocks “TRANSDUCER_CH1” (flow channel 1, base index 1200), “TRANSDUCER_CH2” (flow channel 2, base index 1300) and “TRANSDUCER_TOT” (totalizer, base index 1550) are prepared for the subsequent automation functions, (e.g. scaling, limit value processing). The automation function is defined by the connections of the outputs.

F06-53xFFxxx-16-xx-xx-en-001



OUT = Output value and output status of the Analog Input function block

4.1 Signal processing

The figure shows the internal structure of the Analog Input function blocks available:




Fig. 3: Signal processing and structure of the Analog Input function blocks

The Analog Input function block receives its input value from the Transducer Blocks TRANSDUCER_CH1 (flow channel 1, base index 1200), TRANSDUCER_CH2 (flow channel 2, base index 1300) or TRANSDUCER_TOT (flow channel 1, base index 1550). The CHANNEL parameter (see Page 171) is used to select which input value is to be processed by the Analog Input function block.

- CHANNEL = 2 → Volume flow channel 1
- CHANNEL = 21 → Sound velocity channel 1
- CHANNEL = 23 → Flow velocity channel 1
- CHANNEL = 30 → Signal strength channel 1
- CHANNEL = 20 → Volume flow channel 2
- CHANNEL = 22 → Sound velocity channel 2
- CHANNEL = 24 → Flow velocity channel 2
- CHANNEL = 31 → Signal strength channel 2
- CHANNEL = 7 → Totalizer 1
- CHANNEL = 8 → Totalizer 2
- CHANNEL = 9 → Totalizer 3
- CHANNEL = 25 → Average volume flow
- CHANNEL = 26 → Volume flow sum
- CHANNEL = 27 → Volume flow difference
- CHANNEL = 28 → Average sound velocity
- CHANNEL = 29 → Totalizer 1

The SIMULATE parameter group, (see Page 179), allows you to replace the input value with a simulation value and to activate simulation. By specifying the status and the simulation value, the reaction of the complete Analog Input function block can be tested.



Note!

The simulation mode is enabled by means of jumpers on the I/O board, (see Operating Instructions for PROline Prosonic Flow 93 FF, BA078D/06/en, Section 5.4).

The L_TYPE parameter is used to select the linearisation type of the input or simulation value, (see Page 174):

- Direct signal conversion
The input value is forwarded without conversion (XD_SCALE = OUT_SCALE). Select this option if the input value is already in the physical units you want.
- Indirect signal conversion
With this setting the input value is re-scaled linearly via the XD_SCALE input scaling to the desired OUT_SCALE output range, (further information on rescaling of the input value can be found on Page 165).
- Indirect signal conversion with root
With this setting the input value is re-scaled via the XD_SCALE parameter group and recalculated using a root function. It is then rescaled again to the desired output range via the OUT_SCALE parameter group.

The LOW_CUT parameter, (see Page 177), allows a limit value to be specified for the low flow cut off. The low flow cut off is activated via the IO_OPTS parameter, (see Page 173). If the converted primary value (PV) is below the limit value then it is set to a value of "0".

In the PV_FTIME parameter, (see Page 178), a filter time can be specified for filtering the converted input value (PV). If a time of 0 seconds is specified then no filtration takes place.

The MODE_BLK parameter group, (see Page 177), is used to select the operating mode of the Analog Input function block.

If the MAN (manual) operating mode is selected then the output value OUT, (see Page 177), can be specified directly.

The output value OUT is compared with warning and alarm limits, (e.g. HI_LIM, LO_LO_LIM, etc.), that can be entered via various parameters. If one of these limit values is violated then a limit value process alarm, (e.g. HI_ALM, LO_LO_ALM, etc.), is triggered.

The most important functions and parameters of the Analog Input function block are listed below. An overview of all the parameters available is provided on Page 167 ff.

4.2 Selecting the operating mode

The operating mode is set by means of the MODE_BLK parameter group, (see Page 177). The Analog Input function block supports the following operating modes:

- AUTO
- MAN
- OOS



Note!

The OOS operating mode is also displayed via the BLOCK_ERR parameter, (see Page 170). In the OOS operating mode, you can access all the write parameters without restriction if write protection is not enabled.

4.3 Selecting the process variable

Prosonic Flow 93 FOUNDATION Fieldbus has eight Analog Input function blocks. The Transducer Block process variables that are to be processed are assigned via the CHANNEL parameter, (see Page 171).

- CHANNEL = 2 → Volume flow channel 1
- CHANNEL = 21 → Sound velocity channel 1
- CHANNEL = 23 → Flow velocity channel 1
- CHANNEL = 30 → Signal strength channel 1
- CHANNEL = 20 → Volume flow channel 2
- CHANNEL = 22 → Sound velocity channel 2
- CHANNEL = 24 → Flow velocity channel 2
- CHANNEL = 31 → Signal strength channel 2
- CHANNEL = 7 → Totalizer 1
- CHANNEL = 8 → Totalizer 2
- CHANNEL = 9 → Totalizer 3
- CHANNEL = 25 → Average volume flow
- CHANNEL = 26 → Volume flow sum
- CHANNEL = 27 → Volume flow difference
- CHANNEL = 28 → Average sound velocity
- CHANNEL = 29 → Totalizer 1

4.4 Linearisation types

In the Analog Input function block, the input value from the Transducer Block can be linearised via the L_TYPE parameter, (see Page 174). The following types of linearisation are available:

- **Direct**
With this setting, the input value avoids the linearisation function and is looped unchanged with the same unit through the Analog Input function block.
- **Indirect**
With this setting the input value is re-scaled linearly via the XD_SCALE input scaling to the desired OUT_SCALE output range, (further information on rescaling of the input value can be found on Page 165).
- **Indirect Square Root**
With this setting, the input value is re-scaled via the XD_SCALE parameter group and recalculated using a root function. It is then rescaled again to the desired output range via the OUT_SCALE parameter group.

4.5 Selecting the units

The XD_SCALE parameter group, (see Page 180), is used to define with which physical unit the input value of the Transducer Block should be read in and processed in the Analog Input function block. Ensure that the unit selected suits the input value selected in the CHANNEL parameter. The unit of the output value OUT is specified via the OUT_SCALE parameter group, (see Page 178). If the "Direct" linearisation mode was selected via the L_TYPE parameter, (see Page 174), the setting of the XD_SCALE and OUT_SCALE parameter groups must be identical as otherwise the function block remains in the OOS operating mode and the "BLOCK CONFIG ERROR" block error is displayed in the BLOCK_ERROR parameter.



Note!

- Example of rescaling the input value → Page 165
- The selection of the system units in the relevant Transducer Blocks does not affect the system unit setting in the Analog Input function block. These settings must be made separately. The unit selected in the Transducer Blocks is only used for the local display, low flow cut off and for simulation.

4.6 Status of the output value OUT

The status of the OUT parameter group communicates the status of the Analog Input function block and the validity of the output value OUT to the downstream function blocks. The following statuses can be displayed:

- **GOOD_NON_CASCADE**

The Analog Input function block is in the AUTO operating mode, i.e. the output value OUT is valid and can be used for further processing.

- **UNCERTAIN**

The output value OUT can only be used for further processing to a limited extent. The "UNCERTAIN" status tells the downstream function blocks that a "notice message" is present in the device, triggered by an active positive zero return or simulation, for example.

- **BAD**

The output value OUT is invalid. The following are possible causes:

- The Analog Input function block is in the OOS operating mode.
- The "BLOCK CONFIG ERROR" status is displayed via the BLOCK_ERR parameter, (see Page 170).
- The Transducer Block TRANSDUCER_CH1 (flow channel 1, base index 1200), TRANSDUCER_CH2 (flow channel 2, base index 1300) or TRANSDUCER_TOT (flow channel 1, base index 1550) is in the OOS operating mode. The Analog Input function block can only process the input value of the Transducer Block in question if the operating mode is set to AUTO.
- A "fault message" is present in the device which is triggered by a serious device error, e.g. a faulty electronic module.



Note!

The reason for the error message in question (notice/fault message) is displayed in the Transducer Block TRANSDUCER_DIAG (diagnosis, base index 1600) via the "Diagnosis - Actual System Condition" parameter.

A list of all the error messages (including troubleshooting measures) is provided in the Operating Instructions for PROline Prosonic Flow 93 FOUNDATION Fieldbus, BA078D/06/en.

4.7 Simulation of input/output

Certain parameters of the Analog Input function block allow simulation of the input and output of the function block:

1. Simulating the input of the Analog Input function block:

The SIMULATE parameter group, (see Page 179), can be used to specify the input value (measured value and status). Since the simulation value runs through the entire function block, all the parameter settings of the block can be checked.



Note!

If simulation is disabled by the jumper on the I/O board, the simulation mode cannot be activated in the SIMULATE parameter, (see Page 179). In the Resource Block, the BLOCK_ERROR parameter, (see Page 92), indicates whether simulation of the Analog Input function block is possible.

2. Simulating the output of the Analog Input function block:

Set the operating mode in the MODE_BLK parameter group (see Page 177) to MAN and specify the desired output value directly in the OUT parameter, (see Page 177).

4.8 Diagnosis

Block errors and diagnosis information are displayed in the Analog Input function block via the BLOCK_ERR parameter, (see Page 170). A description of the block errors supported is provided on Page 170.



Note!

Further information on trouble-shooting and fault elimination while configuring the Analog Input function block is provided in the Operating Instructions for PROline Prosonic Flow 93 FF, BA052D/06/en.

4.9 Rescaling the input value

In the Analog Input function block, the input value or input range can be scaled in accordance with the automation requirements.

Example:

- The measuring range of the sensor channel 1 is 0...30 m³/h.
- The output range to the automation system should be 0...100%.


The Analog Input function block must be configured as follows:

- Select the input value in the CHANNEL parameter, (see Page 171)
Select: Channel = 2 → Volume flow channel 1
- L_TYPE parameter, (see Page 174)
Select: L_TYPE = Indirect
The “volume flow channel 1” process variable of the Transducer Block TRANSDUCER_CH1 (flow channel 1, base index 1200) is rescaled linearly to the desired OUT_SCALE output range via the XD_SCALE input scaling.
- XD_SCALE parameter group, (see Page 180)

XD_SCALE 0 %	= 0
XD_SCALE 100 %	= 30
XD_SCALE UNIT	= m ³ /h
- OUT_SCALE parameter group, (see Page 178)

OUT_SCALE 0 %	= 0
OUT_SCALE 100 %	= 100
OUT_SCALE UNIT	= %

The result is that with an input value of, for example, 15 m³/h a value of 50% is output via the OUT parameter.



4.10 Limit values

The limit values are based on the output value OUT. If the output value OUT exceeds or undershoots the defined limit values, an alarm is sent to the fieldbus host system via the limit value process alarms.

The following limit values can be defined:

- | | | | |
|-------------|----------------|----------|----------------|
| – HI_HI_LIM | (see Page 172) | – HI_LIM | (see Page 173) |
| – LO_LO_LIM | (see Page 175) | – LO_LIM | (see Page 175) |

4.11 Alarm detection and processing

Process alarms provide information on particular block statuses and block events. The status of the process alarms is communicated to the fieldbus host system via the BLOCK_ALM parameter, (see Page 169). The ACK_OPTION parameter, (see Page 167), specifies whether an alarm must be acknowledged via the fieldbus host system.

The following process alarms are generated by the Analog Input function block:

• Block process alarms

A block process alarm is triggered via the BLOCK_ERR parameter, (see Page 170). The BLOCK_ALM parameter (see Page 169) is used to show the block process alarms and communicate them to the fieldbus host system. The following block process alarms can be generated by the Analog Input function block:

- SIMULATION ACTIVE
- INPUT FAILURE
- OUT OF SERVICE
- BLOCK CONFIG ERROR

If the option of the process alarm (BLOCK ALM) has **not** been enabled in the ACK_OPTION parameter, (see Page 167), the process alarms must be acknowledged in the BLOCK_ALM parameter, (see Page 169).

• Limit value process alarms

If a limit value is violated then the priority specified for the limit value alarm is checked before the limit value violation is communicated to the fieldbus host system.

The priority that specifies the action in the event of an active limit value violation is determined by the following parameters:

- | | | | |
|-------------|----------------|----------|----------------|
| – HI_HI_PRI | (see Page 172) | – HI_PRI | (see Page 173) |
| – LO_LO_PRI | (see Page 176) | – LO_PRI | (see Page 176) |

The status of the limit value process alarms is communicated to the fieldbus host system via the following parameters:

- | | | | |
|-------------|----------------|----------|----------------|
| – HI_HI_ALM | (see Page 172) | – HI_ALM | (see Page 172) |
| – LO_LO_ALM | (see Page 175) | – LO_ALM | (see Page 175) |

If the option of a limit value process alarm has **not** been enabled in the ACK_OPTION parameter, (see Page 167), then this must be acknowledged directly in its parameter (see list).




Note!

The ALARM_SUM parameter, (see Page 169), shows the current status of all the process alarms.

4.12 Parameters of the Analog Input function block

The following table shows all the parameters available for the Analog Input function block.

Analog Input function block / Base index: AI 1 = 350, AI 2 = 390, AI 3 = 430, AI 4 = 470, AI 5 = 510, AI 6 = 550, AI 7 = 590, AI 8 = 630		
Parameter	Write access with operating mode (MODE_BLK)	Description
ACK_OPTION	AUTO - MAN - OOS	This parameter is used to specify whether a process alarm must be acknowledged at the time of alarm detection by the fieldbus host system. If this option is enabled the process alarm is acknowledged automatically. Options: HI_HI_ALM Upper limit value alarm HI_ALM Upper limit value warning LO_LO_ALM Lower limit value alarm LO_ALM Lower limit value warning BLOCK ALM Block alarm Factory setting: The option is not enabled for any alarm, the alarms must be acknowledged.
ALARM_HYS	AUTO - MAN - OOS	Entry of the hysteresis value for the upper and lower warning or alarm limit values. The alarm conditions remain active as long as the measured value is within the hysteresis. The hysteresis value affects the following warning and alarm limit values of the Analog Input function block: • HI_HI_ALM (upper limit value alarm) • HI_ALM (Upper limit value warning) • LO_LO_ALM (lower limit value alarm) • LO_ALM (lower limit value warning) User input: 0...50% Factory setting: 0.5%  Note! The hysteresis value relates to a percentage of the range of the OUT_SCALE parameter group in the Analog Input function block, (see Page 178). (Continued on next page)

Analog Input function block /		
Base index: AI 1 = 350, AI 2 = 390, AI 3 = 430, AI 4 = 470, AI 5 = 510, AI 6 = 550, AI 7 = 590, AI 8 = 630		
Parameter	Write access with operating mode (MODE_BLK)	Description
ALARM_HYS (contd.)	AUTO - MAN - OOS	Example: The top diagram shows the limit values defined for the LO_LIM and HI_LIM warnings with their respective hystereses (grey background) and the signal curve of the output value OUT. The bottom two diagrams show the behaviour of the associated HI_ALM and LO_ALM alarms in relation to the changing signal curve (0 = no alarm, 1 = alarm output). a = The block output value OUT exceeds the HI_LIM limit value, HI_ALM is activated. b = The block output value OUT undershoots the hysteresis value of HI_LIM, HI_ALM is deactivated. c = The block output value OUT undershoots the LO_LIM limit value, LO_ALM is activated. d = The block output value OUT exceeds the hysteresis value of LO_LIM, LO_ALM is deactivated.  F06-53vFFxx-05-xx-xx-en-002

Analog Input function block / Base index: AI 1 = 350, AI 2 = 390, AI 3 = 430, AI 4 = 470, AI 5 = 510, AI 6 = 550, AI 7 = 590, AI 8 = 630		
Parameter	Write access with operating mode (MODE_BLK)	Description
ALARM_SUM	AUTO - MAN - OOS	Displays the current status of the process alarms in the Analog Input function block. Display: HI_HI_ALM Violation of the upper limit value alarm HI_ALM Violation of the upper limit value warning LO_LO_ALM Violation of the lower limit value alarm LO_ALM Violation of the lower limit value warning BLOCK ALM Block alarm  Note! In addition, the process alarms can also be disabled in this parameter group.
ALERT_KEY	AUTO - MAN - OOS	Entry of the identification number of the plant unit. This information can be used by the fieldbus host system for sorting alarms and events. User input: 1...255 Factory setting: 0
BLOCK_ALM	AUTO - MAN - OOS	Displays the current block status with information on pending configuration, hardware or system errors, including details of the alarm time (date, time) when the error occurred. The block alarm is triggered in the event of the following block errors: • SIMULATION ACTIVE • INPUT FAILURE • OUT OF SERVICE • BLOCK CONFIG ERROR  Note! If the option of the alarm has not been enabled in the ACK_OPTION parameter, the alarm can only be acknowledged via this parameter.

Analog Input function block / Base index: AI 1 = 350, AI 2 = 390, AI 3 = 430, AI 4 = 470, AI 5 = 510, AI 6 = 550, AI 7 = 590, AI 8 = 630		
Parameter	Write access with operating mode (MODE_BLK)	Description
BLOCK_ERR	read only	Displays the active block error. Display: SIMULATION ACTIVE Simulation in the "Simulate" parameter group of the Analog Input function block is active. OUT OF SERVICE (OOS) The function block is in the "Out of Service" operating mode. INPUT FAILURE This block error indicates that the input value transmitted by the Transducer Block "TRANSDUCER_CH1", "TRANSDUCER_CH 2" (volume flow channel 1 and 2) or "TRANSDUCER_TOT" (totalizer) is not valid. Possible causes: A serious device error, such as a faulty electronic module, is present. The exact cause of the error is then displayed in the "Diagnosis - Actual System Condition" parameter in the Transducer Block "TRANSDUCER_DIAG" (diagnosis, base index 1600). More information on eliminating errors can be found in the Operating Instructions for PROline Prosonic Flow 93 FOUNDATION Fieldbus, BA078D/06/en.  Note! The "INPUT FAILURE" block error is relayed to downstream function blocks or higher-level process control systems by means of the status "BAD" for the output value OUT (AI Block). BLOCK CONFIG ERROR In the Analog Input function block, a configuration error is present which can be caused by the following: • A unit was selected via the XD_SCALE parameter group which does not suit the input value set in the CHANNEL parameter. For example, if "volume flow channel 1" was defined as the input value, a valid unit for the volume flow, such as m³/h, must be selected in the XD_SCALE parameter group. • No valid input value was selected in the CHANNEL parameter, (CHANNEL = 0, Uninitialized). • No valid linearisation type was selected in the L_TYPE parameter, (L_TYPE = 0, Uninitialized). • For "Direct" linearisation type, (L_TYPE parameter): The settings (unit, scaling) in the XD_SCALE and OUT_SCALE parameter groups do not match.  Note! • The operating mode of the Analog Input function block cannot be set to "AUTO" in the event of a "BLOCK CONFIG ERROR" block error. • The status of the output value OUT (AI Block) is BAD until the configuration error is eliminated which means that it cannot be used for downstream function blocks.

Analog Input function block / Base index: AI 1 = 350, AI 2 = 390, AI 3 = 430, AI 4 = 470, AI 5 = 510, AI 6 = 550, AI 7 = 590, AI 8 = 630		
Parameter	Write access with operating mode (MODE_BLK)	Description
CHANNEL	OOS	Assignment of the output values (process variables) of the Transducer Blocks "TRANSDUCER_CH1" (flow channel 1, base index 1200), "TRANSDUCER_CH 2" (flow channel 2, base index 1300) or "TRANSDUCER_TOT" (totalizer, base index 1550) to the input of the Analog Input function block in question. The Transducer Block of makes eight process variables available to the input channels of the Analog Input function blocks: User input: 2 = Volume flow channel 1 7 = Totalizer 1 8 = Totalizer 2 9 = Totalizer 3 20 = Volume flow channel 2 21 = Sound velocity channel 1 22 = Sound velocity channel 2 23 = Flow velocity channel 1 24 = Flow velocity channel 2 25 = Average volume flow 26 = Volume flow sum 27 = Volume flow difference 28 = Average sound velocity 29 = Average flow velocity 30 = Signal strength channel 1 31 = Signal strength channel 2 Factory setting: 0 = Uninitialized  Note! If 0 (= Uninitialized) is selected, the operating mode of the function block does not switch to the AUTO status. In this case, the "BLOCK CONFIG ERROR" block error is displayed in the BLOCK_ERROR parameter.
FIELD_VAL	read only	Displays the input value of "TRANSDUCER_CH1" (flow channel 1, base index 1200), "TRANSDUCER_CH 2" (flow channel 2, base index 1300) or "TRANSDUCER_TOT" (totalizer, base index 1550) including the related status. The value relates to a percentage of the XD_SCALE input range and when simulation is active is replaced by the simulation value. $\text{FIELD_VAL} = \frac{100 \cdot (\text{Process variables PV} - \text{XD_SCALE_0\%})}{(\text{XD_SCALE_100\%} - \text{XD_SCALE_0\%})}$  Note! The process variables and the input value of the Analog Input function block are assigned via the CHANNEL parameter.
GRANT_DENY	AUTO - MAN - OOS	Releases or restricts the access authorisation of a fieldbus host system to the field device.  Note! This parameter is not evaluated by PROline Prosonic Flow 93 FOUNDATION Fieldbus.

Analog Input function block / Base index: AI 1 = 350, AI 2 = 390, AI 3 = 430, AI 4 = 470, AI 5 = 510, AI 6 = 550, AI 7 = 590, AI 8 = 630		
Parameter	Write access with operating mode (MODE_BLK)	Description
HI_ALM	AUTO - MAN - OOS	Alarm status display for the upper warning limit value, (HI_LIM), including details of the time of the alarm (date, time) and the value that triggered the alarm.  Note! - In addition, the active alarm can be acknowledged in this parameter group. - If the option of the alarm has not been enabled in the ACK_OPTION parameter, the alarm can only be acknowledged via this parameter.
HI_HI_ALM	AUTO - MAN - OOS	Alarm status display for the upper alarm limit value, (HI_HI_LIM), including details of the time of the alarm (date, time) and the value that triggered the alarm.  Note! - In addition, the active alarm can be acknowledged in this parameter group. - If the option of the alarm has not been enabled in the ACK_OPTION parameter, the alarm can only be acknowledged via this parameter.
HI_HI_LIM	AUTO - MAN - OOS	Entry of the alarm limit value for the upper alarm, (HI_HI_LIM). If the output value OUT exceeds this limit value then the alarm status parameter HI_HI_ALM is output. User input: Range and unit of OUT_SCALE Factory setting: 3402823466 x 10³⁸
HI_HI_PRI	AUTO - MAN - OOS	Specifies the action taken when the upper alarm limit value (HI_HI_LIM) is exceeded. User input: 0 The violation of the upper alarm limit is not evaluated. 1 No notification if the upper alarm limit is violated. 2 Reserved for block alarms. 3-7 The violation of the upper alarm limit is output as a user notice with the appropriate priority (3 = low priority, 7 = high priority). 8-15 The violation of the upper alarm limit is output as a critical alarm with the appropriate priority (8 = low priority, 15 = high priority). Factory setting: 0


Analog Input function block / Base index: AI 1 = 350, AI 2 = 390, AI 3 = 430, AI 4 = 470, AI 5 = 510, AI 6 = 550, AI 7 = 590, AI 8 = 630		
Parameter	Write access with operating mode (MODE_BLK)	Description
HI_LIM	AUTO - MAN - OOS	Entry of the alarm limit value for the upper warning (HI_ALM). If the output value OUT exceeds this limit value then the alarm status parameter HI_ALM is output. User input: Range and unit of OUT_SCALE Factory setting: $3402823466 \times 10^{38}$
HI_PRI	AUTO - MAN - OOS	Specifies the action taken when the upper warning limit value (HI_LIM) is exceeded. User input: 0 The violation of the upper warning limit is not evaluated. 1 No notification if the upper warning limit is violated. 2 Reserved for block alarms. 3-7 The violation of the upper warning limit is output as a user notice with the appropriate priority (3 = low priority, 7 = high priority). 8-15 The violation of the upper warning limit is output as a critical alarm with the appropriate priority (8 = low priority, 15 = high priority). Factory setting: 0
IO_OPTS	OOS	Activates the options for processing the input and output values of the function block (I/O options). The following options are supported: Options: Low Cutoff Factory setting: Not enabled  Note! The switch-on point of the low flow cut off can be entered via the "LOW_CUT" parameter, (see Page 177).

Analog Input function block / Base index: AI 1 = 350, AI 2 = 390, AI 3 = 430, AI 4 = 470, AI 5 = 510, AI 6 = 550, AI 7 = 590, AI 8 = 630		
Parameter	Write access with operating mode (MODE_BLK)	Description
L_TYPE	MAN	Selects the type of linearisation for the input value. Options: Uninitialized Direct With this setting, the input value avoids the linearisation function and is looped unchanged with the same unit through the Analog Input function block. With this option the scaling and unit of the XD_SCALE and OUT_SCALE parameter groups must be identical. If this is not the case, the function block changes to the OOS operating mode and the "BLOCK CONFIG ERROR" block error is displayed in the BLOCK_ERROR parameter. $PV = \text{Input value}$ Indirect With this setting, the input value is re-scaled linearly via the XD_SCALE input scaling to the desired OUT_SCALE output range. $PV = \frac{X}{100} \cdot (Y - Z) - Z$ X = FIELD_VAL Y = OUT_SCALE_100% Z = OUT_SCALE_0%  Note! Further information in rescaling the input value is provided on Page 165. Indirect Square Root With this setting, the input value is re-scaled via the XD_SCALE parameter group and recalculated using a root function. It is then rescaled again to the desired output range via the OUT_SCALE parameter group. $PV = \sqrt{\frac{X}{100}} \cdot (Y - Z) - Z$ X = FIELD_VAL Y = OUT_SCALE_100% Z = OUT_SCALE_0% Factory setting: Uninitialized  Note! If "Uninitialized" is selected, the operating mode of the function block does not switch to the AUTO status. In this case, the "BLOCK CONFIG ERROR" block error is displayed via the BLOCK_ERROR parameter.

Analog Input function block / Base index: AI 1 = 350, AI 2 = 390, AI 3 = 430, AI 4 = 470, AI 5 = 510, AI 6 = 550, AI 7 = 590, AI 8 = 630		
Parameter	Write access with operating mode (MODE_BLK)	Description
LO_ALM	AUTO - MAN - OOS	Alarm status display for the lower warning limit value, (LO_LIM), including details of the time of the alarm (date, time) and the value that triggered the alarm.  Note! • In addition, the active alarm can be acknowledged in this parameter group. • If the option of the alarm has not been enabled in the ACK_OPTION parameter, the alarm can only be acknowledged via this parameter.
LO_LIM	AUTO - MAN - OOS	Entry of the alarm limit value for the lower warning, (LO_ALM). If the output value OUT undershoots this limit value then the alarm status parameter LO_ALM is output. User input: Range and unit of OUT_SCALE Factory setting: $-3402823466 \times 10^{38}$
LO_LO_ALM	read only	Alarm status display for the lower alarm limit value, (LO_LO_LIM), including details of the time of the alarm (date, time) and the value that triggered the alarm.  Note! • In addition, the active alarm can be acknowledged in this parameter group. • If the option of the alarm has not been enabled in the ACK_OPTION parameter, the alarm can only be acknowledged via this parameter.
LO_LO_LIM	AUTO - MAN - OOS	Entry of the alarm limit value for the lower alarm, (LO_LO_ALM). If the output value OUT undershoots this limit value then the alarm status parameter LO_LO_ALM is output. User input: Range and unit of OUT_SCALE Factory setting: $-3402823466 \times 10^{38}$

Analog Input function block / Base index: AI 1 = 350, AI 2 = 390, AI 3 = 430, AI 4 = 470, AI 5 = 510, AI 6 = 550, AI 7 = 590, AI 8 = 630		
Parameter	Write access with operating mode (MODE_BLK)	Description
LO_LO_PRI	AUTO - MAN - OOS	Specifies the action taken when the lower alarm limit value (LO_LO_LIM) is undershot. User input: 0 The violation of the lower alarm limit is not evaluated. 1 No notification to master if the lower alarm limit is violated. 2 Reserved for block alarms. 3-7 The violation of the lower alarm limit is output as a user notice with the appropriate priority (3 = low priority, 7 = high priority). 8-15 The violation of the lower alarm limit is output as a critical alarm with the appropriate priority (8 = low priority, 15 = high priority). Factory setting: 0
LO_PRI	AUTO - MAN - OOS	Specifies the action taken when the lower warning limit value (LO_LIM) is exceeded. User input: 0 The violation of the lower warning limit is not evaluated. 1 No notification to master if the lower warning limit is violated. 2 Reserved for block alarms. 3-7 The violation of the lower warning limit is output as a user notice with the appropriate priority (3 = low priority, 7 = high priority). 8-15 The violation of the lower warning limit is output as a critical alarm with the appropriate priority (8 = low priority, 15 = high priority). Factory setting: 0

Analog Input function block / Base index: AI 1 = 350, AI 2 = 390, AI 3 = 430, AI 4 = 470, AI 5 = 510, AI 6 = 550, AI 7 = 590, AI 8 = 630		
Parameter	Write access with operating mode (MODE_BLK)	Description
LOW_CUT	AUTO - MAN - OOS	Entry of a limit value for the low flow cut off. If the converted measured value is below this limit value then PV is shown as zero. User input: Range and unit of OUT_SCALE Factory setting: 0  Note! • This parameter is not active unless the I/O option "low flow cut off" has been selected in the IO_OPTS parameter, (see Page 173). • The unit used is copied from the OUT_SCALE parameter group.
MODE_BLK	AUTO - MAN - OOS	Displays the current (Actual) and desired (Target) operating mode of the Analog Input function block, the permitted modes (Permitted) supported by the Resource Block and the normal operating mode (Normal). Display: AUTO MAN OOS  Note! The Analog Input function block supports the following operating modes: • AUTO (automatic mode): The block is executed. • MAN (manual intervention by the operator): The output value OUT can be specified manually. • OOS (out of service): The block is in the "Out of Service" mode. With the output value OUT the last valid value is output. The status of the output value OUT switches to BAD.
OUT	MAN - OOS	Displays the output value with alarm evaluation and the status of the Analog Input function block.  Note! • If MAN (manual) is selected for the operating mode in the MODE_BLK parameter then the output value OUT can be specified manually here. • The unit used is copied from the OUT_SCALE parameter group.


Analog Input function block / Base index: AI 1 = 350, AI 2 = 390, AI 3 = 430, AI 4 = 470, AI 5 = 510, AI 6 = 550, AI 7 = 590, AI 8 = 630		
Parameter	Write access with operating mode (MODE_BLK)	Description
OUT_SCALE	MAN - OOS	Definition of the measuring range (lower and upper limit), the physical unit and the number of decimal places for the output value OUT. Factory setting: 0...100 %  Note! - The measuring range definition in this parameter group does not limit the output value OUT. If the output value OUT is outside the measuring range, the value is still transmitted. - If "Direct" was selected in the L_TYPE parameter, the settings for the measuring range and unit must be identical to those in the XD_SCALE parameter group. If this is not the case, the function block does not switch to the AUTO operating mode. The "BLOCK CONFIG ERROR" block error is then displayed in the BLOCK_ERR parameter.
PV	read only	Displays the process variable used for the block execution, including the status of the process variable.  Note! The unit used is copied from the OUT_SCALE parameter group.
PV_FTIME	AUTO - MAN - OOS	Entry of the filter time constant (in seconds) of the digital filter of the 1st order. This time is required in order for 63% of a change in the FIELD_VAL parameter to have an effect on the value of PV. The diagram shows the signal curves of the Analog Input function block over time:  a) The FIELD_VAL parameter changes. b) The PV parameter has reacted 63% to the change in the FIELD_VAL parameter. Factory setting: 0 s F06-53rFFxxx-05-xx-xx-en-003

Analog Input function block / Base index: AI 1 = 350, AI 2 = 390, AI 3 = 430, AI 4 = 470, AI 5 = 510, AI 6 = 550, AI 7 = 590, AI 8 = 630		
Parameter	Write access with operating mode (MODE_BLK)	Description
SIMULATE	AUTO - MAN - OOS	Simulation of the input value and input status. Since this value runs through the entire algorithm, the behaviour of the Analog Input function block can be checked. Factory setting: Simulation Disabled (simulation not active)  Note! • The BLOCK_ERR parameter of the Resource Block indicates whether simulation is possible, (see Page 92). • The BLOCK_ERR parameter of the Analog Input function block indicates whether simulation is active, (see Page 170). • The simulation mode is enabled by means of jumpers on the I/O board, (see Operating Instructions for PROline Prosonic Flow 93 FOUNDATION Fieldbus, BA078D/06/en).
ST_REV	read only	Displays the revision status of the static data.  Note! The revision status parameter is incremented on each modification of static data.
STATUS_OPTS	OOS	Specifies the options for status processing and processing of the output value OUT. The following options are supported by the Analog Input function block: Options: Uncertain if MAN mode: The status of the output value OUT changes to UNCERTAIN if the operating mode is set to "MAN". Propagate Fault Forward: Fault is forwarded on. The status of the corresponding Transducer Block is relayed to the downstream function blocks via the BKCAL_OUT parameter. Factory setting: No options active
STRATEGY	AUTO - MAN - OOS	Parameter for grouping and thus faster evaluation of blocks. Grouping is carried out by entering the same numerical value in the STRATEGY parameter of each individual block. Factory setting: 0  Note! These data are neither checked nor processed by the Analog Input function block.

Analog Input function block / Base index: AI 1 = 350, AI 2 = 390, AI 3 = 430, AI 4 = 470, AI 5 = 510, AI 6 = 550, AI 7 = 590, AI 8 = 630		
Parameter	Write access with operating mode (MODE_BLK)	Description
TAG_DESC	AUTO - MAN - OOS	Entry of a user-specific text of max. 32 characters for unique identification and assignment of the block. Factory setting: " _ _ _ _ _ " no text
UPDATE_EVT	read only	Displays whether static block data have been modified, including date and time.
XD_SCALE	MAN - OOS	In this parameter group, the input value from the Transducer Block "TRANSDUCER_CH1" (flow channel 1, base index 1200), "TRANSDUCER_CH 2" (flow channel 2, base index 1300) or "TRANSDUCER_TOT" (totalizer, base index 1550) is scaled and the unit is defined. User input: Measuring range of the process variable (input value) Factory setting: 0...100 %  Note! - Defining the measuring range in this parameter group does not represent a restriction. If the value is outside the measuring range, it is transferred nonetheless. - The selection of units depends on the setting in the CHANNEL parameter, (see Page 171): Channel = 2: only units for the volume flow are valid Channel = 7: only units for totalizer 1 are valid Channel = 8: only units for totalizer 2 are valid Channel = 9: only units for totalizer 3 are valid Channel = 20: only units for the volume flow are valid Channel = 21: only units for the sound velocity are valid Channel = 22: only units for the sound velocity are valid Channel = 23: only units for the flow velocity are valid Channel = 24: only units for the flow velocity are valid Channel = 25: only units for the volume flow are valid Channel = 26: only units for the volume flow are valid Channel = 27: only units for the volume flow are valid Channel = 28: only units for the sound velocity are valid Channel = 29: only units for the flow velocity are valid Channel = 30: only units for the signal strength are valid Channel = 31: only units for the signal strength are valid - The function block remains in the OOS (out of service) mode if the unit selected does not suit the input value selected in the CHANNEL parameter. In this case, the "BLOCK CONFIG ERROR" block error is displayed via the BLOCK_ERROR parameter. - An example of rescaling the input value is provided on Page 165.

5 Discrete Output function block

The Discrete Output (DO) function block processes the discrete setpoint value received from an upstream function block or higher-level process control system, with which various instrument functions (e.g. zero point adjustment or totalizer reset) can be initiated in the downstream Transducer Blocks.



CAS_IN_D = Remote input value and status from an upstream block
 OUT_D = Discrete output value and status
 BKCAL_OUT_D = Output value and status for the BKCAL_IN_D input of another block.

5.1 Signal processing

The figure shows the internal structure of the Discrete Output function block of PROline Prosonic Flow 93 FOUNDATION Fieldbus:




Fig. 4: Signal processing in the Discrete Output function block

In the CAS (cascade operation) operating mode, the Discrete Output function block receives, via the CAS_IN_D function block input, a discrete signal from an upstream function block. This signal controls the setpoint value (SP_D parameter) of the function block and, after internal calculation, is sent as an output signal (OUT_D parameter) to the Transducer Blocks for control of instrument functions (e.g. zero point adjustment). The output value and status of the Discrete Output function block is communicated to the upstream block via the BKCAL_OUT_D output.

Signal processing in the RCAS (remote cascade operation) operating mode is largely identical to the CAS operating mode. However, in this operating mode, control of the SP_D parameter does not take place via an upstream function block but rather via a fieldbus host system. The output value and status of the Discrete Output function block is communicated to the fieldbus host system as a feedback message via the RCAS_OUT_D parameter.

In the AUTO (automatic) operating mode, the setpoint value (SP_D parameter) is prescribed directly in the Discrete Output function block. In this case, the CAS_IN_D parameter is not taken into consideration in the internal calculation.

In the MAN (manual) operating mode, the output value (OUT_D parameter) can be prescribed directly in the Discrete Output function block. No internal calculation takes place.

The most important functions and parameters of the Discrete Output function block are listed below; you will find an overview of all the parameters available on Page 184 ff.

5.2 Selecting the operating mode

The operating mode is set by means of the MODE_BLK parameter group, (see Page 187). The Discrete Output function block supports the following operating modes:

- AUTO
- MAN
- CAS
- RCAS
- OOS

5.3 Security behaviour

There is a safety default available (fault state) for the Discrete Output function block. This is activated when a fault condition (of the corresponding valid setpoint value) exists longer than defined in the FSTATE_TIME parameter, or when the SET_FSTATE parameter in the Resource Block is activated. The security behaviour is determined via the FSTATE_TIME, FSTATE_VAL_D, and IO_OPTS parameters.

5.4 Assignment: DO function block/Transducer Blocks

The Discrete Output function block and the Transducer Blocks are assigned/connected via the CHANNEL parameter, (option “16” → Discrete Output function block).

5.5 Values for the CAS_IN_D, RCAS_IN_D, OUT_D, and SP_D parameters

Via the Discrete Output function block, different instrument functions in the appropriate Transducer Blocks can be initiated via manufacturer-specific, fixed setpoint values from an upstream function block.

Here it must be observed that the desired function is only then executed when a status change from the value 0 (Discrete state 0) to the corresponding function value takes place (see Table). The value 0 always serves as the starting point for the corresponding control of instrument functions. A status change from a value not equal to zero to another value has no effect.

Input allocation of the CAS_IN_D, RCAS_IN_D, OUT_D, SP_D parameters

Status changes			Action
Discrete state 0	→	Discrete state 1	Reserved
Discrete state 0	→	Discrete state 2	Positive zero return channel 1 "ON"
Discrete state 0	→	Discrete state 3	Positive zero return channel 1 "OFF"
Discrete state 0	→	Discrete state 4	Zero point adjustment channel 1
Discrete state 0	→	Discrete state 5	Reserved
Discrete state 0	→	Discrete state 6	Reserved
Discrete state 0	→	Discrete state 7	Reset totalizers 1, 2, 3
Discrete state 0	→	Discrete state 8	Reset totalizer 1
Discrete state 0	→	Discrete state 9	Reset totalizer 2
Discrete state 0	→	Discrete state 10	Reset totalizer 3
Discrete state 0	→	Discrete state 11	Reserved
Discrete state 0	→	Discrete state 12	Reserved
Discrete state 0	→	Discrete state 13	Reserved
Discrete state 0	→	Discrete state 14	Reserved
Discrete state 0	→	Discrete state 15	Reserved
Discrete state 0	→	Discrete state 16	Positive zero return channel 2 "ON"
Discrete state 0	→	Discrete state 17	Positive zero return channel 2 "OFF"
Discrete state 0	→	Discrete state 18	Zero point adjustment channel 2

Example for the control of positive zero return via the Discrete Output function block.

The following example shows how the positive zero return for channel 1 can be activated or deactivated by an upstream function block via the Discrete Output function block during a cleaning procedure.

1. In the first step, the connection between the Discrete Output function block and the Transducer Blocks must be established. For this, the value "16" (= Discrete Output) must be assigned to the CHANNEL parameter.
2. In the CAS operating mode, the Discrete Output function block processes the setpoint value prescribed at the CAS_IN_D input from an upstream function block and transfers it to the Transducer Blocks.

Activating the positive zero return, channel 1

With a starting value of 0 (Discrete state 0), the positive zero return is activated by a status change from 0 → 2 at the CAS_IN_D input.

Deactivating the positive zero return, channel 1

The positive zero return for channel 1 can only then be deactivated when the input value at CAS_IN_D has first been set to output value 0 (Discrete state 0). Only then can the positive zero return be deactivated again through a status change from 0 → 3 at the CAS_IN_D input.

5.6 Parameters of the Discrete Output function block

Discrete Output function block / base index 780		
Parameter	Write access with operating mode (MODE_BLK)	Description
ALERT_KEY	AUTO - MAN - OOS - CAS - RCAS	Entry of the identification number of the plant unit. This information can be used by the fieldbus host system for sorting alarms and events. User input: 1...255 Factory setting: 0
BLOCK_ALM	AUTO - MAN - OOS - CAS - RCAS	Displays the current block status with information on pending configuration, hardware or system errors, including details of the alarm time (date, time) when the error occurred. The block alarm is triggered in the event of the following block errors: • SIMULATION ACTIVE • INPUT FAILURE • OUTPUT FAILURE • READBACK FAILURE • OUT OF SERVICE • BLOCK CONFIG ERROR
BKCAL_OUT_D	read only	Displays the discrete output value and output status transferred in the case of cascade control to the BKCAL_IN_D input of the upstream function block.
BLOCK_ERR	read only	Displays the active block error. Display: SIMULATION ACTIVE Simulation in the "SIMULATE_D" parameter group of the Discrete Output Block is active. INPUT FAILURE Input fault. The input value of the upstream function block has a status of BAD. OUTPUT FAILURE Fault in Transducer Block. READBACK FAILURE A fault in the hardware used by the READBACK_D parameter. OUT OF SERVICE The block has the status "Out of Service". BLOCK CONFIG ERROR • An operating switchover is not possible, since the value of the Period of Execution time = 0. • A switchover to the RCAS operating mode is not possible since "Uninitialized" was selected in the SHED_OPT parameter.

Discrete Output function block / base index 780		
Parameter	Write access with operating mode (MODE_BLK)	Description
CAS_IN_D	AUTO - MAN - OOS - CAS - RCAS	Displays the discrete input value and status copied from an external function block in the CAS operating mode. Discrete state 0 = Starting point, no effect Discrete state 1 = Reserved Discrete state 2 = Positive zero return channel 1 "ON" Discrete state 3 = Positive zero return channel 1 "OFF" Discrete state 4 = Zero point adjustment channel 1 Discrete state 5 = Reserved Discrete state 6 = Reserved Discrete state 7 = Reset totalizers 1, 2, 3 Discrete state 8 = Reset totalizer 1 Discrete state 9 = Reset totalizer 2 Discrete state 10 = Reset totalizer 3 Discrete state 11 = Reserved Discrete state 12 = Reserved Discrete state 13 = Reserved Discrete state 14 = Reserved Discrete state 15 = Reserved Discrete state 16 = Positive zero return channel 2 "ON" Discrete state 17 = Positive zero return channel 2 "OFF" Discrete state 18 = Zero point adjustment channel 2  Note! - The desired function will only then be executed when a status change from 0 (Discrete state 0) to the corresponding function value, (e.g. Discrete state 2 = positive zero return ON), takes place. - The remote setpoint value read in via the CAS_IN_D parameter is only used if the Discrete Output function block is in the CAS operating mode. In the AUTO operating mode, the value of the SP_D parameter is used as a setpoint value.
CHANNEL	OOS	 Note! With PROline Prosonic Flow 93 FOUNDATION Fieldbus, this parameter is fixed at 16. Assignment of the logical hardware channels of the Transducer Blocks "TRANSDUCER_CH1" (flow channel 1, base index 1200), "TRANSDUCER_CH 2" (flow channel 2, base index 1300) or "TRANSDUCER_TOT" (totalizer, base index 1550) to the input of the Discrete Output function block in question. Options: 0 = Uninitialized 16 = Discrete Output Factory setting: 0 = Uninitialized

Discrete Output function block / base index 780		
Parameter	Write access with operating mode (MODE_BLK)	Description
FSTATE_TIME	AUTO - MAN - OOS - CAS - RCAS	Entry of the delay time which must expire with a fault of the external reference value (RCAS_IN_D parameter), before the defined fault operation is initiated. Factory setting: 0 s  Note! After expiry of the delay time and a still active fault, the following values are used for further processing: • If the option "Fault State to value" was selected in the IO_OPTS parameter, the value of the FSTATE_VAL_D (fault replacement value) parameter will be used. • If the option "Fault State to value" was not selected in the IO_OPTS parameter, the value of the RCAS_IN_D parameter will continue to be used.
FSTATE_VAL_D	AUTO - MAN - OOS - CAS - RCAS	Entry of a fault condition replacement value for the RCAS_IN_D parameter. This value is used for further processing instead of the RCAS_IN_D parameter when the following conditions are met:: • An active fault of the RCAS_IN_D parameter exists. • The delay time FSTATE_TIME has elapsed. • The "Fault state to value" option has been selected in the IO_OPTS parameter. Options: 0 = Starting point, no effect 1 = Reserved 2 = Positive zero return channel 1 "ON" 3 = Positive zero return channel 1 "OFF" 4 = Zero point adjustment channel 1 5 = Reserved 6 = Reserved 7 = Reset totalizers 1, 2, 3 8 = Reset totalizer 1 9 = Reset totalizer 2 10 = Reset totalizer 3 11 = Reserved 12 = Reserved 13 = Reserved 14 = Reserved 15 = Reserved 16 = Positive zero return channel 2 "ON" 17 = Positive zero return channel 2 "OFF" 18 = Zero point adjustment channel 2 Factory setting: 0
GRANT_DENY	AUTO - MAN - OOS - CAS - RCAS	Releases or restricts the access authorisation of a fieldbus host system to the field device.  Note! This parameter is not evaluated by PROline Prosonic Flow 93 FOUNDATION Fieldbus.

Discrete Output function block / base index 780		
Parameter	Write access with operating mode (MODE_BLK)	Description
IO_OPTS	OOS	Activates the options for processing the input and output values of the function block (I/O options). Options: • PV for BKCAL_OUT For BKCAL_OUT_D, the value of PV_D parameter is used instead of the SP_D parameter. • SP-PV Track in MAN SP_D follows PV_D in the MAN operating mode. • SP-PV Track in LO SP_D follows PV_D in the LO operating mode. • Invert Inverting of the output value OUT_D to the Transducer Block. • Fault State to value When security behaviour is initiated, FSTATE_VAL_D is used as a setpoint value. • Use Fault State Value on restart During instrument startup, FSTATE_VAL_D is used as setpoint value until a valid value is available. • Target to MAN if Fault State activated When security behaviour is initiated, the requested (Target) operating mode of the MODE_BLK parameter group is set to MAN, and the original target operating mode is lost. After leaving the security behaviour, the block remains in MAN and must be set to the desired operating mode by the user. Factory setting: Not enabled
MODE_BLK	AUTO - MAN - OOS - CAS - RCAS	Displays the current (Actual) and desired (Target) operating mode of the Discrete Output function block, the permitted modes (Permitted) supported by the Resource Block and the normal operating mode (Normal). Display: AUTO - MAN - OOS - CAS - RCAS The Discrete Output function block supports the following operating modes: • AUTO (automatic mode): The setpoint value specified by the user via the SP_D parameter is used in the execution of the internal Discrete Output algorithm. • MAN (manual intervention by the operator): The OUT_D parameter can be specified directly by the user. • OOS (out of service): The block has the status "Out of Service". The Discrete Output algorithm of the block is not executed. The last valid value is output at the OUT_D parameter and the status changes to BAD. • CAS (cascade mode): Via the input or CAS_IN_D parameter, the Discrete Output function block receives the setpoint value (for internal calculation) directly from another function block. The internal Discrete Output algorithm is executed. • RCAS (remote cascade): Via the RCAS_IN_D parameter, the Discrete Output function block receives the setpoint value (for internal calculation) directly from the fieldbus host system. The internal Discrete Output algorithm is executed.

Discrete Output function block / base index 780		
Parameter	Write access with operating mode (MODE_BLK)	Description
OUT_D	MAN - OOS	Displays the discrete output value and the status of the Discrete Output function block.  Note! If MAN (manual) is selected for the operating mode in the MODE_BLK parameter then the output value OUT_D can be specified manually here.
PV_D	read only	Displays the discrete process variable value and status determined in the READBACK_D parameter.
PV_STATE	AUTO - MAN - OOS - CAS - RCAS	In this parameter, the fieldbus host system can store a reference to a description of the possible states of the PV_D parameter.  Note! This parameter is not evaluated by PROline Prosonic Flow 93 FOUNDATION Fieldbus.
RCAS_IN_D	AUTO - MAN - OOS - CAS - RCAS	In this parameter, the discrete setpoint value (value and status) provided externally, (fieldbus host system, other function block etc.), is read in for internal calculation and displayed.  Note! This parameter is only active in the RCAS operating mode.
RCAS_OUT_D	read only	Displays the discrete output value and status of the specified setpoint value transferred to the fieldbus host system in the course of cascade control.  Note! This parameter is only active in the RCAS operating mode.
READBACK_D	read only	Displays the input signal condition and status of the feedback message input.
SHED_OPT	AUTO - MAN - OOS - CAS - RCAS	Selects the action taken if the monitoring time is exceeded, (see SHED_RCAS parameter, Page 96) in the RCAS operating mode. During the monitoring time, parameter updating between the fieldbus host system and the Discrete Output function block is checked. If the parameters are not being updated then on expiry of the monitoring time the Discrete Output function block switches from the RCAS operating mode to the mode selected here. Options: Uninitialized NormalShed_NormalReturn NormalShed_NoReturn ShedToAuto_NormalReturn ShedToAuto_NoReturn ShedToManual_NormalReturn ShedToManual_NoReturn ShedToRetainedTarget_NormalReturn ShedToRetainedTarget_NoReturn Factory setting: Uninitialized


Discrete Output function block / base index 780		
Parameter	Write access with operating mode (MODE_BLK)	Description
SIMULATE_D	AUTO - MAN - OOS - CAS - RCAS	Simulation of the value and status of the process variable PV_D. Factory setting: Simulation Disabled (simulation not active)  Note! - During the simulation, the value of OUT_D is not passed on to the Transducer Block. The Transducer Block keeps the last valid value from before the simulation was activated. - The BLOCK_ERROR parameter of the Resource Block indicates whether simulation is possible.
SP_D	AUTO - MAN - OOS	Entry of the discrete setpoint value. Options: 0 = Starting point, no effect 1 = Reserved 2 = Positive zero return channel 1 "ON" 3 = Positive zero return channel 1 "OFF" 4 = Zero point adjustment channel 1 5 = Reserved 6 = Reserved 7 = Reset totalizers 1, 2, 3 8 = Reset totalizer 1 9 = Reset totalizer 2 10 = Reset totalizer 3 11 = Reserved 12 = Reserved 13 = Reserved 14 = Reserved 15 = Reserved 16 = Positive zero return channel 2 "ON" 17 = Positive zero return channel 2 "OFF" 18 = Zero point adjustment channel 2
ST_REV	read only	Displays the revision status of the static data.  Note! The revision status parameter is incremented on each modification of static data.
STATUS_OPTS	OOS	Selects the available status options for specifying the status processing and processing of the output value OUT_D. The following options are supported: Options: Propagate Fault Backward Pass on fault operation to upstream blocks. Factory setting: No option active

Discrete Output function block / base index 780		
Parameter	Write access with operating mode (MODE_BLK)	Description
STRATEGY	AUTO - MAN - OOS - CAS - RCAS	Parameter for grouping and thus faster evaluation of blocks. Grouping is carried out by entering the same numerical value in the STRATEGY parameter of each individual block. Factory setting: 0  Note! These data are neither checked nor processed by the Discrete Output function block.
TAG_DESC	AUTO - MAN - OOS - CAS - RCAS	Entry of a user-specific text of max. 32 characters for unique identification and assignment of the block. Factory setting: " _ _ _ _ _ " no text
UPDATE_EVT	read only	Displays whether static block data have been modified, including date and time.
XD_STATE	AUTO - MAN - OOS - CAS - RCAS	In this parameter, the fieldbus host system can store a reference to a description of the possible states of the PV_D parameter.  Note! This parameter is not evaluated by PROline Prosonic Flow 93 FOUNDATION Fieldbus.

6 PID function block (PID controller)

A PID function block contains the input channel processing, the proportional integral-differential control (PID) and the analog output channel processing. The configuration of the PID function block depends on the automation task. The following can be realised: basic closed-control loops, feedforward control, cascade control, cascade control with limiting.

The possibilities available for data processing within the PID function block include: signal scaling and limiting, operating mode control, feedforward control, limiting control, alarm detection, signal status propagation.



- IN = Input of the controlled variable from another function block.
- CAS_IN = Input of the remote setpoint value from another function block.
- BKCAL_IN = Input of the feedback value and status from the BKCAL_OUT output of the downstream function block which ensures bumpless switching of the operating mode.
- TRK_IN_D = Discrete input for activating the external output tracking function.
- TRK_VAL = Input for the external value for tracking from another function block.
- FF_VAL = Input for the disturbance variable from another function block.
- OUT = Output value and status (manipulated variable) of the PID function block.
- BKCAL_OUT = Output for the feedback value and status transferred to the BKCAL_IN input of the upstream function block to ensure bumpless switching of the operating mode.

6.1 Signal processing




Fig. 5: Internal structure of the PID function block

6.2 PID function block equation

The PID function block (PID controller) can be used for various automation strategies. The function block has a flexible control algorithm that can be configured differently depending on the application.

$$y = \text{GAIN} \cdot \left(e + \frac{1}{\text{RESET}} \cdot \int e \cdot \Delta t + \text{RATE} \cdot \frac{\Delta e}{\Delta t} \right) + F$$

y = Manipulated variable calculated from the PID algorithm.

GAIN = Proportional gain factor (P-term)

RESET = Time constant for the integral function (I-term)

RATE = Time constant for the derivative action (D-term)

e = Control deviation (e = setpoint value - PV)

F = Disturbance variable (F = FF_VAL · FF_GAIN)

The OUT output value results following checking of the OUT_HI_LIM and OUT_LO_LIM range limits, (see Page 211).

The PID function block consists of a proportional term, an integral term and a derivative term. The manipulated variable is calculated on the basis of the control deviation between the setpoint value SP and the process variable PV (controlled variable).

The individual PID terms are used in the calculation of the manipulated variable as follows:

- Proportional term:

The proportional term reacts directly and immediately to a change in the setpoint value SP or the process variable PV (controlled variable). The manipulated variable is modified by the proportional factor GAIN. This corresponds to the control deviation multiplied by the gain factor. If a controller works only with the proportional term, then the control has a lasting control deviation.

- Integral term:

The control deviation arising from the calculation of the manipulated variable using the proportional term is integrated via the integral term of the controller until this control deviation is negligible. The integral function RESET corrects the manipulated variable depending on the size and duration of the control deviation. If the value for the integral function RESET is set to zero then the controller works with pure I-control. The influence of the integral term on the control is greater if the value of the integral function RESET is reduced.

- Derivative term:

In the case of control sections with long delays, e.g. temperature controls, it is useful to use the derivative term RATE of the controller. Using the derivative term RATE the manipulated variable is calculated as a function of the change in the control deviation.

6.3 Selecting the operating mode

The operating mode is set by means of the MODE_BLK parameter group, (see Page 210). The PID function block supports the following operating modes:

- AUTO
- MAN
- OOS
- CAS
- RCAS
- ROUT



Note!

The OOS block status is also displayed via the BLOCK_ERR parameter, (see Page 201). In the OOS operating mode, you can access all the write parameters without restriction if write protection is not enabled.

6.4 Setpoint value specification

The PID function block works with different setpoint values (reference values) depending on the active operating mode:

- The PID function block is in the AUTO operating mode:
The setpoint value of the SP parameter, (see Page 214), is used to calculate the manipulated variable. This setpoint value is specified manually by the operator in the SP parameter.
- The PID function block is in the CAS operating mode:
The setpoint value of the CAS_IN parameter, (see Page 202), is used to calculate the manipulated variable. This setpoint value is copied from an external function block and read in via the CAS_IN parameter in the PID function block.
- The PID function block is in the RCAS operating mode:
The setpoint value of the RCAS_IN parameter, (see Page 213), is used to calculate the manipulated variable. This setpoint value is copied from the fieldbus host system and read in via the RCAS_IN parameter in the PID function block.



Note!

The range of the setpoint value entry can be restricted via the SP_HI_LIM and SP_LO_LIM parameters, (see Page 215).

6.5 Damping

Specifying a time in the PV_FTIME parameter, (see Page 212), slows down the reaction of the internal process variables to changes in the input value IN, (controlled variable). This output filter is useful where the input value fluctuates greatly. Where a time of 0 seconds is specified, the output value is not filtered.

6.6 Limit values

The limit values are based on the value of the process variable PV, (see Page 212). If the process variable PV exceeds or undershoots the defined limit values, an alarm is sent to the fieldbus host system via the limit value process alarms. The following limit values can be defined:

- | | | | |
|-------------|----------------|-------------|----------------|
| – HI_HI_LIM | (see Page 205) | – HI_LIM | (see Page 206) |
| – LO_LO_LIM | (see Page 208) | – LO_LIM | (see Page 207) |
| – DV_HI_ALM | (see Page 202) | – DV_LO_ALM | (see Page 204) |

6.7 Alarm detection and processing

Process alarms provide information on particular block statuses and block events. The status of the process alarms is communicated to the fieldbus host system via the BLOCK_ALM parameter, (see Page 201). The ACK_OPTION parameter, (see Page 197), specifies whether an alarm must be acknowledged via the fieldbus host system.

The following process alarms are generated by the PID function block:

- Block process alarms

A block process alarm is triggered via the BLOCK_ERR parameter, (see Page 201). The BLOCK_ALM parameter (see Page 197) is used to show the block process alarms and communicate them to the fieldbus host system. The following block process alarm can be generated by the PID function block:

- OUT OF SERVICE

- If the option of the process alarm (BLOCK ALM) has **not** been enabled in the ACK_OPTION parameter, (see Page 197), the process alarm can only be acknowledged in the BLOCK_ALM parameter, (see Page 197).

- Limit value process alarms

If a limit value is violated then the priority specified for the limit value alarm is checked before the limit value violation is communicated to the fieldbus host system. The priority that specifies the action in the event of an active limit value violation is determined by the following parameters:

- | | | | |
|-------------|----------------|-------------|----------------|
| – HI_HI_PRI | (see Page 206) | – HI_PRI | (see Page 207) |
| – LO_LO_PRI | (see Page 207) | – LO_PRI | (see Page 209) |
| – DV_HI_PRI | (see Page 203) | – DV_LO_PRI | (see Page 204) |

The status of the limit value process alarms is communicated to the fieldbus host system via the following parameters:

- | | | | |
|-------------|----------------|-------------|----------------|
| – HI_HI_ALM | (see Page 205) | – HI_ALM | (see Page 205) |
| – LO_LO_ALM | (see Page 208) | – LO_ALM | (see Page 207) |
| – DV_HI_ALM | (see Page 202) | – DV_LO_ALM | (see Page 203) |

If the option of a limit value process alarm has **not** been enabled in the ACK_OPTION parameter, (see Page 197), then this must be acknowledged directly in its parameter (see list).



Note!

The ALARM_SUM parameter, (see Page 199), shows the current status of all the process alarms.

6.8 Example: Basic PID control

The continual flow into a container is to be controlled.

The volume flow of the fluid is captured via a flow transmitter (FT) and made available to the PID function block via an Analog Input function block. The PID function block may be either in the flowmeter or in the control valve. The manipulated variable that is forwarded to the control valve (FV) is calculated in the PID function block using the deviation between the measured volume flow and the specified setpoint value (desired volume flow).




Fig. 6: PID control for continual flow into a container

Connecting the function blocks

The PID function block receives its input value (controlled variable) from an Analog Input function block (OUT output value). This input value, which corresponds to the measured volume flow of the flowmeter, is read into the PID function block via the IN parameter, (see Page 207).

In the AUTO operating mode, the setpoint value is specified manually via the SP parameter, (see Page 214).

The manipulated variable calculated in the PID function block is connected to the CAS_IN input parameter of the Analog Output function block via the output value OUT, (see Page 211). The Analog Output function block forwards this manipulated variable to the control valve.

In addition, the BKCAL_OUT output parameter of the Analog Output function block is read in via the BKCAL_IN input parameter, (see Page 201), of the PID function block to ensure bumpless switching of the operating mode.




Fig. 7: Connecting the function blocks

6.9 Example of configuration

The measuring range of the flowmeter (controlled variable) is 0...30 m³/h.

The desired flow value (setpoint value) is specified manually by means of the SP parameter and should be 15 m³/h. The Analog Output function block is actuated over an output range of 0 ... 100%.

Configuration:

- Setting the input range and input unit of the controlled variable at input IN:

PV_SCALE 0 % = 0
PV_SCALE 100% = 30
PV_SCALE UNIT = m³/h

- Setting the output range and output unit of the manipulated variable at output OUT:

OUT_SCALE 0 % = 0
OUT_SCALE 100 % = 100
OUT_SCALE UNIT = %

- Defining the input limits for the setpoint value range:

SP_LO_LIM = 0
SP_HI_LIM = 30

- Defining the output limits for the manipulated variable at output OUT:

OUT_LO_LIM = 0
OUT_HI_LIM = 100

- Setting the bypass function:

In order to be able to deactivate the bypass function via the BYPASS parameter, the Bypass Enable option must first be activated via the CONTROL_OPTS parameter.

- Setting the control parameter (depending on the controlled system):

GAIN - proportional gain factor (P-term)
RESET- time constant for the integral function (I-term)
RATE- time constant for the derivative action (D-term)

- Specifying the setpoint value via SP parameter:

SP = 15


- Configuration of the limit value and control deviation alarms and associated priorities, if required.

- In order for the PID function block to be executed the operating mode must be set to AUTO.


6.10 Parameters of the PID function block

The following table shows all the parameters available for the PID function block:

PID function block (PID controller) / base index 810		
Parameter	Write access with operating mode (MODE_BLK)	Description
ACK_OPTION	ROUT - RCAS - CAS - AUTO - MAN - OOS	This parameter is used to specify whether a process alarm must be acknowledged at the time of alarm detection by the fieldbus host system. If this option is enabled the process alarm is acknowledged automatically. Options: HI_HI_ALM Upper limit value alarm HI_ALM Upper limit value warning LO_LO_ALM Lower limit value alarm LO_ALM Lower limit value warning DV_HI_ALM Limit value alarm for upper control deviation (SP-PV) DV_LO_ALM Limit value alarm for lower control deviation (SP-PV) BLOCK_ALM Block alarm Factory setting: The option is not enabled for any alarm, the alarms must be acknowledged

PID function block (PID controller) / base index 810		
Parameter	Write access with operating mode (MODE_BLK)	Description
ALARM_HYS	ROUT - RCAS - CAS - AUTO - MAN - OOS	Entry of the hysteresis value for the upper and lower warning or alarm limit values. The alarm conditions remain active as long as the measured value is within the hysteresis. The hysteresis value affects the following warning and alarm limit values of the PID function block: • HI_HI_ALM (upper limit value alarm) • HI_ALM (upper limit value warning) • LO_LO_ALM (lower limit value alarm) • LO_ALM (lower limit value warning) • DV_HI_ALM (limit value for upper control deviation) • DV_LO_ALM (limit value for lower control deviation) User input: 0...50% Factory setting: 0.5%  Note! The hysteresis value relates to a percentage of the range of the PV_SCALE parameter in the PID function block, (see Page 213). Example: The top diagram shows the defined LO_LIM and HI_LIM alarm limit values with their respective hystereses (grey background) and the signal curve of the process variable PV. The bottom two diagrams show the behaviour of the associated HI_ALM and LO_ALM alarms in relation to the changing signal curve (0 = no alarm, 1 = alarm output). a = Process variable PV exceeds the limit value HI_LIM, HI_ALM is activated. b = Process variable PV undershoots the hysteresis value of HI_LIM, HI_ALM is deactivated. c = Process variable PV undershoots the limit value LO_LIM, LO_ALM is activated. d = Process variable PV exceeds the hysteresis value of LO_LIM, LO_ALM is deactivated.  F06-53xFFxx-05-xx-xx-en-002

PID function block (PID controller) / base index 810		
Parameter	Write access with operating mode (MODE_BLK)	Description
ALARM_SUM	ROUT - RCAS - CAS - AUTO - MAN - OOS	Displays the current status of the process alarms. Display: HI_HI_ALM Violation of the upper limit value alarm HI_ALM Violation of the upper limit value warning LO_LO_ALM Violation of the lower limit value alarm LO_ALM Violation of the lower limit value warning DV_HI_ALM Violation of the limit value alarm for the upper control deviation DV_LO_ALM Violation of the limit value alarm for the lower control deviation BLOCK_ALM Block alarm  Note! In addition, the process alarms can also be disabled in this parameter group.
ALERT_KEY	ROUT - RCAS - CAS - AUTO - MAN - OOS	Entry of the identification number of the plant unit. This information can be used by the fieldbus host system for sorting alarms and events. User input: 1...255 Factory setting: 0
BAL_TIME	ROUT - RCAS - CAS - AUTO - MAN - OOS	This parameter is used to enter the time for which the weighting factor counteracts the integral term of the saturation, (calculated manipulated variable > OUT_HI_LIM). Factory setting: 0 s

PID function block (PID controller) / base index 810		
Parameter	Write access with operating mode (MODE_BLK)	Description
BKCAL_HYS	ROUT - RCAS - CAS - AUTO - MAN - OOS	Entry of the hysteresis value for the upper and lower manipulated variable range limit value OUT_HI_LIM and OUT_LO_LIM. The hysteresis value relates to a percentage of the value in the OUT_SCALE parameter group, (see Page 212). If the calculated manipulated variable exceeds or undershoots the range defined by the range limit values then this range violation is shown in the LIMITS monitoring parameter in the OUT parameter group and communicated to the downstream blocks. The range violation remains active as long as the value of the calculated manipulated variable does not undershoot or overshoot the hysteresis value again. User input: 0...50% Factory setting: 0.5% Example: The top diagram shows the defined manipulated variable range limit values OUT_HI_LIM and OUT_LO_LIM with the BKCAL_HYS hysteresis (grey background) and the signal curve of the calculated manipulated variable. The bottom diagram shows the behaviour of the LIMITS range limit value monitor, of the OUT parameter group, to the changing signal curve of the calculated manipulated variable. "NotLimited" = No range limit value violation "HighLimited" = Range limit value violation is output "LowLimited" = Range limit value violation is output a = The calculated manipulated variable exceeds the upper manipulated variable range limit value OUT_HI_LIM. In the OUT parameter group the status "HighLimited" is output via LIMITS. b = The calculated manipulated variable undershoots the BKCAL_HYS hysteresis value of the upper manipulated variable range limit value OUT_HI_LIM. In the OUT parameter group the status "NotLimited" is output via LIMITS. c = The calculated manipulated variable undershoots the lower manipulated variable range limit value OUT_LO_LIM. In the OUT parameter group the status "LowLimited" is output via LIMITS. d = The calculated manipulated variable exceeds the BKCAL_HYS hysteresis value of the lower manipulated variable range limit value OUT_LO_LIM. In the OUT parameter group the status "NotLimited" is output via LIMITS.  F06-53xFFxx-05-xx-xx-en-004

PID function block (PID controller) / base index 810		
Parameter	Write access with operating mode (MODE_BLK)	Description
BKCAL_IN	ROUT - RCAS - CAS - AUTO - MAN - OOS	Displays the analog input value and status copied in the case of cascade control from the BKCAL_OUT output of the downstream function block. The cascade control is initialised with this value to ensure bumpless switching of the operating mode.
BKCAL_OUT	read only	Displays the analog output value and output status transferred in the case of cascade control to the BKCAL_IN input of the upstream function block. The cascade control is initialised with this value to ensure bumpless switching of the operating mode.
BLOCK_ALM	ROUT - RCAS - CAS - AUTO - MAN - OOS	Displays the current block status with information on pending configuration, hardware or system errors, including details of the alarm time (date, time) when the error occurred.  Note! If the option of the alarm has not been enabled in the ACK_OPTION parameter, the alarm can only be acknowledged via this parameter.
BLOCK_ERR	read only	Displays the active block error. Display: OUT OF SERVICE The block has the status "Out of Service".
BYPASS	MAN - OOS	This parameter can be used to activate and deactivate calculation of the manipulated variable by the PID control algorithm. Options: Uninitialized OFF Bypass deactivated: the manipulated variable determined by the PID control algorithm is output via the OUT parameter. ON BYPASS activated: the value of the setpoint value SP is output directly via the OUT parameter.  Caution! The BYPASS parameter is enabled in the controller options (CONTROL_OPTS parameter). This must be set before commissioning.

PID function block (PID controller) / base index 810		
Parameter	Write access with operating mode (MODE_BLK)	Description
CAS_IN	ROUT - RCAS - CAS - AUTO - MAN - OOS	Displays the analog setpoint value and status copied from an external function block in the CAS operating mode. This value is shown in the unit of the PV_SCALE parameter group.  Note! The remote setpoint value read in via the CAS_IN parameter is only used if the PID function block is in the CAS operating mode. In the AUTO operating mode, the value of the SP parameter is used as a setpoint value.
CONTROL_OPTS	OOS	Selects the available controller options for specifying the automation strategy. Options: Bypass Enable Enables the BYPASS parameter Direct Acting Direct effect Track Enable Enables tracking Track in Manual Operating mode MAN with active tracking PV for BKCAL_OUT Use value and status of the PV parameter for the BKCAL_OUT parameter No OUT Limits in Manual No output restriction in the MAN operating mode. If the range limit value OUT_HI_LIM or OUT_LO_LIM is exceeded or undershot, this has no effect on the OUT parameter. Factory setting: No option activated
DV_HI_ALM	ROUT - RCAS - CAS - AUTO - MAN - OOS	Alarm status display for the upper control deviation, including details of the time of the alarm (date, time) and the value that triggered the alarm. The controlled variable exceeds the setpoint value by more than the value specified in the DV_HI_LIM parameter.  Note! In addition, the active alarm can be acknowledged in this parameter group.

PID function block (PID controller) / base index 810		
Parameter	Write access with operating mode (MODE_BLK)	Description
DV_HI_LIM	ROUT - RCAS - CAS - AUTO - MAN - OOS	Entry of the limit value for the upper control deviation. If the controlled variable exceeds the setpoint value by this value, then the warning DV_HI_ALM is output. User input: Range and unit of PV_SCALE Factory setting: 3402823466 x 10³⁸  Note! If the setting for the end of the scale is changed in the PV_SCALE parameter this value should be modified accordingly.
DV_HI_PRI	ROUT - RCAS - CAS - AUTO - MAN - OOS	Specifies the action taken when the upper control deviation (DV_HI_LIM) is exceeded. User input: 0 The violation of the limit value for the upper control deviation is not evaluated. 1 No notification if the limit value for the upper control deviation is violated. 2 Reserved for block alarms. 3-7 The violation of the limit value for the upper control deviation is output as a user notice with the appropriate priority (3 = low priority, 7 = high priority). 8-15 The violation of the limit value for the upper control deviation is output as a critical alarm with the appropriate priority (8 = low priority, 15 = high priority). Factory setting: 0
DV_LO_ALM	ROUT - RCAS - CAS - AUTO - MAN - OOS	Alarm status display for the lower control deviation, including details of the time of the alarm (date, time) and the value that triggered the alarm. The controlled variable undershoots the setpoint value by more than the value specified in the DV_LO_LIM parameter.  Note! In addition, the active alarm can be acknowledged in this parameter group.

PID function block (PID controller) / base index 810		
Parameter	Write access with operating mode (MODE_BLK)	Description
DV_LO_LIM	ROUT - RCAS - CAS - AUTO - MAN - OOS	Entry of the limit value for the lower control deviation. If the controlled variable undershoots the setpoint value by this value, then the warning DV_LO_ALM is output. User input: Range and unit of PV_SCALE Factory setting: -3402823466 x 10³⁸  Note! If the setting for the end of the scale is changed in the PV_SCALE parameter this value should be modified accordingly.
DV_LO_PRI	ROUT - RCAS - CAS - AUTO - MAN - OOS	Specifies the action taken when the lower control deviation (DV_LO_LIM) is undershot. User input: 0 The violation of the limit value for the lower control deviation is not evaluated. 1 No notification if the limit value for the lower control deviation is violated. 2 Reserved for block alarms. 3-7 The violation of the limit value for the lower control deviation is output as a user notice with the appropriate priority (3 = low priority, 7 = high priority). 8-15 The violation of the limit value for the lower control deviation is output as a critical alarm with the appropriate priority (8 = low priority, 15 = high priority). Factory setting: 0
FF_GAIN	MAN - OOS	Entry of the disturbance gain for the feedforward control. Factory setting: 0  Note! The disturbance gain is multiplied by the disturbance variable (FF_VAL) and the result is added to the calculated manipulated variable.
FF_SCALE	MAN - OOS	Definition of the measuring range (lower and upper limit), the physical unit and the number of decimal places for the disturbance variable (FF_VAL). Factory setting: 0...100%

PID function block (PID controller) / base index 810		
Parameter	Write access with operating mode (MODE_BLK)	Description
FF_VAL	ROUT - RCAS - CAS - AUTO - MAN - OOS	For displaying and entering the value and status of the disturbance variable. User input: Range and unit of FF_SCALE
GAIN	ROUT - RCAS - CAS - AUTO - MAN - OOS	Entry of the proportional gain factor. Factory setting: 0  Note! If the value 0 is specified for this parameter then the status of the OUT parameter changes to BAD.
GRANT_DENY	ROUT - RCAS - CAS - AUTO - MAN - OOS	Releases or restricts the access authorisation of a fieldbus host system to the field device.  Note! This parameter is not evaluated by PROline Prosonic Flow 93 FF.
HI_ALM	ROUT - RCAS - CAS - AUTO - MAN - OOS	Alarm status display for the upper warning limit value, (HI_LIM), including details of the time of the alarm (date, time) and the value that triggered the alarm.  Note! In addition, the active alarm can be acknowledged in this parameter group.
HI_HI_ALM	ROUT - RCAS - CAS - AUTO - MAN - OOS	Alarm status display for the upper alarm limit value, (HI_HI_LIM), including details of the time of the alarm (date, time) and the value that triggered the alarm.  Note! In addition, the active alarm can be acknowledged in this parameter group.
HI_HI_LIM	ROUT - RCAS - CAS - AUTO - MAN - OOS	Entry of the alarm limit value for the upper alarm, (HI_HI_ALM). If the value PV exceeds this limit value then the alarm status parameter HI_HI_ALM is output. User input: Range and unit of PV_SCALE Factory setting: $3402823466 \times 10^{38}$  Note! If the setting for the end of the scale is changed in the PV_SCALE parameter this value should be modified accordingly.


PID function block (PID controller) / base index 810		
Parameter	Write access with operating mode (MODE_BLK)	Description
HI_HI_PRI	ROUT - RCAS - CAS - AUTO - MAN - OOS	Specifies the action taken when the upper alarm limit value (HI_HI_LIM) is exceeded. User input: 0 The violation of the upper alarm limit value is not evaluated. 1 No notification if the upper alarm limit value is violated. 2 Reserved for block alarms. 3-7 The violation of the upper alarm limit value is output as a user notice with the appropriate priority (3 = low priority, 7 = high priority). 8-15 The violation of the upper alarm limit value is output as a critical alarm with the appropriate priority (8 = low priority, 15 = high priority). Factory setting: 0
HI_LIM	ROUT - RCAS - CAS - AUTO - MAN - OOS	Entry of the alarm limit value for the upper warning (HI_ALM). If the value PV exceeds this limit value then the alarm status parameter HI_ALM is output. User input: Range and unit of PV_SCALE Factory setting: $3402823466 \times 10^{38}$  Note! If the setting for the end of the scale is changed in the PV_SCALE parameter this value should be modified accordingly.


PID function block (PID controller) / base index 810		
Parameter	Write access with operating mode (MODE_BLK)	Description
HI_PRI	ROUT - RCAS - CAS - AUTO - MAN - OOS	Specifies the action taken when the upper warning limit value (HI_LIM) is exceeded. User input: 0 The violation of the upper warning limit value is not evaluated. 1 No notification if the upper warning limit value is violated. 2 Reserved for block alarms. 3-7 The violation of the upper warning limit value is output as a user notice with the appropriate priority (3 = low priority, 7 = high priority). 8-15 The violation of the upper warning limit value is output as a critical alarm with the appropriate priority (8 = low priority, 15 = high priority). Factory setting: 0
IN	ROUT - RCAS - CAS - AUTO - MAN - OOS	Displays the analog controlled variable with information on the status and value.  Note! Scaling of the input range and selection of the unit of the controlled variable are carried out via the PV_SCALE parameter group.
LO_ALM	ROUT - RCAS - CAS - AUTO - MAN - OOS	Alarm status display for the lower warning limit value, (LO_LIM), including details of the time of the alarm (date, time) and the value that triggered the alarm.  Note! In addition, the active alarm can be acknowledged in this parameter group.
LO_LIM	ROUT - RCAS - CAS - AUTO - MAN - OOS	Entry of the alarm limit value for the lower warning, (LO_ALM). If the value PV exceeds this limit value then the alarm status parameter LO_ALM is output. User input: Range and unit of PV_SCALE Factory setting: -3402823466 x 10³⁸  Note! If the setting for the end of the scale is changed in the PV_SCALE parameter this value should be modified accordingly.

PID function block (PID controller) / base index 810		
Parameter	Write access with operating mode (MODE_BLK)	Description
LO_LO_ALM	ROUT - RCAS - CAS - AUTO - MAN - OOS	Alarm status display for the lower alarm limit value, (LO_LO_LIM), including details of the time of the alarm (date, time) and the value that triggered the alarm.  Note! In addition, the active alarm can be acknowledged in this parameter group.
LO_LO_LIM	ROUT - RCAS - CAS - AUTO - MAN - OOS	Entry of the alarm limit value for the lower alarm, (LO_LO_ALM). If the value PV undershoots this limit value then the alarm status parameter LO_LO_ALM is output. User input: Range and unit of PV_SCALE Factory setting: -3402823466 x 10³⁸  Note! If the setting for the end of the scale is changed in the PV_SCALE parameter this value should be modified accordingly.
LO_LO_PRI	ROUT - RCAS - CAS - AUTO - MAN - OOS	Specifies the action taken when the lower alarm limit value (LO_LO_LIM) is undershot. User input: 0 The violation of the lower alarm limit value is not evaluated. 1 No notification if the lower alarm limit value is violated. 2 Reserved for block alarms. 3-7 The violation of the lower alarm limit value is output as a user notice with the appropriate priority (3 = low priority, 7 = high priority). 8-15 The violation of the lower alarm limit value is output as a critical alarm with the appropriate priority (8 = low priority, 15 = high priority). Factory setting: 0

PID function block (PID controller) / base index 810		
Parameter	Write access with operating mode (MODE_BLK)	Description
LO_PRI	ROUT - RCAS - CAS - AUTO - MAN - OOS	Specifies the action taken when the lower warning limit value (LO_LIM) is undershot. User input: 0 The violation of the lower warning limit value is not evaluated. 1 No notification if the lower warning limit value is violated. 2 Reserved for block alarms. 3-7 The violation of the lower warning limit value is output as a user notice with the appropriate priority (3 = low priority, 7 = high priority). 8-15 The violation of the lower warning limit value is output as a critical alarm with the appropriate priority (8 = low priority, 15 = high priority). Factory setting: 0

PID function block (PID controller) / base index 810		
Parameter	Write access with operating mode (MODE_BLK)	Description
MODE_BLK	ROUT - RCAS - CAS - AUTO - MAN - OOS	Displays the current (Actual) and desired (Target) operating mode of the PID function block, the permitted modes (Permitted) supported by the Resource Block and the normal operating mode (Normal). Display: AUTO MAN OOS CAS RCAS ROUT The PID function block supports the following operating modes: • AUTO (automatic mode): The setpoint value specified by the user via the SP parameter is used in the execution of the internal PID algorithm. • MAN (manual intervention by the operator): The OUT parameter can be specified directly by the user. • OOS (out of service): The block has the status "Out of Service". The PID algorithm of the block is not executed. The last valid value is output at the OUT parameter and the status changes to BAD. • CAS (cascade mode): Via the input or CAS_IN parameter, the PID function block receives the setpoint value for internal calculation of the manipulated variable directly from another function block. The internal PID algorithm is executed. • RCAS (remote cascade): Via the RCAS_IN parameter, the PID function block receives the setpoint value for internal calculation of the manipulated variable directly from the fieldbus host system. The internal PID algorithm is executed. • ROUT (remote output): Via the ROUT_IN parameter, the PID function block receives the actuating value directly from the fieldbus host system. The manipulated variable is output again via the OUT parameter without the internal PID algorithm being executed.

PID function block (PID controller) / base index 810		
Parameter	Write access with operating mode (MODE_BLK)	Description
OUT	MAN - OOS	Displays the output value (manipulated variable) of the PID function block. The output value contains the value, the limit value status, the status and the alarm evaluation. The output value OUT is a function of the OUT_HI_LIM and OUT_LO_LIM range limit values. If the calculated manipulated variable exceeds or undershoots the range limit values then the value of the range limit value in question is output as the output value OUT, (see diagram).  F06-53xFFxxx-05-xx-xx-en-005 Note! If MAN (manual intervention by the operator) is selected for the operating mode in the MODE_BLK parameter then the output value OUT can be specified manually here. The unit used is copied from the OUT_SCALE parameter group, the input area corresponds to OUT_SCALE $\pm 10\%$.
OUT_HI_LIM	ROUT - RCAS - CAS - AUTO - MAN - OOS	Entry of the maximum permissible analog manipulated variable that can be output from the PID function block. User input: Range and unit of OUT_SCALE $\pm 10\%$ Factory setting: 100
OUT_LO_LIM	ROUT - RCAS - CAS - AUTO - MAN - OOS	Entry of the minimum permissible analog manipulated variable that can be output from the PID function block. User input: Range and unit of OUT_SCALE $\pm 10\%$ Factory setting: 0

PID function block (PID controller) / base index 810		
Parameter	Write access with operating mode (MODE_BLK)	Description
OUT_SCALE	OOS	Definition of the measuring range (lower and upper limit), the physical unit and the number of decimal places for the manipulated variable (OUT). Factory setting: 0...100%  Note! The range limits are defined via the OUT_HI_LIM and OU_LO_LIM parameters .
PV	read only	Displays the process variable used for the block execution, including the status.  Note! The unit used is copied from the PV_SCALE parameter group.
PV_FTIME	ROUT - RCAS - CAS - AUTO - MAN - OOS	Entry of the filter time constant (in seconds) of the digital filter of the 1st order. This time is required in order for 63% of a change in the controlled variable at input IN to have an effect on the value of PV. The diagram shows the signal curves between the parameters IN and PV over time:  F06-53\Fxx-05-xx-xx-en-006 a) The IN parameter changes. b) The PV parameter has reacted 63% to the change in the IN parameter. Factory setting: 0 s

PID function block (PID controller) / base index 810		
Parameter	Write access with operating mode (MODE_BLK)	Description
PV_SCALE	OOS	Definition of the measuring range (lower and upper limit), the physical unit and the number of decimal places for the process variable (PV). Factory setting: 0...100%  Note! If this parameter group is modified then the following parameters should be checked and modified if necessary: • DV_HI_LIM • DV_LO_LIM • HI_LIM • HI_HI_LIM • LO_LIM • LO_LO_LIM • RCAS_IN • RCAS_OUT • SP_LO_LIM • SP_HI_LIM • SP
RATE	ROUT - RCAS - CAS - AUTO - MAN - OOS	Entry of the time constant for the derivative action (D-term) Factory setting: 0 s
RCAS_IN	ROUT - RCAS - CAS - AUTO - MAN - OOS	In this parameter, the analog setpoint value (value and status) provided by the fieldbus host system is read in for internal calculation of the manipulated variable and displayed.  Note! • Value statement and unit of PV_SCALE. • If the setting for the end of the scale is changed in the PV_SCALE parameter this value should be modified accordingly. • This parameter is only active in the RCAS operating mode.
RCAS_OUT	read only	Displays the analog output value and status of the specified setpoint value transferred to the fieldbus host system in the course of cascade control. The cascade control is initialised with this value to ensure bumpless switching of the operating mode.  Note! • Value statement and unit of PV_SCALE. • If the setting for the end of the scale is changed in the PV_SCALE parameter this value should be modified accordingly. • This parameter is only active in the RCAS operating mode.
RESET	ROUT - RCAS - CAS - AUTO - MAN - OOS	Entry of the time constant for the integral function (I-term). Factory setting: $3402823466 \times 10^{38} \text{ s}$  Note! The integral function is disabled by entering 0 seconds.

PID function block (PID controller) / base index 810		
Parameter	Write access with operating mode (MODE_BLK)	Description
ROUT_IN	ROUT - RCAS - CAS - AUTO - MAN - OOS	In this parameter, the manipulated variable (value and status) provided by the fieldbus host system is read in and displayed.  Note! - Value statement and unit of OUT_SCALE - This parameter is only active in the ROUT operating mode. - The PID algorithm is no longer executed.
ROUT_OUT	read only	Displays the analog output value and status of the manipulated variable transferred to the fieldbus host system in the course of cascade control. The cascade control is initialised with this value to ensure bumpless switching of the operating mode.  Note! - Value statement and unit of OUT_SCALE - This parameter is only active in the ROUT operating mode.
SHED_OPT		Selects the action taken if the monitoring time is exceeded (see SHED_RCAS, SHED_ROUT parameters on Page 96) in the RCAS or ROUT operating mode. During the monitoring time, parameter updating between the fieldbus host system and the PID function block is checked. If the parameters are not being updated then on expiry of the monitoring time the PID function block switches from the RCAS or ROUT operating mode to the mode selected here. Options: Uninitialized NormalShed_NormalReturn NormalShed_NoReturn ShedToAuto_NormalReturn ShedToAuto_NoReturn ShedToManual_NormalReturn ShedToManual_NoReturn ShedToRetainedTarget_NormalReturn ShedToRetainedTarget_NoReturn Factory setting: Uninitialized
SP	AUTO - MAN - OOS	Entry of the setpoint value (reference value). User input: Range and unit of PV_SCALE $\pm 10\%$  Note! If the setting for the end of the scale is changed in the PV_SCALE parameter this value should be modified accordingly.

PID function block (PID controller) / base index 810		
Parameter	Write access with operating mode (MODE_BLK)	Description
SP_HI_LIM	ROUT - RCAS - CAS - AUTO - MAN - OOS	Entry of the upper limit of the setpoint value (reference value). User input: Range and unit of PV_SCALE $\pm 10\%$ Factory setting: 100  Note! If the setting for the end of the scale is changed in the PV_SCALE parameter this value should be modified accordingly.
SP_LO_LIM	ROUT - RCAS - CAS - AUTO - MAN - OOS	Entry of the lower limit of the setpoint value (reference value). User input: Value and range of PV_SCALE $\pm 10\%$ Factory setting: 100  Note! If the setting for the end of the scale is changed in the PV_SCALE parameter this value should be modified accordingly.
SP_RATE_DN	ROUT - RCAS - CAS - AUTO - MAN - OOS	Entry of the ramping rate of a diminishing setpoint value in the AUTO operating mode. Factory setting: $3402823466 \times 10^{38}$ PV per second  Note! • If the value "0" is entered then this parameter is deactivated and the setpoint value is used directly. • The speed restriction is only active in the AUTO operating mode.
SP_RATE_UP	ROUT - RCAS - CAS - AUTO - MAN - OOS	Entry of the ramping rate of an increasing setpoint value in the AUTO operating mode. Factory setting: $3402823466 \times 10^{38}$ PV per second  Note! • If the value "0" is entered then this parameter is deactivated and the setpoint value is used directly. • The speed restriction is only active in the AUTO operating mode.
ST_REV	read only	Displays the revision status of the static data.  Note! The revision status parameter is incremented on each modification of static data.

PID function block (PID controller) / base index 810		
Parameter	Write access with operating mode (MODE_BLK)	Description
STATUS_OPTS	OOS	Selects the available status options for specifying the status processing and processing of the output value OUT. The following options are supported: Options: IFS if Bad IN Trigger disturbance status of downstream Analog Output function block if the controlled variable (IN) changes the status to BAD. IFS if Bad CAS_IN Trigger disturbance status of downstream Analog Output function block if the remote setpoint value (CAS_IN) changes the status to BAD. Use Uncertain as Good The status UNCERTAIN is used as GOOD. Target In Manual if Bad IN Switch to the MAN operating mode if the controlled variable switches the status to BAD. Factory setting: No option active
STRATEGY	ROUT - RCAS - CAS - AUTO - MAN - OOS	Parameter for grouping and thus faster evaluation of blocks. Grouping is carried out by entering the same numerical value in the STRATEGY parameter of each individual block. Factory setting: 0  Note! These data are neither checked nor processed by the PID function block.
TAG_DESC	ROUT - RCAS - CAS - AUTO - MAN - OOS	Entry of a user-specific text of max. 32 characters for unique identification and assignment of the block. Factory setting: " _ _ _ _ _ " no text
TRK_IN_D	ROUT - RCAS - CAS - AUTO - MAN - OOS	Displays the discrete input (value and status) that initiates the external or output tracking function. On activation of tracking the operating mode switches to LO (Local Compulsory Tracking). In so doing the manipulated variable at the output OUT adopts the value specified at input TRK_VAL.
TRK_SCALE	MAN - OOS	Definition of the measuring range (lower and upper limit), the physical unit and the number of decimal places for the external tracking variable (TRK_VAL). Factory setting: 0...100%

PID function block (PID controller) / base index 810		
Parameter	Write access with operating mode (MODE_BLK)	Description
TRK_VAL	ROUT - RCAS - CAS - AUTO - MAN - OOS	Displays the analog input value and input status read in from another function block for the external tracking function in the unit of the TRK_SCALE parameter group.
UPDATE_EVT	read only	Displays whether static block data have been modified, including date and time.

7 Index (FOUNDATION Fieldbus)

A

ACK_OPTION	
AI function block	167
PID function block	197
Resource Block	91
Additional line	
Assign	136
Assign (multiplex)	139
Display Mode	138
Display mode (multiplex)	141
Format	137
Format (multiplex)	140
100% Value	137
100% Value (multiplex)	140
Add. Line	
Assign	136
Display Mode	138
Format	137
100% Value	137
Add. Line Multiplex	
Assign	139
Display Mode	141
Format	140
100% value	140
Alarm Delay	157
Alarm detection	
AI function block	166
PID function block	194
Resource Block	90
Transducer Block	104
Alarm processing	
AI function block	166
PID function block	194
Resource Block	90
Transducer Blocks	104
ALARM_HYS	
AI function block	167
PID function block	198
ALARM_SUM	
AI function block	169
PID function block	199
Resource Block	91
ALERT_KEY	
AI function block	169
DO function block	184
PID function block	199
Resource Block	91
Transducer Blocks	106
Amplifier	
HW-Identification	99
HW-Identification number	99
HW-Revision No.	99
Production No.	99
Production number	99
SW-Identification	99
SW-Identification number	99

SW-Revision No.	99
SW-Revision No. T-DAT	99
T-DAT SW-Revision No.	99
Amp. Device Family	
TRANSDUCER_CH1/_CH2	128
TRANSDUCER_DIAG	158
TRANSDUCER_DISP	147
TRANSDUCER_TOT	155
Analog Input function block	
Alarm detection, alarm processing	166
Diagnosis	165
General description	160
Input/output simulation	164
Limit values	166
Linearisation types	163
Operating mode	162
Parameter description	167
Process variable selection	162
Rescaling	165
Selecting the units	163
Signal processing	160
Status, output value OUT	164
Arc length	125
Assign	
Totalizer 1	150
Totalizer 2	152
Totalizer 3	154

B

BAL_TIME	199
Base index	
1200 (TRANSDUCER_CH1)	109
1300 (TRANSDUCER_CH2)	109
1500 (TRANSDUCER_DISP)	129
1550 (TRANSDUCER_TOT)	148
1600 (TRANSDUCER_DIAG)	156
1650 (TRANSDUCER_SERV)	159
258 (Resource Block)	89
350 (AI function block 1)	160
390 (AI function block 2)	160
430 (AI function block 3)	160
470 (AI function block 4)	160
510 (AI function block 5)	160
550 (AI function block 6)	160
590 (AI function block 7)	160
630 (AI function block 8)	160
780 (Discrete Output function block)	181
810 (PID function block)	191
BKCAL_HYS	200
BKCAL_IN	201
BKCAL_OUT	201
BKCAL_OUT_D	184
Block model	87
Block status, Resource Block	89

B (continued)

BLOCK_ALM	
AI function block	169
DO function block	184
PID function block	201
Resource Block	91
Transducer Blocks	108
BLOCK_ERR	
AI function block	170
DO function block	184
PID function block	201
Resource Block	92
Transducer Blocks	107
BYPASS	201

C

Cable Length	124
Calibration Data	
Calibration Factor	126
Correction Factor	126
Deviation ARC Length	127
Deviation Path Length	127
Deviation Sensor Distance	126
Unit Deviation ARC Length	127
Unit Deviation Path Length	127
Unit Deviation Sensor Distance	127
Zero point	126
Calibration factor	126
CAS_IN	202
CAS_IN_D	185
CHANNEL	
AI function block	171
DO function block	185
CLR_FSTATE	92
Configuration	
Contrast LCD	130
Display Damping	130
Language	130
Xline calculated	131
CONFIRM_TIME	92
Contrast LCD	130
CONTROL_OPTS	202
Correction factor	126
CYCLE_SEL	92
CYCLE_TYPE	92

D

Damping	
Display	130
Flow	112
PID function block	193
DD_RESOURCE	92
DD_REV	93
Define failsafe mode (totalizers)	155

Deviation	
Arc length	127
Path length	127
Sensor distance	126
DEV_REV	93
DEV_TYPE	93
Diagnosis	
Actual System Condition	156
AI function block	165
Previous System Condition	156
Transducer Block	105
Discrete Output function block	
Assignment, channel	182
General description	181
Operating mode	182
Parameter description	184
Security behaviour	182
Signal processing	181
Values for CAS_IN_D, RCAS_IN_D, OUT_D and SP_D	182
Display	
Access Status (programming level)	109
Flow Velocity	111
Signal Strength	111
Sound Velocity	111
Test	131
Totalizer 1	149
Totalizer 2	151
Totalizer 3	153
Volume Flow	110
DV_HI_ALM	202
DV_HI_LIM	203
DV_HI_PRI	203
DV_LO_ALM	203
DV_LO_LIM	204
DV_LO_PRI	204

F

FAULT_STATE	93
FEATURES	93
FEATURES_SEL	94
FF_GAIN	204
FF_SCALE	204
FF_VAL	205
FIELD_VAL	171
FOUNDATION Fieldbus parameters	106
FREE_SPACE	94
FREE_TIME	94
FSTATE_VAL_D	186
FSTATE_TIME	186

G

GAIN	205
GRANT_DENY	
AI function block	171
DO function block	186
PID function block	205
Resource Block	94

H

HARD_TYPES	94
HI_ALM	
AI function block	172
PID function block	205
HI_HI_ALM	
AI function block	172
PID function block	205
HI_HI_LIM	
AI function block	172
PID function block	205
HI_HI_PRI	
AI function block	172
PID function block	206
HI_LIM	
AI function block	173
PID function block	206
HI_PRI	
AI function block	173
PID function block	207

I

IN	207
Info Line	
Assign	142
Display Mode	144
Format	143
100% Value	143
Info Line Multiplex	
Assign	145
Display mode	147
Format	146
100% Value	146
Information line	
Assign	142
Assign (multiplex)	145
Display mode	144
Display Mode (multiplex)	147
Format	143
Format (multiplex)	146
100% value	143
100% Value (multiplex)	146
IO_OPTS	
AI function block	173
DO function block	187
ITK_VER	94
I/O Module	
HW-Identification	99
HW-Identification number	99
HW-Revision No.	99
HW-Revision number	99
Production No.	99
Production number	99
SW-Identification	99
SW-Identification number	99
SW-Revision No.	99

SW-Revision number	99
Type	99
I/O Module Type	99

L

Language	130
Limit values	
AI function block	166
PID function block	194
LIM_NOTIFY	94
Linearisation type (AI function block)	163
Liner (pipe)	
Material	119
Sound Velocity	120
Thickness	120
Liquid	
Selection	120
Sound Velocity	121
Sound Velocity Max.	122
Sound Velocity Min.	121
Temperature	121
Liquid Data	
Liquid	120
Max. Sound Velocity	122
Min. Sound Velocity	121
Sound Velocity	121
Temperature	121
Unit Max. Sound Velocity	122
Unit Min. Sound Velocity	122
Unit Sound Velocity	121
Unit Temperature	121
Low Flow Cut Off	
Assign	114
Off Value	114
On Value	114
Unit	114
LOW_CUT	177
LO_ALM	
AI function block	175
PID function block	207
LO_LIM	
AI function block	175
PID function block	207
LO_LO_ALM	
AI function block	175
PID function block	208
LO_LO_LIM	
AI function block	175
PID function block	208
LO_LO_PRI	
AI function block	176
PID function block	208
LO_PRI	
AI function block	176
PID function block	209
L_TYPE	174

M

Main line	
Assign.	132
Assign (multiplex)	134
Format.	133
Format (multiplex)	135
100% value.	133
100% value (multiplex)	134
Main line multiplex	
Assign.	134
Format.	135
100% value.	134
Main values (calculated)	131
MANUFAC_ID	95
MAX_NOTIFY	95
Measurement method	122
MEMORY_SIZE	95
MIN_CYCLE_T	95
Mode	
Totalizer 1	150
Totalizer 2	152
Totalizer 3	154
MODE_BLK	
AI function block.	177
DO function block.	187
PID function block	210
Resource Block	95
Transducer Blocks	107

N

NV_CYCLE_T	95
----------------------	----

O

Operating mode	
AI function block.	162
DO function block.	182
PID function block	193
Resource Block	89
Transducer Blocks	104
Operating Time	158
Operation - test display	131
Options	
Process variable AI fct. block.	162
Units AI fct. block	163
OUT	
AI function block.	177
PID function block	211
Output values (Transducer Block)	103
OUT_D	188
OUT_HI_LIM.	211
OUT_LO_LIM	211
OUT_SCALE	
AI function block.	178
PID function block	212

P

Parameter	
Analog Input function block	167
Discrete Output function block.	184

E+H parameters, Transducer Block diagnosis "TRANSDUCER_DIAG"	156
E+H parameters, Transducer Block display "TRANSDUCER_DISP"	129
E+H parameters, Transducer Block totalizer "TRANSDUCER_TOT"	148
E+H parameters, Transducer Block volume flow channel 1 TRANSDUCER_CH1	109
E+H parameters, Transducer Block volume flow channel 2 TRANSDUCER_CH2	109
FF parameters, Transducer Blocks	106
PID function block.	197
Resource Block (base index 258)	91
Path length	126
PID controller	
Configuration example	196
Control example	195
Equation	192
PID function block	
Alarm detection and processing	194
Configuration (example)	196
Control (example)	195
Damping	193
General description	191
Limit values.	194
Operating mode	193
Parameter description	197
Setpoint value specification	193
Signal processing.	191
Pipe	
Circumference	118
Diameter	118
Liner Material	119
Material	117
Nominal Diameter	116
Sound Velocity	118
Standard	116
Wall Thickness	119
Pipe Data	
Circumference	118
Liner Material	119
Liner Thickness.	120
Nominal Diameter	116
Pipe Diameter	118
Pipe Material.	117
Pipe Standard.	116
Reference Value	117
Sound Velocity Liner.	119
Sound Velocity Pipe	118
Unit Circumference.	118
Unit Liner Thickness	120
Unit Nominal Diameter	116
Unit Pipe Diameter	119
Unit Reference Value	117
Unit Sound Velocity Pipe	118
Unit Wall Thickness.	119
Wall Thickness	119
Positive Zero Return	113

Pressure Shock Suppression	115	Wire Length	125
PV		Sensor serial number	99
AI function block	178	Sensor, installation direction	112
PID function block	212	Setpoint value specification, PID	193
PV_D	188	SET_FSTATE	96
PV_FTIME		SHED_OPT	
AI function block	178	DO function block	188
PID function block	212	PID function block	214
PV_SCALE	213	SHED_RCAS	96
PV_STATE	188	SHED_ROUT	97
R		Signal processing	
RATE	213	AI function block	160
RCAS_IN	213	DO function block	181
RCAS_IN_D	188	PID function block	191
RCAS_OUT	213	Transducer Blocks	102
RCAS_OUT_D	188	SIMULATE	179
READBACK_D	188	SIMULATE_D	189
Reference value	117	Simulation	
Rescaling input value, (AI fct. block)	165	AI function block	164
RESET	213	Error occurrence	157
Reset		Measurand	128
All totalizers	155	Measurand value	128
System	157	Measured variable	128
Totalizer 1	150	Resource Block	90
Totalizer 2	152	Unit	128
Totalizer 3	154	Value measurand	128
Resource Block (base index 258)	89	SP	214
RESTART	96	SP_D	189
ROUT_IN	214	SP_HI_LIM	215
ROUT_OUT	214	SP_LO_LIM	215
RS_STATE	96	SP_RATE_DN	215
S		SP_RATE_UP	215
Sensor		STATUS_OPTS	
Arc length	125	AI function block	179
Cable Length	124	DO function block	189
Configuration	124	PID function block	216
Distance	125	STRATEGY	
Path length	126	AI function block	179
Position	124	DO function block	190
Serial Number	99	PID function block	216
Type (selection)	123	Resource Block	97
Wire length	125	Transducer Blocks	106
Sensor installation direction	112	ST_REV	215
Sensor Param.		AI function block	179
ARC Length	125	DO function block	189
Cable Length	124	Resource Block	97
Measurement	122	Transducer Blocks	106
Path Length	126	System	
Position Sensor	124	Alarm Delay	157
Sensor Configuration	124	Operation Time	158
Sensor Distance	125	Reset	157
Sensor Type	123	Simulation Failsafe Mode	157
Unit ARC Length	126	Troubleshooting	158
Unit Path Length	126	System Condition	
Unit Sensor Distance	125	Actual	156
Unit Wire Length	125	Previous	156

S (continued)

System Param.	
Adjust zero point.	113
Flow Damping.	112
Installation Direction Sensor.	112
Positive Zero Return.	113
System Unit	
Flow Velocity.	111
Length.	112
Sound Velocity.	111
Temperature.	111
Viscosity.	112
Volume Flow.	110
System Value	
Flow Velocity.	111
Signal Strength.	111
Sound Velocity.	111
Volume Flow.	110

T

TAG_DESC	
AI function block.	180
DO function block.	190
PID function block.	216
Resource Block.	97
Transducer Blocks.	106
T-DAT	
Loading/saving data.	158
Save/Load.	158
Test display.	131
TEST_RW.	97
Totalizer Handling	
Failsafe All.	155
Reset All.	155
Totalizer 1	
Assign.	150
Display Value.	149
Mode.	150
Reset.	150
System Unit.	149
System Value.	149
Unit.	149
Totalizer 2	
Assign.	152
Display Value.	151
Mode.	152
Reset.	152
System Unit.	151
System Value.	151
Unit.	151
Totalizer 3	
Assign.	154
Display Value.	153
Mode.	154
Reset.	154
System Unit.	153
System Value.	153
Unit.	153

Transducer	
Blocks.	100
Error.	108
Type.	108
Transducer Block	
TRANSDUCER_CH1 (volume flow channel 1).	109
TRANSDUCER_CH2 (volume flow channel 2).	109
TRANSDUCER_DIAG (diagnosis).	156
TRANSDUCER_DISP (display).	129
TRANSDUCER_SERV (service).	159
TRANSDUCER_TOT (totalizer).	148
Transducer Block E+H parameters.	109
Transducer Blocks	
Alarm detection, alarm processing.	104
Diagnosis (error messages).	105
Select operating mode.	104
Transmission blocks.	100
TRK_IN_D.	216
TRK_SCALE.	216
TRK_VAL.	217
Troubleshooting (EEPROM).	158

U

Unit (display)	
Arc length deviation.	127
ARC Length.	126
Liner Material Strength.	120
Max. Sound Velocity (liquid).	122
Min. Sound Velocity (liquid).	122
Nominal diameter.	116
Path Length.	126
Path length deviation.	127
Pipe Circumference.	118
Pipe Diameter.	119
Reference Value.	117
Sensor Distance.	125
Sensor distance deviation.	127
Simulation measurand.	128
Sound Velocity (liquid).	121
Sound Velocity (pipe).	118
Temperature (liquid).	121
Wall Thickness (pipe).	119
Wire Length.	125
Unit (selection)	
Flow Velocity.	111
Length.	112
Sound Velocity.	111
Temperature.	111
Totalizer 1.	149
Totalizer 2.	151
Totalizer 3.	153
Viscosity.	112
Volume Flow.	110
Un-/Locking - Access Code	
TRANSDUCER_CH1/_CH2.	109
TRANSDUCER_DIAG.	156
TRANSDUCER_TOT.	148

Un-/locking - access code	
TRANSDUCER_DISP	129
Un-/Locking - Access Status	
TRANSDUCER_CH1/_CH2	109
TRANSDUCER_DIAG	156
TRANSDUCER_TOT	148
Un-/locking - access status	
TRANSDUCER_DISP	129
Un-/locking - define private code	
TRANSDUCER_DISP	129
UPDATE_EVT	
AI function block	180
DO function block	190
PID function block	217
Resource Block	97
Transducer Blocks	107
W	
Wire length	125
Write protection and simulation	90
WRITE_ALM	97
WRITE_LOCK	98
WRITE_PRI	98
X	
XD_SCALE	180
XD_STATE	190
Z	
Zero point	126
Zero point adjustment	113

Europe		
Austria □ Endress+Hauser Ges.m.b.H. Wien Tel. (01) 88056-0, Fax (01) 88056-35		
Belarus □ Belorgsintez Minsk Tel. (0172) 508473, Fax (0172) 508583		
Belgium / Luxembourg □ Endress+Hauser N.V. Brussels Tel. (02) 2480600, Fax (02) 2480553		
Bulgaria INTERTECH-AUTOMATION Sofia Tel. (02) 664869, Fax (02) 9631389		
Croatia □ Endress+Hauser GmbH+Co. Zagreb Tel. (01) 6637785, Fax (01) 6637823		
Cyprus I+G Electrical Services Co. Ltd. Nicosia Tel. (02) 484788, Fax (02) 484690		
Czech Republic □ Endress+Hauser GmbH+Co. Praha Tel. (026) 6784200, Fax (026) 6784179		
Denmark □ Endress+Hauser A/S Søborg Tel. (70) 131132, Fax (70) 132133		
Estonia ELVI-Aqua Tartu Tel. (7) 441638, Fax (7) 441582		
Finland □ Endress+Hauser Oy Helsinki Tel. (0204) 83160, Fax (0204) 83161		
France □ Endress+Hauser S.A. Huningue Tel. (389) 696768, Fax (389) 694802		
Germany □ Endress+Hauser Messtechnik GmbH+Co. Weil am Rhein Tel. (07621) 975-01, Fax (07621) 975-555		
Great Britain □ Endress+Hauser Ltd. Manchester Tel. (0161) 2865000, Fax (0161) 9981841		
Greece I & G Building Services Automation S.A. Athens Tel. (01) 9241500, Fax (01) 9221714		
Hungary Mile Ipari-Elektro Budapest Tel. (01) 4319800, Fax (01) 4319817		
Iceland BIL ehf Reykjavik Tel. (05) 619616, Fax (05) 619617		
Ireland Flomeaco Company Ltd. Kildare Tel. (045) 868615, Fax (045) 868182		
Italy □ Endress+Hauser S.p.A. Cernusco s/N Milano Tel. (02) 921921, Fax (02) 92107153		
Latvia Rino TK Riga Tel. (07) 315087, Fax (07) 315084		
Lithuania UAB "Agava" Kaunas Tel. (07) 202410, Fax (07) 207414		
Netherland □ Endress+Hauser B.V. Naarden Tel. (035) 6958611, Fax (035) 6958825		
Norway □ Endress+Hauser A/S Tranby Tel. (032) 859850, Fax (032) 859851		
Poland □ Endress+Hauser Polska Sp. z o.o. Warszawy Tel. (022) 7201090, Fax (022) 7201085		
Portugal Tecnisis, Lda Cacém Tel. (21) 4267290, Fax (21) 4267299		
Romania Romconseng S.R.L. Bucharest Tel. (01) 4101634, Fax (01) 4112501		
Russia □ Endress+Hauser Moscow Office Moscow Tel. (095) 1587564, Fax (095) 1589871		
Slovakia Transcom Technik s.r.o. Bratislava Tel. (7) 44888684, Fax (7) 44887112		
Slovenia □ Endress+Hauser D.O.O. Ljubljana Tel. (061) 5192217, Fax (061) 5192298		
Spain □ Endress+Hauser S.A. Sant Just Desvern Tel. (93) 4803366, Fax (93) 4733839		
Sweden □ Endress+Hauser AB Sollentuna Tel. (08) 55511600, Fax (08) 55511655		
Switzerland □ Endress+Hauser Metso AG Reinach/BL 1 Tel. (061) 7157575, Fax (061) 7111650		
Turkey Intek Endüstriyel Ölçü ve Kontrol Sistemleri İstanbul Tel. (0212) 2751355, Fax (0212) 2662775		
Ukraine Photonika GmbH Kiev Tel. (44) 26881, Fax (44) 26908		
Yugoslavia Rep. Meris d.o.o. Beograd Tel. (11) 4441966, Fax (11) 4441966		
Africa		
Egypt Anasia Heliopolis/Cairo Tel. (02) 4179007, Fax (02) 4179008		
Morocco Oussama S.A. Casablanca Tel. (02) 241338, Fax (02) 402657		
South Africa □ Endress+Hauser Pty. Ltd. Sandton Tel. (011) 4441386, Fax (011) 4441977		
Tunisia Contrôle, Maintenance et Regulation Tunis Tel. (01) 793077, Fax (01) 788595		
America		
Argentina □ Endress+Hauser Argentina S.A. Buenos Aires Tel. (01) 145227970, Fax (01) 145227909		
Bolivia Tritec S.R.L. Cochabamba Tel. (042) 56993, Fax (042) 50981		
Brazil □ Samson Endress+Hauser Ltda. Sao Paulo Tel. (011) 50313455, Fax (011) 50313067		
Canada □ Endress+Hauser Ltd. Burlington, Ontario Tel. (905) 6819292, Fax (905) 6819444		
Chile □ Endress+Hauser Chile Ltd. Santiago Tel. (02) 3213009, Fax (02) 3213025		
Colombia Colsein Ltda. Bogota D.C. Tel. (01) 2367659, Fax (01) 6104186		
Costa Rica EURO-TEC S.A. San Jose Tel. (02) 961542, Fax (02) 961542		
Ecuador Insetec Cia. Ltda. Quito Tel. (02) 269148, Fax (02) 461833		
Guatemala ACISA Automatizacion Y Control Industrial S.A. Ciudad de Guatemala, C.A. Tel. (03) 345985, Fax (03) 327431		
Mexico □ Endress+Hauser S.A. de C.V. Mexico City Tel. (5) 5682405, Fax (5) 5687459		
Paraguay Incoel S.R.L. Asuncion Tel. (021) 213989, Fax (021) 226583		
Uruguay Circular S.A. Montevideo Tel. (02) 925785, Fax (02) 929151		
USA □ Endress+Hauser Inc. Greenwood, Indiana Tel. (317) 535-7138, Fax (317) 535-8498		
Venezuela Controlva C.A. Caracas Tel. (02) 9440966, Fax (02) 9444554		
Asia		
China □ Endress+Hauser Shanghai Instrumentation Co. Ltd. Shanghai Tel. (021) 54902300, Fax (021) 54902303		
□ Endress+Hauser Beijing Office Beijing Tel. (010) 68344058, Fax (010) 68344068		
Hong Kong □ Endress+Hauser HK Ltd. Hong Kong Tel. 25283120, Fax 28654171		
India □ Endress+Hauser (India) Pvt Ltd. Mumbai Tel. (022) 8521458, Fax (022) 8521927		
Indonesia PT Grama Bazita Jakarta Tel. (21) 7975083, Fax (21) 7975089		
Japan □ Sakura Endress Co. Ltd. Tokyo Tel. (0422) 540613, Fax (0422) 550275		
Malaysia □ Endress+Hauser (M) Sdn. Bhd. Petaling Jaya, Selangor Darul Ehsan Tel. (03) 7334848, Fax (03) 7338800		
Pakistan Speedy Automation Karachi Tel. (021) 7722953, Fax (021) 7736884		
Papua-Neuguinea SBS Electrical Pty Limited Port Moresby Tel. 3251188, Fax 3259556		
Philippines □ Endress+Hauser Philippines Inc. Metro Manila Tel. (2) 3723601-05, Fax (2) 4121944		
Singapore □ Endress+Hauser (S.E.A.) Pte., Ltd. Singapore Tel. 5668222, Fax 5666848		
South Korea □ Endress+Hauser (Korea) Co., Ltd. Seoul Tel. (02) 6587200, Fax (02) 6592838		
Taiwan Kingjarl Corporation Taipei R.O.C. Tel. (02) 27183938, Fax (02) 27134190		
Thailand □ Endress+Hauser Ltd. Bangkok Tel. (2) 9967811-20, Fax (2) 9967810		
Vietnam Tan Viet Bao Co. Ltd. Ho Chi Minh City Tel. (08) 8335225, Fax (08) 8335227		
Iran PATSA Co. Tehran Tel. (021) 8754748, Fax (021) 8747761		
Israel Instrumetrics Industrial Control Ltd. Netanya Tel. (09) 8357090, Fax (09) 8350619		
Jordan A.P. Parpas Engineering S.A. Amman Tel. (06) 4643246, Fax (06) 4645707		
Kingdom of Saudi Arabia Anasia Ind. Agencies Jeddah Tel. (02) 6710014, Fax (02) 6725929		
Lebanon Network Engineering Jbeil Tel. (3) 944080, Fax (9) 548038		
Sultanate of Oman Mustafa Sultan Science & Industry Co. LLC. Ruwi Tel. 602009, Fax 607066		
United Arab Emirates Descon Trading EST. Dubai Tel. (04) 2653651, Fax (04) 2653264		
Yemen Yemen Company for Ghee and Soap Industry Taiz Tel. (04) 230664, Fax (04) 212338		
Australia + New Zealand		
Australia ALSTOM Australia Limited Milpera Tel. (02) 97747444, Fax (02) 97744667		
New Zealand EMC Industrial Group Limited Auckland Tel. (09) 4155110, Fax (09) 4155115		
All other countries		
□ Endress+Hauser GmbH+Co. Instruments International D-Weil am Rhein Germany Tel. (07621) 975-02, Fax (07621) 975345		

For more Endress+Hauser product please visit: www.ainstru.com
<http://www.endress.com>
 Mail: Sales@ainstru.com