



Level



Pressure



Flow



Temperature



Liquid
Analysis



Registration



Systems
Components



Services



Solutions

Operating Instructions

Deltatop

DO61W, DO62C, DO63C, DO64P, DO65F

Orifices for differential pressure flow measurement




Table of contents

1	Safety instructions	4	Index	38
1.1	Designated use	4		
1.2	Installation, commissioning, operation	4		
1.3	Hazardous area	4		
1.4	Notes on safety conventions and symbols	5		
2	Identification	6		
2.1	Nameplate	6		
2.2	Product structure	6		
2.3	Documentation	7		
2.4	Certificates and approvals	9		
2.5	Registered trademarks	9		
3	Installation	10		
3.1	Incoming acceptance, transport, storage	10		
3.2	Dimensions	10		
3.3	Mounting position for liquid applications	11		
3.4	Mounting position for gas applications	12		
3.5	Mounting position for steam applications	13		
3.6	General mounting conditions	15		
3.7	Installation hints	18		
3.8	Installation check	21		
4	Wiring	22		
4.1	Wiring of the Deltabar S differential pressure transmitter	22		
5	Operation and commissioning	23		
5.1	Configuration of the Deltabar S differential pressure transmitter	23		
5.2	Configuration of a temperature and pressure compensation	23		
5.3	Usage of the accessories	25		
6	Troubleshooting	29		
6.1	Error messages of the Deltabar S	29		
6.2	Application errors	30		
7	Maintenance and repairs	31		
7.1	Maintenance	31		
7.2	Exterior cleaning	31		
7.3	Replacing seals	31		
7.4	Spare parts	31		
7.5	Return	32		
7.6	Disposal	32		
7.7	Contact addresses of Endress+Hauser	32		
8	Accessories	33		
8.1	Overview	33		
8.2	Rectifier DA63R	34		
8.3	Oval flange adapter PZO	37		

1 Safety instructions

1.1 Designated use

The measuring system is used to measure the volume or mass flow of saturated steam, over-heated steam, gases and liquids.

Resulting from incorrect or from use other than that designated the operational safety of the measuring devices can be suspended. The manufacturer accepts no liability for damages being produced from this.

1.2 Installation, commissioning, operation

The Deltatop measuring system is fail-safe and is constructed to the state-of-the-art. It meets the appropriate standards and EC directives. However, if you use it improperly or other than for its designated use, it may pose application-specific hazards, e.g. product overflow due to incorrect installation or configuration. Installation, electrical connection, start-up, operation and maintenance of the measuring device must therefore be carried out exclusively by trained specialists authorised by the system operator. Technical personnel must have read and understood these operating instructions and must adhere to them. You may only undertake modifications or repair work to the device when it is expressly permitted by the operating instructions.

1.3 Hazardous area

Measuring systems for use in hazardous environments are accompanied by separate "Ex documentation", which is an integral part of this Operating Manual. Strict compliance with the installation instructions and ratings as stated in this supplementary documentation is mandatory.

- Ensure that all personnel are suitably qualified.
- Observe the specifications in the certificate as well as national and local standards and regulations.

1.4 Notes on safety conventions and symbols

In order to highlight safety-relevant or alternative operating procedures in the manual, the following conventions have been used, each indicated by a corresponding symbol in the margin.

Safety conventions	
	Warning! A warning highlights actions or procedures which, if not performed correctly, will lead to personal injury, a safety hazard or destruction of the instrument
	Caution! Caution highlights actions or procedures which, if not performed correctly, may lead to personal injury or incorrect functioning of the instrument
	Note! A note highlights actions or procedures which, if not performed correctly, may indirectly affect operation or may lead to an instrument response which is not planned
Explosion protection	
	Device certified for use in explosion hazardous area If the device has this symbol embossed on its name plate it can be installed in an explosion hazardous area
	Explosion hazardous area Symbol used in drawings to indicate explosion hazardous areas. Devices located in and wiring entering areas with the designation "explosion hazardous areas" must conform with the stated type of protection.
	Safe area (non-explosion hazardous area) Symbol used in drawings to indicate, if necessary, non-explosion hazardous areas. Devices located in safe areas still require a certificate if their outputs run into explosion hazardous areas
Electrical symbols	
	Direct voltage A terminal to which or from which a direct current or voltage may be applied or supplied
	Alternating voltage A terminal to which or from which an alternating (sine-wave) current or voltage may be applied or supplied
	Grounded terminal A grounded terminal, which as far as the operator is concerned, is already grounded by means of an earth grounding system
	Protective grounding (earth) terminal A terminal which must be connected to earth ground prior to making any other connection to the equipment
	Equipotential connection (earth bonding) A connection made to the plant grounding system which may be of type e.g. neutral star or equipotential line according to national or company practice
	Temperature resistance of the connection cables States, that the connection cables must be resistant to a temperature of at least 85 °C.

2 Identification

2.1 Nameplate

Endress+Hauser  	
Deltatop	
Made in Germany, D-79689 Maulburg	
Order Code:	
Ident.No.:	
Serial No.:	
Pipe ID:	
Throat ID:	
β :	
Press. rate:	
25002572—	

	Mat. of primary:
	Fluid:
	Flow rate:
	Calc. dP value:
	Pressure:
	Temperature:
	25002573—

P01-DOxxxxxx-18-xx-00-xx-001

Order Code: Order code of the instrument according to the product structure (see Technical Information TI422P)

Ident. No.: Identification number; characterizes the instrument unambiguously

Serial No.: Serial number

Pipe ID: Inner diameter of the measuring pipe

Throat ID: Diameter of the orifice bore

β : diameter ratio (= throat ID / pipe ID)

Press. rate: pressure rating

Mat. of primary: Material of the orifice

Fluid: Fluid for which the instrument has been sized

Flow rate: Flow rate for which the instrument has been sized (operating point)

Calc dP value: calculated differential pressure at the operating point

Pressure: operating pressure

Temperature: operating temperature

CE 0035: CE mark for pressure equipment directive (→  9)

2.2 Product structure

See Technical Information TI 422P.

2.3 Documentation

2.3.1 Deltatop

Document	Device	Designation
Technical Information		
TI422P	DO61W, DO62C, DO63C, DO64P, DO65F	Differential pressure flow measurement with orifices and Deltabar differential pressure transmitter
TI425P	DP61D, DP62D, DP63D	Differential pressure flow measurement with Pitot tubes and Deltabar differential pressure transmitter
Operating Instructions		
BA368P	DO61W, DO62C, DO63C, DO64P, DO65F	Differential pressure flow measurement with orifices and Deltabar differential pressure transmitter
BA369P	DP61D, DP62D, DP63D	Differential pressure flow measurement with Pitot tubes and Deltabar differential pressure transmitter

2.3.2 Deltabar S

Document	Device	Designation
Technical Information		
TI382	Deltabar S	Differential pressure transmitter
Operating Instructions		
BA270P	Deltabar S	Differential pressure transmitter - HART
BA294P	Deltabar S	Differential pressure transmitter - PROFIBUS PA
BA301P	Deltabar S	Differential pressure transmitter - FOUNDATION FIELDBUS
Description of Instrument Functions		
BA274P	Cerabar S/Deltabar S/Deltapilot S	Pressure and differential pressure transmitter HART
BA296P	Cerabar S/Deltabar S/Deltapilot S	Pressure and differential pressure transmitter PROFIBUS PA
BA303P	Cerabar S/Deltabar S/Deltapilot S	Pressure and differential pressure transmitter FOUNDATION FIELDBUS
Safety Instructions (ATEX)		
XA235P	Deltabar S	ATEX II 1/2 G EEx ia
XA237P	Deltabar S	ATEX II 1/2 D
XA239P	Deltabar S	ATEX II 1/3 D
XA240P	Deltabar S	ATEX II 2G EEx d
XA241P	Deltabar S	ATEX II 3 G EEx nA
XA242P	Deltabar S	ATEX II 1/2 G EEx id; ATEX II 2 G EEx d
XA243P	Deltabar S	ATEX II 1/2 GD EEx ia
XA275P	Deltabar S	ATEX II 1 GD EEx ia

2.3.3 Omnigrad T (RTD resistance thermometer) iTEMP (temperature head transmitter)

Document	Device	Designation
Technical Information		
TI269T	Omnigrad T TR24	RTD resistance thermometer
TI070R	iTEMP TMT181	temperature head transmitter 4...20 mA
TI078R	iTEMP TMT182	temperature head transmitter HART
TI079R	iTEMP TMT184	temperature head transmitter PROFIBUS PA
Operating Instructions		
KA141R	iTEMP TMT181	temperature head transmitter 4...20 mA
KA142R	iTEMP TMT182	temperature head transmitter HART
BA115R	iTEMP TMT184	temperature head transmitter PROFIBUS PA
Safety Instructions (ATEX)		
XA003T	Omnigrad T TR24	ATEX II 1 GD EEx ia IIC
XA004R	iTEMP TMT181 (4...20 mA)	ATEX II 1 G EEx ia IIC
XA006R	iTEMP TMT182 (HART)	ATEX II 1 G EEx ia IIC
XA008R	iTEMP TMT184 (PROFIBUS PA)	ATEX II 1 G EEx ia IIC

2.3.4 Flow and Energy Manager RMS621/RMC621

Document	Device
Technical Information	
TI092R	Energy Manager RMS621
TI098R	Flow and Energy Manager RMC621
Operating Instructions	
BA127R	Energy Manager RMS621
BA144R	Flow and Energy Manager RMC621

2.4 Certificates and approvals

2.4.1 CE mark, declaration of conformity

The device is designed to meet state-of-the-art safety requirements, has been tested and left the factory in a condition in which it is safe to operate. The device complies with the applicable standards and regulations as listed in the EC declaration of conformity and thus complies with the statutory requirements of the EC directives. Endress+Hauser confirms the successful testing of the device by affixing to it the CE mark.

2.4.2 European Pressure Equipment Directive 97/23/EC (PED)

Depending on nominal diameter, medium, pressure and temperature, primary elements (orifices) are categorized according to the European Pressure Equipment Directive 97/23/EC (PED).

- **Article 3.3 ($\leq$ DN25 /1"):** no CE marking
- **Category I:** CE marking without identification number of the notified body for QA surveillance.
- **Category II:** CE marking with identification number of the notified body for QA surveillance.

For safety reasons all devices $>$ DN25 /1" are classified as Category III equipment.

DO61W and DO64P are made of PED compliant materials (DO61W) or comply to Article 3.3 and thus do not bear a CE marking.

2.5 Registered trademarks

HART®

Registered trademark of HART Communication Foundation, Austin, USA

PROFIBUS®

Registered trademark of the PROFIBUS Trade Organisation, Karlsruhe, Germany

FOUNDATION Fieldbus®

Registered trademark of the Fieldbus Foundation Austin, Texas, USA

VITON®

Registered trademark of the company, E.I. Du Pont de Nemours & Co., Wilmington, USA

Ermeto®

Registered trademark of the Parker Hannifin GmbH, Bielefeld, Germany

3 Installation

3.1 Incoming acceptance, transport, storage

3.1.1 Incoming acceptance

Check the packing and contents for any sign of damage.

Check the shipment, make sure nothing is missing and that the scope of supply matches your order.

3.1.2 Transport



Caution!

Follow the safety instructions and transport conditions for instruments of more than 18 kg.

Do not lift the measuring instrument by the housing of the transmitter in order to transport it.

3.1.3 Storage

For storing and transport, shock proof packaging of the measuring instrument is required. The original packaging material provides optimum protection.

The permissible storage temperature for the Deltabar transmitter is -40 °C ... +80 °C.


3.2 Dimensions

See Technical Information TI422P.

3.3 Mounting position for liquid applications









With liquid applications, the transmitter must be mounted below the pipe. All impulse pipes must be installed with a slope of at least 1:15 to the transmitter - coming from the process connection. This ensures that trapped air and bubbles travel back to the process pipe and thus do not influence the measurement.

When measuring in fluids with solid content, such as dirty liquids, installing separators (5) and drain valves (6) is useful for capturing and removing sediment.



P01-DOxxxxx-11-xx-xx-xx-011

A: Preferred configuration; **B:** alternative configuration (requires less space; only possible for clean media)
1: Orifice plate; **2:** Shut-off valves; **3:** Three valve manifold; **4:** Differential pressure transmitter Deltabar; **5:** Separator; **6:** Drain valve

compact; vertical	compact; horizontal	remote; vertical	remote; horizontal
flow upwards DO6xxxx-EM...  P01-DO61Wxxx-11-00-00-xx-001	mounting left DO6xxxx-EB...  P01-DO61Wxxx-11-00-00-xx-009	taps 90° DO6xxxx-DT...  P01-DO61Wxxx-11-00-00-xx-015	tap angle according to DIN DO6xxxx-DF...  P01-DO61Wxxx-11-00-00-xx-021
flow downwards DO6xxxx-EP...  P01-DO61Wxxx-11-00-00-xx-002	mounting right DO6xxxx-EC...  P01-DO61Wxxx-11-00-00-xx-010	taps 0° DO6xxxx-DS...  P01-DO61Wxxx-11-00-00-xx-016	taps 0° DO6xxxx-DE...  P01-DO61Wxxx-11-00-00-xx-022


For flow measurements in vertical pipes, the primary device should be mounted at a position with upward flow. This prevents partial filling of the pipe during the measurement.

3.4 Mounting position for gas applications









With gas applications, the transmitter must be mounted above the pipe. All impulse pipes must be installed with a slope of at least 1:15 to the process connection - coming from the transmitter. This ensures that any condensate flows back into the process pipe and thus does not influence the measurement.



Note!
When measuring in humid gases, installation of condensate separators (5) and drain valves (6) is useful for capturing and removing condensate.



A: Preferred configuration; **B:** Alternative configuration (if the transmitter can not be mounted above the pipe)
1: Orifice plate; **2:** Shut-off valves; **3:** Three-valve manifold; **4:** Differential pressure transmitter Deltabar; **5:** Separator; **6:** Drain valves

compact; vertical	compact; horizontal	remote; vertical	remote, horizontal
flow upwards DO6xxx-CM...  P01-DO61Wxxx-11-00-00-xx-001	mounting left DO6xxx-CB...  P01-DO61Wxxx-11-00-00-xx-007	taps 90° DO6xxx-BT...  P01-DO61Wxxx-11-00-00-xx-013	tap angle according to DIN DO6xxx-BF...  P01-DO61Wxxx-11-00-00-xx-019
flow downwards DO6xxx-CP...  P01-DO61Wxxx-11-00-00-xx-002	mounting right DO6xxx-CC...  P01-DO61Wxxx-11-00-00-xx-008	taps 0° DO6xxx-BS...  P01-DO61Wxxx-11-00-00-xx-014	taps 0° DO6xxx-BE...  P01-DO61Wxxx-11-00-00-xx-020

3.5 Mounting position for steam applications

With steam applications, two condensate chambers have to be applied. They must be mounted on the same level. The transmitter must be located below the pipe. The pipes between the transmitter and the condensate chambers must be completely filled with water on both sides.

A 5-valve manifold allows simple piping and can be used instead of T-sections and additional blow-out valves.


The impulse pipes must be installed with a slope of at least 1:15 to reliably ensure rising of trapped air in the water of the impulse line to the transmitter.

It is recommended to use flange pairs – or preferably welded connections – for steam applications. Behind the condensate chambers Ermeto 12S connections are permissible.



Note!

When measuring in steam, installing separators (5) and drain valves (7) is useful for capturing and removing dirt.














P01-DOxxxxxx-11-xx-xx-xx-013

A: with 3-valve manifold; for easy venting of the transmitter; especially for small differential pressures;

B: with 5-valve manifold for blowing out the impulse pipes;

1: Orifice plate; **2:** Shut-off valves; **3:** manifold; **4:** Differential pressure transmitter Deltabar; **5:** Separator; **6:** Condensate chambers; **7:** Drain valves

compact; vertical	compact; horizontal	remote; vertical	remote; horizontal
flow upwards DO6xxxx-GM...  P01-DO61Wxxx-11-00-00-xx-005	mounting left DO6xxxx-GB...  P01-DO61Wxxx-11-00-00-xx-011	taps 90°; flow upwards DO6xxxx-FN...  P01-DO61Wxxx-11-00-00-xx-017	taps 180° DO6xxxx-FG...  P01-DO61Wxxx-11-00-00-xx-023
flow downwards DO6xxxx-GP...  P01-DO61Wxxx-11-00-00-xx-006	mounting right DO6xxxx-GC...  P01-DO61Wxxx-11-00-00-xx-012	taps 90°; flow downwards DO6xxxx-FR...  P01-DO61Wxxx-11-00-00-xx-026	
		taps 0°; flow upwards DO6xxxx-FM...  P01-DO61Wxxx-11-00-00-xx-018	taps 0°; mounting left DO6xxxx-FB...  P01-DO61Wxxx-11-00-00-xx-024
		taps 0°; flow downwards DO6xxxx-FP...  P01-DO61Wxxx-11-00-00-xx-027	taps 0°; mounting right DO6xxxx-FC...  P01-DO61Wxxx-11-00-00-xx-025

3.6 General mounting conditions

3.6.1 Up- and downstream lengths


In order to ensure a homogeneous flow profile it is necessary to mount the orifice in a sufficient distance to narrowings or bends of the pipe. The required upstream lengths for different types of obstacles are summarized in the following table. Detailed specifications can be obtained from ISO 5167-2.

Type of obstacle	$\beta \leq 0,2$		$\beta = 0,5$		$\beta = 0,75$	
	A ¹⁾	B ²⁾	A ¹	B ²	A ¹	B ²
Upstream length						
90° bend	6 x D	3 x D	22 x D	9 x D	44 x D	20 x D
2x90° bend ³⁾ in the same plane	10 x D	-	22 x D	10 x D	44 x D	22 x D
2x90° bend in perpendicular planes	19 x D	18 x D	44 x D	18 x D	44 x D	20 x D
concentric reducer	5 x D	-	8 x D	5 x D	13 x D	8 x D
concentric expander	6 x D	-	20 x D	9 x D	36 x D	18 x D
ball/gate valve, fully open	12 x D	6 x D	12 x D	6 x D	24 x D	12 x D
Downstream length						
any obstacle	4 x D	2 x D	6 x D	3 x D	8 x D	4 x D

D: inner pipe diameter; $\beta = d/D$: diameter ratio (d : inner orifice diameter)

- 1) for 0% of additional uncertainty
- 2) for 0,5% of additional uncertainty
- 3) The required lengths depend on the distance of the two elbows; typical values are given in this table. For detailed specifications refer to ISO 5167-2. The upstream length is also calculated by the selection and sizing tool "Applicator".

Examples (schematic)



P01-DOxxxxxx-11-xx-xx-xx-007

1: upstream length; **2:** downstream length;
a: 90° bend; **b:** valve, open; **c:** 2x90° bend



Note!

The requirements concerning the pipe as stated in ISO 5167 must be met (weld seams, roughness etc).



Note!

The required upstream length can be reduced by a rectifier (see page 34). Details are specified in ISO 5167-2.

3.6.2 Homogeneity

The fluid must be homogeneous. **Changes of the state of aggregation** (liquid, gas, steam) are not permissible.
The measuring pipe must be **completely filled**.


3.6.3 Mounting position

- The mounting position must be chosen such that access to the transmitter is always possible.
- If the following process temperatures are exceeded, a remote version has to be used. The transmitter must be mounted in a sufficient distance from the primary device.

Application	Maximum temperature for the compact version
Gas / Liquids	200 °C (392 °F)
Steam	300 °C (572 °F)

3.6.4 Heat insulation

Some applications require suitable measures to avoid heat loss to the ambience. A wide range of materials can be used to provide the required insulation.
With insulated pipes make sure that the impulse pipes are not covered in order to ensure sufficient heat dissipation. Otherwise the transmitter may become overheated (or undercooled). This applies equally to both the compact and the remote version.
The maximum insulation thickness for the compact version is 120 mm.



Caution!
Danger of electronics overheating!
Make sure that the impulse pipes between the primary element and the transmitter are always kept free of insulation.

3.6.5 Mounting position for temperature and pressure compensation

Separate process connections


Two additional probes are required for temperature and pressure compensation:

- **An absolute pressure sensor**

According to ISO 5167, this sensor must always be mounted on the upstream side of the orifice.

- **A temperature probe**

In order to avoid disturbances of the flow profile, this probe is to be mounted on the downstream side of the orifice. In doing so, the minimum downstream length L has to be observed (→ 15).




P01-DOxxxxxx-15-xx-xx-xx-010

- 1: Absolute pressure sensor
- 2: orifice and differential pressure transmitter
- 3: temperature probe
- 4: evaluation unit
- A: downstream length

Combined process connection for absolute and differential pressure

An adapter (e.g. oval flange adapter PZO, see page 37) can be used to screw a pressure transmitter or a pressure transducer onto the Deltabar flange.

The absolute pressure transmitter is to be mounted at the "+" side of the Deltabar.



P01-DOxxxxxx-14-xx-xx-xx-013

- 1: Deltabar
- 2: Transmitter for absolute pressure
- 3: Oval flange adapter PZO

For the calculation of the compensated flow refer to page 23 f.

3.6.6 Measuring range

The lower limit of the measuring range is determined by the minimum Reynolds number required for the measurement. For details see Technical Information TI22P.

The limit can be calculated by the "Applicator" selection and sizing tool.

3.7 Installation hints

3.7.1 General hints

- The primary element is calculated for specific pipe and operating data. Therefore it is essential to check if the data on the nameplate (see page 6) match the actual operating data.
- Before installing the device, check if the required upstream and downstream lengths are provided (see page 15).
- Observe the required mounting position:
 - for liquids: page 11
 - for gases: page 12
 - for steam: page 13
- For remote versions:

The shut-off valves are mounted to the pressure taps of the primary element or (in the case of steam applications) to the condensate chambers.
- For remote versions:

The impulse pipes have to be installed with a slope of at least 1:15.

 - For steam and liquids, a venting possibility has to be provided at the highest point.
 - For gases, a drainage has to be provided at the lowest point.

The impulse lines (+) and (–) have to be mounted to the respective inlets (process connection) of the manifold. The transmitter is directly screwed to the manifold with the supplied screws and gaskets.

3.7.2 Installation of DO61W (Flange tap)

- Observe the orientation of the orifice: The upstream side is marked by the labelling on the orifice plate handle.
- The instrument is supplied with welding neck flanges (orifice flange union). If necessary, the instrument must be disassembled before the welding. The welding and the checking of the welding seams must be performed according to the state of the art taking into account all relevant welding regulations.
- Orifice plates with a flat face are centered by the flange screws. In the case of horizontal mounting the lower flange screws have to be mounted first. The orifice plate and the gaskets are inserted from above. The remaining screws are mounted and slightly fastened. The orifice plate must be centered (this can be checked from the outer flange diameter). Then the flange screws can be tightened.

3.7.3 Installation of DO62C (Corner tap)

- Observe the orientation of the orifice: The upstream side is marked by "+" on the carrier ring.
- When installing the primary element between flanges with flat face, two gaskets suitable for the pressure, temperature and type of medium have to be applied (not included in scope of supply). The gaskets and the primary element must not project into the pipe. Therefore, according to DIN 19205, the inner diameter of the carrier rings is slightly larger than the pipe diameter.
- Carrier rings with flat face are centered by the flange screws. In the case of horizontal mounting the lower flange screws have to be mounted first. The carrier ring and the gaskets are inserted from above. The remaining screws are mounted and slightly fastened. The carrier ring must be centered (this can be checked from the outer flange diameter). Then the flange screws can be tightened.

3.7.4 Installation of DO63C (Annular chamber)


- Observe the orientation of the orifice: The upstream side is marked by "+" on the carrier ring.
- When installing the primary element between flanges with flat face, two gaskets suitable for the pressure, temperature and type of medium have to be applied (not contained in scope of supply). The gaskets and the primary element must not project into the pipe. Therefore, according to DIN 19205, the inner diameter of the carrier ring is slightly larger than the pipe diameter.
- Carrier rings with flat face are centered by the flange screws. In the case of horizontal mounting the lower flange screws have to be mounted first. The carrier ring and the gaskets are inserted from above. The remaining screws are mounted and slightly fastened. The carrier ring must be centered (this can be checked from the outer flange diameter). Then the flange screws can be tightened.
- To replace the orifice plate, the instrument must be completely detached from the measuring pipe and the connection bracket of the carrier rings must be opened.

3.7.5 Installation of DO64P (Orifice plate)

For flange tapping

The tapping flanges must comply with DIN19214 or ANSI16.36, respectively.

For D-D/2 tapping



P01-DOxxxxxx-14-xx-xx-017

The following conditions have to be met for D-D/2 tapping:

- Distance between orifice plate and "+" tap: $0,9D \dots 1,1D$
- Distance between orifice plate and "-" tap:
 - $0,48D \dots 0,52D$ for $\beta \leq 0,6$
 - $0,49D \dots 0,51D$ for $\beta > 0,6$

Both distances are measured from the upstream face of the orifice plate.

- The centreline of the tapping shall meet the pipe centreline at an angle as near to 90° as possible, but in every case within 3° of the perpendicular.
- The diameter of pressure tapings shall be less than $0,13D$ and less than 13 mm.

General mounting hints

- Observe the orientation of the orifice: The upstream side is marked by the labelling on the handle of the orifice plate.
- When installing the primary element between flanges with flat face, two gaskets suitable for the pressure, temperature and type of medium have to be applied (not contained in scope of supply).
- Orifice plates with flat face are centered by the flange screws. In the case of horizontal mounting the lower flange screws have to be mounted first. The orifice plate and the gaskets are inserted from above. The remaining screws are mounted and slightly fastened. The orifice plate must be centered (this can be checked from the outer flange diameter). Then the flange screws can be tightened.
- To replace the orifice plate, the flanges can be forced apart by the jack screws.

3.7.6 Installation of DO65F (Meter run)

- Observe the orientation of the orifice: The longer pipe of the meter run must point upstream.
- The meter run is mounted to the measuring pipe by the end flanges.

3.8 Installation check

Perform the following checks after installing the measuring device:

- Is the device damaged (visual inspection)?
- Do the process temperature/pressure, ambient temperature, measuring range etc. correspond to the specifications of the device?
- Does the marking of the flow direction on the device match the direction of flow through the pipe?
- Are the measuring point number and labeling correct (visual inspection)?
- Is the orientation chosen for the sensor correct, in other words suitable for sensor type, application and fluid properties, in particular fluid temperature?
- Is the measuring device protected against moisture and direct sunlight?
- Are all screws firmly tightened?

4 Wiring

4.1 Wiring of the Deltabar S differential pressure transmitter

The wiring of the Deltabar S differential pressure transmitter is described in the following documents:

Communication	Operating Instructions
4...20 mA HART	BA270P
PROFIBUS PA	BA294P
Foundation Fieldbus	BA301P

The appropriate Operating Instructions are supplied together with the Deltabar S.

5 Operation and commissioning

5.1 Configuration of the Deltabar S differential pressure transmitter

The operation of the Deltabar S differential pressure transmitter and the commissioning of the measurement are described in the following documents:

Communication	Operating Instructions
4...20 mA HART	BA270P
PROFIBUS PA	BA294P
Foundation Fieldbus	BA301P

The appropriate Operating Instructions are supplied together with the Deltabar S.



Note!

If the differential pressure transmitter is ordered with the primary device, then it is completely pre-configured on delivery. A parametrization is not required in this case.

If an unconfigured differential pressure transmitter is used, the configuration data can be obtained from the supplied calculation sheet or can be calculated by the "Applicator" selection and sizing tool.

5.2 Configuration of a temperature and pressure compensation

5.2.1 Calculation of the compensated volume or mass flow

- **for steam**

by Energy Manager RMS621 from Endress+Hauser;
for details see Technical Information TI092R

- **for all media**

by the Flow and Energy Manager RMC621 from Endress+Hauser;
for details see Technical Information TI098R

- **for all media**

by a PLC;
in this case the compensation calculation has to be programmed by the user

5.2.2 Calculation formula for the temperature and pressure compensation

At first the starting point for the compensation has to be defined. The starting point is the calculation sheet, which accompanies every primary element. On the calculation sheet, layout data can be found for a specific operating condition (pressure and temperature).

The relationship between flow and differential pressure is described by a square root function:

$$Q_m = \sqrt{2 \Delta p \rho} \quad \text{for the mass flow (or volume flow at normal or standard conditions)}$$

and

$$Q_v = \sqrt{\frac{2 \Delta p}{\rho}} \quad \text{for the volume flow}$$

where

ρ = the density of the medium.

If the current output of the Deltabar transmitter is set to flow values, the square root function is already implemented. Otherwise the square root function must be computed externally, e.g. in a PLC. Please make sure that the square root function is not applied twice.

Whenever the real operating conditions differ from the conditions used in the calculation sheet, the density of the gas will change and thus also the calculated flow rate will change according to the above-mentioned formula.

$$\rho_2 = \rho_1 \frac{P_2}{P_1} \frac{T_1}{T_2} \frac{Z_1}{Z_2}$$

where

P = absolute pressure

T = absolute temperature (K)

Z = compressibility factor

1 = operating condition according to the calculation sheet

2 = actually measured operating condition

The compensation can now be computed as follows:

$$Q_2 = Q_1 \sqrt{\frac{P_2}{P_1} \frac{T_1}{T_2} \frac{Z_1}{Z_2}} \quad \text{for the mass flow (or volume flow at standard conditions)}$$

$$Q_2 = Q_1 \sqrt{\frac{P_1}{P_2} \frac{T_2}{T_1} \frac{Z_2}{Z_1}} \quad \text{for the volume flow}$$

The compressibility factor Z can be neglected if its value is close to 1. If the compressibility factor is to be included in the compensation, the value must be determined according to the actually measured pressure and temperature. Compressibility factors are available in the corresponding literature in tables or graphs or can be calculated, e.g. using the Soave-Redlich-Kwong procedure.

5.3 Usage of the accessories

5.3.1 Condensate pots (for steam applications)

Usage


Usage of condensate pots is recommended for gaseous media, which condense when cooling down in the impulse pipes. This is mainly the case in steam; depending on temperature and pressure it may also occur in other media (e.g. in alcohols).

Operating principle

Condensate pots ensure that the impulse lines are always completely filled with liquid and that the membrane of the transmitter is not exposed to hot steam. The liquid level is maintained by condensing steam. Excess condensate flows back and is re-evaporated.

The usage of condensate pots considerably reduces fluctuations of the water column. The stabilized measuring signal and the increased zero point stability ensure a consistent measurement quality.

The water column transfers the pressure to the transmitter membrane.



P01-DOxxxxxx-15-xxx-xxx-007

A. water; B. steam; C. condensing steam; D. excess condensate flows back

Installation and commissioning

- When installing the condensate pots, make sure that they are located at the same height. Otherwise the zero point adjustment is hardly achievable.
- Before commissioning, the condensate chambers as well as the impulse pipes to the Deltabar differential pressure transmitter must be completely filled with water. There are different possible methods for the filling of the condensate chambers:
 - through the filling nozzle at the condensate chambers (if present)
 - through the condensate drain valve or the venting valve of the Deltabar differential pressure transmitter. To do so, the impulse lines must be connected to the water supply, e.g. by a hose connector.
 - after the commissioning of the steam pipe wait until the impulse pipes and the condensate chambers have been filled by themselves with condensate. To do so, the valves at the manifold have to be closed.



Caution!

It is essential to avoid any overheating of the Deltabar differential pressure transmitter. Depending on the steam temperature the temperature at the manifold has to be monitored. If there is any risk of overheating, the shut-off valves in the impulse pipes must be closed.



Note!

In any case after filling and after commissioning of the steam supply, wait for stable conditions before performing the zero point adjustment.

5.3.2 Shut-off valves

Usage

Shut-off-valves are used with remote versions for high pressure and high temperature applications. They are used as a primary shut-off for the measuring point.

Depending on national regulations primary shut-off with two shut-off valves per impulse pipe may be recommended or required.

Operating principle


The primary shut-off provides separation close to the process between the measuring system and the measuring pipe in the case of leakages or if maintenance measures are carried out at the impulse pipes.

Installation and commissioning

After completion of the installation, the shut-off valves must be closed. When starting the commissioning, the shut-off valves should be opened cautiously and the complete measuring system should be checked for leakages.


5.3.3 Manifold

Versions




P01-DOxxxxxx-14-xx-xx-xx-014

3-valve manifold



P01-DOxxxxxx-14-xx-xx-xx-015

5-valve manifold; milled



P01-DOxxxxxx-14-xx-xx-xx-016

5-valve manifold; forged

Valve	Application
1, 2	Separates the Deltabar differential pressure transmitter from the process
3	Equalization valve (zero point adjustment of the Deltabar differential pressure transmitter)
4, 5	■ Venting (for liquids and steam) ■ Draining (for gases) ■ Complete emptying of the impulse pipes (e.g. for maintenance purposes)

Usage

The manifold is used to separate the Deltabar differential pressure transmitter from the process and to perform the zero point adjustment.

Operating principle

If the Deltabar differential pressure transmitter has to be removed from the measuring point (e.g. for exchange or repair), it is possible to completely separate the transmitter from the process by closing all three valves.

Commissioning

During commissioning a zero point adjustment of the Deltabar differential pressure transmitter should be performed in any case. During the first commissioning, when starting the process, all valves should be closed. Then, the valves of the "-" and "+" side should be opened cautiously. The equalization valve remains closed.

After this, make sure that the impulse pipes, the manifold and the transmitter are completely vented (for liquids and steam) or drained (for gases).

Zero point adjustment

To perform the zero point adjustment, first close the valve at the "-" side and then open the equalization valve (3), such that the "+" and the "-" side of the transmitter are exposed to the same static process pressure (+). In this state the zero point adjustment of the Deltabar differential pressure can be performed (refer to the Operating Instructions of the Deltabar). After completion of the zero point adjustment the measuring system is put back into operation by performing the same steps in reverse order.

The zero point adjustment should be checked and – if necessary – adjusted regularly. Also the measuring system should regularly be checked for complete venting or draining, respectively.

Venting/draining

The additional valves of 5-valve manifolds are used for venting or draining or to empty the impulse pipes completely (e.g. for maintenance purposes). In steam applications these valves are used to blow out the impulse pipes.



Note!

The complete venting or draining of the Deltabar differential pressure transmitter is always performed by appropriate devices at the side opposite to the transmitter flanges.



Caution!

If all three valves at the manifold are opened at the same time, the pressure difference may cause a flow of the medium through the manifold. With hot media this may result in an overheating of the manifold and of the Deltabar differential pressure transmitter. Therefore, it is essential to avoid simultaneous opening of all three valves under operating conditions.

6 Troubleshooting

6.1 Error messages of the Deltabar S

Error messages of the Deltabar S differential pressure transmitter are described in the following Operating Instructions:

Communication	Operating Instructions
4...20 mA HART	BA270P
PROFIBUS PA	BA294P
Foundation Fieldbus	BA301P

The appropriate Operating Instructions are supplied together with the Deltabar S.

6.2 Application errors

Error	Possible cause; measure
No flow indicated	Installation errors - No contact between process and transmitter -> Check if the valves to the differential pressure transmitter are open. Configuration errors - Configuration of the transmitter or flow calculator false or missing -> Check and adjust configuration
Zero point drift; measured value fluctuations	Planning errors - high turndown -> if necessary use different measuring cell or select arrangement with multiple transmitters ("split range", see Technical Information TI422P) Installation errors - Gas or liquid in the impulse pipe/in the transmitter -> vent or drain impulse pipes and transmitter (see page 28) Calibration errors - low-flow-cut-off not activated -> activate low-flow-cut-off (see Operating Instructions of Deltabar) - no zero point adjustment -> perform zero point adjustment (see page 28) - no compensation for gas measurements -> complete temperature and pressure compensation (see page 23)
Wrong measuring value	Planning errors - wrong pipe data; wrong flow data; wrong medium data -> compare values of the sizing sheet - data sheet to the actual values - inappropriate pipe (disturbed flow profile caused by fixtures, weld seams, protruding sealings, in- and outlets, fittings etc.) -> remove obstacles disturbing the flow profile - relative humidity does not match the planning data -> make sure that the relative humidity matches the specifications on the calculation sheet - wrong measuring range of the differential pressure transmitter -> if necessary, use different measuring cell Installation errors - wrong mounting position -> check mounting position (see page 11, 12, 13) - Wrong orifice orientation -> DO61W, DO64P: The labelling of the orifice plate must point into the upstream direction. -> DO62C, DO63C: The "+" side of the carrier ring must point into the upstream direction. -> DO65F: The longer pipe of the meter run must point into the upstream direction. - Upstream or downstream length too short -> check up and downstream lengths (see page 15) - leakages -> check complete measuring system for leakages Calibration error - compensation for gas measurements wrong or missing -> complement temperature and pressure compensation (see page 23) - wrong transmitter settings -> check configuration of the Deltabar differential pressure transmitter (see Operating Instructions of Deltabar) -> check configuration of the Flow Manager (see Operating Instructions of RMC621/RMS621) Maintenance error - wear of the orifice (especially with abrasive media) -> if necessary, exchange orifice plate

7 Maintenance and repairs

7.1 Maintenance

The following maintenance tasks should be performed in regular intervals:

- Checking of the zero-point adjustment
- for wet gases: drain the condensate
- for soiled media: remove the sediment
- for abrasive media: check the primary device for abrasions
- for build-up formation: check and clean the primary device; exchange gaskets



Note!

Primary elements do not require further maintenance if used appropriately. During standard revisions of the measuring point it is recommended to examine the primary element carefully to ensure its functionality (material/edge sharpness, traces of wear)



Caution!

Required maintenance work must be carried out with consideration of the responsible department and/or trained staff. Security advices of these departments and the staff have to be taken into account (checking pressure/temperature; valves have to be closed)



Caution!

If maintenance measures (e.g. exchange of the transmitter or the manifold) have to be carried out under process conditions, it must be ensured that all valves are closed and that there is no danger of leaking medium. If necessary, temperature and pressure have to be checked before unmounting the instrument.

7.2 Exterior cleaning

When cleaning the exterior, always use cleaning agents that do not attack the surface of the housing and the seals.

7.3 Replacing seals

Under normal circumstances, wetted seals need not to be replaced. Replacement is necessary only in special circumstances, for example if aggressive or corrosive fluids are incompatible with the seal material.

7.4 Spare parts

Material number	Description
71071897	Screw set UNF7/16x1-3/4", Steel, Viton Consists of: ■ 4x Screw, length 1-3/4", Steel ■ 4x Washer ■ 2x Seal Viton Usage: Manifold DA63M, milled Not for manifold + connection IEC61518, both side
71071899	Screw set UNF7/16x1-3/4", Steel, PTFE Consists of: ■ 4x Screw, length 1-3/4", Steel ■ 4x Washer ■ 2x Seal PTFE Usage: Manifold DA63M, milled Not for manifold + connection IEC61518, both side

Material number	Description
71071900	Screw set UNF7/16x2-1/4", Steel, Viton Consists of: ■ 4x Screw, length 2-1/4", Steel ■ 4x Washer ■ 2x Seal Viton Usage: Manifold DA63M, forging Not for manifold + connection IEC61518, both side
71071901	Screw set UNF7/16x2-1/4", Steel, PTFE Consists of: ■ 4x Screw, length 2-1/4", Steel ■ 4x Washer ■ 2x Seal PTFE Usage: Manifold DA63M, forging Not for manifold + connection IEC61518, both side

7.5 Return

The following procedures must be carried out before a transmitter is sent to Endress+Hauser e.g. for repair or calibration:

- Remove all residue which may be present. Pay special attention to the gasket grooves and crevices where fluid may be present. This is especially important if the fluid is dangerous to health, e.g. corrosive, poisonous, carcinogenic, radioactive, etc.
- Always enclose a duly completed "Declaration of contamination" form (a copy of the "Declaration of contamination" is included at the end of this operating manual). Only then can Endress +Hauser transport, examine and repair a returned device.
- Enclose special handling instructions if necessary, for example a safety data sheet as per EN 91/155/EEC.

Additionally specify:

- An exact description of the application.
- The chemical and physical characteristics of the product.
- A short description of the error that occurred (specify error code if possible)
- Operating time of the device.

7.6 Disposal

In case of disposal please separate the different components according to their material consistence.

7.7 Contact addresses of Endress+Hauser

Contact addresses can be found on our homepage: www.endress.com/worldwide. If you have any questions, please do not hesitate to contact your Endress+Hauser representative.

8 Accessories

8.1 Overview

The following accessories are available for the differential-pressure flow measurement with orifices:

- DA61V: Shut-Off Valve (see Technical Information TI422P)
- DA61C: Condensate pot (see Technical Information TI422P)
- DA63M: Manifold (see Technical Information TI422P)
- DA63R: Rectifier (see page 34)
- PZO: Oval flange adapter (see page 37)

The condensate pots, shut-off valves and manifold can be ordered together with the orifice. They are included in the product structures DO61W, DO62C, DO63C and DO65F.

Alternatively, they can be ordered by their own product structures. For details refer to Technical Information TI422P.

The rectifier can only be ordered by its own product structure.

8.2 Rectifier DA63R


8.2.1 Usage

The rectifier can be used to reduce the required upstream length between an obstacle in the pipe and the orifice.

Installation conditions

- Distance between rectifier and obstacle: min. 8,5 D
- Distance between rectifier and orifice: min. 7,5 D

D: inner pipe diameter



P01-DOxxxxxx-11-xx-xx-xx-015


Pressure loss

Pressure loss across the rectifier:

$$\Delta p = 1,5 \rho v^2$$

- Δp : Pressure loss across the rectifier [Pa]
- ρ : Density of the fluid [kg/m³]
- v : Flow velocity [m/s]

8.2.2 Dimensions



P01-DOxxxxxx-14-xx-xx-xx-018

The Zanker perforated plate conditioner according to ISO 5167-2 consists of 32 bores in a circular symmetrical arrangement. The dimensions of the bores depend on the inner diameter D of the pipe:

- 4 bores, bore diameter $0,141 D$, reference diameter $0,25 D$
- 8 bores, bore diameter $0,139 D$, reference diameter $0,56 D$
- 4 bores, bore diameter $0,1365 D$, reference diameter $0,75 D$
- 8 bores, bore diameter $0,11 D$, reference diameter $0,85 D$
- 8 bores, bore diameter $0,077 D$, reference diameter $0,90 D$

The plate thickness is $1/8 D$.

The plate diameter is adjusted to the outer diameter of the flange (according to feature 30 "orifice").

8.2.3 Versions


Version	Mean Diameter
DA63R25	DN25 / 1"
DA63R40	DN40 / 1-1/2"
DA63R50	DN50 / 2"
DA63R65	DN65 / 2-1/2"
DA63R80	DN80 / 3"
DA63R1H	DN100 / 4"
DA63R1Z	DN125 / 5"
DA63R1F	DN150 / 6"
DA63R2H	DN200 / 8"
DA63R2F	DN250 / 10"
DA63R3H	DN300 / 12"
DA63R3F	DN350 / 14"
DA63R4H	DN400 / 16"

8.2.4 Product structure

10	Version
S	Standard
Y	special version, to be specified
30	Orifice
	EN flanges
BAC	PN6 B1, 316L
BBC	PN10 B1, 316L
BCC	PN16 B1, 316L
BDC	PN25 B1, 316L
BEC	PN40 B1, 316L
BFC	PN63 B2, 316L
BGC	PN100 B2, 316L
BHC	PN160 E, 316L
	ANSI flanges
FAC	Cl.150 RF, 316L
FBC	Cl.300 RF, 316L
FCC	Cl.600 RF, 316L
FDC	Cl.900 RF, 316L
FEC	Cl.1500 RF, 316L
FFC	Cl.2500 RF, 316L
FKC	Cl.900 RTJ, 316L
FLC	Cl.1500 RTJ, 316L
FMC	Cl.2500 RTJ, 316L
Y99	special version, to be specified
550	Additional Option (optional, multiple options can be selected)
F1	EN10204-3.1 material (wetted parts) inspection certificate
F2	EN10204-3.1 material, NACE MR0175 (wetted parts) inspection certificate
895	Marking
Z1	Tagging (TAG), see additional spec.

8.3 Oval flange adapter PZO

8.3.1 Dimensions



P01-DOxxxx-15-xx-xx-xx-022

8.3.2 Product structure PZO

010	Approval
R	Basic version
B	EN10204-3.1 material, oval flange inspection certificate
S	Cleaned from oil+grease, oxygen service
020	Process Connection
A	FNPT1/2-14
030	Material
2	Steel C22.8
1	316L
040	Seal
1	PTFE
2	FKM Viton
050	Mounting Screw
1	2x Mounting screw M10
4	2x Mounting screw M12
2	2x Mounting screw UNF7/16-20
3	Not selected

Index

A

annular chamber 19
 application errors 30
 approvals 9

C

CE mark 9
 certificates 9
 cleaning 31
 commissioning 4
 condensate pots 25
 corner tap 18

D

declaration of conformity 9
 declaration of contamination 32
 Deltabar S 7, 22–23, 29
 dimensions 10
 disposal 32
 documentation 7
 downstream lengths 15
 draining 28

E

Energy Manager 8
 error messages 29

F

flange tap 18
 Flow and Energy Manager 8

G

gas applications 12

H

hazardous area 4
 heat insulation 16

I

incoming acceptance 10
 installation 4
 iTEMP 8

L

liquid applications 11

M

maintenance 31
 manifold 27
 measuring range 17
 meter run 20
 mounting conditions 15
 mounting position 11–13, 16

N

nameplate 6

O

Omnigrad T 8
 operation 4
 orifice plate 20
 oval flange adapter 37

P

pressure compensation 17, 23
 Pressure Equipment Directive 9
 product structure 6

R

rectifier 34
 return 32

S

seals 31
 shut-off valves 26
 spare parts 31
 steam applications 13
 storage 10

T

temperature compensation 17, 23
 trademarks 9
 transport 10

U

upstream lengths 15

V

venting 28

Z

zero point adjustment 28

Declaration of Hazardous Material and De-Contamination *Erklärung zur Kontamination und Reinigung*

RA No.

Please reference the Return Authorization Number (RA#), obtained from Endress+Hauser, on all paperwork and mark the RA# clearly on the outside of the box. If this procedure is not followed, it may result in the refusal of the package at our facility.

Bitte geben Sie die von E+H mitgeteilte Rücklieferungsnummer (RA#) auf allen Lieferpapieren an und vermerken Sie diese auch außen auf der Verpackung. Nichtbeachtung dieser Anweisung führt zur Ablehnung ihrer Lieferung.

Because of legal regulations and for the safety of our employees and operating equipment, we need the "Declaration of Hazardous Material and De-Contamination", with your signature, before your order can be handled. Please make absolutely sure to attach it to the outside of the packaging.

Aufgrund der gesetzlichen Vorschriften und zum Schutz unserer Mitarbeiter und Betriebseinrichtungen, benötigen wir die unterschriebene "Erklärung zur Kontamination und Reinigung", bevor Ihr Auftrag bearbeitet werden kann. Bringen Sie diese unbedingt außen an der Verpackung an.

Type of instrument / sensor

Geräte-/Sensortyp

Serial number

Seriennummer



Used as SIL device in a Safety Instrumented System / Einsatz als SIL Gerät in Schutzeinrichtungen

Process data / Prozessdaten

Temperature / Temperatur _____ [°F] _____ [°C]

Pressure / Druck _____ [psi] _____ [Pa]

Conductivity / Leitfähigkeit _____ [µS/cm]

Viscosity / Viskosität _____ [cp] _____ [mm²/s]

Medium and warnings

Warnhinweise zum Medium



	Medium / concentration Medium / Konzentration	Identification CAS No.	flammable entzündlich	toxic giftig	corrosive ätzend	harmful/ irritant gesundheitsschädlich/ reizend	other * sonstiges*	harmless unbedenklich
Process medium Medium im Prozess								
Medium for process cleaning Medium zur Prozessreinigung								
Returned part cleaned with Medium zur Endreinigung								

* explosive; oxidising; dangerous for the environment; biological risk; radioactive

* explosiv; brandfördernd; umweltgefährlich; biogefährlich; radioaktiv

Please tick should one of the above be applicable, include safety data sheet and, if necessary, special handling instructions.

Zutreffendes ankreuzen; trifft einer der Warnhinweise zu, Sicherheitsdatenblatt und ggf. spezielle Handhabungsvorschriften beilegen.

Description of failure / Fehlerbeschreibung

Company data / Angaben zum Absender

Company / Firma _____	Phone number of contact person / Telefon-Nr. Ansprechpartner: _____
Address / Adresse _____	Fax / E-Mail _____
_____	Your order No. / Ihre Auftragsnr. _____

"We hereby certify that this declaration is filled out truthfully and completely to the best of our knowledge. We further certify that the returned parts have been carefully cleaned. To the best of our knowledge they are free of any residues in dangerous quantities."

"Wir bestätigen, die vorliegende Erklärung nach unserem besten Wissen wahrheitsgetreu und vollständig ausgefüllt zu haben. Wir bestätigen weiter, dass die zurückgesandten Teile sorgfältig gereinigt wurden und nach unserem besten Wissen frei von Rückständen in gefahrbringender Menge sind."

(place, date / Ort, Datum)

Name, dept./Abt. (please print / bitte Druckschrift)

Signature / Unterschrift

For more Endress+Hauser product please visit: www.ainstru.com
Mail: Sales@ainstru.com

www.endress.com/worldwide

Endress+Hauser 
People for Process Automation

