


Operating Instructions

Liquicap M

FMI51 HART

Capacitive Level Measurement





A0023555

Table of contents

1	About this document	6		
1.1	Document function	6		
1.2	Document conventions	6		
1.2.1	Safety symbols	6		
1.2.2	Electrical symbols	6		
1.2.3	Tool symbols	6		
1.2.4	Symbols for certain types of information and graphics	7		
1.3	Documentation	8		
1.3.1	Technical Information	8		
1.3.2	Certificates	8		
1.4	Registered trademarks	10		
2	Basic safety instructions	11		
2.1	Requirements for the personnel	11		
2.2	Workplace safety	11		
2.3	Operational safety	11		
2.3.1	Ex-area	11		
2.4	Product safety	11		
3	Incoming acceptance and product identification	12		
3.1	Incoming acceptance	12		
3.2	Product identification	12		
3.3	Storage and transport	12		
4	Mounting	13		
4.1	Quick installation guide	13		
4.2	Mounting requirements	14		
4.2.1	Mounting the sensor	14		
4.2.2	Support with marine approval (GL)	15		
4.3	Measuring condition	15		
4.4	Minimum probe length for nonconductive media < 1 µS/cm	16		
4.5	Installation examples	16		
4.5.1	Rod probes	16		
4.6	Probe with separate housing	19		
4.6.1	Extension heights: separate housing	19		
4.6.2	Wall bracket	21		
4.6.3	Wall mounting	21		
4.6.4	Pipe mounting	22		
4.6.5	Shortening the connecting cable	22		
4.7	Installation instructions	23		
4.7.1	Probe installation	24		
4.7.2	Aligning the housing	25		
4.7.3	Sealing the probe housing	25		
4.8	Post-installation check	25		
5	Electrical connection	26		
5.1	Connecting requirements	26		
5.1.1	Potential equalization	26		
5.1.2	Electromagnetic compatibility (EMC)	26		
5.1.3	Cable specification	26		
5.1.4	Connector	27		
5.1.5	Supply voltage	27		
5.2	Wiring and connecting	27		
5.2.1	Connection compartment	27		
5.2.2	Terminal assignment	29		
5.2.3	Connecting HART with other supply units	30		
5.3	Post-connection check	30		
6	Operation options	31		
6.1	Overview of operation options	31		
6.1.1	Display and operating elements at the FEI50H electronic insert	31		
6.1.2	Operation via the optional display and operating module	32		
6.1.3	The operating menu	34		
6.2	Error messages	37		
6.3	Locking and unlocking configuration	37		
6.3.1	Key locking	37		
6.3.2	Key unlocking	37		
6.3.3	Software locking	37		
6.4	Resetting to factory setting	38		
6.4.1	Using the reset	38		
6.4.2	Effects of a reset	38		
6.4.3	Performing a reset	38		
6.5	Operation via FieldCare Device Setup	38		
6.5.1	Function scope	38		
6.5.2	Source for device description files	38		
7	Commissioning	39		
7.1	Installation and function check	39		
7.2	Basic setup without the display or operating module	39		
7.2.1	Function switch: position 1. Operation	40		
7.2.2	Function switch: position 2. Carry out empty calibration - for empty tanks	40		
7.2.3	Function switch: position 2. Carry out empty calibration - for almost empty tanks	40		
7.2.4	Function switch: position 3. Carry out full calibration - for full tanks	41		
7.2.5	Function switch: position 3. Carry out full calibration - for almost full tanks	41		
7.2.6	Function switch: position 4. Measuring modes	42		
7.2.7	Function switch: position 5. Measuring range	42		

7.2.8	Function switch: position 6. Proof test - self-test	43	8	Diagnostics and troubleshooting ...	76
7.2.9	Function switch: position 7. Reset - restore factory settings	43	8.1	Diagnostic information via LEDs	76
7.2.10	Function switch: position 8. Download or upload sensor DAT (EEPROM)	43	8.1.1	Green LED flashing	76
7.3	Menu: "Basic setup". Commissioning with display and operating module	44	8.1.2	Red LED flashing	76
7.3.1	Initial commissioning	44	8.2	System error messages	76
7.3.2	Function: "Basic setup"	46	8.2.1	Error signal	76
7.3.3	Function: "Medium property"	47	8.2.2	Last errors	76
7.3.4	Operating mode: "Empty calibr." and function - "Wet"	47	8.2.3	Types of error	76
7.3.5	Operating mode: "Full calibr." and function - "Wet"	48	8.2.4	Error codes	77
7.3.6	Operating mode: "Empty calibr." and function - "Dry"	48	8.3	Possible measuring errors	78
7.3.7	Operating mode: "Full calibration" and function - "Dry" for conductive and nonconductive media	49	8.3.1	Measured value is incorrect	78
7.3.8	Operating mode: "Empty calibration" and function - "Dry" for "Interface" or "Unknown" medium properties	50	8.4	Firmware history	79
7.3.9	Operating mode: "Full calibration" and function - "Dry" for "Interface" or "Unknown" medium properties	50	9	Maintenance	80
7.3.10	Function: "Output damping"	50	9.1	External cleaning	80
7.4	Menu: "Safety setting"	50	9.2	Cleaning the probe	80
7.4.1	Function: "Safety settings"	52	9.3	Seals	80
7.4.2	Function: "Safety settings"	52	9.4	Endress+Hauser services	80
7.4.3	Function: "Safety settings"	53	10	Repair	81
7.4.4	Function: "Operating mode"	53	10.1	General notes	81
7.4.5	Function: "Safety settings"	54	10.2	Spare parts	81
7.4.6	Function: "Output on alarm"	54	10.3	Repairing Ex-certified devices	81
7.4.7	Function: "Proof test" - self-test	55	10.4	Replacement	82
7.5	Menu: "Linearization"	55	10.5	Return	82
7.5.1	Function: "Linearization"	57	10.6	Disposal	82
7.5.2	Function: "Linearization"	60	10.6.1	Removing the measuring device	82
7.6	Menu: "Output"	62	10.6.2	Disposing of the measuring device ...	82
7.6.1	Submenu: "Extended calibr."	63	11	Accessories	83
7.6.2	Submenu: "HART setting"	64	11.1	Protective cover	83
7.6.3	Menu: "Simulation"	65	11.2	Commubox FXA195 HART	83
7.7	Menu: "Device properties"	65	11.3	HAW56x surge arrester	83
7.7.1	Submenu: "Display"	68	11.4	Weld-in adapter	83
7.7.2	Submenu: "Diagnosis"	69	12	Technical data	84
7.7.3	Submenu: "System parameters"	70	12.1	Probe	84
7.8	Operation	71	12.1.1	Capacitance values of the probe	84
7.9	FieldCare: operating program from Endress +Hauser	71	12.1.2	Additional capacitance	84
7.9.1	FieldCare	72	12.1.3	Probe lengths for continuous measurement in conductive liquids ..	84
7.9.2	Interface measurement	72	12.2	Input	85
7.9.3	Dry calibration for interface measurement	73	12.2.1	Measured variable	85
7.9.4	Wet calibration for interface measurement	74	12.2.2	Measuring range	85
			12.3	Output	85
			12.3.1	Output signal	85
			12.3.2	Signal on alarm	85
			12.3.3	Linearization	85
			12.4	Performance characteristics	86
			12.4.1	Reference operating conditions	86
			12.4.2	Maximum measured error	86
			12.4.3	Influence of ambient temperature ...	86
			12.4.4	Influence of process pressure	86
			12.4.5	Switch-on behavior	86
			12.4.6	Measured value reaction time	86
			12.4.7	Response time	87

12.4.8 Accuracy of factory calibration 87

12.4.9 Resolution 87

12.5 Operating conditions: Environment 88

12.5.1 Ambient temperature range 88

12.5.2 Climate class 88

12.5.3 Vibration resistance 88

12.5.4 Shock resistance 88

12.5.5 Degree of protection 88

12.6 Operating conditions: Process 89

12.6.1 Process temperature range 89

12.6.2 Process pressure limits 90

12.6.3 Pressure and temperature derating . . 91

Index 93

1 About this document

1.1 Document function

These Operating Instructions contain all the information that is required in various phases of the life cycle of the device: from product identification, incoming acceptance and storage, to mounting, connection, operation and commissioning through to troubleshooting, maintenance and disposal.

1.2 Document conventions

1.2.1 Safety symbols



This symbol alerts you to a dangerous situation. Failure to avoid this situation will result in serious or fatal injury.



This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in serious or fatal injury.



This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in minor or medium injury.



This symbol contains information on procedures and other facts which do not result in personal injury.

1.2.2 Electrical symbols



Alternating current



Direct current and alternating current



Direct current



Ground connection

A grounded terminal which, as far as the operator is concerned, is grounded via a grounding system.

Protective earth (PE)

Ground terminals that must be connected to ground prior to establishing any other connections.

The ground terminals are located on the interior and exterior of the device:

- Interior ground terminal: protective earth is connected to the mains supply.
- Exterior ground terminal: device is connected to the plant grounding system.

1.2.3 Tool symbols



Phillips head screwdriver



Flat blade screwdriver



Torx screwdriver



Allen key



Open-ended wrench

1.2.4 Symbols for certain types of information and graphics



Permitted

Procedures, processes or actions that are permitted



Preferred

Procedures, processes or actions that are preferred



Forbidden

Procedures, processes or actions that are forbidden



Tip

Indicates additional information




Reference to documentation



Reference to graphic



Notice or individual step to be observed



Series of steps



Result of a step



Operation via operating tool



Write-protected parameter

1, 2, 3, ...

Item numbers

A, B, C, ...

Views



Safety instructions

Observe the safety instructions contained in the associated Operating Instructions

1.3 Documentation

1.3.1 Technical Information

Liquicap M FMI51

TI01484F

1.3.2 Certificates

ATEX safety instructions

Liquicap M FMI51

- II 1/2 G Ex ia IIC T3...T6 Ga/Gb
II 1/2 G Ex ia IIB T3...T6 Ga/Gb
II 1/2 D Ex ia IIIC T90 °C Da/Db
XA00327F
- II 1/2 Ex ia/db IIC T6...T3 Ga/Gb
II 1/2 Ex ia/db eb IIC T6...T3 Ga/Gb
II 1/2 D Ex ia /tb IIIC T90 °C Da/Db
XA00328F
- Ga/Gb Ex ia IIC T3...T6
Zone 20/21 Ex iaD 20/Ex tD A21 IP65 T 90 °C
IECEx BVS 08.0027X
XA00423F
- II 3 G Ex nA IIC T6 Gc
II 3 G Ex nA nC IIC T5 Gc
II 3C D Ex tc IIIC T100 °C Dc
XA00346F

INMETRO safety instructions

Liquicap M FMI51

- Ex d [ia Ga] IIB T3...T6 Ga/Gb
Ex d [ia Ga] IIC T3...T6 Ga/Gb
Ex de [ia Ga] IIC T3...T6 Ga/Gb
XA01171F
- Ex ia IIC T* Ga/Gb
Ex ia IIB T* Ga/Gb
Ex ia IIIC T90 °C Da/Db IP66
XA01172F

NEPSI safety instructions

- Liquicap M FMI51
Ex ia IIC/IIB T3...T6 Ga/Gb
XA00417F
- Liquicap M FMI51
Ex d ia IIC/IIB T3/T4/T6 Ga/Gb
Ex d e ia IIC/IIB T3/T4/T6 Ga/Gb
XA00418F
- Liquicap M FMI51
Ex nA IIC T3...T6 Gc
Ex nA nC IIC T3...T6 Gc
XA00430F

Overfill protection DIBt (WHG)

Liquicap M FMI51

ZE00265F

Functional safety (SIL2)

Liquicap M FMI51

SD00198F

Control Drawings (CSA and FM)

- Liquicap M FMI51
FM IS
ZD00220F
- Liquicap M FMI51
CSA IS
ZD00221F
- Liquicap M FMI51
CSA XP
ZD00233F

1.4 Registered trademarks

HART®

Registered trademark of the FieldComm Group, Austin, USA

TRI CLAMP®

Registered trademark of Alfa Laval Inc., Kenosha, USA

2 Basic safety instructions

2.1 Requirements for the personnel

The personnel must fulfill the following requirements to carry out the necessary tasks:

- ▶ Are trained, qualified to perform specific functions and tasks.
- ▶ Are authorized by the plant owner or operator to perform specific tasks.
- ▶ Are familiar with federal or national regulations.
- ▶ Have read and understood the instructions in the manual and supplementary documentation.
- ▶ They follow instructions and comply with conditions.

2.2 Workplace safety

For work on and with the device:

- ▶ Wear the required protective equipment according to federal or national regulations.

2.3 Operational safety

When performing configuration, testing, and maintenance work on the device, alternative supervisory measures must be taken to guarantee the operational safety and process safety.

2.3.1 Ex-area

When using the measuring system in Ex-areas, the appropriate national standards and regulations must be observed. Separate Ex-documentation, which constitutes an integral part of this documentation, is supplied with the device. The installation procedures, connection data and safety instructions it contains must be observed.

- Make sure that the technical staff has adequate training.
- The special measuring and safety-related requirements for the measuring points must be observed.

2.4 Product safety

This measuring device is designed following good engineering practice to meet state-of-the-art safety requirements, has been tested, and left the factory in a condition in which it is safe to operate.

It meets general safety standards and legal requirements. It is compliant with the EC directives listed in the device-specific EC Declaration of Conformity. Endress+Hauser confirms this by affixing the CE mark to the device.

3 Incoming acceptance and product identification


3.1 Incoming acceptance

Check whether the packaging or content is damaged. Check that the goods delivered are complete and compare the scope of delivery with the information in your order.

3.2 Product identification

The measuring device can be identified in the following ways:

- nameplate data
- extended order code with a breakdown of the device features on the delivery note
- the serial number from nameplates in *W@M Device Viewer*
(www.endress.com/deviceviewer: all of the information on the measuring device is displayed along with an overview of the scope of the technical documentation provided
- the serial number on the nameplate into the *Endress+Hauser Operations App* or use the *Endress+Hauser Operations App* to scan the 2-D matrix code (QR Code) on the nameplate



1 The Liquicap M nameplate

- 2 Order number
- 3 Serial number
- 4 Electronic insert
- 5 Electronic insert output value
- 6 Ambient temperature at housing
- 7 Max. permissible pressure in tank
- 8 Safety certificates
- 9 Functional safety
- 10 Probe length values
- 11 ATEX approval
- 12 WHG approval (German Water Resources Act)
- 13 Safety information
- 14 Production date
- 15 Bar code


3.3 Storage and transport

For storage and transportation, pack the device in such a way as to protect it against impact. The original packaging offers the best protection for this. The permitted storage temperature is -50 to $+85$ °C (-58 to $+185$ °F) ± 5 °C (± 8 °F).

4 Mounting

4.1 Quick installation guide

A probe installation




A0040388

- 1. Screw the probe onto the proper place.
- 2. Fasten the probe with proper torque in accordance with the thread size (see table below).

A ¹⁾	B ²⁾
G½	< 80 Nm (59.0 lbf ft)
G¾	< 100 Nm (73.7 lbf ft)
G1	< 180 Nm (132.8 lbf ft)
G1½	< 500 Nm (368.7 lbf ft)

- 1) Thread size
- 2) Torque

Aligning the housing



A0042107

A0042108

A0042109

i Tighten the clamping screw with torque < 1 Nm (0.74 lbf ft).


4.2 Mounting requirements

4.2.1 Mounting the sensor

The Liquicap M FMI51 can be installed from the top or from the bottom.

i Make sure that:

- the probe is not installed in the area of the filling curtain
- the probe is not in contact with the container wall
- the distance from the container floor is ≥ 10 mm (0.39 in)
- multiple probes are mounted next to each other at the minimum distance between the probes of 500 mm (19.7 in)
- the probe is at a sufficient distance from the agitator if using the probe in agitator tanks
- the rod probes with a ground tube are used in the event of severe lateral load




A0040392

Unit of measurement mm (in)

4.2.2 Support with marine approval (GL)

Conductive or nonconductive support can be provided for fully insulated rod probes. Partially insulated rod probes may only be supported with insulation at the uninsulated end of the probe.

i Rod probes with a diameter of 10 to 16 mm (0.39 to 0.63 in) and a length ≥ 1 m (3.3 ft) have to be supported, see → 15



A0040416

Unit of measurement mm (in)

$L/4$ $\frac{1}{4}$ probe length

$L/2$ $\frac{1}{2}$ probe length

L Active probe length

Example of calculating distances


- probe length $L = 2$ m (6.6 ft)
 - $L/4 = 500$ mm (19.7 in)
 - $L/2 = 1$ m (3.3 ft)
- Measured from the end of the probe rod = 300 mm (11.8 in).

4.3 Measuring condition

Measuring range $L1$ is possible from the tip of the probe to the process connection.

Particularly suited for small containers.

Use a ground tube for nonconductive media.



A0040419

Unit of measurement mm (in)

L1 Measuring range

L3 Inactive length



When installing in a nozzle, use inactive length (L3).

The 0 % and 100 % calibration can be inverted.

4.4 Minimum probe length for nonconductive media < 1 µS/cm

The minimum probe length can be calculated using the formula:

$$l_{\min} = \frac{\Delta C_{\min}}{C_s \cdot (\epsilon_r - 1)}$$

A0040204

$l_{\min}$ minimum probe length

$\Delta C_{\min}$ 5 pF

C_s probe capacitance in air

ϵ_r dielectric constant, e.g. oil = 2.0

4.5 Installation examples

4.5.1 Rod probes

The probe can be installed in:

- conductive tanks made from metal
- nonconductive tanks made from plastic


If the process connection of the probe is insulated from the metal tank using a seal material, then the ground connection on the probe housing must be connected to the tank using a short line.

If the probe is installed in a plastic tank, then a probe with the ground tube must be used. The probe housing must be grounded.

i A fully insulated rod probe may be neither shortened nor extended.


Damaged insulation of the probe rod causes improper measurements.

The following application examples show the vertical installation for continuous level measurement.




A0040425

2 A probe with the conductive tanks




A0040426

3 A probe with the ground tube for the nonconductive tanks




A0040427

4 A probe with the inactive length for the insulated tanks



A0040428


5 A probe with ground tube and inactive length for mounting nozzles



A0040429

6 A probe fully insulated with clad flange for aggressive media

4.6 Probe with separate housing



7 Connection of the probe and separate housing

- A Explosive zone 1
 B Explosive zone 0
 L1 Rod length: max. 4 m (13 ft)
 L4 Cable length


The maximum cable length L4 and rod length L1 cannot exceed 10 m (33 ft).

- i** The maximum cable length between the probe and separate housing is 6 m (20 ft). The required cable length must be indicated in the ordering process of a Liquicap M with separate housing.

If the cable connection has to be shortened or led through a wall, then it must be separated from the process connection.

4.6.1 Extension heights: separate housing

- i** The cable has:
- a minimum bending radius of $r \geq 100 \text{ mm}$ (3.94 in)
 - diameter $\varnothing 10.5 \text{ mm}$ (0.14 in)
 - outer jacket made of silicone, notch resistance



A0040471

8 Housing side: wall mounting, pipe mounting, and sensor side. Unit of measurement mm (in)

The parameters value ¹⁾:

B parameter

- polyester housing (F16)
76 mm (2.99 in)
- stainless steel housing (F15)
64 mm (2.52 in)
- aluminum housing (F17)
65 mm (2.56 in)

H1 parameter

- polyester housing (F16)
172 mm (6.77 in)
- stainless steel housing (F15)
166 mm (6.54 in)
- aluminum housing (F17)
177 mm (6.97 in)

D parameter

- probes Ø10 mm (0.39 in) rod
38 mm (1.5 in)
- probes Ø16 mm (0.63 in) rod, without fully insulated inactive length
 - 38 mm (1.5 in)
 - threads: G¾", G1", NPT¾", NPT1", Clamp 1", Clamp 1½", Universal Ø44 mm (1.73 in), flange < DN50, ANSI 2", 10K50
- probes Ø16 mm (0.63 in) rod, without fully insulated inactive length
 - 50 mm (1.97 in)
 - threads: G1½", NPT1½", Clamp 2", DIN 11851, flange ≥ DN50, ANSI 2", 10K50
- Probes Ø22 mm (0.87 in) rod, with fully insulated inactive length
38 mm (1.5 in)

1) See parameters on the drawings.

H5 parameter


- probes Ø10 mm (0.39 in) rod
66 mm (2.6 in)
- probes Ø16 mm (0.63 in) rod, without fully insulated inactive length
 - 66 mm (2.6 in)
 - threads: G $\frac{3}{4}$ ", G1", NPT $\frac{3}{4}$ ", NPT1", Clamp 1", Clamp 1½", Universal Ø44 mm (1.73 in), flange < DN50, ANSI 2", 10K50
- probes Ø16 mm (0.63 in) rod, without fully insulated inactive length
 - 89 mm (3.5 in)
 - threads: G1½", NPT1½", Clamp 2", DIN 11851, flange ≥ DN50, ANSI 2", 10K50
- probes Ø22 mm (0.87 in) rod, with fully insulated inactive length
89 mm (3.5 in)

4.6.2 Wall bracket

The wall bracket is part of the scope of delivery.


The wall bracket must be screwed first to the separate housing before you can use it as a drilling template.

The distance between the holes is reduced by screwing it to the separate housing.




A0033881


Unit of measurement mm (in)

4.6.3 Wall mounting

A0042318




A0042319



A0042320

4.6.4 Pipe mounting

i The maximum pipe diameter is 50.8 mm (2 in).



4.6.5 Shortening the connecting cable

NOTICE

Risk of damage to connections and cable.

- Make sure that neither the connecting cable nor the probe is turning with the pressing screw!


i Recalibration must be performed before commissioning.



The maximum connection length between the probe and the separate housing is 6 m (20 ft).

When ordering a device with separate housing, the desired length must be specified.

If the cable connection has to be shortened or led through a wall, it must be separated from the process connection.

Disconnecting the connection cable





9 Cable connections

- 1 External screening (not required)
- 2 Strand black (bk) (not required)
- 3 Coaxial cable with central core a screening
- 4 Solder the red (rd) strand with the central core of the coaxial cable (probe)
- 5 Solder the strand with the screening of the yellow (ye) coaxial cable (ground)
- 6 Strand yellow and green (gn/ye) with a ring terminal

i We recommend reusing all strands with ring terminals in case of shortening the connecting cable.

To avoid the risk of short-circuiting when the strands are not to be reused, the connections of the new ring terminals fitted must be isolated with a heat shrinking sleeve.

Use heat-shrink tubes to insulate all soldered joints.

4.7 Installation instructions

NOTICE


Do not damage the probe insulation during installation!

- Check the rod insulation.

NOTICE

Do not screw the probe using the probe housing!

- Use an open-end wrench to screw the probe.



A0040476

4.7.1 Probe installation

Probe with thread

Cylindrical threads $G\frac{1}{2}$, $G\frac{3}{4}$, $G1$, $G1\frac{1}{2}$

To be used with the elastomer fiber seal supplied or another chemically resistant seal. Make sure that the temperature resistance of a seal is correct.



The following applies to probes with a parallel thread and supplied seal:

Thread $G\frac{1}{2}$

- for pressures up to 25 bar (362.5 psi): 25 Nm (18.4 lbf ft)
- maximum torque: 80 Nm (59.0 lbf ft)

Thread $G\frac{3}{4}$

- for pressures up to 25 bar (362.5 psi): 30 Nm (22.1 lbf ft)
- maximum torque: 100 Nm (73.8 lbf ft)

Thread $G1$

- for pressures up to 25 bar (362.5 psi): 50 Nm (36.9 lbf ft)
- maximum torque: 180 Nm (132.8 lbf ft)

Thread $G1\frac{1}{2}$

- for pressures up to 100 bar (1450 psi): 300 Nm (221.3 lbf ft)
- maximum torque: 500 Nm (368.8 lbf ft)

Conical threads $\frac{1}{2}$ NPT, $\frac{3}{4}$ NPT, 1 NPT, $1\frac{1}{2}$ NPT

Wrap the thread with a suitable sealing material. Use conductive sealing material only.

Probe with Tri-Clamp, sanitary connection or flange

The process seal must meet the specifications of the application. Check the seal's resistance to temperature and medium.

If the flange is PTFE-clad, this generally suffices as the seal up to the permitted operating pressure.


Probe with PTFE-clad flange



Use spring washers!

Depending on process pressure and process temperature, check and re-tighten the screws at regular intervals.

Recommended torque: 60 to 100 Nm (44.3 to 73.8 lbf ft).




A0040477

1 Spring washer

4.7.2 Aligning the housing

The housing can be rotated 270° to align with the cable entry. To prevent moisture penetration, route the connecting cable downwards in front of the cable gland and secure it with a cable tie. This is particularly recommended for outdoor mounting.

Aligning the housing



A0042107

A0042108

A0042109



The clamping screw for aligning the housing type T13 is located in the electronics compartment.

4.7.3 Sealing the probe housing

Make sure that the cover is sealed. Water cannot enter into the device when performing installation, connection and configuration tasks. Always seal the housing cover and cable entries securely.

The O-ring seal on the housing cover is shipped with a coat of special lubricant applied. In this way, the cover can be sealed tight and the aluminum thread does not bite when screwing down.

Never use mineral oil-based grease as this destroys the O-ring.

4.8 Post-installation check

After installing the measuring device, carry out the following checks:

- ☐ Do a visual check for damages.
- ☐ Does the device meet the specifications at the measuring point with regard to process temperature and pressure, ambient temperature, measuring range?
- ☐ Has the process connection been tightened with the tightening torque?
- ☐ Check if the measuring points are correctly labeled.
- ☐ Is the device adequately protected against precipitation and direct sunlight?

5 Electrical connection

i Before connecting the power supply, note the following:

- the supply voltage must match the data specified on the nameplate
- switch off the supply voltage before connecting the device
- connect the potential equalization to the ground terminal on the sensor

i When using the probe in hazardous areas, the relevant national standards and the information in the safety instructions (XA) must be observed.

Use the specified cable gland only.

5.1 Connecting requirements

5.1.1 Potential equalization

⚠ DANGER

Risk of explosion!

- Connect the cable screen on the sensor side only!

Connect the potential equalization to the outer ground terminal of the housing (T13, F13, F16, F17, F27). In the case of the stainless steel housing F15, the ground terminal can also be located in the housing. For further safety instructions, please refer to the separate documentation for applications in hazardous areas.

5.1.2 Electromagnetic compatibility (EMC)

Interference emission to EN 61326, Electrical Equipment Class B. Interference immunity to EN 61326, Annex A (Industrial) and NAMUR Recommendation NE 21 (EMC).


Failure current is accordance to NAMUR NE43: FEI50H = 22 mA.

A standard commercial instrument cable can be used.

i Information on connecting shielded cables is provided in Technical Information TI00241 "EMC test procedures".

5.1.3 Cable specification

Connect the electronic inserts by using commercially available instrument cables. If a potential equalization is present, and the shielded instrument cables are used, connect the shielding on both sides to optimize the shielding effect.



A Cable entry

B Electronic insert connections - cable size max. 2.5 mm² (14 AWG)

C The ground connection outside the housing, cable size max. 4 mm² (12 AWG)

Ød Cable diameter


A0040478

Cable entries

- nickel-plated brass
 $\varnothing d = 7$ to 10.5 mm (0.28 to 0.41 in)
- synthetic material
 $\varnothing d = 5$ to 10 mm (0.2 to 0.38 in)
- stainless steel
 $\varnothing d = 7$ to 12 mm (0.28 to 0.47 in)

5.1.4 Connector

For the version with a connector M12, the housing does not have to be opened for connecting the signal line.

PIN assignment for M12 connector

A0011175

- 1 Positive potential
- 2 Not used
- 3 Negative potential
- 4 Ground

5.1.5 Supply voltage

All of the following voltages are terminal voltages directly at the device:

- 12.0 to 36.0 V_{DC} in the non-hazardous area
- 12.0 to 30.0 V_{DC} in the Ex ia hazardous area
- 14.4 to 30.0 V_{DC} in the Ex d hazardous area

5.2 Wiring and connecting**5.2.1 Connection compartment**

Depending on explosion protection, the connection compartment is available in the following variants:

Standard protection

- polyester housing F16
- stainless steel housing F15
- aluminum housing F17
- aluminum housing F13
- stainless steel housing F27
- aluminum housing T13, with the separate connection compartment

Ex ia protection

- polyester housing F16
- stainless steel housing F15
- aluminum housing F17
- aluminum housing F13
- stainless steel housing F27
- aluminum housing T13, with the separate connection compartment


Ex d protection

- aluminum housing F13
- stainless steel housing F27
- aluminum housing T13, with the separate connection compartment

Gas-tight process seal

- aluminum housing F13
- stainless steel housing F27
- aluminum housing T13, with the separate connection compartment

To connect the electronic insert to the power supply:




A0040635

1. Unscrew the housing cover.
2. Remove the housing cover.
3. Release the cable gland.
4. Insert the cable.

i Applies to the housing T13.

To connect the electronic insert to the power supply:




A0040637

1. Unscrew the housing cover.
2. Remove the housing cover.
3. Release the cable gland.
4. Insert the cable.

5.2.2 Terminal assignment

2-wire, 4 to 20 mA with HART


The twin-core connecting cable is connected to the screw terminals with conductor cross-section 0.5 to 2.5 mm² (20 to 13 AWG) in the connection compartment at the electronic insert. If the superimposed communication signal (HART) is used, a shielded cable must be used with the shielding connected at the sensor and power supply. Protective circuits against reverse polarity, HF influences, and overvoltage peaks are integrated.



A0040479

- A Supply voltage, communication resistor 250 Ω
 B Commubox FXA195
 C Grounding terminal

5.2.3 Connecting HART with other supply units



A0040750

 10 Remote control via HART protocol

- 1 PLC
- 2 Transmitter power supply unit e.g. RN221N with communication resistor
- 3 Connection output for Commubox FXA191, FXA195
- 4 Computer with control software (DeviceCare or FieldCare, AMS Device Manager, SIMATIC PDM)
- 5 Commubox FXA191 (RS232) or FXA195 (USB)
- 6 Transmitter

 If the HART communication resistor is not integrated with the supply unit, a 250 Ω communication resistor must be included in the 2-wire line.

5.3 Post-connection check

After wiring the measuring device, carry out the following checks:

- ☐ Is the terminal assignment correct?
- ☐ Is the cable gland sealed tight?
- ☐ Is the housing cover fully screwed?
- ☐ Is the device operational and is the green LED flashing when the device is on?


6 Operation options

6.1 Overview of operation options

This device can operate with:

- the operating elements at the FEI50H electronic insert
- the display and operating module
- the HART protocol with Commubox FXA195 and FieldCare operating program

6.1.1 Display and operating elements at the FEI50H electronic insert



11 FEI50H electronic insert

- 1 Key
- 2 Green LED - operational status
- 3 Mode switch
- 4 Red LED - fault
- 5 Key
- 6 Current pick-off 4 to 20 mA

Function switch

- 1: Operation
select for normal operation
- 2: Empty calibration
select to set empty calibration
- 3: Full calibration
select to set full calibration
- 4: Measuring modes
select to choose between operation for media that form buildup (e.g. yogurt) or for media without buildup (e.g. water)

- 5: Measuring range
select the measuring range in pF for:
 - measuring range probe length < 6 m (20 ft) corresponds to 2 000 pF
 - measuring range probe length > 6 m (20 ft) corresponds to 4 000 pF
- 6: Self-test
select to activate the self-test
- 7: Reset - factory settings
select to restore the factory settings
- 8: Upload sensor DAT (EEPROM)
 - select to transfer the calibration values in the electronic insert to the sensor DAT (EEPROM) if replacing the probe
 - select to transfer the calibration values of the sensor DAT (EEPROM) to the electronics if replacing the electronic insert

Red LED - indicates a fault or malfunction

- flashes 5x per second
capacity at probe is too large, short-circuit at the probe or FEI50H is defective
- flashes 1x per second
the temperature in the electronic insert is outside the permitted temperature range

Key

press to execute the functions set via the function switch

Display connector

connector dedicated for optional onsite display and operating module

Current pick-off 4 to 20 mA

connect the multimeter for full or empty calibration without disconnecting the main circuit

Key


press to execute the functions set via the function switch

Green LED - indicates operation

- flashes 5x per second
the device operates
- flashes 1x per second
the device is in the calibration mode

6.1.2 Operation via the optional display and operating module

Display and operating elements



 12 Display and operating elements

- 1 Menu title
- 2 Item code of a displayed function
- 3 Key symbols
- 4 Hardware keys

Symbols on the display

Operating mode of the device

- **User** 
 - user parameters can be edited
- **Lock** 
 - all parameters are locked
- **Scrollbar** 
 - scroll up or down to access more functions

Locking state of the currently displayed parameter

- **Display parameter** 
 - the parameter cannot be edited in the current operating mode of the device
- **Write parameter** 
 - the parameter can be edited

Key symbols


The keys work as softkeys. This means that their function and meaning depend on the current position in the operating menu. The key functions are indicated by symbols in the bottom line of the display.

- **Down** 
 - moves the bar downwards in a picklist
- **Up** 
 - moves the bar upwards in a picklist
- **Enter** 
 - enter the selected submenu or selected function
 - confirm the edited function value
- **Previous function** 
 - go to the previous function within the function group
- **Next function** 
 - go to the next function within the function group
- **Confirm selection** 
 - select the option from the picklist
- **Increase value** 
 - increases the selected position of an alphanumeric function
- **Decrease value** 
 - decreases the selected position of an alphanumeric function
- **Error list** 
 - opens the list of the errors currently present
 - the symbol is inverted and flashes if a warning is present
 - the symbol appears constantly if an alarm is present

Hardware key combinations

The following hardware key combinations apply regardless of the menu item in question:


Escape



A0032709

- 1 Due to editing a function: exits the editing mode for the current function
- 2 Due to navigating: returns to the next-highest menu level


Increase contrast



A0032710

Increases the contrast of the display module


Decrease contrast



A0032711

Decreases the contrast of the display module

Locking and unlocking




A0032712

- 1 Locks the device against parameter changes
- 2 Press all three keys to unlock the device

6.1.3 The operating menu

Function codes

The functions of Liquicap M are arranged in an operating menu. 5-digit item code is shown on the display for every function to aid orientation within the menu.



A0040486

- 1 Function group
- 2 Channel
- 3 Number of the function within the group

The first position refers to:


- C: Basic setup
- S: Safety setting
- L: Linearization
- O: Output
- D: Device properties

The second position refers to
the position is out of function

The third position refers to
the individual functions within the function group

Launching menus

 The display automatically switches to the main screen with the measured value, if the submenu is not chosen or the navigation key is not pressed for 15 minutes.



A0040488

- 1 Main menu button
- 2 Actual errors button
- 3 Measured value button

Measured value

displays the measured value in %, mA or pF

Main menu

- contains all the parameters of Liquicap M, and is split into submenus
- the submenus contain additional submenus
- to overview the menu, submenus, and all functions →  39

Actual errors

- if an error is detected, the display shows related softkey symbol over the center key
- if the symbol flashes than a warning was detected
- if the symbol is displayed continuously then an alarm-type error was detected

 More information about the differences between "Alarm" and "Warning" →  76.

 Press the center key to display the currently pending errors list.

Selecting a submenu

1. Press  or  to select the submenu.
2. Press  to enter the selected menu.

If the submenu contains additional submenus, continue in the same manner until you reach the function level.

► Press  or  to select the function in submenu.

 Return to the next-highest menu level any time by pressing "Escape" →  33.

If the menu has only one submenu then the soft keys are not displayed.

Selecting a function and subfunction

If the function level has been reached, it is possible to navigate through the functions with  and . The current values of all the related subfunctions are displayed.

- 1. Press  or  to select the ordered function.
- 2. Press  to enter the selected function.
- 3. Press  or  to select the ordered subfunction.
- 4. Press  to enter the selected function.

 If the function has only one subfunction, than the soft keys are not displayed.

 Return to the next-highest menu level any time by pressing "Escape" →  33.

Editing functions with the picklist

- 1. Press  or  to select the ordered option.
- 2. Press  to select this option.

The new value is now transferred to the device.

Edit another subfunction in the same way.

 Return to the next-highest menu level any time by pressing "Escape" →  33.

Editing numeric and alphanumeric functions

If you select a numeric function like "Empty calibration" , "Full calibration" or an alphanumeric function like "Device marking" , the editor for numbers or alphanumeric characters opens.

- 1. Press  or  until this position shows the ordered value.
- 2. Press  to enter the value and go to the next position.
- 3. Repeat step for the next position.
- 4. Once all the necessary positions have been entered, press  or  until  appears at the marker.
- 5. Press  to transfer the entire value to the device.

Special functions when making entries

They also call up the following symbols for special editing tasks which make inputting information easier and make it possible to make corrections quickly.

In the editor for numbers and alphanumeric characters, the  and  keys not only call up numbers and letters.



A0040580

 13 The number to the left of the marker is transferred to the device.




A0040581

 14 Exit the editor. The old function value remains.



A0040582

15 The marker jumps to the next position.



A0040583

16 The marker jumps back to the previous position.



A0040584

17 The current position and all positions to the right are deleted.

Return to the measured value display

Pressing the left and center key simultaneously has the following effect:

- it takes you from the editing mode to the display mode of the functions
- it takes you from the display mode of the functions to the submenu
- it takes you from the submenu to the main menu
- it takes you from the main menu to the measured value display

6.2 Error messages

If the automatic monitoring function of Liquicap M detects an error, the related softkey symbol appears over the center key.

If the softkey symbol is flashing, only "Warning"-type errors are present.

If the symbol is displayed continuously, at least one "Alarm"-type error is present.

Press the key in the center to display the currently pending errors list.

To find information about the differences between "Alarm" and "Warning" → 76

6.3 Locking and unlocking configuration

6.3.1 Key locking

Press all three keys simultaneously. The device is then locked.

6.3.2 Key unlocking

Press all three keys simultaneously. The device is then unlocked.

6.3.3 Software locking

Locking the device is described in "Safety settings" → 52.

In the menu, the current locking status of the device is displayed in the "Status" subfunction under "Safety settings" SAX01.

The following values can appear:

Unlocked

all parameters can be modified

Locked

The device is locked from the operating menu. It can only be enabled again by entering "100" in the "Safety settings" function. If an attempt is made to change a parameter, the device goes to the "Safety settings" function. "Key locking" is displayed in the "Status" subfunction. Press all the keys simultaneously. The device then goes back to the default settings and all parameters can be changed again.

Key locked

The device has been locked with the operating keys. It can only be enabled again by pressing all three keys simultaneously.



A key symbol is shown on the display when locked.

6.4 Resetting to factory setting



The reset can affect the measurement as the current values are overwritten by factory values: 0% (4 mA) and 100 % (20 mA).

6.4.1 Using the reset

A reset is always recommended if a device with an unknown history is used.

6.4.2 Effects of a reset

- all parameters are reset to the factory setting
- the linearization is reset to "linear"



The linearization table is retained and can be activated again where necessary.

The factory settings of the parameters are marked in bold in the menu overview.

For more information go to the chapter "Basic setup" → 44.

6.4.3 Performing a reset

To do a reset, enter the value "333" in the "Device properties → Diagnosis → Password reset / Reset" function.

6.5 Operation via FieldCare Device Setup

6.5.1 Function scope

FDT-based plant asset management tool from Endress+Hauser. It can configure all smart field devices in a system and helps you manage them. By using the status information, it is also a simple but effective way of checking their status and condition.



For additional information about FieldCare, see Operating Instructions BA00027S and BA00059S

Connection options: HART via Commubox FXA195 and the USB port of a computer

6.5.2 Source for device description files

- www.endress.com → Downloads
- CD-ROM (contact Endress+Hauser)
- DVD (contact Endress+Hauser)

7 Commissioning

 The device is operated via the electronic insert, the display or with FieldCare. If a display is attached to the electronic insert, the function keys  or  and the Mode switch at the electronic insert are deactivated. All other settings can be made using the function keys on the display or with FieldCare.

7.1 Installation and function check

Make sure that the post-installation check and final check have been completed before you start your measuring point:

- go to the chapter "Post-installation check" →  25
- go to the chapter "Post-connection check" →  30

7.2 Basic setup without the display or operating module

This section describes how to commission the device with the function switch and the operating keys  and  on the FEI50H electronic insert.

 On leaving the factory, Liquicap M devices are calibrated for media with a conductivity of $\geq 100 \mu\text{S}/\text{cm}$ for all water-based liquids such as acids and alkalis.


A recalibration is only necessary if the 0 to 100 % value should be adjusted to suit customer-specific requirements, the distance to the tank wall is $< 250 \text{ mm}$ (9.84 in) or if the liquid is not conductive.

Only the "Wet-type" calibration can be carried out without the display and operating module.

During the "Wet-type" calibration, the 0 % value or the 100 % value is adjusted to customer-specific requirements. This calibration can be carried out if the tank is empty, full or partially filled.

During full calibration, the probe must be covered by the liquid in the installed state.

An empty and full calibration must be performed.



A0040485

18 FEI50H electronic insert

- 1 Key
- 2 Green LED - operational status
- 3 Mode switch
- 4 Red LED - fault
- 5 Key
- 6 Current pick-off 4 to 20 mA

7.2.1 Function switch: position 1. Operation

In normal operation, the function switch must be set to position 1.

7.2.2 Function switch: position 2. Carry out empty calibration - for empty tanks

When the tank is empty (0 %), the empty calibration sets the signal current to the lower value of 4 mA. When empty calibration is completed, the electric current value of 4 mA is displayed at the ammeter.

To perform empty tank calibration:

1. Turn the function switch to position 2.
2. Press the and keys together for 2 s until the green or red LED flashes.
3. Release the two keys.
4. The flashing stops after 5 s.
 ↳ Empty calibration is saved.

7.2.3 Function switch: position 2. Carry out empty calibration - for almost empty tanks

If possible, the exact tank level should be known and should not exceed < 30 %.

Exceeding the permitted tank level reduces the accuracy of the zero-point that corresponds to the empty tank. An ammeter must be connected to the current pick-off at the electronic insert. For example, the level was determined for 15 %, the electric current value that corresponds to that 15 % must be determined.

The lower current value can be adjusted with the $\square$ and $\oplus$ keys.

The following must also be considered:

- the lower current value means that the tank is empty, 0 % is 4 mA.
- the upper current value means that the tank is full, 100 % is 20 mA.
- this results in a measuring range of 16 mA for a change from 0 to 100 %. For example 0.16 mA increase in the current for every 1 % increase in the level.
- for a 15 % level, this is $15 \% \times 0.16 \text{ mA per } \%$ which equals the 2.4 mA. This must be added to 4 mA to obtain the current value to be set: $2.4 \text{ mA} + 4 \text{ mA} = 6.4 \text{ mA}$.

To perform empty tank calibration on a partially filled tank:

1. Turn the function switch to position 2.
2. Press the $\square$ or $\oplus$ keys for 2 s.
3. Set the desired current value ($>4 \text{ mA}$) using the multimeter connected.
4. Release the key.
 - ↳ Empty calibration is saved.

7.2.4 Function switch: position 3. Carry out full calibration - for full tanks

If the tank is full (100 %), the full calibration sets the signal current to the upper value of 20 mA. When empty calibration is completed, the current value of 20 mA is displayed at the ammeter.

To perform full tank calibration:

1. Turn the function switch to position 3.
2. Press the $\square$ and $\oplus$ keys together for 2 s until the green or red LED flashes.
3. Release the two keys again.
4. The flashing stops after 10 s.
 - ↳ Empty calibration is saved.

7.2.5 Function switch: position 3. Carry out full calibration - for almost full tanks

If possible, the exact level of the tank should be known and should be as large as possible ($> 70 \%$).

Too low level reduces the accuracy of the upper point which corresponds to the full tank. An ammeter must be connected to the current pick-off at the electronic insert.

For example, the level was determined for 90 %, the electric current value that corresponds to the level of 90 % must be determined. The upper current value can be adjusted with the $\square$ and $\oplus$ keys. The $\oplus$ key increases the value, the $\square$ key reduces the value.

The following must also be considered:

- the lower current value means that the tank is empty, 0 % is 4 mA.
- the upper current value means that the tank is full, 100 % is 20 mA.
- this results in a measuring range of 16 mA for a change from 0 to 100 %. For example 0.16 mA increase in the current for every 1 % increase in the level.
- for a 90 % level, this is $90 \% \times 0.16 \text{ mA per } \%$ which equals the 14.4 mA. This must be added to the 4 mA to obtain the current value to be set: $4 \text{ mA} + 14.4 \text{ mA} = 18.4 \text{ mA}$. It is possible to take the upper current value and then subtract $10 \% \times 0.16 \text{ mA per } \%$ which equals 1.6 mA from 20 mA.

To perform full calibration on a partially filled tank:

1. Turn the function switch to position 3.

2. Press  or  key for 2 s.
3. Connect the multimeter to the current pick-off.
4. Set the ordered electric current value < 20 mA.
5. Release the key.
 - ↳ The full calibration is saved.

7.2.6 Function switch: position 4. Measuring modes

 Before carrying out empty and full calibration, the medium properties must be configured. If the medium is conductive and tends to form buildup, the "Buildup" operating mode must be selected.

In this operating mode, the buildup on the probe rod is compensated.

The "No buildup" operating mode is set at the factory.

Subfunction: "Medium property"

The **No buildup** operating mode should be set for media that do not tend to form buildup on the probe rod (e.g. water, beverages). As of conductivity of 100 µS/cm like all water-based liquids such as acids, alkalis, the measured value is independent of the conductivity of the liquid (independent of concentration fluctuations).

In the **Buildup** operating mode, the buildup compensation function integrated into the software is activated. In this operating mode, the measured value is independent of the conductivity of the liquid as of conductivity of 1 000 µS/cm (independent of concentration fluctuations).

This compensates measuring errors caused by conductive media sticking to the probe rod such as yogurt. This corresponds to buildup compensation.

To choose between media forming buildup and media not forming buildup:

1. Turn the function switch to position 4.
2. Press  key for media that tend to form buildup.
 - ↳ The green LED confirms your entry by flashing three times.
3. Press  key for media that do not form buildup.
 - ↳ The green LED confirms your entry by flashing three times.

7.2.7 Function switch: position 5. Measuring range

At the factory, the measuring range is always calibrated to the ordered probe length. If the electronic insert is used in another probe, the measuring range must be configured in accordance with the probe length.

To configure the measuring range 2 000 pF for probe length < 6 m (20 ft) or 4 000 pF for probe length > 6 m (20 ft):

1. Turn the function switch to position 5.
2. Press  to set measuring range 2 000 pF
 - ↳ The green LED flashes three times - the value is set.
3. Press  to set measuring range 4 000 pF
 - ↳ The green LED flashes three times - the value is set.

7.2.8 Function switch: position 6. Proof test - self-test

 Before and after the automatic proof test, it is essential to check whether the level value displayed corresponds to the actual level value ²⁾.

When the self-test is activated, the current output is set to 4 mA and follows a ramp function up to 22 mA. This test is completed after 40 s.

To activate the device self-test:

1. Turn the function switch to position 6.
2. Press  and  keys together to start the function test.
 - ↳ The green LED flashes quickly until the current error is reached.
The red LED flashes until the test is completed.

 After the self-test, the device automatically returns to the operating mode.

7.2.9 Function switch: position 7. Reset - restore factory settings

 The reset can affect the measurement as the current values are overwritten by the factory values of calibration 0% (4 mA) and 100% (20 mA).

To restore the factory settings:

1. Disconnect the electronic insert from the power supply.
2. Turn the function switch to position 7.
3. Press and hold the  and  keys together while the device is being reconnected to the power supply.
 - ↳ Red LED flashes slowly and then starts to flash quickly.
4. Wait until the red LED stops flashing.
5. Release the  and  keys.

7.2.10 Function switch: position 8. Download or upload sensor DAT (EEPROM)

Calibration values can be transmitted with this function.

A distinction is made between two types:

- the sensor has been replaced and the electronic insert should continue to be used
- the electronic insert has been replaced but the sensor should continue to be used

The calibration values already set can be transferred from the sensor to the electronic insert or from the electronic insert to the sensor.

Download

To transfer the calibration values from the electronic insert to the sensor:

1. Turn the function switch to position 8.
2. Press the  key to start downloading from the electronic insert to the sensor.
 - ↳ The green LED flashes for 2 s, confirming your entry.

The device restarts.

Upload

To transfer the calibration values from the sensor to the electronic insert:

1. Turn the function switch to position 8.

2) This applies from version FW: V 01.03.00

2. Press the  key to start uploading from the sensor to the electronic insert.
 - ↳ The green LED flashes for 2 s, confirming your entry.

The device restarts.

7.3 Menu: "Basic setup". Commissioning with display and operating module

 This section describes how to commission the Liquicap M, the display and the operating module. The procedure for commissioning through FieldCare, DeviceCare or FieldXpert handheld terminal is the same. More detailed information can be found in the Operating Instructions for FieldCare BA 224F/00 supplied together with the handheld terminal.

7.3.1 Initial commissioning

On the first power-up, you are requested to select the language for the display texts. After this selection, the measured value is displayed.

 If a reset is performed at the device and if the power supply is switched off and on again, the language of the display texts has to be selected again.

Menu structures: Main menu

The main menu is activated by means of the right Enter key .


The following menu headings appear. These are explained in more detail over the following pages:

- Basic setup →  46
- Safety setting →  52
- Linearization →  57
- Output →  62
- Device properties →  65

 Liquicap M devices are calibrated on leaving the factory for media with a conductivity of $\geq 100 \mu\text{S}/\text{cm}$. Recalibration is only necessary if the 0 % value or the 100 % value should be adjusted to suit customer-specific requirements, the distance to the tank wall is $< 250 \text{ mm}$ (9.84 in) or if the liquid is not conductive.

A distinction is generally made between two types of calibration:

- Wet calibration
During wet calibration, the probe must be covered by a liquid in the installed state. This calibration can be done if the tank is empty, full or partially full. Empty and full calibration must be performed.
- Dry calibration
During dry calibration, empty and full calibration can be done without the probe being in contact with the liquid. The calibration values can be entered directly in units of length.



A0040521

- A Customer specified 0% level (empty tank)
- B Factory setting for 0% level (empty tank)
- C Factory setting for 100% level (full tank)
- D Customer specified 100% level (full tank)

Configure the settings in the "Basic setup" menu:



The factory settings are shown in bold.

Basic setup

- function: Basic setup
 - subfunction:
 - Medium property: **no buildup**, buildup
 - Cal. type: Dry, **Wet**
- function: Medium property ³⁾
 - subfunction: Medium property
 - **Conductive**
 - Nonconductive ⁴⁾
 - interface
 - unknown
 - subfunction: DC value ⁵⁾
 - Value
 - subfunction: Unit level ⁶⁾
 - **% (percentage)**
 - m
 - mm
 - ft
 - inch
- function: Empty calibr.
 - subfunction: Value empty
 - **0 %**
 - subfunction: Measure capacity
 - xxxx pF
 - subfunction: Confirm cal.:
 - **Yes**
- function: Full calibr.
 - subfunction: Value full
 - **100%**
 - subfunction: Measure capacity
 - xxxx pF
 - subfunction: Confirm cal.:
 - **Yes**
- function: Output damping
 - subfunction: Output damping
 - **1 s**

7.3.2 Function: "Basic setup"**Subfunction: "Medium property"**

The "No buildup" operating mode should be set for media that do not tend to form buildup on the probe rod, like water, beverages, etc. For conductivity of 100 $\mu\text{S}/\text{cm}$, the measured value is independent ⁷⁾ of the conductivity of the liquid.

In the "Buildup" operating mode, the buildup compensation function integrated with the software is activated. In this operating mode, the measured value is independent ⁷⁾ of the conductivity of the liquid conductivity of 1 000 $\mu\text{S}/\text{cm}$.

This compensates measuring errors caused by conductive media sticking to the probe rod such as yogurt. This corresponds to buildup compensation.

3) The function is displayed if the function value "Dry" was selected under the subfunction "Cal. type".

4) The function value can be selected only for probes with a ground tube.

5) The subfunction is displayed if the function value "Nonconductive" was selected under the subfunction "Medium property".

6) The subfunction is displayed if the function value "Nonconductive" or "Conductive" was selected under the subfunction "Medium property".

7) Independent of concentration fluctuations.

Subfunction: "Cal. type"

In the "Dry" "Cal. type" empty and full calibration can be carried out without the probe being in contact with the liquid. The calibration values can be entered directly in units of length.

In the "Wet" "Cal. Type", the probe must be covered by the liquid in the installed state for a full calibration. This calibration can also be carried out if the tank is partially full. Both the empty calibration and full calibration must be performed.

7.3.3 Function: "Medium property"

 This function is only displayed if the function value "Dry" was selected under the subfunction "Cal. type".

Subfunction: "Medium property"

The properties of the medium are entered here.

- "Nonconductive": the conductivity of the medium is $\leq 1 \mu\text{S}/\text{cm}$ - only with the ground tube
- "Conductive": the conductivity of the medium is $\geq 100 \mu\text{S}/\text{cm}$
- "Interface": the properties of the two media can be entered in the operating program of ToF Tool. The associated calibration values are then calculated
- "Unknown": the medium properties are not known. The capacitance values of the "Empty calibr." and "Full calibr." functions can be entered directly

Subfunction: "DC value"

 This subfunction is only displayed if the function value "Nonconductive" was selected under the subfunction "Medium property".

The dielectric constant for the liquid to be measured is entered here, go to the "Measuring condition" →  15.

Subfunction: "Unit level"

 This subfunction is only displayed if the function value "Conductive" or "Nonconductive" was selected under "Medium property".

The desired level unit for Basic setup is entered here.

7.3.4 Operating mode: "Empty calibr." and function - "Wet"

 The calibration data can be calculated with **CapCalc.xls**

With "Empty calibration", the 0% value or the 4 mA value is assigned to the level value.

 The procedure applies to the "Wet" type of calibration. Information on "Dry" calibration is provided below.

Subfunction: "Value empty"

The current level value is entered here, for example 5% partial filling → "Value empty" 5% or 0% partial filling → "Value empty" 0%.

 To keep the calibration error to a minimum, the level should be between 0% and 30%.

Subfunction: "Measure capacity"

The capacitance value currently measured is displayed here.

Subfunction: "Confirm cal."

In this function, empty calibration is confirmed and the "Measure capacity" currently measured is assigned to the percentage level value entered as "Value empty".

7.3.5 Operating mode: "Full calibr." and function - "Wet"

With "Full calibration", the 100% value or the 20 mA value is assigned to the level value.

i The procedure applies to the "Wet" type of calibration. Information on "Dry" calibration is provided further below.

Subfunction: "Value full"

The current level value is entered here, for example 90% partial filling → "Value full" 90% or 100% filling → "Value full" 100%.

i To keep the calibration error to a minimum, the level should be between 70% and 100%.

Subfunction: "Measure capacity"


The capacitance value currently measured is displayed here.

Subfunction: "Confirm cal."

Full calibration must be confirmed with this function.

7.3.6 Operating mode: "Empty calibr." and function - "Dry"

The "Empty" value can be entered directly in units of length if the medium property has been set to conductive or nonconductive.

Subfunction: "Value empty ", medium property for the conductive and nonconductive medium

A0040522

L1 Active probe rod.

L3 Thread length.

E The distance from the active probe rod to the desired zero-point.

Value E:

Empty calibration ≤ active probe length

$E \leq L1 - (\text{thread length } L3 + \text{plug})$

Thread length:

L3 for G1½ = 25 mm (0.98 in)

L3 for G <1½ = 19 mm (0.75 in)

Plug:

10 mm (0.39 in) rod = 10 mm (0.39 in)

16 mm (0.63 in) rod = 15 mm (0.59 in)

22 mm (0.87 in) rod = 15 mm (0.59 in)

Subfunction: "Cap. empty"

The calculated capacitance value is displayed here. This field cannot be edited.


Subfunction: "Confirm cal."

Empty calibration is confirmed with this subfunction.

7.3.7 Operating mode: "Full calibration" and function - "Dry" for conductive and nonconductive media

The "Full" value can be entered directly in units of length.

Subfunction: "Value full", medium property - conductive, nonconductive



A0040523

L1 Active probe rod.

L3 Thread length.

F The distance from the zero-point to the desired 100% point.

Value full:

$F \leq$ Empty value

Subfunction: "Cap. full"

The calculated capacitance value is displayed here. This field cannot be edited.

Subfunction: "Confirm cal."

Full calibration is confirmed with this subfunction.

7.3.8 Operating mode: "Empty calibration" and function - "Dry" for "Interface" or "Unknown" medium properties

Subfunction: "Value empty"

This field displays 0% and cannot be edited.

Subfunction: "Cap. empty"

Enter the capacitance value, for example calculated with CapCalc.xls.

Subfunction: "Confirm cal."

Empty calibration must be confirmed with this subfunction.

7.3.9 Operating mode: "Full calibration" and function - "Dry" for "Interface" or "Unknown" medium properties

Subfunction: "Value full"

This field displays 100% and cannot be edited.

Subfunction: "Cap. full"

Enter the capacitance value, for example calculated with CapCalc.xls.

Subfunction: "Confirm cal."

Empty calibration must be confirmed with this subfunction.

7.3.10 Function: "Output damping"

With this function, you can set the reaction time of your measuring device to changes in the level. If surfaces are turbulent, a higher output damping should be selected.

7.4 Menu: "Safety setting"

Follow the settings in the "Safety settings" menu.



The factory settings are shown in bold.

Safety settings

- function: Safety settings
 - subfunction: Code
 - **100**
 - subfunction: Status
 - **Unlocked**
 - Locked
- function: Safety settings
 - subfunction: Operating mode
 - Standard
 - SIL/WHG
 - subfunction: Output damping
 - **1 s**
 - subfunction: Output 1
 - MAX
 - subfunction: Parameter okay
 - no
 - Yes
- function: Safety settings
 - subfunction: Cap. empty
 - x.xx pF
 - subfunction: Value empty
 - x.xxx%
 - subfunction: Cap. full
 - 2 000 pF
 - subfunction: Value full
 - 100.000%
 - subfunction: Parameter okay
 - no
 - Yes
- function: Operating mode
 - subfunction: Operating mode
 - **Standard**
 - SIL/WHG
 - subfunction: SIL op. mode ⁸⁾
 - **Unlocked**
 - Locked
 - subfunction: Status
 - **Unlocked**
 - Locked
- function: Output on alarm
 - subfunction: Output
 - **Max**
 - Hold
 - User-spec.
 - subfunction: Output value ⁹⁾
 - xx.xx mA
- function: Proof test
 - subfunction: Proof test
 - **Off**
 - On

8) The subfunction is displayed if the "SIL/WHG" option was selected under the "Operating mode" subfunction.

9) The subfunction is displayed if the "User-specific" option was selected under the "Output" subfunction.

7.4.1 Function: "Safety settings"

Subfunction: "Code"

With this subfunction, you can lock the device against unpermitted or unintentional changes.

Enter a number that is not equal 100 to lock the device. The parameters cannot be modified.

Enter 100 to unlock the device. Parameters can be modified again.

Subfunction: "Status"

This subfunction displays the current locking status of the device.

The following values can appear:

- Unlocked
All writeable parameters can be modified.
- Locked
The device has been locked via the operating menu. It can only be unlocked by entering "100" in the "Code" subfunction.

7.4.2 Function: "Safety settings"

Subfunction: "Operating mode"

This subfunction displays the set operating mode and cannot be edited.

Operating modes:

- Standard
- SIL/WHG

Subfunction: "Output damping"

This subfunction displays the output damping setting. Output damping is the time during which the measuring system reacts to changes in level of the liquid and is between 0 to 60 s.

Subfunction: "Output 1"

This subfunction displays the set value which the output assumes in an alarm condition.

Values:

- MAX (22 mA)
- Hold - the last value is held
- User-spec.

Subfunction: "Parameter okay"

With this subfunction, you confirm that the parameter values displayed under the "Safety settings II" function are correct.



The "Parameter okay" subfunction has to be confirmed with "Yes" so the device can be locked for the SIL/WHG operating mode. In addition, the SIL/WHG function value has to be selected for the "Operating mode" subfunction and "Locked" must be set for the "Status" subfunction. The device can be unlocked using the special release code. The release code is "7452".

7.4.3 Function: "Safety settings"

Subfunction: "Cap. empty"

This subfunction displays the measured capacitance during empty calibration in pF.

Subfunction: "Value empty"

This subfunction displays the empty calibration value in %.

Subfunction: "Cap. full"

This subfunction displays the measured capacitance during full calibration in pF.

Subfunction: "Value full"

This subfunction displays the full calibration value in %.

Subfunction: "Parameter okay"

With this subfunction, you confirm that the parameter values displayed under the "Safety settings II" function are correct.



The "Parameter okay" subfunction has to be confirmed with "Yes" so the device can be locked for the SIL/WHG operating mode. In addition, the SIL/WHG function value has to be selected for the "Operating mode" subfunction and "Locked" must be set for the "Status" subfunction. The device can be unlocked using the special release code. The release code is "7452".

7.4.4 Function: "Operating mode"

Subfunction: "Operating mode"

With this subfunction, you can switch from the Standard operating mode to the SIL/WHG operating mode:

- Standard
- SIL/WHG

The following parameters are set to defined values in the "SIL/WHG" operating mode:

- Output damping: Output damping is fixed at 1 s.
- Output on alarm: The "Output on alarm" function is fixed at 22 mA.

In the "SIL/WHG" operating mode, cyclic self-monitoring of the device is like a memory test, processor test, current output, etc.

Subfunction: "SIL operating mode"

You can lock or unlock the device in this subfunction. No parameters can be changed in the locked state.

Subfunction: "Status"

This subfunction displays the current locking status of the device.

The following values can appear:

- Unlocked
All writeable parameters can be modified.
- Locked
The device has been locked via the operating menu.



The device can be only unlocked by entering "100" in the subfunction "Code" →  52.

7.4.5 Function: "Safety settings"

Subfunction: "Operating mode"

The "Standard" or "SIL/WHG" operating mode entered is displayed here.

Subfunction: "Output damping"

The output damping entered is displayed here.

Subfunction: "Value empty"

The capacitance of the empty calibration is displayed here.

Subfunction: "Value full"

The capacitance of the full calibration is displayed here.

Subfunction: "Parameter okay"

With this subfunction, you confirm that the parameter values displayed under the "Safety settings II" function are correct.

 The "Parameter okay" subfunction has to be confirmed with "Yes" so the device can be locked for the SIL/WHG operating mode. In addition, the SIL/WHG function value has to be selected for the "Operating mode" subfunction and "Locked" must be set for the "Status" subfunction. The device can be unlocked using the special release code. The release code is "7452".


7.4.6 Function: "Output on alarm"

Subfunction: "Output"

This function determines the value the output in question assumes when an alarm condition occurs.

Options:

- Max
22 mA
- Hold
the last value is retained
- User-spec.
as defined in the "Output value" subfunction



A0040524

- A Output current flow in "Max" setting
 B Output current flow in "Hold" setting
 C Output current flow in "User spec." setting

Subfunction: "Output value" - only for "Output" and "User-specific"

In this function, specify the user-specific value the current output should assume in an alarm condition.

Value range: 3.8 to 22 mA.

7.4.7 Function: "Proof test" - self-test

From version FW: V 01.03.00:

- before and after the automatic proof test, it is essential to check whether the level value displayed corresponds to the actual level value
- after the self-test, the device automatically returns to the operating mode

Subfunction: "Proof test"

With this subfunction, you activate the device self-test. All electronic components relevant to the function are tested. Within 40 s, the current output goes through the range of 4 to 22 mA.

7.5 Menu: "Linearization"

"Linearization" is used for converting the level to any unit. You can determine the volume or the mass in a tank of any shape. Liquicap M makes various linearization modes available for situations that occur frequently. Furthermore, a linearization table can be entered for tanks and containers of any shape.



The number and type of subfunctions depend on the type of linearization selected. Only the "Type" and "Mode" subfunctions are always available.

You can make the following settings in the "Linearization" menu.



The factory settings are shown in bold.

Linearization

- function: Linearization
 - subfunction: Type
 - None
 - **Linear**
 - Horizontal cyl ¹⁰⁾
 - Sphere ¹⁰⁾
 - Pyramid bottom ¹¹⁾
 - Conical bottom ¹¹⁾
 - Angled bottom ¹¹⁾
 - Table
 - subfunction: Mode
 - **level**
 - Ullage
 - subfunction: Simulation
 - **Sim. off**
 - Sim. level
 - Sim. volume
 - subfunction: Sim. level value or Sim. vol. value ¹²⁾
 - xx.x%

10) If you enter a value for this function, you must also enter a value for the "Diameter" subfunction in another step.

11) If you enter a value for this function, you must also enter a value for the "Intermed. height" subfunction in another step.

12) The function is displayed if the "Sim. off" option was not selected under the "Simulation" subfunction.

- function: Linearization
 - subfunction: Customer unit
 - % (percentage)
 - l
 - hl
 - m³
 - dm³
 - cm³
 - ft³
 - usgal
 - igal
 - kg
 - t
 - lb
 - ton
 - m³
 - ft³
 - mm
 - inch
 - user-spec.
 - subfunction: Customized text ¹³⁾
 - subfunction: Diameter ¹⁴⁾
 - xxxx m
 - subfunction: Intermed. height ¹⁵⁾
 - xx m
 - subfunction: Edit ¹⁶⁾
 - **Read:** Table No.: 1, Input level: x m, Input volume: %
 - **Manual:** Table No.: 1, Input level: x m, Input volume: %
 - **Semi-automat.:** Table No.: 1, Input level: x m, Input volume: %
 - Delete
 - subfunction: Status table ¹⁶⁾
 - **Enabled**
 - Disabled
 - subfunction: Max. scale ¹⁶⁾
 - 100 %

7.5.1 Function: "Linearization"

Subfunction: "Type"

Select the type of linearization in this subfunction.

Options:

- None

In this type of linearization, the measured level is not converted but instead is output linearly in the level unit selected →  47.
- Linear


In this type of linearization, the measured value output is linear to the measured level.

¹³⁾ The function is displayed if the "User-spec." option was selected under the "Customer unit" subfunction.

¹⁴⁾ The function is displayed if the "Horizontal cyl" or "Sphere" option was selected under the "Type" subfunction.

¹⁵⁾ The function is displayed if the "Pyramid bottom", "Conical bottom" or "Angled bottom" option was selected under the "Type" subfunction.

¹⁶⁾ The function is displayed if the "Table" option was selected under the "Type" subfunction



A0040551

A The maximum tank content.
B Customer unit


The following parameters must be specified:

- the unit for the linearized value
- the maximum tank contents measured in a customer unit

Options:

- Horizontal cyl.
- Sphere

In these types of linearization, the volume in a spherical tank or in a horizontal cylindrical tank is calculated from the liquid level.



A0040552

$\varnothing d$ The cylindrical or spherical tank diameter
B The maximum tank content
C Customer unit


The following parameters must be specified:

- the unit for the linearized value
- the tank diameter
- the maximum tank contents measured in a customer unit

Options:

- Pyramid bottom
- Conical bottom
- Angled bottom

In these types of linearization, the volume in a spherical tank or in a horizontal cylindrical tank is calculated from the liquid level.



A0040554

H The intermediate height
B The maximum tank content
C Customer unit


The following parameters must be specified:

- the unit for the linearized value
- The intermediate height in accordance with the diagram
- the maximum tank contents measured in a customer unit

Options:

Table

In this type of linearization, the measured value is calculated using a linearization table. The table can comprise up to 32 "Level - Volume" value pairs. The table must be monotone.




A0040562

The following parameters must be specified:

- the unit for the linearized value
- the linearization table

Subfunction: "Mode"

In this subfunction, specify whether the measurement should refer to level A or to the empty area B.



A Filled area
B Empty area

Subfunction: "Simulation"

In this subfunction, you can simulate the level or the volume by entering a level under "Sim. level value" or a volume under "Sim. vol. value".

Subfunction: "Sim. level value" or "Sim. vol. value"

In this subfunction, you can enter the level or volume value to be simulated.

7.5.2 Function: "Linearization"

Subfunction: "Customer unit"

In this subfunction, enter the desired unit for the linearized values, for example: kg, m³, ft³.

Subfunction: "Customized text"

In this subfunction, enter your specific name for the unit. The measured value indicated in the main screen will then be displayed in this unit.

Subfunction: "Diameter"

In this subfunction, specify the diameter of the horizontal cylindrical tank or the spherical tank. Subfunction is available only for the "dry" type of basic setup.

Subfunction: "Intermed. height"

In this function, specify the intermediate height H (☞ → ☞ 57) of the container in question. The probe length $L1$ must be entered here in the event of a wet calibration.

Subfunction: "Edit"

Use this function to enter, modify or read the linearization table.

The following options are available:

- **Read**
The table editor is opened. The existing table can be read but not edited.
- **Manual**
The table editor is opened. Table values can be entered or modified.
- **Semi-automat.**
The table editor is opened. The level value is read in automatically. The related measured value must be entered by the user.
- **Delete**
The linearization table is deleted.

 The linearization table can only be edited if it is disabled.

The table editor

A	B	C
1	0,0000	0,0000
2	0,0000	0,0000
3	0,0000	0,0000
...	0,0000	0,0000

A0040751

A Row number
B Level column
C Value column

1. Press  to go to the next row.
2. Press  to go to the previous row.
3. Press  to open marked row for editing.

A	B	C
1	0,0000	0,0000
2	0,0000	0,0000
3	0,0000	0,0000
...	0,0000	0,0000

A0040752

A Row number
B Level column
C Value column

1. Press  or  to navigate within the table.
2. Press  or  to navigate on No. column.
3. Press  to "Delete", "Insert" or "Move" the entire row.

 You can return to the previous step by pressing **Escape** →  33.

Subfunction: "Status table"

In this function, you can specify whether the linearization table should be used or not.

Options:

- **Enabled**
The table is used.
- **Disabled**
The table is not used. The measured value is output linearly with regard to the level unit.

Subfunction: "Max. scale"

In this function, specify the maximum contents of the tank in the customer unit.

7.6 Menu: "Output"

You can make the following settings in the "Output" menu:

 The factory settings are shown in bold.

Submenu: Extended calibr.

- function: Extended calibr.
 - subfunction: Measuring range
 - **2 000 pF**
 - 4 000 pF
 - subfunction: Sensor DAT Stat.
 - **OK**
 - subfunction: Sensor DAT
 - **Upload**
 - Download
- function: Output / Calculat
 - subfunction: Curr. turn down
 - On
 - **Off**
 - subfunction: Turn down 4 mA ¹⁷⁾
 - **0%**
 - subfunction: Turn down 20 mA ¹⁷⁾
 - **100%**
 - subfunction: 4 mA threshold
 - On
 - **Off**

Submenu: HART setting

- function: HART setting
 - subfunction: HART address
 - 0
 - subfunction: No. of preambles
 - 5
 - subfunction: Short TAG HART
 - TAG
- subfunction: Output / Calculat
 - - Current span
 - **4 to 20 mA**
 - Fix. curr. HART
 - subfunction: mA value ¹⁸⁾
 - **4 mA**

Submenu: Simulation

- function: Simulation
 - **Off**
 - On
- function: Simulation value ¹⁹⁾
 - xx.xx mA

¹⁷⁾ This function is only displayed if the "On" option was selected under the "Curr. turn down" subfunction.

¹⁸⁾ This function is only displayed if the function value "Fix. curr. HART" was selected under the "Current span" subfunction.

¹⁹⁾ This function is only displayed if the "On" option was selected under the "Simulation" function.

7.6.1 Submenu: "Extended calibr."

Function: "Extended calibr."

In this function, you can specify the measuring range.

Subfunction: "Measuring range"

Specify the measuring range in this subfunction.

- $C_A = 0$ to 2 000 pF for probe length < 6 m (20 ft)
- $C_A = 0$ to 4 000 pF for probe length > 6 m (20 ft)

 At the factory, the measuring range is always calibrated to the probe length ordered. If the electronic insert is used in another probe, the measuring range must be configured in accordance with the probe length.

Function: "Output/Calculat."

Subfunction: "Sensor DAT stat."

This subfunction shows the status of the sensor DAT.

- OK - sensor DAT is ready for use
- Error - sensor DAT is not ready for use or missing

Subfunction: "Sensor DAT"

Calibration values can be transmitted with this function. A distinction is made between two types:

- the sensor has been replaced and the electronic insert should continue to be used
- the electronic insert has been replaced but the sensor should continue to be used

For these instances, the calibration values already set can be transferred from the sensor to the electronic insert or from the electronic insert to the sensor.

Upload

To transfer the calibration values from the sensor to the electronic insert.

Download

To transfer the calibration values from the electronic insert to the sensor.

Subfunction: "Curr. turn down"

 This subfunction is not available for "Current span", "Fix. curr. HART".

This function can switch on the current turn down. The current output refers only to a freely definable part of the measuring range. This is then magnified when displayed.

Subfunction: "Turn down 4 mA"


 This subfunction is available only for "Curr. turn down", "On".

Enter the measured value at which the current should be 4 mA.

Subfunction: "Turn down 20 mA"

 This subfunction is available only for "Curr. turn down", "On".

Enter the measured value at which the current should be 20 mA.




- A Turn down 4 mA
B Turn down 20 mA

Subfunction: "4 mA threshold" - for Current span = 4 to 20 mA

It is possible to switch on the 4 mA threshold in this subfunction. The 4 mA threshold means that the current never is below, 4 mA even if the measured value is negative.

Options:

- Off
The threshold is switched off. Currents under 4 mA can occur.
- On
The threshold is switched on. The current is never below 4 mA.



- A 4 mA threshold off.
B 4 mA threshold on.

7.6.2 Submenu: "HART setting"

Function: "HART settings"

Subfunction: "HART address"

In this subfunction, specify the HART communication address for the device.

Possible values:

- for standard operation: 0
- for multidrop operation: 1 - 15



In multidrop operation, the output current is 4 mA as standard. However, it can be changed in the "mA value" function.

Subfunction: "No. of preambles"

In this subfunction, specify the number of preambles for the HART protocol. Increase the value if there are communication problems on the lines.

Subfunction: "Short TAG HART"


Here, you can enter the TAG name for HART communication in the device.

Function: Output / Calculat.*Subfunction: "Current span"*

In this subfunction, select the current span to which the measuring range should be mapped.

Options:

- 4 to 20 mA
the measuring range 0 to 100 % is mapped to the 4 to 20 mA current span
- Fix. curr. HART
a fixed current is an output. Its value can be specified in the "mA value" subfunction. The measured value is only transmitted via the HART signal



- A Current span = 4 to 20 mA.
 B Current span = fix. curr. HART.
 C mA value

7.6.3 Menu: "Simulation"**Function: "Simulation"***Subfunction: "Simulation"*

This function switches on or off the simulation of output current.

Options:

- Off
The device is not in the simulation mode. The device is in the measuring mode.
- On
The device is in the simulation mode. A measured value is not output. Instead, the current output assumes the value defined in the "Simulation value" subfunction.

Subfunction: "Simulation value" - only for "Simulation On" mode

Specify the current value to be simulated in this function.

7.7 Menu: "Device properties"

 The factory settings are shown in bold.

You can configure the following settings in the "Device properties" menu:

submenu: Display

- function: Language
 - **English**
 - Deutsch
 - Francais
 - Espanol
 - Italiano
 - Nederlands
- function: Display format
 - subfunction: Format
 - Decimal**
 - ft-in-1/16"
 - subfunction: No of decimals
 - x
 - x.x
 - **x.xx**
 - x.xxx
 - subfunction: Sep. character
 - **(dot)**
 - ,
 - subfunction: Back to home
 - 900 s

submenu: Diagnostics

- function: Actual error
 - subfunction: Actual error 1
 -
 - subfunction: Actual error 2
 -
 - subfunction: Actual error 3
 -
- function: Last error
 - subfunction: reset errorlist
 - Keep
 - Delete
 - Last error 2
 -
 - Last error 3
 -
- function: Password / reset
 - subfunction: Reset
 - 12345
 - subfunction: Status
 - **Unlocked**
- function: Electronic temp.
 - Electronic temp.
 - xx.x °C
 - Max. temp.
 - xx.x °C
 - Min. temp.
 - xx.x °C
 - Temperature unit
 - °C
 - °F
 - K
 - Min / Max temp.
 - **Keep**
 - Delete
 - Reset Min.
 - Reset Max.
- function: Measure capacity
 - subfunction: Measure capacity
 - xxxx.xx pF
 - subfunction: Max. capacity val
 - xxxx.xx pF
 - Min / Max capacity
 - **Keep**
 - Delete
 - Reset Min.
 - Reset Max.

submenu: System parameters

- function: Device information
 - subfunction: Device designation
 - Liquicap-FMI5x
 - subfunction: Serial No.
 -
 - subfunction: EC Serial No.
 - xxxxxxxxxxxx
 - subfunction: Device marking
 - FMI51- OrderCode
- function: Device information
 - subfunction: Dev. rev
 - x
 - subfunction: Software version
 - V01.zz.zz.zzz
 - subfunction: DD version
 - xx
- function: Device information
 - subfunction: Working hour
 - xxxxx h
 - subfunction: Current run time
 - 000d00h00m
- subfunction: Probe length
 - Probe length
 - xxx mm
 - Sensitivity
 - 0.0

7.7.1 Submenu: "Display"**Function: "Language"**

Select the language for the display and operating module.

Options:

- English
- Deutsch
- Français
- Español
- Italiano
- Nederlands

Function: "Display format"

The "Display format" refers to how the measured value is displayed.

Subfunction: "Format"

Select the display format for displaying numbers.

Options:

- Decimal
- ft-in-1/16"

Subfunction: "No. of decimals"

Select the number of places after the decimal point for displaying numbers.

Options:

- x
- x.x
- x.xx
- x.xxx

Subfunction: "Sep. character"

Select the separator for displaying decimal numbers.

Options:

- . (dot)
- , (comma)

7.7.2 Submenu: "Diagnosis"

Function: "Actual error"

With this function, you can call up the list of all currently pending errors. The errors are arranged by priority.

If you select an error, a text field appears with a brief description of the error.

Error code list →  77

Function: "Last error"

With this function, you can call up the list of all rectified errors. The option of resetting the error list with "Reset error list" is also available. It overwrites the last three error codes with 0.

Function: "Password / reset"

This function restores the factory settings. All parameters are reset to factory settings.

Subfunction: "Reset"



The factory settings are bold in the menu overview.

Enter the reset code "333" or "7864" to reset all the parameters to the factory settings.

During a "333" reset, linearization is reset to "linear". However, any linearization table available is retained and can be activated again where necessary.

During a "7864" reset, linearization is reset to "linear" and the linearization table is deleted.

The subfunctions are also reset:

- "Electronic temp."
- "Max. temp."
- "Max. capacity val."
- "Min. capacity val."
- "Min/Max capacity"

Function: "Electronic temp."

This function displays the temperature measured by the electronic insert.

Subfunction: "Electronic temp."

The subfunction displays the current electronics temperature.

Subfunction: "Max. temp."

The subfunction displays the highest temperature value measured by the device.

Subfunction: "Min. temp."

The subfunction displays the lowest temperature value measured by the device.

Subfunction: "Temperature unit"

The subfunction determines the temperature unit.

Options:

- °C
- °F
- K

Subfunction: "Min/Max temp."

The subfunction resets the "Min/Max temp."

Function: "Measure capacity"

This function displays measuring capacities that were measured by the electronic insert during operation.

Subfunction: "Measure capacity"

This subfunction displays the currently measured capacity.

Subfunction: "Max. capacity val."

This subfunction displays the highest capacitance value measured by the device.

Subfunction: "Min. capacity val."

This subfunction displays the lowest capacitance value measured by the device.

Subfunction: "Min/Max capacity"

The subfunction resets the "Min. or Max. capacity".

7.7.3 Submenu: "System parameters"



All functions listed in this section can be viewed only.

Function: "Device information"

This function displays all device information with which the device can be identified.

Subfunction: "Device marking"

This subfunction displays the device name e.g. Liquicap M-FMI51.

Subfunction: "Serial No."

This subfunction displays the serial number of the device that was assigned in the factory.

Subfunction: "EC Serial No."

This subfunction displays the serial number of the electronic insert.

Subfunction: "Device marking"

This subfunction displays the device marking and the order code.

Subfunction: "Dev. rev"

This subfunction displays the version of the electronic-hardware.

Subfunction: "Software version"

This subfunction displays the software version of the device that was assigned in the factory.

Subfunction: "DD version"

This function indicates the DD version with which this device can be operated using FieldCare.

Subfunction: "Working hour"

This subfunction displays the number of operating hours.

Subfunction: "Current run time"

This subfunction displays the "current run time" of the device. The first three digits display the number of days, followed by "d". The next two digits display the hours, followed by "h". The last two digits indicate the minutes. This subfunction displays the "current run time" of the device. The first three digits display the number of days, followed by "d". The next two digits display the hours, followed by "h". The last two digits indicate the minutes.

Function: "Probe length"

In this function, more probe information can be displayed.

Subfunction: "Probe length"

You can read the current probe length in this subfunction.

Probe length (L1) = A – (thread length – plug)

More information are provided → 48.

Subfunction: "Sensitivity"

You can read off the current sensitivity in mm/pF in this subfunction.

7.8 Operation

After Basic setup, Liquicap M outputs the measured value via:

- the display and operating module
- the current output ²⁰⁾
- the digital HART signal

7.9 FieldCare: operating program from Endress+Hauser

The FieldCare operating program is Endress+Hauser plant asset management tool based on FDT technology. It is possible to use FieldCare to configure all Endress+Hauser devices as well as third-party devices which support the FDT standard. The following operating systems are supported:

- Windows 7 Professional SP1 (x32+x64)
- Windows 7 Ultimate SP1 (x32+x64)
- Windows 7 Enterprise SP1 (x32+x64)
- Windows Server 2008 R2 SP2
- Windows 8.1
- Windows 8.1 Professional
- Windows 8.1 Enterprise
- Windows 10 Professional
- Windows 10 Enterprise

²⁰⁾ The entire measuring range (0 to 100 %) is then mapped to the range (4 to 20 mA) of the current output.

FieldCare supports the following functions:

- configuration of transmitters in online operation
- tank linearization
- loading and saving device data by upload and download
- documentation of the measuring point

Connection options:

HART via Commubox FXA195 and the USB port of a computer.

 After reinstalling FieldCare, or by clicking a link in the Help menu, a video can be activated that explains the possible applications of the program in just a few minutes.

7.9.1 FieldCare

Function scope

FDT-based plant asset management tool from Endress+Hauser. It can configure all smart field devices in a system and helps you manage them. By using the status information, it is also a simple but effective way of checking their status and condition.

 For additional information about FieldCare, see Operating Instructions BA00027S and BA00059S

Connection options: HART via Commubox FXA195 and the USB port of a computer


Source for device description files

- www.endress.com → Downloads
- CD-ROM (contact Endress+Hauser)
- DVD (contact Endress+Hauser)

7.9.2 Interface measurement

If there are different media in the container like water and oil, the capacitance values for "Empty calibration" and "Full calibration" can be calculated.

CapCalc.xls is a capacitance calculation program in FieldCare which can be used to calculate the calibration values for level measurement and interface measurement.



A0040616

- 1 Nonconductive medium $< 1 \mu\text{S}/\text{cm}$, $\text{DC} < 5$
- 2 Emulsion
- 3 Conductive medium $\geq 100 \mu\text{S}/\text{cm}$

The program calculates the calibration values on the basis of the entered data. The secure functioning of interface measurement can already be determined at this time. The


calculated calibration values can be transmitted to the FEI50H electronic insert via the display or FieldCare.

 Capacitance interface measurement is also suitable for very pronounced emulsion layers. The emulsion layer average is always measured.

7.9.3 Dry calibration for interface measurement


Calculating the calibration data with CapCalc

1.




Click the "CA" button in the toolbar to start CapCalc.

2.



Click "Activate macros" button.

3.



Click the "Next" button in the top right.

Editing the probe and application-specific data

Editing the probe and application-specific data.

1.

Endress+Hauser **People for Process Automation**

Sprache wählen
Select language

19.01.2007

Print

Info

Probe type FMI51, rod 10mm, PTFE or PFA

Probe diameter 8 mm

Probe diameter with isolation 10 mm

DC-value of isolation 1,9

Base capacity 27,07 pF

Auxiliary capacities 0 pF

Probe length L1 1000 mm

inactive length L3 0 mm

Value Empty E 1000 mm

Value Full F 500 mm

Wall distance 250 mm

Medium top

Name oil

Conductivity 0,01 µS/cm

Dielectric constant 2,1

Medium bottom

Name water

Conductivity 180 µS/cm

Dielectric constant 80,4

Calibration data level

Calibration data interface measurement

Probe type

Auxiliary capacities

DC handbook

Click the "Probe type" button.

2. Select the probe type.
3. Enter the length probe L1 in accordance with the nameplate.
4. Enter the inactive length L3 in accordance with the nameplate.
5. Enter the "Value empty E".
6. Enter the "Value full F".
7. Enter the "Wall distance".
8. Enter the conductivity value of the medium in the "Medium top".
9. Enter the dielectric constant value of the medium in the "Medium top".
10. Enter the conductivity value of the medium in the "Medium bottom".
11. Enter the dielectric constant value of the medium in the "Medium bottom".
12. Click the "Calibration data interface measurement" button to obtain the capacitance values for the calibration.
 - ↳ The capacitance values for empty calibration and full calibration are calculated and displayed as a result.

Use the "DC handbook" button to transfer the DC values and the conductivity of the corresponding media to the calculation program, if the medium properties are not known.

7.9.4 Wet calibration for interface measurement

This chapter describes the wet calibration procedure for "Empty calibration" and "Full calibration".

Empty calibration

1. Fill the container with the top medium.

2. Perform "Empty calibration 0%" regarding procedure →  44.

 If it is not possible to fill the tank, perform the "Empty calibration" with the probe exposed in the air, however expect a calibration inaccuracy approximately 2.5 % per meter. The water and oil are the reference media.

Full calibration

1. Fill the container with the bottom medium.
2. Perform "Full calibration 100%" regarding procedure →  44.

The empty and full calibration is completed and all data are saved in the electronic insert and DAT sensor.

8 Diagnostics and troubleshooting

The operating status of the device is indicated by the LEDs on the electronic insert.

8.1 Diagnostic information via LEDs

8.1.1 Green LED flashing

Green LED indicates operation:

- flashes every 5 s
the device is in the operation mode
- flashes once per 1 s
the device is in the calibration mode
- flashes 4x:
the device confirms a parameter change, function switch position 4, 5, 6

8.1.2 Red LED flashing

 To analyze the errors find the list in the chapter "Error codes" →  77

Red LED indicates a fault.

- Warning: LED flashes 5x per second
 - capacitance at probe is too high
 - probe insulation break detection
 - FEI50H is defective
- Alarm: LED flashes 1x per second
the temperature in the electronic insert is over the permitted range

8.2 System error messages

8.2.1 Error signal

Errors occurring during commissioning or during operation are displayed as follows:

- error symbol, error code and error description on the display and operating module
- current output, can be set:
 - Max: 110%, 22 mA
 - Hold - last value is retained
 - User-spec. value

8.2.2 Last errors

This function enables to call up a list of most recent errors.

8.2.3 Types of error

The alarm is represented by the symbol  which appears on the display. An error message is also shown on the display.

The output signal assumes a value that can be specified with the "Output on alarm" function:

- Max: 110%, 22 mA
- Hold - last value is retained
- User-spec. value

The warning is represented by the flashing symbol  which appears on the display. An error message is shown on the display.

The device continues measuring.

8.2.4 Error codes

The error codes shown on the display are 4-digit codes:

Position 1: Type of error

- A - alarm
- W - warning

Positions 2-4:

refers to the error in accordance to with the error list

Alarm codes

- A 101, A 102, A 110, A 152
Checksum error
- total reset and recalibration is necessary
- A 106
Downloading - please wait
wait until the downloading is complete
- A 111, A 112, A 113, A 114, A 115, A 155, A 164, A 171, A 404, A 405, A 407, A 408, A 409, A 410, A 411, A 412, A 413, A 414, A 415, A 416, A 417, A 418, A 421, A 422, A 423, A 424
Electronics defective
- switch the device off and then on
- if the error persists contact Endress+Hauser Service
- A 116
Download error
- repeat download or perform a total reset
- A 426
Data of Sensor-DAT (EEPROM) not consistent
- repeat download from the electronic insert or perform a total reset
- A 427
Current output not calibrated
- repeat download or perform a total reset
- A 1121
current output not calibrated
- contact Endress+Hauser-Service
- A 400
Measured capacitance too high
- change measuring range, verify probe
- A 403
Measured capacitance too low
- verify probe
- A 420
No sensor DAT (EEPROM) available
- exchange sensor
- A 428
Probe insulation break detection
- verify probe
- A 1601
Linearization curve not monotone for level
- re-enter linearization
- A 1604
Calibration faulty
- correct calibration

Warning codes

- W103, W153
Initializing - Please wait
- if the message does not disappear after a few seconds replace the electronics
 - W153
Initializing
- if the message does not disappear after a few seconds replace the electronics
 - W 425
Warning insulation defective
- check insulation
 - W 429
Proof test active
- wait until the proof test is completed
 - W 1601
Linearization curve not monotone for level
- re-enter linearization
 - W 1611
Level linearization points
- enter additional linearization points
 - W 1662
The temperature at electronic insert too high (max. temp. at sensor exceeded)
- lower ambient temperature by suitable measures
 - W 430
Data of probe and electronic insert not compatible
- check probe, perform a total reset
 - W 1671
Linearization table entered incorrectly
- re-adjust table
 - W 1681
Current outside measuring range
- perform basic setup and check linearization
 - W 1683
Current turn down calibration faulty
- repeat calibration
 - W 1801
Level simulation switched on
- switch off level simulation
 - W 1802
Simulation switched on
- switch off simulation
 - W 1806
The current output is in simulation mode
- set the current output to normal mode
 - W 511
The electronic insert has lost calibration data
- contact Endress+Hauser-Service
-  If none of the proposed remedial measures achieves the desired result, perform the reset →  43


8.3 Possible measuring errors

8.3.1 Measured value is incorrect

If the measured values are incorrect, follow this procedure:

1. Verify empty and full calibration.
2. Clean the probe.

3. Verify the probe.
4. Change the installation position. Do not mount probe in a filling curtain.
5. Check ground from process connection to the tank wall. $R < 1 \Omega$.
6. For conductive media, check the probe insulation. $R > 800 \text{ k}\Omega$.
7. Increase output damping, if the surface is turbulent.



A0040621

19 Electronic insert contacts

- | | |
|---|------------------------|
| 1 | Guard |
| 2 | SDA_TXD |
| 3 | GND |
| 4 | GND EEPROM |
| 5 | GND |
| 6 | DVCC 3 V _{DC} |
| 7 | Probe |
| 8 | SCL_RXD |

8.4 Firmware history

Firmware V 01.00.zz / 08.2005

Updates:

- original-firmware
- operable with FieldCare version 2.08.00 and higher

Firmware V 01.03.zz / 02.2007

Updates:

expansion feature suitable for SIL 2 applications

9 Maintenance

No special maintenance work is required for the Liquicap M level transmitter.

9.1 External cleaning

Do not use a corrosive or aggressive cleaning agent to clean the housing surface and seals.

9.2 Cleaning the probe

Depending on the application, buildup of contamination or soiling can form on the probe rod. A high level of material buildup can affect the measurement result.

The regular cleaning of the probe rod is recommended if the medium tends to create a high level of buildup.

Make sure that the insulation of the probe rod is not damaged if hosing down or during mechanical cleaning.

Make sure that the probe rod insulation is resistant to cleaning agents.

9.3 Seals

The process seals of the sensor must be replaced periodically, especially when using molded aseptic seals!

The intervals between seal replacement depend on the frequency of the cleaning cycles and on the fluid and cleaning temperature.

9.4 Endress+Hauser services

Endress+Hauser offers a wide range of services.



Your Endress+Hauser Sales Center can provide detailed information on the services.

10 Repair

10.1 General notes

The Endress+Hauser repair and conversion concept provides the following:

- The measuring devices have a modular design.
- Spare parts are grouped into logical kits with the associated Installation Instructions.
- Repairs are carried out by Endress+Hauser Service or by appropriately trained customers.
- Certified devices can only be converted to other certified devices by Endress+Hauser Service or at the factory.

10.2 Spare parts

Find spare parts

Check whether it is possible to use the spare part for the measuring device.

1. Launch the Endress+Hauser Device Viewer via a web browser:
www.endress.com/deviceviewer
2. Enter the order code or the product root in the respective field.
 - ↳ Once the order code or the product root has been entered, all the suitable spare parts are listed.
The product status is displayed.
Available drawings of the spare parts are displayed.
3. Locate the order code of the spare part set (on the product label on the package).
 - ↳ **NOTE!**
The order code of the spare part set (on the product label on the package) can differ from the production number (on the label directly on the spare part)!
4. Check whether the order code of the spare part set appears in the list of the spare parts displayed:
 - ↳ **YES:** The spare part set may be used for the measuring device.
NO: The spare part set may not be used for the measuring device.
If you have any questions please contact your Endress+Hauser Service organization.
5. On the **Spare parts** tab click the PDF symbol in the **MH** column.
 - ↳ The Installation Instructions attached to the listed spare part are opened as a PDF file and can also be saved as a PDF file.
6. Click one of the drawings shown on the **Spare part drawings** tab.
 - ↳ The corresponding exploded drawing is opened as a PDF file and can also be saved as a PDF file.

10.3 Repairing Ex-certified devices

If repairing Ex-certified devices remember that:

- Ex-certified devices may only be repaired by experienced and skilled staff or by Endress+Hauser Service
- observe all applicable standards, certificates, national Ex-area regulations and all Safety Instructions (XA)
- use only genuine spare parts from Endress+Hauser
- note the device designation on the nameplate to order the spare parts
- replace the component by the same type
- carry out the replacing in accordance with the instructions

- carry out the individual test for the device
- change the device only with a device certificated by Endress+Hauser
- report every change and repair of the device

10.4 Replacement

After replacing a Liquicap M or the electronic insert, the calibration values must be transferred to the replacement device.

Options:

- if the probe is replaced, the calibration values in the electronic insert can be transferred to the sensor DAT (EEPROM) module via a manual download
- if the electronic insert is replaced, the calibration values of the sensor DAT (EEPROM) module can be transferred to the electronics via a manual upload

It is possible to restart the device without having to carry out a new calibration →  63.

10.5 Return

The requirements for safe device return can vary depending on the device type and national legislation.

1. Refer to the website for more information:
<http://www.endress.com/support/return-material>
2. Return the device if repairs or a factory calibration are required, or if the wrong device was ordered or delivered.

10.6 Disposal

10.6.1 Removing the measuring device

1. Switch off the device.

WARNING

Danger to personnel from process conditions.

- Beware of hazardous process conditions such as pressure in the measuring device, high temperatures or aggressive fluids.
- 2. Carry out the mounting and connection steps from the "Mounting the measuring device" and "Connecting the measuring device" sections in reverse order. Observe the safety instructions.

10.6.2 Disposing of the measuring device

WARNING

Danger to personnel and environment from fluids that are hazardous to health.

- Ensure that the measuring device and all cavities are free of fluid residues that are hazardous to health or the environment, e.g. substances that have permeated into crevices or diffused through plastic.

Observe the following notes during disposal:

- Observe valid federal/national regulations.
- Ensure proper separation and reuse of the device components.

11 Accessories

11.1 Protective cover

Protective cover for F13, F17 and F27 housing
order number: 71040497

Protective cover for F16 housing
order number: 71127760

11.2 Commubox FXA195 HART

For intrinsically safe HART communication with FieldCare via the RS232C interface or USB.

11.3 HAW56x surge arrester

Surge arrester for limiting overvoltage in signal lines and components is described in Brief Operating Instructions: KA00130R.

11.4 Weld-in adapter

All available weld-in adapters are described in the document TI00426F.

The documentation is available in the Download section on Endress+Hauser web site:
www.endress.com

12 Technical data

12.1 Probe

12.1.1 Capacitance values of the probe

The basic capacitance of the probe is approximately 18 pF.

12.1.2 Additional capacitance

Mount the probe at a minimum distance of 50 mm (1.97 in) from a conductive container wall:

approximately 1.3 pF/100 mm (3.94 in) in the air for a rod probe

Fully insulated probe rod in water:

- approximately 38 pF/100 mm (3.94 in) for 16 mm (0.63 in) rod
- approximately 45 pF/100 mm (3.94 in) for 10 mm (0.39 in) rod
- approximately 50 pF/100 mm (3.94 in) for 22 mm (0.87 in) rod

Rod probe with the ground tube:

- approximately 6.4 pF/100 mm (3.94 in) in air
- approximately 38 pF/100 mm (3.94 in) in water for 16 mm (0.63 in) probe rod
- approximately 45 pF/100 mm (3.94 in) in water for 10 mm (0.39 in) probe rod

12.1.3 Probe lengths for continuous measurement in conductive liquids

The maximum length of the rod probe ≤ 4 m (13 ft) for capacitive range 0 to 2 000 pF.

12.2 Input

12.2.1 Measured variable

Continuous measurement of change in capacitance between the probe rod and container wall or ground tube, depending on the level of a liquid.

The probe covered -> high capacitance.

The probe not covered -> low capacitance.

12.2.2 Measuring range

- measuring frequency:
500 kHz
- span ΔC
 - recommended: 25 to 4 000 pF
 - possible: 2 to 4 000 pF
- final capacitance C_E :
max. 4 000 pF
- adjustable initial capacitance C_A :
 - < 6 m (20 ft) 0 to 2 000 pF
 - > 6 m (20 ft) 0 to 4 000 pF

12.3 Output

12.3.1 Output signal

FEI50H (4 to 20 mA / HART version 5)

3.8 to 20.5 mA with HART protocol

12.3.2 Signal on alarm

FEI50H (4 to 20 mA / HART version 5)

Fault diagnosis can be called up via:

- red LED on the local display
- error symbol on the local display
- plain text on the display
- current output 22 mA
- digital interface: HART status error message

12.3.3 Linearization

FEI50H (4 to 20 mA / HART version 5)

The Liquicap M linearization function enables conversion of the measured value into any desired length or volume units. Linearization tables for volume calculation of horizontal cylindrical tanks and spherical tanks are pre-programmed. Any other tables with up to 32 value pairs can be input manually or semi-automatically.

12.4 Performance characteristics

12.4.1 Reference operating conditions

Room temperature:
 $+20\text{ °C (+68 °F)} \pm 5\text{ °C (\pm 8 °F)}$

Span:

- standard measuring range
5 to 2 000 pF
- extended measuring range
5 to 4 000 pF
- span for reference - corresponds to approximately 1 m (3.3 ft) probe length
5 to 4 000 pF

12.4.2 Maximum measured error

Non-repeatability (reproducibility) as per DIN 61298-2:
 maximum $\pm 0.1\text{ %}$

Non-linearity for limit point setting (linearity) as per DIN 61298-2:
 maximum $\pm 0.5\text{ %}$

12.4.3 Influence of ambient temperature

Electronic insert

$< 0.06\text{ %}/10\text{ K}$ related to the full-scale value

Separate housing

change in capacitance of connecting cable $0.015\text{ pF / m per K}$

12.4.4 Influence of process pressure

In the case of fully insulated probes in conductive liquids:

$< 10.0\text{ %}$ related to the full scale value


12.4.5 Switch-on behavior

14 s, the stable measured value after the switch-on procedure, a start-up in safe status
 22 mA

12.4.6 Measured value reaction time

Operating mode: $t_1 \leq 0.3\text{ s}$

SIL operating mode: $t_1 \leq 0.5\text{ s}$



A0040622

τ Time constant
 t_1 Dead time

12.4.7 Response time

FEI50H (4 to 20 mA / HART version 5)

The response time affects the speed at which the display and the current output react to changes in the level.

The factory setting for time constant $\tau = 1$ s; 0 to 60 s can be set.


12.4.8 Accuracy of factory calibration

Empty calibration (0 %) and full calibration (100 %):

- probe length < 2 m (6.6 ft)
≤ 5 mm (0.2 in)
- probe length > 2 m (6.6 ft)
approximately ≤ 2 %

Reference conditions for the factory calibration:

- medium conductivity ≥ 100 $\mu\text{S}/\text{cm}$
- minimum distance to tank wall = 250 mm (9.84 in)



A0040419

Unit of measurement mm (in)

L1 Measuring range from the tip of the probe to the process connection

L3 The inactive length



In an installed state, recalibration is only necessary when:

- the 0 % or the 100 % values have to be adjusted specifically for the customer
- the liquid is not conductive
- the probe distance to the tank wall is < 250 mm (9.84 in)

12.4.9 Resolution

Analog in % (4 to 20 mA)

- 11 bit/ 2 048 steps, 8 μA
- the resolution of the electronics can be directly converted to units of length of the probe
e.g. rod probe length is 1 000 mm, resolution equals $1\,000\text{ mm}/2\,048 = 0.48\text{ mm}$

12.5 Operating conditions: Environment

12.5.1 Ambient temperature range

- F16 housing: -40 to +70 °C (-40 to +158 °F)
- remaining housing: -50 to +70 °C (-58 to +158 °F)
- observe derating
- use a protective cover, when operating outdoors

12.5.2 Climate class

DIN EN 60068-2-38/IEC 68-2-38: Z/AD check

12.5.3 Vibration resistance

DIN EN 60068-2-64/IEC 68-2-64: 20 to 2 000 Hz, 0.01 g²/Hz

12.5.4 Shock resistance

DIN EN 60068-2-27/IEC 68-2-27: 30g acceleration

12.5.5 Degree of protection



All protection degree regarding EN60529.

NEMA4X protection degree regarding NEMA250.

Polyester housing F16

Protection degree:

- IP66
- IP67
- NEMA 4X

Stainless steel housing F15

Protection degree:

- IP66
- IP67
- NEMA 4X

Aluminum housing F17

Protection degree:

- IP66
- IP67
- NEMA 4X

Aluminum housing F13 with gas-tight process seal

Protection degree:

- IP66
- IP68 ²¹⁾
- NEMA 4X

Stainless steel housing F27 with gas-tight process seal

Protection degree:

- IP66
- IP67
- IP68 ²¹⁾
- NEMA 4X

21) Only with M20 cable entry or G½ thread.

Aluminum housing T13 with gas-tight process seal and separate connection compartment (Ex d)

Protection degree:

- IP66
- IP68 ²¹⁾
- NEMA 4X

Separate housing

Protection degree:

- IP66
- IP68 ²¹⁾
- NEMA 4X

12.6 Operating conditions: Process


12.6.1 Process temperature range

The following diagrams apply for:

- insulation
 - PTFE
 - PFA
 - FEP
- standard applications outside hazardous areas

i The temperature is restricted to $T_a -40\text{ °C}$ (-40 °F) when the polyester housing F16 is used or if additional option B is selected: free from paint-wetting impairment substances, only FMI51.


Probe with compact housing



T_a Ambient temperature

T_p Process temperature

Probe with separate housing



A0040624

T_a Ambient temperature

T_p Process temperature

1 The permitted ambient temperature at the separate housing is the same as indicated for the compact housing.

Influence of process temperature

Error in case of fully insulated probes typically 0.13 %/K related to the full-scale value.

12.6.2 Process pressure limits

Probe Ø10 mm (0.39 in) including insulation

–1 to 25 bar (–14.5 to 362.5 psi)

Probe Ø16 mm (0.63 in) including insulation

- –1 to 100 bar (–14.5 to 1450 psi)
- in regards to an inactive length, the maximum permitted process pressure is 63 bar (913.5 psi)
- for CRN approval and inactive length: the maximum permitted process pressure is 32 bar (464 psi)

Probe Ø22 mm (0.87 in) including insulation

–1 to 50 bar (–14.5 to 725 psi)

Refer to the following standards for the pressure values permitted at higher temperatures:


- EN 1092-1: 2005 Table, Appendix G2
With regard to its resistance and temperature property, the material 1.4435 is identical to 1.4404 (AISI 316L) which is grouped under 13E0 in EN 1092-1 Tab. 18. The chemical composition of the two materials can be identical.
- ASME B 16.5a - 1998 Tab. 2-2.2 F316
- ASME B 16.5a - 1998 Tab. 2.3.8 N10276
- JIS B 2220

The lowest value from the derating curves of the device and the selected flange applies.

12.6.3 Pressure and temperature derating

For process connections ½", ¾", 1", flanges <DN50, <ANSI 2", <JIS 10K (10 mm (0.39 in) rod) and process connections ¾", 1", flanges <DN50, <ANSI 2", <JIS 10K (16 mm (0.63 in) rod)


Rod insulation: PTFE, PFA



P_p Process pressure
 T_p Process temperature

For process connections 1½", flanges <DN50, <ANSI 2", <JIS 10K (16 mm (0.63 in) rod)


Rod insulation: PTFE, PFA



P_p Process pressure
 T_p Process temperature
 63 Process pressure for probes with an inactive length

With a fully insulated inactive length (22 mm (0.87 in) rod)

Rod insulation: PTFE, PFA



A0040627

P_p Process pressure
 T_p Process temperature

Index

0 ... 9

4 mA threshold 64

A

About this document 6
Accessories 83
Accuracy of factory calibration 87
Additional capacitance 84
Aligning the housing 25
Ambient temperature range 88

B

Basic safety instructions 11
Basic setup without the display or operating module . . 39

C

Cable specification 26
Calculating the calibration data with CapCalc 73
Capacitance values of the probe 84
CE mark 11
Certificates 8
Cleaning the probe 80
Climate class 88
Commissioning 39
Commubox FXA195 HART 83
Conical threads 24
Connecting HART 30
Connecting requirements 26
Connection compartment 27
Connector 27
Cylindrical threads 24

D

Declaration of Conformity 11
Degree of protection 88
Diagnostic information via LEDs 76
Diagnostics and troubleshooting 76
Display and operating elements 32
Disposal 82
Document
 Function 6
Document function 6
Documentation 8
Dry calibration for interface measurement 73

E

Editing functions with the picklist 36
Editing numeric and alphanumeric functions 36
Editing the probe and application-specific data 74
Effects of a reset 38
Electrical connection 26
Electromagnetic compatibility 26
Endress+Hauser services
 Repair 80
Environment 88
Error codes 77
Error messages 37

Error signal 76
Ex-area
 Explosive area 11
Extension heights: separate housing 19
External cleaning 80

F

FEI50H electronic insert 31
FieldCare 71, 72
 Function 38, 72
Firmware history 79
Function codes 34
Function switch: position 1.
 Operation 40
Function switch: position 2
 Carry out empty calibration - for almost empty tanks 40
Function switch: position 2.
 Carry out empty calibration - for empty tanks 40
Function switch: position 3
 Carry out full calibration - for almost full tanks . . . 41
 Carry out full calibration - for full tanks 41
Function switch: position 4
 Measuring modes 42
Function switch: position 5
 Measuring range 42
Function switch: position 6
 Proof test - self-test 43
Function switch: position 7
 Reset - restore factory settings 43
Function switch: position 8
 Download or upload sensor DAT (EEPROM) 43
Function: "Actual error" 69
Function: "Basic setup" 46
Function: "Device information" 70
Function: "Display format" 68
Function: "Electronic temp." 69
Function: "Extended calibr." 63
Function: "HART settings" 64
Function: "Language" 68
Function: "Last error" 69
Function: "Linearization" 57, 60
Function: "Measure capacity" 70
Function: "Medium property" 47
Function: "Operating mode" 53
Function: "Output damping" 50
Function: "Output on alarm" 54
Function: "Password / reset" 69
Function: "Proof test"
 Self-test 55
Function: "Safety settings" 52, 53, 54
Function: "Simulation" 65
Function: Output / Calculat. 65
Funktion: "Output/Calculat." 63

G

Green LED flashing 76

H

Hardware key combinations 33

HAW56x surge arrester 83

I

Incoming acceptance 12

Influence of ambient temperature 86

Influence of process pressure 86

Initial commissioning 44

Input 85

Installation and function check 39

Installation examples 16

Installation instructions 23

Interface measurement 72

K

Key locking 37

Key symbols 33

Key unlocking 37

L

Last errors 76

Launching menus 35

Linearization 85

Locking and unlocking configuration 37

M

M12 connector 27

Maintenance 80

Maximum

measured error 86

Measured value is incorrect 78

Measured value reaction time 86

Measured variable 85

Measuring condition 15

Measuring device

Conversion 81

Disposal 82

Removing 82

Repairs 81

Measuring range 85

Menu structures: Main menu 44

Menu: "Basic setup"

Commissioning with display and operating module

. 44

Menu: "Device properties" 65

Menu: "Linearization" 55

Menu: "Output" 62

Menu: "Safety setting" 50

Menu: "Simulation" 65

Minimum probe length for nonconductive media 16

Mounting 13

Mounting requirements 14

Mounting the sensor 14

O

Operating conditions 88

Operating conditions: Process 89

Operating mode: "Empty calibr."

Function - "Dry" 48

Function - "Wet" 47

Operating mode: "Empty calibration"

Function - "Dry" for "Interface" or "Unknown"

medium properties 50

Operating mode: "Full calibr."

Function - "Wet" 48

Operating mode: "Full calibration"

Function - "Dry"

Conductive and nonconductive media 49

Function - "Dry" for "Interface" or "Unknown"

medium properties 50

Operation 71

Operation options 31

Operation via FieldCare Device Setup 38

Operation via the optional display and operating

module 32

Operational safety 11

Output 85

Output signal 85

Overview of operation options 31

P

Performance characteristics 86

Performing a reset 38

Pipe mounting 22

Possible measuring errors 78

Post-connection check 30

Post-installation check 25

Potential equalization 26

Pressure and temperature derating 91

Probe installation 24

Probe length 71, 84

Probe with PTFE-clad flange 24

Probe with separate housing 19

Probe with Tri-Clamp 24

Process pressure limits 90

Process temperature range 89

Product identification 12

Product safety 11

Protective cover 83

Q

Quick installation guide 13

R

Red LED flashing 76

Reference operating conditions 86

Registered trademarks 10

Repair 81

Repairing Ex-certified devices 81

Replacement 82

Device components 81

Requirements for the personnel 11

Resetting to factory setting - reset 38

Resolution 87

Response time 87

Return 82
 Return to the measured value display 37

S

Sealing the probe housing 25
 Seals 80
 Selecting a function and subfunction 36
 Selecting a submenu 35
 Shock resistance 88
 Shortening the connecting cable 22
 Signal on alarm 85
 Software locking 37
 Spare parts 81
 Special functions when making entries 36
 Storage 12
 Subfunction: "Cal. type" 47
 Subfunction: "Cap. empty" 49, 50, 53
 Subfunction: "Cap. full" 49, 50, 53
 Subfunction: "Code" 52
 Subfunction: "Confirm cal." 48, 49, 50
 Subfunction: "Curr. turn down" 63
 Subfunction: "Current run time" 71
 Subfunction: "Current span" 65
 Subfunction: "Customer unit" 60
 Subfunction: "Customized text" 60
 Subfunction: "DC value" 47
 Subfunction: "DD version" 71
 Subfunction: "Dev. rev" 70
 Subfunction: "Device marking" 70
 Subfunction: "Diameter" 60
 Subfunction: "EC Serial No." 70
 Subfunction: "Edit" 60
 Subfunction: "Electronic temp." 69
 Subfunction: "Format" 68
 Subfunction: "HART address" 64
 Subfunction: "Intermed. height" 60
 Subfunction: "Max. capacity val." 70
 Subfunction: "Max. scale" 62
 Subfunction: "Max. temp." 69
 Subfunction: "Measure capacity" 47, 48, 70
 Subfunction: "Medium property" 42, 46, 47
 Subfunction: "Min. capacity val." 70
 Subfunction: "Min. temp." 70
 Subfunction: "Min/Max capacity" 70
 Subfunction: "Min/Max temp." 70
 Subfunction: "Mode" 59
 Subfunction: "No. of decimals" 68
 Subfunction: "No. of preambles" 64
 Subfunction: "Operating mode" 52, 53, 54
 Subfunction: "Output 1" 52
 Subfunction: "Output damping" 52, 54
 Subfunction: "Output value" 55
 Subfunction: "Output" 54
 Subfunction: "Parameter okay" 54
 Subfunction: "Parameter okay" 52, 53
 Subfunction: "Probe length" 71
 Subfunction: "Proof test" 55
 Subfunction: "Reset" 69
 Subfunction: "Sensitivity" 71

Subfunction: "Sensor DAT stat." 63
 Subfunction: "Sensor DAT" 63
 Subfunction: "Sep. character" 69
 Subfunction: "Serial No." 70
 Subfunction: "Short TAG HART" 64
 Subfunction: "SIL operating mode" 53
 Subfunction: "Sim. level value" or "Sim. vol. value" 60
 Subfunction: "Simulation value" 65
 Subfunction: "Simulation" 60, 65
 Subfunction: "Software version" 71
 Subfunction: "Status table" 61
 Subfunction: "Status" 52, 53
 Subfunction: "Temperature unit" 70
 Subfunction: "Type" 57
 Subfunction: "Unit level" 47
 Subfunction: "Value empty"
 Medium property for conductive and
 nonconductive medium 48
 Subfunction: "Value empty" 47, 50, 53, 54
 Subfunction: "Value full" 48, 50, 53, 54
 Medium property - conductive, nonconductive 49
 Subfunction: "Working hour" 71
 Submenu: "Diagnosis" 69
 Submenu: "Display" 68
 Submenu: "Extended calibr." 63
 Submenu: "HART setting" 64
 Submenu: "System parameters" 70
 Supply voltage 27
 Switch-on behavior 86
 Symbols on the display 33
 System error messages 76

T

Technical data 84
 Technical data: probe 84
 Technical Information 8
 Terminal assignment 29
 The operating menu 34
 The table editor 61
 Transport 12
 Turn down 4 mA 63
 Types of error 76

U

Using the reset 38

V

Vibration resistance 88

W

Wall bracket 21
 Wall mounting 21
 Weld-in adapter 83
 Wet calibration for interface measurement 74
 Wiring and connecting 27
 Workplace safety 11



www.addresses.endress.com

For more Endress+Hauser product please visit: www.ainstru.com
Mail: Sales@ainstru.com