



Level



Pressure



Flow



Temperature



Liquid
Analysis



Registration



Systems
Components



Services




Solutions

Operating Instructions

Prosonic M FMU40/41/42/43/44


Ultrasonic Level Measurement



BA239F/00/en/01.09
71089089

Valid as of software version:
V 01.04

Short instructions



Contents of the operating instructions

This operating instructions describes the installation and commissioning of the Prosonic M ultrasonic level transmitter. It contains all the functions required for a normal measuring operation. Also, the Prosonic M provides additional functions for optimising the measuring point and for converting the measured value. These functions are not included in this operating instructions.

You can find an **overview of all the device functions** in the Appendix.

You can find a **detailed description of all the device functions** in the operating instructions BA 240F/00/en "Prosonic M – Description of Instrument Functions". This is located on the supplied documentation CD-ROM.

Table of contents

1	Safety instructions	4		
1.1	Designated use	4	6.5	Basic Setup with the Endress+Hauser operating program 58
1.2	Installation, commissioning, operation	4	6.6	Commissioning with a FOUNDATION Fieldbus configuration tool 62
1.3	Hazardous area	4	6.7	Commissioning with the handheld terminal DXR375/FC375 67
1.4	Notes on safety conventions and symbols	5		
2	Identification	6	7	Troubleshooting
2.1	Nameplate	6	7.1	System error messages 68
2.2	Product structure FMU 40	7	7.2	Application errors 72
2.3	Product structure FMU 41	8		
2.4	Product structure FMU 42	9	8	Maintenance and repairs
2.5	Product structure FMU 43	11	8.1	Exterior cleaning 74
2.6	Product structure FMU 44	12	8.2	Repairs 74
2.7	Scope of delivery	14	8.3	Repairs to Ex-approved devices 74
2.8	Certificates and approvals	14	8.4	Replacement 74
2.9	Registered trademarks	14	8.5	Spare parts (housing type F12) 75
3	Installation	15	8.6	Spare parts (housing type T12) 78
3.1	Design; dimensions	15	8.7	Return 81
3.2	Installation variants	18	8.8	Disposal 81
3.3	Installation conditions	20	8.9	Software history 81
3.4	Measuring range	23	8.10	Contact addresses of Endress+Hauser 82
3.5	Installation hint for FMU 40/41	25	9	Accessories
3.6	Turn housing	25	9.1	Weather protection cover 83
3.7	Post installation check	25	9.2	Installation bracket for FMU 40/41 83
4	Wiring	26	9.3	Adapter flange 84
4.1	Electrical connection	26	9.4	Cantilever 85
4.2	Wiring with Foundation Fieldbus plug	28	9.5	Mounting Frame 86
4.3	Cable specifications Foundation Fieldbus	28	9.6	Wall Bracket 86
4.4	Supply voltage	28	9.7	Mounting bracket for FMU 42/43/44 87
4.5	Recommended connection	29	9.8	Commubox FXA291 87
4.6	Post connection check	29	9.9	ToF Adapter FXA291 87
5	Operation	30	9.10	Remote display FHX40 88
5.1	Operating options	30	10	Technical Data
5.2	Operation with the display and operating module VU331	32	10.1	Technical data at a glance 89
5.3	Operation with an Endress+Hauser operating program 36		11	Appendix
5.4	Operation with a FOUNDATION Fieldbus configuration program	40	11.1	Operating menu 94
5.5	Operation with the handheld terminal DXR375/FC375 42		11.2	Block model of the Prosonic M 96
6	Commissioning	44	11.3	Resource block 97
6.1	Function check	44	11.4	Sensor Block 98
6.2	Unlocking the device	44	11.5	Diagnostic Block 101
6.3	Resetting the device	46	11.6	Display Block 102
6.4	Commissioning by the display and operating module VU331	48	11.7	Analog input block 103
			11.8	List of start indices 107
			11.9	Measuring principle 108
			Index	110

1 Safety instructions

1.1 Designated use

The Prosonic M is a compact measuring device for continuous, non-contact level measurement. Depending on the sensor, the measuring range is up to 15 m in fluids and up to 7 m in bulk solids. By using the linearisation function, the Prosonic M can also be used for flow measurements in open channels and measuring weirs.

1.2 Installation, commissioning, operation

The Prosonic M is fail-safe and is constructed to the state-of-the-art. It meets the appropriate standards and EC directives. However, if you use it improperly or other than for its designated use, it may pose application-specific hazards, e.g. product overflow due to incorrect installation or configuration. Installation, electrical connection, start-up, operation and maintenance of the measuring device must therefore be carried out exclusively by trained specialists authorised by the system operator. Technical personnel must have read and understood these operating instructions and must adhere to them. You may only undertake modifications or repair work to the device when it is expressly permitted by the operating instructions.

1.3 Hazardous area

Measuring systems for use in hazardous environments are accompanied by separate "Ex documentation", which is an integral part of this Operating Manual. Strict compliance with the installation instructions and ratings as stated in this supplementary documentation is mandatory.

- Ensure that all personnel are suitably qualified.
- Observe the specifications in the certificate as well as national and local standards and regulations.


1.4 Notes on safety conventions and symbols

In order to highlight safety-relevant or alternative operating procedures in the manual, the following conventions have been used, each indicated by a corresponding symbol in the margin.

Safety conventions	
	Warning! A warning highlights actions or procedures which, if not performed correctly, will lead to personal injury, a safety hazard or destruction of the instrument
	Caution! Caution highlights actions or procedures which, if not performed correctly, may lead to personal injury or incorrect functioning of the instrument
	Note! A note highlights actions or procedures which, if not performed correctly, may indirectly affect operation or may lead to an instrument response which is not planned
Explosion protection	
	Device certified for use in explosion hazardous area If the device has this symbol embossed on its name plate it can be installed in an explosion hazardous area
	Explosion hazardous area Symbol used in drawings to indicate explosion hazardous areas. Devices located in and wiring entering areas with the designation “explosion hazardous areas” must conform with the stated type of protection.
	Safe area (non-explosion hazardous area) Symbol used in drawings to indicate, if necessary, non-explosion hazardous areas. Devices located in safe areas still require a certificate if their outputs run into explosion hazardous areas
Electrical symbols	
	Direct voltage A terminal to which or from which a direct current or voltage may be applied or supplied
	Alternating voltage A terminal to which or from which an alternating (sine-wave) current or voltage may be applied or supplied
	Grounded terminal A grounded terminal, which as far as the operator is concerned, is already grounded by means of an earth grounding system
	Protective grounding (earth) terminal A terminal which must be connected to earth ground prior to making any other connection to the equipment
	Equipotential connection (earth bonding) A connection made to the plant grounding system which may be of type e.g. neutral star or equipotential line according to national or company practice
	Temperature resistance of the connection cables States, that the connection cables must be resistant to a temperature of at least 85 °C.

2 Identification

2.1 Nameplate



1: Order Code; 2: Serial number; 3: Designation according to Directive 94/9/EC and designation of the type of protection (only for certified device variants); 4: Reference to additional safety-relevant documentation (only for certified device variants); 5: Communication variant and supply voltage (the appropriate option is highlighted)

2.2 Product structure FMU 40

Certificates				
	A			Variant for non-hazardous area
	E			NEPSI Ex nA II T6
	G			ATEX II 3G EEx nA II T6
	I			NEPSI Ex ia IIC T6
	J			NEPSI Ex d(ia) IIC T6
	K			TIIS Ex ia II C T6
	N			CSA General Purpose
	Q			NEPSI DIP
	S			FM IS Cl. I,II,III Div. 1 Gr. A-G / NI Cl. I Div. 2
	T			FM XP Cl. I,II,III Div. 1 Gr. A-G
	U			CSA IS Cl. I,II,III Div. 1 Gr. A-G / NI Cl. I Div. 2
	V			CSA XP Cl. I,II,III Div. 1 Gr. A-G
	1			ATEX II 1/2 G or II 2 G; EEX ia IIC T6
	2			ATEX II 1/2D, Alu blind cover
	4			ATEX II 1/2 G or II 2 G; EEX d [ia] IIC T6
	5			ATEX II 1/3D
	Y			Special certificate
Process connection				
	R			G 1½" thread ISO 228
	N			NPT 1½" - 11,5 thread
	Y			Special version
Power supply/communication				
	B			2 wire, 4...20mA-loop/HART
	H			4 wire, 10,5...32VDC / 4-20mA HART
	G			4 wire, 90...253VAC / 4-20mA HART
	D			2 wire, PROFIBUS PA
	F			2 wire, Foundation Fieldbus
	Y			Special version
Display / on-site operation				
	1			Without LC display
	2			With LC display VU 331 incl. on-site operation
	3			Prepared for remote display FHX 40
	9			Special version
Housing				
	A			Aluminium F12 housing coated to IP 68
	C			Aluminium T12 housing coated to IP 68; with separate terminal compartment
	D			Aluminium T12 housing coated to IP 68; with separate terminal compartment; with overvoltage protection
	9			Special version
Screw union/entry				
	2			M20x1.5 screw union
	3			G 1/2" entry
	4			NPT 1/2" entry
	5			M12 PROFIBUS-PA plug-in connector
	6			7/8" FF plug
	9			Special version
FMU 40 -				Product designation

2.3 Product structure FMU 41

Certificates				
	A			Variant for non-hazardous area
	E			NEPSI Ex nA II T6
	G			ATEX II 3G EEx nA II T6
	I			NEPSI Ex ia IIC T6
	J			NEPSI Ex d(Ia) IIC T6
	K			TIIS Ex ia II C T6
	N			CSA General Purpose
	Q			NEPSI DIP
	S			FM IS Cl. I,II,III Div. 1 Gr. A-G / NI Cl. I Div. 2
	T			FM XP Cl. I,II,III Div. 1 Gr. A-G
	U			CSA IS Cl. I,II,III Div. 1 Gr. A-G / NI Cl. I Div. 2
	V			CSA XP Cl. I,II,III Div. 1 Gr. A-G
	1			ATEX II 1/2 G or II 2 G; EEX ia IIC T6
	2			ATEX II 1/2D, Alu blind cover
	4			ATEX II 1/2 G or II 2 G; EEX d [ia] IIC T6
	5			ATEX II 1/3D
	Y			Special certificate
Process connection				
	R			G 2" thread ISO 228
	N			NPT 2" – 11,5 thread
	Y			Special version
Power supply/communication				
	B			2 wire, 4...20mA-loop/HART
	H			4 wire, 10,5...32VDC / 4-20mA HART
	G			4 wire, 90...253VAC / 4-20mA HART
	D			2 wire, PROFIBUS PA
	F			2 wire, Foundation Fieldbus
	Y			Special version
Display / on-site operation				
	1			Without LC display
	2			With LC display VU 331 incl. on-site operation
	3			Prepared for remote display FHX 40
	9			Special version
Housing				
	A			Aluminium F12 housing coated to IP 68
	C			Aluminium T12 housing coated to IP 68 with separate terminal compartment
	D			Aluminium T12 housing coated to IP 68; with separate terminal compartment; with overvoltage protection
	9			Special version
Screw union/entry				
	2			M20x1.5 screw union
	3			G 1/2" entry
	4			NPT 1/2" entry
	5			M12 PROFIBUS-PA plug-in connector
	6			7/8" FF plug
	9			Special version
FMU 41 -				Product designation

2.4 Product structure FMU 42

Certificates				
A	Variant for non-hazardous area			
E	NEPSI Ex nA II T6			
G	ATEX II 3G EEx nA II T6			
I	NEPSI Ex ia IIC T6			
J	NEPSI Ex d (Ia) IIC T6			
K	TIIS Ex ia II C T6 (in preparation)			
N	CSA General Purpose			
Q	NEPSI DIP			
S	FM IS Cl. I,II,III Div. 1 Gr. A-G / NI Cl. I Div. 2			
T	FM XP Cl. I,II,III Div. 1 Gr. A-G			
U	CSA IS Cl. I,II,III Div. 1 Gr. A-G / NI Cl. I Div. 2			
V	CSA XP Cl. I,II,III Div. 1 Gr. A-G			
1	ATEX II 1/2 G EEX ia IIC T6			
2	ATEX II 1/2 D, Alu bond cover			
4	ATEX II 1/2 G EEX d [ia] IIC T6			
5	ATEX II 1/3D			
Y	Special certificate			
Process connection				
M	Mounting bracket FAU20			
P	UNI flange 3"/DN80/80, PP, max. 2.5bar abs./ 36psia suitable for 3" 150lbs / DN80 PN16 / 10K 80			
Q	UNI flange 3"/DN80/80, PVDF, max. 2.5bar abs./ 36psia suitable for 3" 150lbs / DN80 PN16 / 10K 80			
S	UNI flange 3"/DN80/80, 316L, max. 2.5bar abs./ 36psia suitable for 3" 150lbs / DN80 PN16 / 10K 80			
T	UNI flange 4"/DN100/100, PP, max. 2.5bar abs./ 36psia suitable for 4" 150lbs / DN100 PN16 / 10K100			
U	UNI flange 4"/DN100/100, PVDF, max. 2.5bar abs./ 36psia suitable for 4" 150lbs / DN100 PN16 / 10K100			
V	UNI flange 4"/DN100/100, 316L, max. 2.5bar abs./ 36psia suitable for 4" 150lbs / DN100 PN16 / 10K100			
Y	Special version			
Power supply/communication				
B	2 wire, 4...20mA-loop/HART			
H	4 wire, 10,5...32VDC / 4-20mA HART			
G	4 wire, 90...253VAC / 4-20mA HART			
D	2 wire, PROFIBUS PA			
F	2 wire, Foundation Fieldbus			
Y	Special version			
Display / on-site operation				
1	Without LC display			
2	With LC display VU 331 incl. on-site operation			
3	Prepared for remote display FHX 40			
9	Special version			
Housing				
A	Aluminium F12 housing coated to IP 68			
C	Aluminium T12 housing coated to IP 68, with separate terminal compartment			
D	Aluminium T 12 housing coated to IP 68, with separate terminal compartment; with overvoltage protection			
Y	Special version			
Gland/Entry				
2	M20x1.5 gland			
3	G 1/2" entry			
4	NPT 1/2" entry			
5	M12 PROFIBUS-PA plug			
6	7/8" FF plug			
9	Special version			

[illegible]

2.5 Product structure FMU 43

Certificates					
	A				Variant for non-hazardous area
	M				FM DIP Class II, III, Div. 1, Gr. E,F,G NI
	N				CSA General Purpose
	P				CSA DIP, Class II, III, Div. 1, Gr. E,F,G NI
	Q				NEPSI DIP
	2				ATEX II 1/2 D or II 2 D, Aluminium Deckel
	5				ATEX II 1/3 D or II 3 D, Sichtdeckel
	Y				Special version
Process connection/material					
	P				Flange DN 100/ANSI 4"/JIS 16K100, PP (universal slip-on flange included)
	S				Flange DN 100/ANSI 4"/JIS 16K100, SS 316TI (universal slip-on flange included)
	K				Without slip-on flange/without mounting bracket (customer mounting equipment)
	M				With mounting bracket
	Y				Special version
Power supply/communication					
	H				4 wire, 10,5...32VDC / 4-20mA HART
	G				4 wire, 90...253VAC / 4-20mA HART
	D				2 wire, PROFIBUS PA
	F				2 wire, Foundation Fieldbus
	Y				Special version
Display / on-site operation					
	1				Without LC display
	2				With LC display VU 331 incl. on-site operation
	3				Prepared for remote display FHX 40
	9				Special version
Housing					
	A				Aluminium F12 housing coated to IP 68
	9				Special version
Screw union/entry					
	2				M20x1.5 screw union
	3				G 1/2" entry
	4				NPT 1/2" entry
	5				M12 PROFIBUS-PA plug-in connector
	6				7/8" FF plug
	9				Special version
FMU 43 -					Product designation

2.6 Product structure FMU 44

Approval			
	A	Non-hazardous area	
	1	ATEX II 1/2G EEx ia IIC T6 (in preparation)	
	4	ATEX II 1/2G EEx d (ia) IIC T6 (in preparation)	
	G	ATEX II 3 G EEx nA II T6 (in preparation)	
	2	ATEX II 1/2 D, Alu blind cover (in preparation)	
	5	ATEX II 1/3 D	
	S	FM IS Cl.I,II,III Div.1 Gr.A-G, NI Cl.I Div.2 (in preparation)	
	T	FM XP Cl.I,II,III Div.1 Gr.A-G (in preparation)	
	N	CSA General Purpose	
	U	CSA IS Cl.I,II,III Div.1 Gr.A-G, NI Cl.I Div.2	
	V	CSA XP Cl.I,II,III Div.1 Gr.A-G	
	K	TIIS EEx ia IIC T6 (in preparation)	
	I	NEPSI Ex ia IIC T6 (in preparation)	
	J	NEPSI Ex d(ia) IIC T6 (in preparation)	
	E	NEPSI Ex nA II T6 (in preparation)	
	Q	NEPSI DIP (in preparation)	
	Y	Special version, to be specified	
Process connection			
	A	8" 150lbs FF, 316L, max 2.5bar abs./36psia	
	E	UNI flange 6"/DN150/150, PP, max 2.5bar abs./ 36psia, suitable for 6" 150lbs / DN150 PN16 / 10K 150	
	F	UNI flange 6"/DN150/150, PVDF, max 2.5bar abs./36psia, suitable for 6" 150lbs /DN150 PN16 / 10K 150	
	G	UNI flange 6"/DN150/150, 316L, max 2.5bar abs. 36psia, suitable for 6" 150lbs / DN150 PN16 / 10K 150	
	H	UNI flange DN200/200, PP, max 2.5bar abs./ 36 psia, suitable for DN200 PN16 / 10K 200	
	J	UNI flange DN200/200, PVDF, max 2.5bar abs./ 36psia, suitable for DN200 PN16 / 10K 200	
	K	UNI flange DN200/200, 316L, max 2.5bar abs./ 36psia, suitable for DN200 PN16 / 10K 200	
	L	8" 150lbs FF, PP, max 2.5bar abs./ 36psia	
	M	Mounting bracket FAU20	
	N	8" 150lbs FF, PVDF, max 2.5bar abs./ 36psia	
	T	UNI flange 4"/DN100/100, PP, max 2.5bar abs./ 36psia, suitable for 4" 150lbs / DN100 PN16 / 10K 100	
	U	UNI flange 4"/DN100/100, PVDF, max. 2.5bar abs./ 36 psia, suitable for 4" 150lbs / DN100 PN16 / 10K 100	
	V	UNI flange 4"/DN100/100, 316L, max 2.5bar abs./ 36psia, suitable for 4" 150lbs / DN100 PN16 / 10K 100	
	Y	Special version, to be specified	
Power supply; Output			
	B	2-wire; 4-20mA HART	
	D	2-wire; PROFIBUS PA	
	F	2-wire; FOUNDATION Fieldbus	
	G	4-wire 90-250VAC; 4-20mA HART	
	H	4-wire 10.5-32VDC; 4-20mA HART	
	Y	Special version, to be specified	
Operation			
	1	w/o display, via communication	
	2	4-line display VU331, Envelope curve display on site	
	3	Prepared for FHX40, Remote display (accessory)	
	9	Special version, to be specified	
FMU 44 -			product designation, part 1

Housing									
						A	F12 Alu, coated IP68 NEMA6P		
						C	T12 Alu, coated IP68 NEMA6P, Separate conn. compartment		
						D	T12 Alu, coated IP68 NEMA6P + OVP, Sep. conn. compartment, OVP = overvoltage protection		
						9	Special version, to be specified		
Cable entry									
						2	Gland M20 (EEx d > thread M20)		
						3	Thread G1/2		
						4	Thread NPT 1/2		
						5	Plug M12		
						6	Plug 7/8"		
						9	Special version, to be specified		
Process Sealing Sensor/ Flange									
						2	Viton		
						3	EPDM		
						9	Special version, to be specified		
Additional option									
						A	Basic version		
						Y	Special version, to be specified		
FMU 44 –							complete product designation		

2.7 Scope of delivery

2.7.1 Instrument and accessories

- Instrument according to the version ordered
- "ToF Tool – FieldTool Package" (2 CD-ROMs)
- for FMU 40/41 in the versions FMU 40 *R**** and FMU 41 *R****: counter nut (PC)
- for FMU 40/41: sealing ring (EPDM)
- for gland M20x1.5:
 - 1 cable gland for 2-wire instruments
 - 2 cable glands for 4-wire instrumentsThe cable glands are mounted on delivery.

2.7.2 Supplied documentation

Short instructions (KA 183F, in the instrument)

intended as a memory jogger for users who are familiar with the operating concept of Endress+Hauser Time-of-Flight instruments.

Operating instructions (BA 239F, this booklet)

This describes the installation and commissioning of the Prosonic M. The operating menu includes all the functions which are required for standard measurement tasks. Any additional functions are **not** included.

Description of Instrument Functions (BA 240F)

contains a detailed description of all the functions of the Prosonic M. You can find this document as a pdf file on the supplied ToF Tool – FieldTool CD-ROM 1.

Safety instructions

Additional safety instructions (XA, ZE, ZD) are supplied with certified device versions. Refer to the nameplate for the names of the safety instructions that apply to your device version.

2.8 Certificates and approvals

CE mark, declaration of conformity

The device is designed to meet state-of-the-art safety requirements, has been tested and left the factory in a condition in which it is safe to operate. The device complies with the applicable standards and regulations as listed in the EC declaration of conformity and thus complies with the statutory requirements of the EC directives. Endress+Hauser confirms the successful testing of the device by affixing to it the CE mark.

2.9 Registered trademarks

ToF®

Registered trademark of the company Endress+Hauser GmbH+Co. KG, Maulburg, Germany

PulseMaster®

Registered trademark of the company Endress+Hauser GmbH+Co. KG, Maulburg, Germany

FOUNDATION™ Fieldbus

Registered trademark of Fieldbus Foundation Austin, Texas, USA

3 Installation

3.1 Design; dimensions

3.1.1 FMU40, FMU41






Abb. 1: Dimensions in mm (inch)

3.1.2 FMU42, FMU44 with slip-on flange



Dimensions in mm (inch)

3.1.3 FMU42, FMU44 with mounting bracket



Dimensions in mm (inch)

3.1.4 FMU43




Abb. 2: Dimensions in mm (inch);
A: with slip-on flange; B: with mounting bracket

3.1.5 Mounting bracket for FMU42, FMU43 and FMU44





Abb. 3: Dimensions in mm (inch)


3.1.6 Flanges for FMU42 and FMU44



suitable for	A	B	C	D	E	number of boreholes
3" 150lbs / DN80 PN16 / 10K 80	150 mm (5,91")	160 mm (6,30")	200 mm (7,87")	19 mm (0,75")	45°	8
4" 150 lbs / DN100 PN16 / 10K 100	175 mm (6,90")	190,5 mm (7,50")	228,6 mm (9,00")	19 mm (0,75")	45°	8
6" 150 lbs / DN150 PN16 / 10 K 150	240 mm (9,45")	241,3 mm (9,50")	285 mm (11,22")	23 mm (0,91")	45°	8
8" 150 lbs	298,5 mm (11,75")	298,5 mm (11,75")	342,9 mm (13,50")	22, 5 mm (0,89")	45°	8
DN200 PN16 / 10 K 200	290 mm (11,42")	295 mm (11,61")	340 mm (13,39")	23 mm (0,91")	30°	12


3.2 Installation variants

3.2.1 Installation variants FMU 40, FMU 41




For installation bracket or adapter flange s. chapter "Accessories".

3.2.2 Installation variants FMU42, FMU44




3.2.3 Installation variants FMU 43



3.3 Installation conditions

3.3.1 Installation conditions for level measurements




L00-FMU4xxxx-17-00-00-de-005

- Do not install the sensor in the middle of the tank (3). We recommend leaving a distance between the sensor and the tank wall (1) measuring 1/6 of the tank diameter.
- Use a protective cover, in order to protect the device from direct sun or rain (2).
- Avoid measurements through the filling curtain (4).
- Make sure that equipment (5) such as limit switches, temperature sensors, etc. are not located within the emitting angle α . In particular, symmetrical equipment (6) such as heating coils, baffles etc. can influence measurement.
- Align the sensor so that it is vertical to the product surface (7).
- Never install two ultrasonic measuring devices in a tank, as the two signals may affect each other.
- To estimate the detection range, use the 3 dB emitting angle α .

Sensor	α	$L_{\max}$	$r_{\max}$
FMU40	11°	5 m	0.48 m
FMU41	11°	8 m	0.77 m
FMU42	9°	10 m	0.79 m
FMU43	6°	15 m	0.79 m
FMU44	11°	20 m	1.93 m

3.3.2 Installation in narrow shafts

In narrow shafts with strong interference echoes, we recommend using an ultrasound guide pipe (e.g. PE or PVC wastewater pipe) with a minimum diameter of 100 mm. Make sure that the pipe is not soiled by accumulated dirt. If necessary, clean the pipe at regular intervals.




L00-FMU4xxxx-17-00-00-en-010

3.3.3 Installation conditions for flow measurements


- Install the Prosonic M at the inflow side, as close above the maximum water level $H_{\max}$ as possible (take into account the blocking distance BD).
- Position the Prosonic M in the middle of the channel or weir.
- Align the sensor membrane parallel to the water surface.
- Keep to the installation distance of the channel or weir.
- You can enter the "Flow to Level" linearisation curve ("Q/h curve") using ToF Tool or manually via the on-site display.

Example: Khafagi-Venturi flume



L00-FMU14xxxx-17-00-00-en-003

Example: Triangular weir




100-FM14xxxx-17-00-00-en-012

3.4 Measuring range

3.4.1 Blocking distance, Nozzle mounting

Install the Prosonic M at a height so that the blocking distance BD is not undershot, even at maximum fill level. Use a pipe nozzle if you cannot maintain the blocking distance in any other way. The interior of the nozzle must be smooth and may not contain any edges or welded joints. In particular, there should be no burr on the inside of the tank side nozzle end. Note the specified limits for nozzle diameter and length. To minimise disturbing factors, we recommend an angled socket edge (ideally 45°).



L00-FMU4xxxx-17-00-00-en-004

BD: blocking distance; **SD:** safety distance; **E:** empty calibration; **F:** full calibration (span); **D:** nozzle diameter; **L:** nozzle length

	Maximum nozzle length[mm]				
Nozzle diameter	FMU40	FMU41	FMU42	FMU43	FMU44
DN50/2"	80				
DN80/3"	240	240	250		
DN100/4"	300	300	300	300	
DN150/6"	400	400	400	300	400
DN200/8"	400	400	400	300	400
DN250/10"	400	400	400	300	400
DN300/12"	400	400	400	300	400
Emitting angle α	11°	11°	9°	6°	11°
Blocking distance [m]	0,25	0,35	0,4	0,6	0,5
Max. range [m] in liquids	5	8	10	15	20
Max. range [m] in solids	2	3,5	5	7	10



Caution!

If the blocking distance is undershot, it may cause device malfunction.

3.4.2 Safety distance

If the level rises to the safety distance SD, the device switches to warning or alarm status. The size of SD can be set freely in the **"Safety distance" (015)** function. The **"in safety distance" (016)** function defines how the device reacts if the level enters the safety distance.

There are three options:

- **Warning:** The device outputs an error message but continues measurement.
- **Alarm:** The device outputs an error message. The output signal assumes the value defined in the **"Output on alarm" (011)** function (MAX, MIN, user-specific value or holds the last value). As soon as the level drops below the safety distance, the device recommences measurement.
- **Self holding:** The device reacts in the same way as for an alarm. However, the alarm condition continues after the level drops below the safety distance. The device only recommences measurement when you cancel the alarm using the **"Ackn. alarm" (017)** function.


3.4.3 Range

The sensor range is dependent on the measuring conditions. Refer to Technical Information TI 365F/00/en for an estimation. The maximum range is shown in the above diagram (valid for good conditions).

Sensor	maximum range
FMU40	5 m
FMU41	8 m
FMU42	10 m
FMU43	15 m
FMU44	20 m

3.5 Installation hint for FMU 40/41


Screw the Prosonic M at the screw-in piece using an 60 AF spanner.
Maximum torque: 20 Nm.



3.6 Turn housing

After mounting, the housing can be turned 350° in order to simplify access to the display and the terminal compartment. Proceed as follows to turn the housing to the required position:

- Undo the fixing screws (1)
- Turn the housing (2) in the required direction
- Tighten up the fixing screws (1). Maximum torque 0.5 Nm.
- Loctite can be used for securing the screw.



3.7 Post installation check

After installing the device, carry out the following checks:

- Is the device damaged (visual inspection)?
- Does the device correspond to the measuring point specifications for process temperature, process pressure, ambient temperature, measuring range etc.
- If available: Are the measuring point number and labelling correct (visual inspection)?
- Is the measuring device sufficiently protected against precipitation and direct sunlight?
- Are the cable glands tightened correctly?
- After aligning the housing, check the process seal at the nozzle or flange.

4 Wiring

4.1 Electrical connection



Caution!

Before connection please note the following:

- The power supply must be identical to the data on the nameplate.
- Switch off power supply before connecting up the instrument.
- Connect equipotential bonding to transmitter ground terminal before connecting up the instrument (s. section "Potential matching")



Warning!

When you use the measuring system in hazardous areas, make sure to comply with national standards and the specifications in the safety instructions (XA's). Make sure you use the specified cable gland.

4.1.1 Wiring in the housing F12


1. Unscrew housing cover (1).
2. Remove display (2) if fitted.
3. Remove cover plate (3) from terminal compartment.
4. Pull out terminal module (4) slightly using pulling loop.
5. Insert cable (5) through gland (6).



Caution!

If possible, insert the cable from above and let a draining loop in order to avoid intrusion of humidity.

6. Connect cable screen to the grounding terminal (7) within the terminal compartment.
7. Make connection according to terminal assignment (see below).
8. Re-insert terminal module (4).
9. Tighten cable gland (6).
10. Tighten screws on cover plate (3).
11. Insert display (2) if fitted.
12. Screw on housing cover (1).
13. Switch on power supply.




L00-FMU14xxxx-04-00-00-yy-008

4.1.2 Wiring in the housing T12


1. Unscrew the cover (1) of the separate connection room.
2. Insert cable (2) through gland (3).
- ⚠ Caution!

If possible, insert the cable from above and let a draining loop in order to avoid intrusion of humidity.
3. Connect cable screen to the grounding terminal (4) within the connection room.
4. Make connection according to the terminal assignment (see below).
5. Tighten cable gland (3).
6. Screw on housing cover (1).
7. Switch on power supply.



100-FM14xxxx-04-00-00-yy-009


4.1.3 Terminal assignment



100-FMxxxx-04-00-00-en-013

4.2 Wiring with Foundation Fieldbus plug

1. Insert plug (1) into bushing (2).
2. Screw firmly.
3. Ground instrument according to the desired safety concept.



L00-FMU4xxxx-04-00-00-yy-011

4.2.1 Pin assignment of the 7/8" plug connector (FOUNDATION Fieldbus plug)

The diagram shows a hexagonal connector with four pins. Pin 1 is labeled with a minus sign (-). Pin 2 is labeled with a plus sign (+). Pin 3 is labeled 'nc' (not connected). Pin 4 is labeled with a ground symbol (a circle with a cross). The pins are arranged in a circle around a central point.	Pin	Meaning
	1	FF -
	2	FF +
	3	not connected
	4	ground

L00-FMxxxxxx-04-00-00-yy-017

4.3 Cable specifications Foundation Fieldbus

Twisted, shielded pairs must be used. The cable specifications can be taken from the FF specification or IEC 61158-2. The following have been found suitable:

- Non-Ex-area:
- Siemens 6XV1 830-5BH10,
 - Belden 3076F,
 - Kerpen CEL-PE/OSCR/PVC/FRLA FB-02YS(ST)YFL.
- Ex-area:
- Siemens 6XV1 830-5AH10,
 - Belden 3076F,
 - Kerpen CEL-PE/OSCR/PVC/FRLA FB-02YS(ST)YFL.


4.4 Supply voltage

The following values are the voltages across the terminals directly at the instrument:

Type	minimum terminal voltage	maximum terminal voltage
standard	9 V	32 V
EEx ia (FISCO model)	9 V	17,5 V
EEx ia (Entity concept)	9 V	24 V

The current consumption is approx. 15 mA for the range of voltages given above.

4.5 Recommended connection



L00-FMU4xxxx-17-00-00-yy-014

1: external ground terminal of the transmitter

For maximum EMC protection please observe the following points:

- As the metal housing of the Prosonic M is isolated from the tank by the plastic sensor, a low-impedance connection between the housing and tank/bracket/flange should be installed in order to ensure electromagnetic compatibility (EMC).
For optimum EMC the connection should be as short as possible. Ideally, a ground strap should be used.
- The continuity of the cable screening between tapping points must be ensured.
- If potential equalisation is present between the individual grounding points, ground the screening at each cable end or connect it to the device housing (as short as possible).
- If there are large differences in potential between grounding points, the grounding should run via a capacitor that is suitable for high frequency use (e.g. ceramic 10 nF/250 V~).



Caution!

Applications, which are subject to the explosion prevention, permit only under special conditions the repeated grounding of the protective screen, see to EN 60 079-14..

4.6 Post connection check

After wiring the device, carry out the following checks:

- Are the terminals correctly assigned?
- Is the cable gland tight?
- If available: Is the Foundation Fieldbus connector screwed tight?
- Is the housing cover fully screwed on?
- If power supply available: Does a display appear on the display module?

5 Operation


This chapter gives an overview of the different operating options for the device. The different methods of parameter access are described and the preconditions for each method are stated. The meaning of the parameters is not described in this chapter. Instead, refer to:

- Chapter 6: "Commissioning"
- Operating Instructions BA240F: "Prosonic M – Description of Instrument Functions"

This chapter contains the following sections:

- 5.1 Operating options
- 5.2 Operation with the display and operating module VU331
- 5.3 Operation with an Endress+Hauser operating software
- 5.4 Operation with a FOUNDATION Fieldbus configuration software
- 5.5 Operation with the handheld terminal DXR375/FC375

5.1 Operating options



L00-FMxxxxxx-14-00-06-de-011

5.1.1 On-site operation


Options for on-site operation

- Display and operating module VU331
- Endress+Hauser operating software ("ToF Tool - FieldTool Package" or "FieldCare")

Parameter access by on-site operation

The following parameters can be accessed by on-site operation:

- Parameters of the device specific blocks (Sensor Block, Diagnostic Block, Display Block)
- Endress+Hauser service parameters
- in the Resource Block: "Device Tag", "Device ID", "Device Revision", "DD Revision" (read only)



The highlighted parameters can be edited by on-site operation.

5.1.2 Remote operation


Options for remote operation

- FOUNDATION Fieldbus configuration tool (e.g. DeltaV or ControlCare)
- Handheld terminal DXR375/FC375

Parameter access by remote operation

The following parameters can be accessed by remote operation:


- Parameters of the device specific blocks (Sensor Block, Diagnostic Block, Display Block)
- Parameters of the FOUNDATION Fieldbus function blocks



The highlighted parameters can be edited by remote operation.


5.2 Operation with the display and operating module VU331

The LCD module VU 331 for display and operation is located beneath the housing cover. The measured value is legible through the glass in the cover. Open the cover to operate the device.



100-FMxxxxx-07-00-00-en-001

5.2.1 Display appearance



100-FMxxxxx-07-00-00-en-002

In the measured value display, the bargraph corresponds to the output. The bargraph is segmented in 10 bars. Each completely filled bar represents a change of 10% of the adjusted span.

5.2.2 Display symbols

The following table describes the symbols that appear on the liquid crystal display:

Sybmol	Meaning
	ALARM_SYMBOL This alarm symbol appears when the instrument is in an alarm state. If the symbol flashes, this indicates a warning.
	LOCK_SYMBOL This lock symbol appears when the instrument is locked, i.e. if no input is possible.
	COM_SYMBOL This communication symbol appears when a data transmission via e.g. HART, PROFIBUS PA or FOUNDATION Fieldbus is in progress.
	SIMULATION_SWITCH_ENABLE This communication symbol appears when simulation in FOUNDATION Fieldbus is enabled via the DIP switch.


5.2.3 Function of the keys

Key(s)	Meaning
 or 	Navigate upwards in the selection list Edit numeric value within a function
 or 	Navigate downwards in the selection list Edit numeric value within a function
 or 	Navigate to the left within a function group
	Navigate to the right within a function group, confirmation.
 and  or  and 	Contrast settings of the LCD
 and  and 	Hardware lock / unlock After a hardware lock, an operation of the instrument via display or communication is not possible! The hardware can only be unlocked via the display. An unlock parameter must be entered to do so.

5.2.4 The operating menu

Function codes

For easy orientation within the function menus, for each function a position is shown on the display.



L00-FMU4xxxx-07-00-00-en-001

The first two digits identify the function group:

- **basic setup** 00
- **safety settings** 01
- **linearisation** 04


...

The third digit numbers the individual functions within the function group:

- | | | | | |
|----------------------|----|---|--------------------------|-----|
| ■ basic setup | 00 | → | ■ tank shape | 002 |
| | | | ■ medium property | 003 |
| | | | ■ process cond. | 004 |
| | | | ... | |

Hereafter the position is always given in brackets (e.g. "**tank shape**" (002)) after the described function.

Navigation within the menu



L00-FMU4xxxx-19-00-00-en-018

1. Change from Measured Value Display to **Group Selection** by pressing **E**.
2. Press **-** or **+** to select the required **Function Group** and confirm by pressing **E**. The active selection is marked by a **_** in front of the menu text.
3. Activate Edit mode with **+** or **-**.

Selection menus

- a. Select the required **Parameter** in selected **function** with **-** oder **+**.
- b. **E** confirms selection; **_** appears in front of the selected parameter.
- c. **E** confirms the edited value; system quits edit mode.
- d. **+** and **-** (= **↵**) interrupts selection; system quits edit mode.

Typing in numerals and text

- a. Press **+** or **-** to edit the first character of the **numeral / text**.
 - b. **E** positions the cursor at the next character; continue with a. until you have completed your input.
 - c. If a **↵** symbol appears at the cursor, press **E** to accept the value entered; system quits edit mode.
 - d. If a **←** symbol appears at the cursor, press **E** to return to the previous character (e.g. for correction of entries).
 - e. **+** and **-** (= **↵**) interrupts selection; system quits edit mode.
4. Press **E** to select the next **function**.
 5. Press **+** and **-** (= **↵**) once; return to previous **function**. Press **+** and **-** (= **↵**) twice; return to **Group Selection**.
 6. Press **+** and **-** (= **↵**) to return to **Measured value display**.

5.3 Operation with an Endress+Hauser operating program

5.3.1 ToF Tool – Fieldtool Package

The ToF Tool is a graphic and menu-guided operating program for measuring devices from Endress+Hauser. It is used for the commissioning, data storage, signal analysis and documentation of the devices. The following operating systems are supported: WinNT4.0, Win2000 and Windows XP. You can set the parameters of the device specific blocks via the ToF Tool.

The ToF Tool supports the following functions:

- Configuration of transmitters in online operation
- Singal analysis via envelope curve
- Tank linearisation
- Loading and saving device data (upload/download)
- Documentation of the measuring point

Connection options:

- via the FXA193/FXA291 service interface



Note!

You can use the ToF Tool to configure the metrological parameters for devices with "FOUNDATION Fieldbus signal". You need an FF configuration program to be able to configure all the FF-specific parameters and to integrate the device into a FF network (see sections 5.1.1 and 5.1.2).

5.3.2 FieldCare


FieldCare is an Endress+Hauser asset management tool based on FDT technology. With FieldCare, you can configure all Endress+Hauser devices as well as devices from other manufacturers that support the FDT standard. The following operating systems are supported: WinNT4.0, Win2000 and Windows XP.

Functions

FieldCare supports the following functions:


- Configuration of transmitters in online operation
- Singal analysis via envelope curve
- Tank linearisation
- Loading and saving device data (upload/download)
- Documentation of the measuring point

Connection with FXA193 (RS232C)




For details refer to Technical Information TI063D (FXA193).

Connection with FXA291 (USB)




For details refer to:
 Technical Information TI405C (Commubox FXA291)
 Operating Instructions KA271 (ToF Adapter FXA291)


Menu-guided commissioning



Signal analysis via envelope curve



Tank linearisation



5.4 Operation with a FOUNDATION Fieldbus configuration program

5.4.1 FOUNDATION Fieldbus configuration programs

The user can obtain special configuration and operating programs offered by different manufacturers for use in configuration. These can be used for configuring both the FOUNDATION Fieldbus functions and all the device-specific parameters. The predefined function blocks allow uniform access to all the network and fieldbus device data.

5.4.2 Device Description files

File names

You will need the following files for commissioning and network configuration:

- **Device Description files:** *.sym, *.ffo
These files describe the structure of the blocks and their parameters. They offer guided setups with the help of menus and methods.
- **Capability file:** *.cff
This file enables offline configuration and describes the device capability in terms of communication stack and function blocks.

The file names consist of the following parts:

- Device Revision (0C3)¹⁾
- DD Revision (0C4)¹⁾ (use the most current version)
- CFF Revision (use the most current version)

Example:

- Device Revision (0C3) = 03
- DD Revision (0C4) = 01
- CFF Revision = 02
- -> files to be used: "0301.sym", "0301.ffo", "030102.cff"

Directory structure

The files are normally stored in the following directory structure:

- /452B48/1011/*.sym
 *.ffo
 *.cff

The directory names have the following meaning:

- 452B48: manufacturer ID of Endress+Hauser
- 1011: device ID of Prosonic M

Source of supply

Host System	Source of supply for the Device Description and Network Configuration files
ABB (Field Controller 800) Allen Bradley (Control Logix) Endress+Hauser (ControlCare) Honeywell (Experion PKS) Invensys SMAR (System 302)	■ www.endress.de (-> Download -> Media type = "Software", "Device Drivers") ■ CD-ROM (Endress+Hauser order code: 56003896) ■ www.fieldbus.org
Emerson (Delta V)	■ www.easydeltav.com

1) "Device Revision" (0C3) and "DD Revision" (0C4) can be obtained through the display and operating module VU331. For details refer to section 5.2: "Operation with the display and operating module VU331"

Host System	Source of supply for the Device Description and Network Configuration files
Yokogawa (CENTUM CS 3000)	■ www.yokogawa.com

5.4.3 Representation of parameters

A FOUNDATION Fieldbus configuration tool offers two types of parameter representation:

- **Representation by parameter name**

Examples: "PAROPERATIONCODE", "PARRESET"

- **Representation by parameter label**

(identical to the labels on the display module VU331 and in an Endress+Hauser operation tool)

Examples: "unlock parameter", "reset"

5.5 Operation with the handheld terminal DXR375/FC375

5.5.1 Connection

The handheld terminal is directly connected to the FOUNDATION Fieldbus communication line. An additional communication resistor is not required.


5.5.2 Device Descriptions

Make sure you have loaded the valid Device Description files (DDs). DDs can be downloaded from the internet at "www.fieldcommunicator.com". The DDs can also be updated by the update functionality of the DXR375/FC375.

5.5.3 User interface

The device parameters are arranged in blocks. The handheld terminal DXR375/FC375 uses this block structure to access the parameters. You can navigate within the structure by the arrow keys and the "Enter" key. Alternatively, you can use the touch-screen functionality of the handheld terminal for navigation. (Double-click on a name opens the respective block or parameter).

5.5.4 Example



100-FMU14xxxx-07-00-00-yy-010

6 Commissioning

This chapter consists of the following sections:

- 6.1 Function check
- 6.2 Unlocking the device
- 6.3 Parameter reset
- 6.4 Commissioning with display and operating module VU331
- 6.5 Commissioning with Endress+Hauser operating software
- 6.6 Commissioning with FOUNDATION Fieldbus configuration tool
- 6.7 Commissioning with handheld terminal DXR375/FC375

6.1 Function check

Make sure that all final checks have been completed before you start up your measuring point:


- Checklist “Post installation check” (see page → 25).
- Checklist “Post connection check” (see page → 29).

6.2 Unlocking the device

Before commissioning, make sure that the device is not locked against parameter changes. On delivery, the device is unlocked. In other cases, however, it may have been locked in one of the following ways:

6.2.1 DIP switch (under the housing cover)

Locking and unlocking



WP = on: parametrization locked
 WP = off: parametrization unlocked
 SIM = on: simulation possible in Analog Input Block by configuration tool
 SIM = off: simulation not possible in Analog Input Block by configuration tool

Parameters affected

Locking by the DIP switch affects **all** parameters.


6.2.2 Key combination (display and operating module VU331)

Locking

Press ,  and  simultaneously.

Unlocking

If you try to change a parameter, the following appears:



```
unlock parameter 0A4
& Hardware locked
```

L00-fmrx0a4-20-00-00-de-001

Press ,  and  simultaneously. The **"unlock parameter" (0A4)** function appears. Enter "2457". Now parameters can be changed.

Parameters affected

Locking by the key combination affects the following parameters:

- Parameters of the device specific blocks (Sensor Block, Diagnostic Block, Display Block)
- Endress+Hauser service parameters

6.2.3 Locking parameter

Locking

Enter a number other than "2457" into the **"unlock parameter" (0A4)** function. (FOUNDATION Fieldbus: Diagnostic Block, parameter PAROPERATIONMODE)

Unlocking

Enter **"2457"** into the **"unlock parameter" (0A4)** function. (FOUNDATION Fieldbus: Diagnostic Block, parameter PAROPERATIONMODE)

Parameters affected

Locking by the locking parameter affects the following parameters:

- Parameters of the device specific blocks (Sensor Block, Diagnostic Block, Display Block)
- Endress+Hauser service parameters


6.3 Resetting the device

It is advisable to reset the device parameters before the commissioning if you want to use a device with an unknown history.

6.3.1 Resetting the parameters of the FOUNDATION Fieldbus function blocks

Parameters affected

- all parameters of the FOUNDATION Fieldbus function blocks



Performing the reset

Resource Block, parameter RESTART; select the option "defaults".

6.3.2 Resetting the parameters of the transducer blocks



Caution!
A reset may lead to impairment of the measurement. As a rule, a basic calibration is required after a reset.




Note!
The default values of each parameter are shown in bold in the menu overview in the appendix.

In order to carry out the reset, enter the number "33333" in the **"reset" (0A3)** function in the **"diagnostics" (0A)** function group.
(FOUNDATION Fieldbus: **Diagnostic Block**, Parameter **PARRESET (reset)**)

Parameters affected

- all parameters of the device specific blocks (Sensor Block, Diagnostic Block, Display Block)



Effects of the reset

- All customer parameters are reset to their default values.
- Customer interference echo suppression is **not** deleted.

- Linearisation is switched to **"linear"**, but the table values are kept. The table can be switched back on in the **"linearisation" (04)** function group in the **"linearisation" (041)** function. (FOUNDATION Fieldbus: Sensor Block, Parameter PARLINEARISATION (linearisation))

Performing the reset

"diagnostics" (0A) function group, "reset" (0A3) function; enter "33333"
(FOUNDATION Fieldbus: Diagnostic Block, parameter PARRESET)

6.3.3 Resetting an interference echo suppression (tank map)

It is always advisable to reset the interference echo suppression (tank mapping) when:

- a device with an unknown history is used
- an incorrect suppression was input

Resetting the tank map with the VU331

1. In the **"extended calibr." (05)** function group select the **"selection" (050)** function.
2. Select **"extended map."**
3. Go to the **"cust. tank map" (055)** function and select the required option:
 - **"reset"**: deletes the existing tank map.
 - **"inactive"**: deactivates the tank map but does not delete it. It can be re-activated when required.
 - **"active"**: activates the tank map.

Resetting the tank map with an Endress+Hauser operating program

1. In the function group **"extended calibr."** select the **"cust. tank map" (055)** function.
2. Select the required option (**"reset"**, **"inactive"** or **"active"**)


Resetting the tank map with a FOUNDATION Fieldbus configuration tool

1. In the **Sensor Block** select the parameter **PARCUSTTANKMAP** (cust tank map).
2. Select the required option (**"reset"**, **"inactive"** or **"active"**).

6.4 Commissioning by the display and operating module VU331


6.4.1 Power up instrument

After switching on the supply voltage, the instrument is first initialised.




Then the following appear for approximately five seconds:

- Device type
- Software version
- Type of digital communication signal




Press **[E]** to exit this display.


On first power-up, you are requested to select the language for the display texts.



Then you are requested to select the unit of length for your measurements.



A measured value is displayed. This is NOT equivalent to the level in your tank. Firstly carry out a basic calibration.



Press **[E]** to switch to the group selection.
Press **[E]** again to start the basic calibration.




The **"Basic setup" (00)** function group lists all the functions which are required for a standard measurement task to commission the Prosonic M. When you have completed your input for a function, the next function appears automatically. In this way, you are guided through the complete calibration.

6.4.2 Application parameters

Function "tank shape" (002)

In this function, select one of the following options:



Function "medium property" (003)



Set the medium type in this function.




You have the following options:



- unknown (e.g. pasty media such as greases, creams, gels etc.)
- liquid
- solid, grain size < 4mm (fine)
- solid, grain size > 4mm (coarse)

Function "process conditions" (004)


For this function, you have the following options:

standard liquids	calm surface	turb. surface
For all fluid applications which do not fit in any of the following groups.	Storage tanks with immersion tube or bottom filling	Storage / accumulation tanks with uneven surface due to free filling, mixing nozzles or small bottom stirrers
	 L00-FMU4xxxx-14-00-00-xx-001	 L00-FMU4xxxx-14-00-00-xx-002
The filters and output damping are set to average values.	The averaging filters and output damping are set to large values. -> Stable measured value -> Accurate measurement -> Slow reaction time	Special filters for stabilising the input signal are activated. -> Stable measured value -> Medium reaction time

add. agitator	fast change	standard solid
Moving surfaces (poss. with vortex formation) due to agitators	Rapid level change, particularly in small tanks	For all bulk solids applications which do not fit in any of the following groups.
 L00-FMU4xxxx-14-00-00-xx-003	 L00-FMU4xxxx-14-00-00-xx-004	 L00-FMU4xxxx-14-00-00-xx-006
Special filters for stabilising the input signal are set to large values. -> Stable measured value -> Medium reaction time	The averaging filters are set to small values. -> Rapid reaction time -> Possibly unstable measured value	The filter and output damping are set to average values.

solid dusty	conveyor belt	Test: no filter
Dusty bulk solids	Bulk solids with rapid level change	All the filters can be switched off for purposes of service and diagnosis.
 L00-FMU4xxxx-14-00-00-xx-007	 L00-FMU4xxxx-14-00-00-xx-005	
The filters are set to detect even relatively weak signals.	The averaging filters are set to small values. -> Rapid reaction time Possibly unstable measured value	All filters off

6.4.3 Empty and full calibration



Function "empty calibration" (005)

In this function, enter the distance E from the sensor membrane to the minimum level (zero point).



Caution!

With dished boiler heads or conical outflows, the zero point should not be deeper than the point at which the ultrasonic wave impinges on the tank bottom.

Function "blocking distance" (059)

In this function the blocking distance (BD) of the sensor is displayed.



Caution!

When entering the full calibration (span), please take into account, that the maximum level may not project into the blocking distance (BD)



Note!

After basic calibration, enter a safety distance (SD) in the **"safety distance" (015)** function. If the level is within this safety distance, the Prosonic M signals a warning or an alarm, depending on your selection in the **"in safety distance" (016)** function.

Function "full calibration" (006)

In this function, enter the span F, i.e. the distance from the minimum level to the maximum level.


6.4.4 Interference echo suppression (tank mapping)

Function "dist./measured value" (008)

In the **"dist./meas.value" (008)** function, the measured distance D from the sensor membrane to the product surface is displayed together with level L. Check these values.

Function "check distance" (051)

The mapping is initialized by this function.



L00-FMR2xxxx-14-00-06-en-010

Select

- **"distance=ok"** if the correct distance is displayed. Any echoes closer to the sensor will be suppressed by the following interference echo suppression.
- **"dist. too small"** if the displayed distance is too small. In this case, the signal comes from an interference echo which will be suppressed.
- **"dist. too big"** if the displayed distance is too large. This error cannot be cancelled by suppressing the interference echo. This means that the following two functions are skipped. Check the application parameters **"tank shape" (002)**, **"medium property" (003)** and **"process cond." (004)** and the **"empty calibr." (005)** in the **"basic setup" (00)** function group.
- **"dist. unknown"** if you do not know the actual distance. This means that the following two functions are skipped.
- **"manual"** if you want to specify the suppression area yourself in the following function.

Function "range of mapping" (052)

The suggested suppression area is displayed in this function. The reference point is always the sensor membrane. You can still edit the value. With manual suppression, the default value is 0 m.



Caution!

The suppression range must end 0.5 m in front of the echo of the actual level. With an empty tank, do not enter E but E – 0.5 m.

Function "start mapping" (053)

You have the following options for this function:

- **off**: Nothing is suppressed.
- **on**: Starts suppression.



Note!

If a mapping already exists, it will be overwritten up to the distance specified in the **"range of mapping" (052)** function. Beyond this distance the existing mapping remains unchanged.

Function dist./measured value (008)

After suppression, the measured distance D from the sensor membrane to the product surface is displayed together with the level. Check that the values correspond to the actual level and/or the actual distance.

The following cases may occur:

- Distance correct – Level correct -> End of basic calibration
- Distance incorrect – Level incorrect -> An additional interference echo suppression must be carried out. Go back to the **"check distance" (051)** function.
- Distance correct – Level incorrect -> Check the value of the **"empty calibr." (005)** function.

Rücksprung zur Gruppenauswahl

Nach der Störechoausblendung ist der Grundabgleich beendet und das Gerät springt automatisch in die Gruppenauswahl zurück.

6.4.5 Envelope curve

After the basic setup, an evaluation of the measurement with the aid of the envelope curve ("envelope curve" (0E) function group) is recommended.

Function "plot settings" (0E1)

In this function, select whether you want to display

- just the envelope curve
- The envelope curve and the echo evaluation line FAC
- The envelope curve and interference echo suppression (map)



Note!

The FAC and the interference echo suppression (map) are explained in BA 240F "Prosonic M – Description of Instrument Functions"


Function "recording curve" (0E2)

In this function, specify whether you want to display

- an individual envelope curve
- The current envelope curve, with cyclical refreshment.

Function "envelope curve display" (0E3)

The envelope curve is displayed in this function. You can use it to obtain the following information:



L00-FMU4xxxx-07-00-00-en-003

Check that the following conditions are fulfilled:

- The echo quality at the end of measuring range should be at least 10dB.
- There should be practically no interference echoes in front of the level signal.
- If interference echoes cannot be avoided, they must be below the suppression curve.




Note!

If the cyclical envelope curve display is still active on the display, the measured value is updated at a slower cycle time. We therefore advise you to exit the envelope curve display after optimising the measuring point. To do this, press $\square$. (The instrument does not leave the envelope curve display automatically.)

Navigation in the envelope curve display

Using navigation, the envelope curve can be scaled horizontally and vertically and shifted to the left or the right. The active navigation mode is indicated by a symbol in the top left hand corner of the display.




L00-FMxxxxxx-07-00-00-en-004

Horizontal Zoom mode

Firstly, go into the envelope curve display. Then press or to switch to the envelope curve navigation. You are then in Horizontal Zoom mode. Either or is displayed.

- increases the horizontal scale.
- reduces the horizontal scale.




L00-FMxxxxxx-07-00-00-yy-007

Move mode

Then press to switch to Move mode. Either or is displayed.

- shifts the curve to the right.
- shifts the curve to the left.




L00-FMxxxxxx-07-00-00-yy-008

Vertical Zoom mode

Press once more to switch to Vertical Zoom mode. is displayed. You now have the following options.

- increases the vertical scale.
- reduces the vertical scale.

The display icon shows the current zoom factor (to).



L00-FMxxxxxx-07-00-00-yy-009

Exiting the navigation

- Press again to run through the different modes of the envelope curve navigation.
- Press and to exit the navigation. The set increases and shifts are retained. Only when you reactivate the "**recording curve**" (**0E2**) function the display settings return to their standard values.

6.5 Basic Setup with the Endress+Hauser operating program


To carry out the basic setup with the operating program, proceed as follows:

- Start the operating program and establish a connection.²⁾
- Select the "**basic setup**" function group in the navigation window.

The following display appears on the screen:

Basic Setup step 1/4:

- measured value



ProsonicM-en-301

- The "**Next**" button moves you to the next screen display:




Note!

Each parameter that is changed must be confirmed with the **RETURN** key!

²⁾ If the connection can not be established, make sure that you use the latest version of the operating program.

Basic Setup step 2/4:

- Enter the application parameters:
 - tank shape
 - medium property
 - process cond.




ProsonicM-en-412

Basic Setup step 3/4:

If "dome ceiling", "horizontal cyl", "..." is selected in the "tank shape" function, the following display appears on the screen:


- empty calibr.
- full calibr.



ProsonicM-en-303

Basic Setup step 4/4:


- This step starts the tank mapping
- The measured distance and the current measured value are always displayed in the header



ProsonicM-en-304

6.5.1 Signal analysis via envelope curve

After the basic setup, an evaluation of the measurement using the envelope curve is recommended.



MicropilotM-en-306

6.5.2 User-specific applications (operation)

For details of setting the parameters of user-specific applications, see separate documentation BA240F/00/en "Prosonic M – Description of Instrument Functions" on the enclosed CD-ROM.

6.6 Commissioning with a FOUNDATION Fieldbus configuration tool



Note!
For commissioning of the device with a FOUNDATION Fieldbus configuration tool you need to know the DEVICE_ID, which consists of the following parts:


Device_ID = 452B481011-XXXXXXX

whereby:

452B48	ID code for Endress+Hauser
1011	ID code for Prosonic M
XXXXXXX	Device serial number, as printed on the nameplate

6.6.1 Fist setup

- 1. Open the configuration tool and load the Device Descriptions (*.ffo, *.sym and – if required by the tool – *.cff). Ensure you use the correct files (see chapter 5.4).
- 2. The first time it is connected, the device reports as follows:




- 3. Identify the device using the DEVICE_ID and assign the desired field device tag name (PD_TAG).
Factory setting: PD_TAG = E+H_PROSONIC_M_XXXXXXX

6.6.2 Parametrization of the Resource Block (Start Index: 400)

1. Enter the desired block name (optional).
Factory setting: RESOURCE_XXXXXXXX
2. Open the Resource Block
3. On delivery, write protection is disabled so that you can access the write parameters via FOUNDATION Fieldbus. Check this status by the parameter WRITE_LOCK:
– Write protectin activated: WRITE_LOCK = LOCKED
– Write protection deactivated: WRITE_LOCK = NOT LOCKED
Deactivate the write protection if necessary, see page 44.
4. Set the operating mode to AUTO in the parameter group MODE_BLK (parameter TARGET).

6.6.3 Parametrization of the Sensor Block (Start Index: 2000)

1. Enter the desired block name (optional)
Factory setting: SENSOR_XXXXXXXX
2. Open the Sensor Block. The following display appears:




Hinweis!

There are two possibilities to edit the parameters of the block:

- A parameter from the list can be opened for editing by a double click.
- You can open one of the FOUNDATION Fieldbus methods. Each method guides you automatically through a number of parameters which are required for a specific configuration task. The following sections describe the parametrization by the "basic setup" method.

3. Open the FOUNDATION Fieldbus method "basic setup":



NI-FBUS-FMU14x-es-003

4. The method contains the following parameters³⁾:
 - a. Application parameters (see section 6.4.2)
 - PARTANKSHAPE (tank shape)
 - PARMEDIUMCONDITION (medium property)
 - PARPROCESSCONDITION (process condition)
 - b. Empty and full calibration (see section 6.4.3)
 - PAREMPTYCALIBRATION (empty calibration)
 - PARFULICALIBRATION (full calibration)
 - c. Interference echo suppression (see section 6.4.4)
 - PARCHECKDISTANCE (check distance)
 - PARSUPPRESSIONDISTANCE (range of mapping)
 - PARSTARTMAPPINGRECORD (start mapping)
 - PARPRESMAPRANGE (pres. map. dist.)
 - PARCUSTTANKMAP (cust. tank map)
5. Set the operating mode to AUTO in the parameter group MODE_BLK (parameter TARGET). Otherwise the measured value can not be processed correctly by the connected Analog Input Block.
6. If measuring errors occur or if the measuring value seems unreliable, it is advisable to check the quality of the measurement by the envelope curve display. This can be done in two different ways:
 - by the display and operating module VU331 (see section 6.4.5)
 - by an Endress+Hauser operating program (see section 6.5.1)

3) In the FOUNDATION Fieldbus configuration tool you can select from two types of parameter display:

- parameter names (e.g. "PARTANKSHAPE")
- label texts (e.g. "tank shape")

6.6.4 Parametrization of the Analog Input Blocks

Prosonic M has two Analog Input Blocks that can be assigned to the various process variables. The following description provides an example for the Analog Input Block 1 (Start Index 500).

1. Enter the desired block name (optional).
Factory setting: ANALOG_INPUT_1_XXXXXXX
2. Open the Analog Input Block.
3. Set the operating mode to OOS (Out of Service) in the parameter group MODE_BLK (parameter TARGET).
4. Using the parameter CHANNEL select the process variable that is to be used as the input value for the function block algorithm (scaling and limit value monitoring). The following settings are possible:
 - CHANNEL = 1: level
 - CHANNEL = 2: distance
 - CHANNEL = 3: temperature
5. In the parameter group XD_SCALE select the desired engineering unit and the block input range (measuring range) for the process variable in question (see the example below).



Caution!

Make sure that the selected unit is suitable for the measurement variable of the selected process variable. Otherwise the parameter BLOCK_ERROR will display the error message "Block Configuration Error" and the block operating mode cannot be set to AUTO.

6. In the L_TYPE parameter, select the mode of linearization for the input variable (Direct, Indirect, Indirect Sq Root). For details refer to section 11.7 in the Appendix.



Caution!

Note that with the type of linearization "Direct" the configuration of the parameter group OUT_SCALE must agree with the configuration of the parameter group XD_SCALE. Otherwise the block operating mode cannot be set to AUTO. Such incorrect configuration is indicated in the parameter BLOCK_ERROR by the "Block Configuration Error" message.

Example:

- The measuring range of the sensor is 0 to 10 m.
- The output range to the automation system should be 0 to 10 m, too.

The following settings are to be made:


- Analog Input Block 1, Parameter CHANNEL -> "1" (measured level)
- Parameter L_TYPE -> DIRECT
- Parameter group XD_SCALE
 - XD_SCALE 0% -> 0
 - XD_SCALE 100% -> 10
 - XD_SCALE_UNIT -> m
- Parameter group OUT_SCALE
 - OUT_SCALE 0% -> 0
 - OUT_SCALE 100% -> 10
 - OUT_SCALE_UNIT -> m

7. If required, use the following parameters to define the limit values for alarm and warning messages:
 - HI_HI_LIM -> Limit value for the upper alarm
 - HI_LIM -> Limit value for the upper warning
 - LO_LIM -> Limit value for the lower warning
 - LO_LO_LIM -> Limit value for the lower alarm
 The limit values entered must be within the value range specified in the parameter group OUT_SCALE.

8. In addition to the limit values you must also specify the action taken if a limit value is exceeded using the alarm priorities (parameters HI_HI_PRI, HI_PRI, LO_PRI, LO_LO_PRI). Reporting to the the fieldbus host system only takes place if the alarm priority is higher than 2. For details refer to section 11.7 in the Appendix.

6.6.5 Connection of the function blocks

1. A concluding overall system configuration is essential so that the operating mode of the Analog Input Block can be set to AUTO and so that the field device is integrated into the system application. To do this, a configuration software (e.g. you host system software) is used to connect the function blocks – normally graphically – to the desired control strategy and then the sequence of the individual process control functions is specified.



Example: Connection of the function blocks with the NI-FBUS Configurator

2. Download the configuration data into the field devices by the download function of the FOUNDATION Fieldbus configuration tool.
3. Set the operating mode of the AI Block to AUTO (parameter group MODE_BLK, parameter TARGET). However, this is only possible under the following conditions:
 - The function blocks are correctly connected with each other.
 - The parametrization of the AI Block is correct (see 6.6.4, steps 5 and 6).
 - The Resource Block is in operating mode AUTO.

6.7 Commissioning with the handheld terminal DXR375/FC375

The steps of the commissioning procedure are the same as with a FOUNDATION Fieldbus configuration tool (→ Page 62 ff.).

The blocks should be parametrized in the following order:

- the RESOURCE BLOCK
- the SENSOR BLOCK
(the "basic setup" method can be used for this, see page →  43)
- the ANALOG INPUT BLOCKS


7 Troubleshooting

7.1 System error messages

7.1.1 Current error

Errors which the Prosonic M detects during commissioning or operation are displayed in the following way:

- **VU331:**
error symbol in the **"measured value" (000)** function
- **VU331 or Endress+Hauser operating program:**
in the **"diagnostics" (0A)** function group in the **"present error" (0A0)** function
Only the highest priority error is displayed; in the case of multiple errors, you can scroll between the different error messages by pressing **[+]** or **[-]**.
- **FOUNDATION Fieldbus:**
 - by the status of the main value in the cyclic data telegram
 - Diagnostic Block, parameter PARACTUALERROR (present error)



7.1.2 Last error

The last error is displayed in the **"diagnostics" (0A)** function group in the **"previous error" (0A1)** function. This display can be deleted in the **"clear last error" (0A2)** function. (FOUNDATION Fieldbus; Diagnostic Block; parameters PARLASTERROR and PARCLEARLASTERROR.

7.1.3 Types of error

Type of error	Symbol	Meaning
Alarm (A)	 continuous	The output signal assumes a value which can be set using the "output on alarm" (010) function: ■ MAX: 110% ■ MIN: -10% ■ Hold: last value is on hold ■ User-specific value
Warning (W)	 flashing	The device continues measurement. An error message is displayed.
Alarm/Warning (E)	You can define whether the error should behave as an alarm or as a warning.	

7.1.4 Error codes

Code	Error description	Action
A102 A110 A152 A160	checksum error	Reset; If alarm still present after reset, replace electronics
W103	initialising	If the message does not disappear after several seconds, replace the electronics
A106	downloading	Wait; Message disappears after load sequence
A111 A113 A114 A115 A121 A125 A155 A164 A171	electronics defect	Reset; Check system for EMC, improve as necessary If alarm still present after reset, replace electronics
A116	download error	Check connection; Restart download
W153	initialising	Wait a few seconds; if error is still displayed, switch the power off and on again
A231	sensor defect	Check connection, if necessary replace HF module or electronics
A281	interruption temperature sensor	Exchange sensor
A502	Sensor type not detected	Exchange sensor and/or electronics
A512	recording of mapping	Alarm disappears after a few seconds
A521	new sensor type detected	Reset
W601	linearisation curve not monotone	Correct table (enter monotonously increasing table)
W611	less than 2 linearisation points	Enter additional value pairs
W621	simulation on	Switch simulation mode off ["output" (06) function group, "simulation" (065) function]
E641	no usable echo	Check basic calibration
E651	level in safety distance – risk of overflow	Error disappears when the level leaves the safety distance. Possibly reset the lock. ["safety settings" (01) function group, "ackn. alarm" (017) function]
A661	Sensor overtemperature	
A671	Linearisation incomplete	Activate linearisation table
W681	current out of range	Carry out basic calibration; check linearisation

Code	Error description	Action
W691	Filling noise detected, level ramp is active	

7.1.5 Influence of the error codes on the output signal

The following table describes the influence of the error codes on the status of the cyclic output values as well as on the parameters BLOCK_ERR and XD_ERROR in the Sensor Block.





The output values are linked to the following measuring values:





- Primary Value (PV): level/volume
- Secondary Value (SV): distance between sensor membrane and surface of the material measured
- Third Value (TV): sensor temperature

Code	PV Status SV Status	PV Substatus SV Substatus	TV Status	TV Substatus	BLOCK_ER	XD_ERROR
A102	BAD	Device Failure	BAD	Device Failure	Memory Failure/ Device needs maintenance now	Electronic Failure
W103	Uncertain	Non specific	GOOD	Non specific	Other	Unspecified Err
A106	BAD	Device Failure	BAD	Device Failure	Other	Unspecified Err
A110	BAD	Device Failure	BAD	Device Failure	Memory Failure/ Device needs maintenance	Electronic Failure
A111	BAD	Device Failure	BAD	Device Failure	Memory Failure/ Device needs maintenance now	Electronic Failure
A113	BAD	Device Failure	BAD	Device Failure	Memory Failure/ Device needs maintenance now	Electronic Failure
A114	BAD	Device Failure	BAD	Device Failure	Memory Failure/ Device needs maintenance now	Electronic Failure
A115	BAD	Device Failure	BAD	Device Failure	Device needs maintenance now	Unspecified Err
A116	BAD	Device Failure	BAD	Device Failure	Device needs maintenance now	Unspecified Err
A121	BAD	Device Failure	BAD	Device Failure	Memory Failure/ Device needs maintenance now	Electronic Failure
A125	BAD	Device Failure	BAD	Device Failure	Memory Failure/ Device needs maintenance now	Electronic Failure
W153	Uncertain	Non specific	GOOD	Non specific	Power up	No Error
A155	BAD	Device Failure	BAD	Device Failure	Device needs maintenance now	Electronic Failure
A160	BAD	Device Failure	BAD	Device Failure	Memory Failure/ Device needs maintenance now	Electronic Failure
A164	BAD	Device Failure	BAD	Device Failure	Memory Failure/ Device needs maintenance now	Electronic Failure
A171	BAD	Device Failure	BAD	Device Failure	Memory Failure/ Device needs maintenance now	Electronic Failure
A231	BAD	Device Failure	BAD	Device Failure	Device needs maintenance now	Unspecified Err
E281 (Warning)	Uncertain	Device Failure	BAD	Device Failure	Device needs maintenance now	Electronic Failure
E281 (Alarm)	BAD	Device Failure	BAD	Device Failure	Device needs maintenance now	Unspecified Err
A502	BAD	Device Failure	BAD	Device Failure	Device needs maintenance now	Unspecified Err
A512	Uncertain	Non specific	GOOD	Non specific	Other	Unspecified Err
A521	BAD	Device Failure	BAD	Device Failure	Device needs maintenance now	Unspecified Err
W601	Uncertain	configuration error	GOOD	Non specific	Other	Configuration Error
W611	Uncertain	configuration error	GOOD	Non specific	Other	Configuration Error
W621	Uncertain	Non specific	GOOD	Non specific	simulation active	No Error

Code	PV Status SV Status	PV Substatus SV Substatus	TV Status	TV Substatus	BLOCK_ER	XD_ERROR
E641 (Alarm)	BAD	Device Failure	GOOD	Non specific	Device needs maintenance now	Unspecified Err
E641 (Warning)	Uncertain	Non specific	GOOD	Non specific	Device needs maintenance now	Unspecified Err
E651 (Alarm)	BAD	Device Failure	GOOD	Non specific	Other	Unspecified Err
E651 (Warning)	Uncertain	Non specific	GOOD	Non specific	Other	Unspecified Err
A661 (Alarm)	BAD	Device Failure	GOOD	Non specific	Device needs maintenance now	Unspecified Err
E661 (Warning)	Uncertain	Non specific	GOOD	Non specific	Device needs maintenance soon	Unspecified Err
A671	BAD	Device Failure	GOOD	Non specific	Configuration Error	No Error
W691	Uncertain	Non specific	GOOD	Non specific	Other	Unspecified Err

7.2 Application errors

Error	Example	Elimination
Measured value (00) is incorrect but measured distance (008) is correct	 L00-FMR2xxxx-19-00-00-en-019	1. Check empty calibration (005) and full calibration (006). (FF: Sensor Block, PAREMPTYCALIBRATION, PARFULLCALIBRATION) 2. Check linearisation – level/ullage (040) (FF: Sensor Block, PARLEVELULLAGEMODE) – max. scale(046) (FF: Sensor Block, PARMAXVOLUME) – diameter vessel (047) (FF: Sensor Block, PARCYLINDERVESSEL) – linearisation table
Measured value (000) and measured distance (008) are incorrect	 L00-FMR2xxxx-19-00-00-en-014	1. For measurements in bypass or stilling well: Select the according option in the "tank shape" (002) function. (FF: Sensor Block, PARTANKSHAPE) 2. Carry out interference echo suppression.
No change in measured value on filling/emptying	 L00-FMR2xxxx-19-00-00-en-015	1. Carry out interference echo suppression. 2. Clean sensor if necessary 3. If necessary, select better installation position 4. If necessary due to wide interference echoes, set function "detection window" (0A7) to "off". (FF: Sensor Block, PARDETECTIONWINDOW)
With an uneven surface (e.g. filling, emptying, running agitator) the measured value may jump sporadically to higher levels	 L00-FMR2xxxx-19-00-00-en-016	1. Carry out interference echo suppression 2. Set the process cond. (004) to "calm surface" or "add. agitator" FF: Sensor Block, PARPROCESSCONDITION) 3. Increase output damping (058). (FF: Sensor Block, PAROUTPUTDAMPING) 4. If necessary, select a different installation position and/or a larger sensor

Error	Example	Elimination
On filling/emptying the measured value drops	  L00-FMR2xxxx-19-00-00-en-017	1. Check tank shape (002), e.g. "dome ceiling" or "horizontal cyl." (FF: Sensor Block, PARTANKSHAPE) 2. If possible, do not select a central installation position 3. Possible user stilling well/echo guide pipe
E 641 (echo loss)	  L00-FMR2xxxx-19-00-00-en-018	1. Check application parameters (002), (003) and (004) (FF: Sensor Block, PARTANKSHAPE, PARMEDIUMCONDITION, PARPROCESSCONDITION) 2. If necessary, select a different installation position and/or a larger sensor 3. Align the sensor parallel to the product surface (particularly for bulk solids applications)

8 Maintenance and repairs

8.1 Exterior cleaning

When cleaning the exterior, always use cleaning agents that do not attack the surface of the housing and the seals.

8.2 Repairs

The Endress+Hauser repair concept assumes that the measuring devices have a modular design and that customers are able to undertake repairs themselves.

Spare parts are contained in suitable kits. They contain the related replacement instructions.

All the spare parts kits which you can order from Endress+Hauser for repairs are listed with their order numbers in the section "Spare parts".

For more information on service and spare parts, contact the Service Department at Endress+Hauser.

8.3 Repairs to Ex-approved devices


When carrying out repairs to Ex-approved devices, please note the following:

- Repairs to Ex-approved devices may only be carried out by trained personnel or by the Endress+Hauser Service.
- Comply with the prevailing standards, national Ex-area regulations, safety instructions (XA) and certificates.
- Only use original spare parts from Endress+Hauser.
- When ordering a spare part, please note the device designation on the nameplate. Only replace parts with identical parts.
- Carry out repairs according to the instructions. On completion of repairs, carry out the specified routine test on the device.
- Only Endress+Hauser Service may convert a certified device into a different certified variant.
- Document all repair work and conversions.

8.4 Replacement

After a complete instrument or electronic module has been replaced, the parameters can be downloaded into the instrument again via the communication interface. Prerequisite to this is that the data were uploaded to the PC beforehand using ToF Tool /FieldCare. Measurement can continue without having to carry out a new setup. Only a linearisation and a tank map (interference echo suppression) have to be recorded again.

8.5 Spare parts (housing type F12)



L00-FMU14x-00-00-00-yy-007

10 Housing

543120-0022 Housing F12, aluminium, G1/2
543120-0023 Housing F12, aluminium, NPT1/2
543120-0024 Housing F12, aluminium, M20
52001992 Housing F12, aluminium, M20, PA connector
52008556 Housing F12, aluminium, M20, FF connector
52013350 Housing F12, aluminium, coated, M20, 4-wire
52013351 Housing F12, aluminium, coated, M20, metal
52013348 Housing F12, aluminium, coated, G1/2, 4-wire
52013349 Housing F12, aluminium, coated, NPT1/2, 4-wire

11 Hood for terminal compartment

52006026 Cover for the connection compartment F12
52019062 Cover for the connection compartment F12, FHX40

12 Set of screws

535720-9020 Set of screws for housing F12/T12

20 Cover

52005936 Cover F12/T12 aluminium, inspection glass, seal
517391-0011 Cover F12/T12 aluminium, coated, seal

30 Electronics

71025600 electronics FMU4x, Ex, 2-wire HART, V4.0
71025602 electronics FMU4x, Ex, 4-wire HART, V4.0
71025603 electronics FMU4x, Ex, PROFIBUS PA, V4.0
52023759 Electronics Prosonic M, Ex, FF, V2.04

35 Terminal module / power unit

52006197 Terminal module 4-pin, HART, 2-wire with connecting cable
52012156 Terminal module 4-pin, PROFIBUS PA, Foundation Fieldbus
52013304 Power unit, 10.5...32V DC (housing F12) for electronics, 4-wire
52013305 Power unit, 90 ...250V AC (housing F12) for electronics, 4-wire
52015585 Power unit, CSA, 10.5...32V DC (housing F12) for electronics, 4-wire
52015586 Power unit, CSA, 90...250V AC (housing F12) for electronics, 4-wire

40 Display

52005585 Display/operating module VU331

50 Probe with process connection

52010509 Sensor FMU40 G1-1/2
52010507 Sensor FMU40 NPT1-1/2
52010510 Sensor FMU41 G2
52010508 Sensor FMU41 NPT2
52023965 Sensor FMU42
52013543 Sensor FMU43 4", gasket

71037028 Sensor FMU44, gasket

55 Flanges

52023919 Flange, Uni-DN80/ANSI 3"/JIS 80A, PP

52023920 Flange, Uni-DN80/ANSI 3"/JIS 80A, PVDF

52023921 Flange, Uni-DN80/ANSI 3"/JIS 80A, 316L

52023922 Flange, Uni-DN100/ANSI 4"/JIS 100A, PP

52023923 Flange, Uni-DN100/ANSI 4"/JIS 100A, PVDF

58 Hexagon nut

52000599 Hexagon nut (SW60) G1-1/2, bk, PC

52000598 Hexagon nut (SW70) G2, bk, PC

65 Sealing kit

52010526 Sealing kit FMU4x

Miscellaneous

52010545 Nameplate Prosonic M, modification


Spare parts for FHX40

52018204 Adaption kit housing F12, 2-wire, FHX40

52018205 Adaption kit housing F12, 4-wire, FHX40

52016334 Cable FHX40, 20m

8.6 Spare parts (housing type T12)



L00-FMU-4x-00-00-00-yy-008

10 Housing

543180-1023 Housing T12, aluminium, NPT1/2, PEL

52006204 Housing T12, aluminium, G1/2, PEL, cover

52006205 Housing T12, aluminium, M20, PEL, cover

11 Hood for terminal compartment

52005643 Hood T12

12 Set of screws

535720-9020 Set of screws for housing F12/T12

20 Cover

517391-0011 Cover F12/T12 aluminium, coated, seal

52005936 Cover F12/T12 aluminium, inspection glass, seal

25 Cover for the connection compartment

518710-0020 Cover T3/T12, aluminium, coated, seal

30 Electronics

71025600 electronics FMU4x, Ex, 2-wire HART, V4.0

71025603 electronics FMU4x, Ex, PROFIBUS PA, V4.0

52023759 Electronics Prosonic M, Ex, FF, V2.04

35 Terminal module / power unit

52013302 Terminal module Ex d, 4-pin, 2-wire, HART, T12

52013303 Terminal module Ex d, 2-pin, 2-wire, PROFIBUS PA, Foundation Fieldbus, T12

52018949 Terminal module EEx ia, 4-pin, HART, T12, OVP

52018950 Terminal module EEx ia, 4-pin, PROFIBUS PA, Foundation Fieldbus, T12, OVP

40 Display

52005585 Display/operating module VU331

50 Probe with process connection

52010509 Sensor FMU40 G1-1/2

52010507 Sensor FMU40 NPT1-1/2

52010510 Sensor FMU41 G2

52010508 Sensor FMU41 NPT2

52023965 Sensor FMU42

71037028 Sensor FMU44, gasket

55 Flanges

52023919 Flange, Uni-DN80/ANSI 3"/JIS 80A, PP

52023920 Flange, Uni-DN80/ANSI 3"/JIS 80A, PVDF

52023921 Flange, Uni-DN80/ANSI 3"/JIS 80A, 316L

52023922 Flange, Uni-DN100/ANSI 4"/JIS 100A, PP

52023923 Flange, Uni-DN100/ANSI 4"/JIS 100A, PVDF

52023924 Flange, Uni-DN100/ANSI 4"/JIS 100A, 316L

58 Hexagon nut

52000598 Hexagon nut (SW70) G2, bk, PC

52000599 Hexagon nut (SW60) G1-1/2, bk, PC

65 Sealing kit

52010526 Sealing kit FMU4x

Miscellaneous

52010545 Nameplate Prosonic M, modification

8.7 Return

The following procedures must be carried out before a transmitter is sent to Endress+Hauser e.g. for repair or calibration:

- Remove all residue which may be present. Pay special attention to the gasket grooves and crevices where fluid may be present. This is especially important if the fluid is dangerous to health, e.g. corrosive, poisonous, carcinogenic, radioactive, etc.
- Always enclose a duly completed "Declaration of contamination" form (a copy of the "Declaration of contamination" is included at the end of this operating manual). Only then can Endress +Hauser transport, examine and repair a returned device.
- Enclose special handling instructions if necessary, for example a safety data sheet as per EN 91/155/EEC.

Additionally specify:

- An exact description of the application.
- The chemical and physical characteristics of the product.
- A short description of the error that occurred (specify error code if possible)
- Operating time of the device.

8.8 Disposal

In case of disposal please separate the different components according to their material consistence.

8.9 Software history

Software version / date	Changes to software	Changes to documentation
V 01.02.00 / 01.2002 V 01.02.02 / 03.2003	Original software Compatible with: ■ ToF Tool ■ Commuwin II (version 2.05.03 and higher) ■ HART Communicator DXR 275 (from OS 4.6) with Rev. 1, DD 1	
V 01.02.04/02.2004	■ FMU 42 added ■ compatible with HART Communicator DXR 375	FMU 42 added
V 01.04.00/07.2006	■ "detection window" function added can be operated via: ■ ToF Tool from version 4.50 ■ HART Communicator DXR375 with Rev. 1, DD1 FOUNDATION Fieldbus Transducer Block divided into: ■ Sensor Block ■ Diagnostic Block ■ Display Block Execution time of the function blocks reduced: ■ AI: 30 ms ■ PID: 80 ms ■ AR: 50 ms ■ IS: 30 ms ■ SC: 40 ms ■ IT: 60 ms	"detection window" added Version: 07.06 Description of FOUNDATION Fieldbus interface completely revised. Version: 11.06


8.10 Contact addresses of Endress+Hauser

Contact addresses can be found on our homepage: www.endress.com/worldwide. If you have any questions, please do not hesitate to contact your Endress+Hauser representative.

9 Accessories


9.1 Weather protection cover

A Weather protection cover made of stainless steel is recommended for outdoor mounting (order code: 543199-0001). The shipment includes the protective cover and tension clamp.



L00-FMR2xxxx-00-00-06-en-001

9.2 Installation bracket for FMU 40/41




L00-FMU4x-00-00-00-de-001

- for FMU 40, G1½: Order No. 942669-0000
- for FMU 41, G2: Order No. 942669-0001

suited for NPT 1½" and 2" as well

9.3 Adapter flange



L00-FMUXX3XXX-00-00-00-en-001


9.3.1 Version with metrical thread (FAU 70 E)

	Process Connection		
	12	DN 50 PN 16 A, flange EN1092-1 (DIN2527 B)	
	14	DN 80 PN 16 A, flange EN1092-1 (DIN2527 B)	
	15	DN 100 PN 16, A, flange EN1092-1 (DIN2527 B)	
		Sensor Connection	
	3	Thread ISO228 G1-1/2	
	4	Thread ISO228 G2	
		Flange Material	
	2	316L	
	7	Polypropylene	
FAU 70 E			Product designation

9.3.2 Version with conical thread(FAU 70 A)

	Process Connection		
	22	2" 150lbs FF, flange ANSI B16.5	
	24	3" 150lbs FF, flange ANSI B16.5	
	25	4" 150lbs FF, flange ANSI B16.5	
	Sensor Connection		
	5	Thread NPT1-1/2	
	6	Thread NPT2	
		Flange Material	
		2	316L
		7	Polypropylene
FAU 70 A			Product designation

9.4 Cantilever




L00-FMU4xxxx-06-00-00-yy-005

A	B	C	D	for Sensor	Material	Order Code
585 mm	250 mm	2 mm	200 mm	FMU 40	316Ti/1.4571	52014132
					galv. steel	52014131
				FMU 41	316Ti/1.4571	52014136
					galv. steel	52014135
1085 mm	750 mm	3 mm	300 mm	FMU 40	316Ti/1.4571	52014134
					galv. steel	52014133
				FMU 41	316Ti/1.4571	52014138
					galv. steel	52014137


- The 50 mm or 62 mm orifices serve for the mounting of the FMU 40 or FMU 41 sensor, respectively.
- The 22 mm orifice may be used for an additional sensor.

9.5 Mounting Frame




Height	Material	Order Code
700 mm	galv. steel	919791-0000
700 mm	1.4301 (AISI 304)	919791-0001
1400 mm	galv. steel	919791-0002
1400 mm	1.4301 (AISI 304)	919791-0003

9.6 Wall Bracket



Material	Order Code
galv. steel	919792-0000
316Ti/1.4571	919792-0001

9.7 Mounting bracket for FMU 42/43/44



L00-FMU4x-00-00-en-003.eps

9.8 Commubox FXA291

The Commubox FXA291 connects Endress+Hauser field instruments with CDI interface (= Endress+Hauser Common Data Interface) to the USB interface of a personal computer or a notebook. For details refer to TI405C/07/en.



Note!

For the following Endress+Hauser instruments you need the "ToF Adapter FXA291" as an additional accessory:

- Cerabar S PMC71, PMP7x
- Deltabar S PMD7x, FMD7x
- Deltapilot S FMB70
- Gammapilot M FMG60
- Levelflex M FMP4x
- Micropilot FMR130/FMR131
- Micropilot M FMR2xx
- Micropilot S FMR53x, FMR540
- Prosonic FMU860/861/862
- Prosonic M FMU4x
- Tank Side Monitor NRF590 (with additional adapter cable)
- Prosonic S FMU9x


9.9 ToF Adapter FXA291

The ToF Adapter FXA291 connects the Commubox FXA291 via the USB interface of a personal computer or a notebook to the following Endress+Hauser instruments:

- Cerabar S PMC71, PMP7x
- Deltabar S PMD7x, FMD7x
- Deltapilot S FMB70
- Gammapilot M FMG60
- Levelflex M FMP4x
- Micropilot FMR130/FMR131
- Micropilot M FMR2xx
- Micropilot S FMR53x, FMR540
- Prosonic FMU860/861/862
- Prosonic M FMU4x
- Tank Side Monitor NRF590 (with additional adapter cable)
- Prosonic S FMU9x

For details refer to KA271F/00/a2.

9.10 Remote display FHX40



100-FMxxxxx-00-00-06-en-003

9.10.1 Technical data (cable and housing) and product structure:

Max. cable length	20 m (65 ft)
Temperature range	-30 °C...+70 °C (-22 °F...158 °F)
Degree of protection	IP65/67 (housing); IP68 (cable) acc. to IEC 60529
Materials	Housing: AlSi12; cable glands: nickle plated brass
Dimensions [mm] / [inch]	122x150x80 (HxWxD) / 4.8x5.9x3.2

		Approval:
	A	Nn-hazardous area
	I	ATEX II 2 G EEx ia IIC T6, ATEX II 3D
	S	FM IS Cl.I Div.1 Gr.A-D
	U	CSA IS Cl.I Div.1 Gr.A-D
	N	CSA General Purpose
	K	TIIS ia IIC T6 (in preparation)
		Cable:
	1	20m/65ft; for HART
	5	20m/65ft; for PROFIBUS PA/FOUNDATION Fieldbus
		Additional option:
	A	Basic version
	B	Mounting bracket, pipe 1" / 2"
FHX40 -		Complete product designation

For connection of the remote display FHX40 use the cable which fits the communication version of the respective instrument.

10 Technical Data

10.1 Technical data at a glance

10.1.1 Input

Measured variable	The distance D between the sensor membrane and the product surface is measured. Using the linearisation function, the device uses D to calculate: ■ level L in any units ■ volume V in any units ■ flow Q across measuring weirs or open channels in any units
-------------------	--

Maximum range/blocking distance

Sensor	Maximum range in liquids ¹	Maximum range in solids ¹	blocking distance
FMU40	5 m	2 m	0.25 m
FMU41	8 m	3.5 m	0.35 m
FMU42	10 m	5 m	0.4 m
FMU43	15 m	7 m	0.6 m
FMU44	20 m	10 m	0.5 m

¹The actual range is dependent on the measuring conditions. Refer to Technical Information TI 365F/00/en for an estimation.

10.1.2 Output

Output signal	Foundation Fieldbus
Signal Coding	Manchester Bus Powered (MBP); Manchester II
Data transmission rate	31.25 KBit/s, voltage mode

Signal on alarm	■ Error symbol, error code and plain text description on the on-site display ■ Status byte of the digital signal input
-----------------	---

10.1.3 Data of the FOUNDATION Fieldbus interface

Basic Data

Device Type	1011 (hex)
Device Revision	04 (hex)
DD Revision	01 (hex)
CFF Revision	01 (hex)
ITK Version	4.61
ITK-Certification Driver-No.	IT035900
Link Master (LAS) capable	yes
Link Master / Basic Device selectable	yes; Default: Basic Device
Number VCRs	24
Number of Link-Objects in VFD	24

Virtual communication references (VCRs)

Permanent Entries	1
Client VCRs	0
Server VCRs	24
Source VCRs	23
Sink VCRs	0
Subscriber VCRs	23
Publisher VCRs	23

Link Settings

Slot time	4
Min. Inter PDU delay	4
Max. response delay	10

Transducer Blocks

Block	Content	Output values
Sensor Block	contains all parameters related to the measurement	■ level or volume¹⁾ (channel 1) ■ distance (channel 2) ■ sensor temperature (channel 3)
Diagnosic Block	contains diagnostic information	no output values
Display Block	contains parameters to configure the local display	no output values

1) je nach Konfiguration des Sensor-Blocks

Function Blocks

Block	Content	Execution time	Functionality
Resource Block	The Resource Block contains all the data that uniquely identifies the field device. It is an electronic version of a nameplate of the device.		enhanced
Analog Input Block 1	The AI block takes the manufacturer's input data, selected by channel number, and makes it available to other function blocks at its output.	30 ms	standard
Analog Input Block 2	The AI block takes the manufacturer's input data, selected by channel number, and makes it available to other function blocks at its output.	30 ms	standard
PID Block	The PID block serves as proportional-integral-derivative controller and is used almost universally to do closed-loop-control in the field including cascade and feedforward.	80 ms	standard
Arithmetic Block	This block is designed to permit simple use of popular measurement math functions. The user does not have to know how to write equations. The math algorithm is selected by name, chosen by the user for the function to be done.	50 ms	standard
Input Selector Block	The input selector block provides selection of up to four inputs and generates an output based on the configured action. This block normally receives its inputs from AI blocks. The block performs maximum, minimum, middle, average and 'first good' signal selection.	30 ms	standard
Signal Characterizer Block	The signal characterizer block has two sections, each with an output that is a non-linear function of the respective input. The non-linear function is determined by a single look-up table with 21 arbitrary x-y pairs.	40 ms	standard

Block	Content	Execution time	Functionality
Integrator Block	The Integrator Function Block integrates a variable as a function of the time or accumulates the counts from a Pulse Input block. The block may be used as a totalizer that counts up until reset or as a batch totalizer that has a setpoint, where the integrated or accumulated value is compared to pre-trip and trip settings, generating discrete signals when these settings are reached.	60 ms	standard

10.1.4 Auxiliary energy

Terminals	Cable cross-section: 0.5 to 2.5 mm (20 to 14 AWG)											
Cable entry	■ Cable gland M20x1.5 (recommended cable diameter 6 ... 10 mm) ■ Cable entry G½ or ½ NPT ■ 7/8" Foundation Fieldbus plug											
Supply voltage	9 V ... 32 V There may be additional restrictions for devices with an explosion protection certificate. Refer to the notes in the appropriate safety instructions (XA).											
Lift-off voltage	9 V											
Basic current	15 mA											
In-rush current	≤ 15 mA											
Error current	0 mA											
FISCO	<table><tr><td>U_i</td><td>17,5 V</td></tr><tr><td>I_i</td><td>500 mA; with surge arrester 273 mA</td></tr><tr><td>P_i</td><td>5,5 W; with surge arrester 1, 2 W</td></tr><tr><td>C_i</td><td>5 mF</td></tr><tr><td>L_i</td><td>0,01 mH</td></tr></table>		U _i	17,5 V	I _i	500 mA; with surge arrester 273 mA	P _i	5,5 W; with surge arrester 1, 2 W	C _i	5 mF	L _i	0,01 mH
U _i	17,5 V											
I _i	500 mA; with surge arrester 273 mA											
P _i	5,5 W; with surge arrester 1, 2 W											
C _i	5 mF											
L _i	0,01 mH											
FNICO compliant	yes											
Polarity sensitive	no											

10.1.5 Performance characteristics

Reaction time	The reaction time depends on the parameter settings. The minimum values are: ■ FMU40/41/42/43: min. 2 s ■ FMU44: min. 3 s		
Reference operating conditions	■ Temperature = +20 °C ■ Pressure = 1013 mbar abs. ■ Humidity = 50 % ■ Ideal reflective surface (e.g. calm, smooth fluid surface)		

- No interference reflections within signal beam
- Set application parameters:
 - Tank shape = flat ceiling
 - Medium property = liquid
 - process conditions = calm surface

Measured value resolution

Sensor	Measured value resolution
FMU40	1 mm
FMU41	1 mm
FMU42	2 mm
FMU43	2 mm
FMU44	2 mm

Measuring error

Typical specifications for reference operating conditions (include linearity, repeatability, and hysteresis):

Sensor	Measuring error
FMU40	$\pm 2\text{ mm}$ or 0.2% of set measuring distance (empty calibration) ¹
FMU41	$\pm 2\text{ mm}$ or 0,2% of set measuring distance (empty calibration) ¹
FMU42	$\pm 4\text{ mm}$ or 0,2% of set measuring distance (empty calibration) ¹
FMU43	$\pm 4\text{ mm}$ or 0,2% of set measuring distance (empty calibration) ¹
FMU44	$\pm 4\text{ mm}$ or 0,2% of set measuring distance (empty calibration) ¹

¹whichever is greater

Influence of the vapor pressure

The vapor pressure at 20 °C (68 °F) gives a hint on the accuracy of the ultrasonic level measurement. If the vapor pressure at 20 °C (68 °F) is below 50 mbar, ultrasonic level measurement is possible with a very high accuracy. This is valid for water, aqueous solutions, water-solid-solutions, dilute acids (hydrochloric acid, sulfuric acid, ...), dilute bases (caustic soda, ...), oils, greases, slurries, pastes, ...

High vapor pressures or outgassing media (ethanol, acetone, ammonia, ...) can influence the accuracy. If conditions like these are present, please contact the Endress+Hauser support.

10.1.6 Ambient conditions

Ambient temperature

–40 °C ... +80 °C

The functionality of the LC display becomes restricted at $T_u < -20\text{ °C}$ and $T_u > +60\text{ °C}$. If the device is operated outdoors in strong sunlight, you should use a protective cover.

Storage temperature

–40 °C ... +80 °C

Climate class

DIN EN 60068-2-38 (Test Z/AD) DIN/IEC 68 T2-30Db

Ingress protection

- With closed housing, tested according to
 - IP 68, NEMA 6P (24h at 1.83m under water surface)
 - IP 66, NEMA 4x
- With open housing: IP 20, NEMA 1 (also ingress protection of the display)

Vibration resistance

DIN EN 60068-2-64 / IEC 68-2-64: 20...2000 Hz, $1\text{ (m/s}^2\text{)}^2\text{/Hz}$; 3 x 100 min


Electromagnetic compatibility (EMC)	■ Interference emission to EN 61326, Equipment Class B ■ Interference immunity to EN 61326, Appendix A (Industrial) and NAMUR Recommendation NE 21 (EMC). ■ A standard installation cable is sufficient if only the analogue signal is used. Use a screened cable when working with a superimposed communication signal (HART).
-------------------------------------	---


10.1.7 Process conditions

Process temperature	-40 °C ... +80 °C A temperature sensor is integrated in the sensor for correction of the temperature-dependent time-of-flight.
Process pressure	■ FMU 40/41: 0.7 bar ... 3 bar abs. ■ FMU 42/43/44: 0.7 bar ... 2.5 bar abs.

11 Appendix

11.1 Operating menu






11.2 Block model of the Prosonic M

The Prosonic M contains the following blocks:

- **Resource Block (RB2)**
 - s. Operating Instructions BA013S: "FOUNDATION Fieldbus – Overview"
- **Sensor Block (TBUL)**
 - contains the parameters relevant to the measurement
- **Diagnostic Block (DIAG)**
 - contains the diagnostic parameters of the Prosonic M
- **Display Block (DISP)**
 - contains the configuration parameters for the display module VU331
- **Analog-Input-Block 1 bzw. 2 (AI)**
 - scale the signal of the Transducer Block and transmit them to the PLCS
- **PID Block (PID)**
 - s. Operating Instructions BA013S: "FOUNDATION Fieldbus – Overview"
- **Arithmetic Block (AR)**
 - s. Operating Instructions BA013S: "FOUNDATION Fieldbus – Overview"
- **Input Selector Block (IS)**
 - s. Operating Instructions BA013S: "FOUNDATION Fieldbus – Overview"
- **Signal Characterizer Block (SC)**
 - s. Operating Instructions BA013S: "FOUNDATION Fieldbus – Overview"
- **Integrator Block (IT)**
 - s. Operating Instructions BA013S: "FOUNDATION Fieldbus – Overview"

11.2.1 Default Block configuration

The input and output variables of the blocks can be interconnected by a network configuration tool (e.g. NI-Fieldbus configurator). The figure below shows, how these connections are set by default.



11.3 Resource block

The resource block contains the parameters used to describe physical resources of the device. It has no linkable inputs or outputs.

11.3.1 Operation

The resource block is opened by a click on the resource line.

If the NI-FBUS Configurator is being used, a series of file tabs appears on the screen. The files can be opened to view and/or edit the parameters in the following table. A short description of the parameter function appears on the side of the screen. A change in the parameter is stored by pressing the WRITE CHANGES button when the block is out of service. Press the READ ALL button to check the values stored in the device.

11.3.2 Parameters

Parameter	Description
TAG_DESC	User description of the intended application of the block.
MODE_BLK	Lists the actual, target, permitted and normal operating modes of the block. – Target: changes the operating mode of the block – Actual: indicates the current operating mode of the block – Permitted: states which operating modes are allowed – Normal: indicates the normal operating mode of the block The possible operating modes of the resources block are: – AUTO: the block is operating as normal – OOS: the block is out of service. If the resource block is out of service, then all blocks within the device (resource) are forced into the same status.
RS_STATE	Indicates the state of the resource block application state machine – On-line: block in AUTO mode – Standby: block in OOS mode
WRITE_LOCK	Indicates the status of DIP-switch WP – LOCKED: device data can be modified – NOT LOCKED: device data can be modified
RESTART	Allows a manual restart: – UNINITIALISED: no status – RUN: normal operational status – RESOURCE: resets the resource block parameters – DEFAULTS: Resets all FOUNDATION Fieldbus parameters within the device, but not the manufacturer specific parameters. – PROCESSOR: make a warm start of the processor
BLOCK_ERROR	Shows error status of software and hardware components – Out-of-Service: the block is in OOS mode – Simulation active: shows the setting of DIP-switch SIM
BLOCK_ALM	Shows any configuration, hardware, connection and system problems in the lock. The cause of the alert is to be seen in the subcode field.

The function of the resource block parameters not described here can be taken from the FOUNDATION Fieldbus specification, see "www.fieldbus.org".

11.4 Sensor Block

The Sensor block contains the parameters required to calibrate the device. These parameters can also be addressed by using the VU331 display module. The calibration of the device is described in Chapter 6.

11.4.1 Operation

Parameter changes from the tool are made off-line while the device is operating. The changes are downloaded by first setting MODE_BLK = OOS then pressing the WRITE CHANGES button. Press the READ ALL button to check the values stored in the device. In order to resume operation, change MODE_BLK to AUTO⁴⁾.

11.4.2 Output values

Parameter	Description
PRIMARY_VALUE	Main value (level, volume or flow)
SECONDARY_VALUE	Measured distance
THIRD_VALUE	Measured temperature

11.4.3 Configuration parameters

The Sensor block also contains the configuration parameters, which are used to commission and calibrate the instrument. They are identical to the functions of the operating menu, except for the service parameters which are not accessible on the bus. Thus, the calibration procedure via the display module (chapter "Commissioning") is equally valid for a calibration via a network configuration tool.

A complete list of the configuration parameters can be found in the "Description of Instrument Functions", BA240F/00/en.

4) If MODE_BLK refuses to be changed to AUTO, an error is present. Control all parameters, perform the required changes and try again to change MODE_BLK to AUTO.

11.4.4 Methods

The FOUNDATION Fieldbus specification provides for the use of so-called methods to simplify the operation of the device. A method is an interactive sequence of steps that must be followed in order to obtain a particular function from the device.

The Prosonic M has got the following methods:

- Basic setup
- Safety settings
- Acknowledge alarm
- temperature
- Linearisation
- Extended calibration
- Output
- System parameters
- Lock TB Manufacturer parameters

Most of these methods are identical to the respective function group in the operating menu. A detailed description of them can be found in the "Description of Instrument functions", BA240F.

11.4.5 Parameter list of the Prosonic M Sensor Block

Parameter	Position Indicator	rel. Index	Variable Name	Size [bytes]	Type	Access	Storage Class	Changeable in Mode
measured value	000	18	PARMEASUREDVALUE	4	FloatingPoint	RO	dynamic	Auto, OOS
tank shape	002	19	PARTANKSHAPE	1	Unsigned8	RW	static	OOS
medium property	003	20	PARMEDIUMCONDITION	1	Unsigned8	RW	static	OOS
process cond.	004	21	PARPROCESSCONDITION	1	Unsigned8	RW	static	OOS
empty calibr.	005	22	PAREMPTICALIBRATION	4	FloatingPoint	RW	static	OOS
full calibr.	006	23	PARFULLCALIBRATION	4	FloatingPoint	RW	static	OOS
echo quality	056	24	PARCHOQUALITY	1	Unsigned8	RO	dynamic	Auto, OOS
check distance	051	25	PARCHECKDISTANCE	1	Unsigned8	RW	dynamic	OOS
range of mapping	052	26	PARSUPPRESSIONDISTANCE	4	FloatingPoint	RW	dynamic	OOS
start mapping	053	27	PARSTARTMAPPINGRECORD	1	Unsigned8	RW	dynamic	OOS
pres. map dist.	054	28	PARPRESMAPRANGE	4	FloatingPoint	RO	dynamic	Auto, OOS
cust. tank map	055	29	PARCUSTTANKMAP	1	Unsigned8	RW	dynamic	OOS
offset	057	30	PAROFFSETOFMEASUREDDISTANCE	4	FloatingPoint	RW	static	OOS
output damping	058	31	PAROUTPUTDAMPING	4	FloatingPoint	RW	static	Auto, OOS
blocking dist.	059	32	PARBLOCKINGDISTANCE	4	FloatingPoint	RW	static	OOS
output on alarm	010	33	PAROUTPUTONALARM	1	Unsigned8	RW	static	OOS
outp. echo loss	012	34	PARREACTIONLOSTECHO	1	Unsigned8	RW	static	OOS
ramp %span/min	013	35	PARRAMPINPERCENTPERMIN	4	FloatingPoint	RW	static	OOS
delay time	014	36	PARDELAYTIMEONLOSTECHO	2	Unsigned16	RW	static	OOS
safety distance	015	37	PARLEVELWITHINSAFETYDISTANCE	4	FloatingPoint	RW	static	OOS
in safety dist.	016	38	PARINSAFETYDISTANCE	1	Unsigned8	RW	static	OOS
ackn. alarm	017	39	PARACKNOWLEDGEALARM	1	Unsigned8	RW	dynamic	Auto, OOS
measured temp.	030	40	PARMEASUREDTEMPERATURE	4	FloatingPoint	RO	dynamic	Auto, OOS
max. temp. limit	031	41	PARMAXTEMLIMIT	4	FloatingPoint	RO	dynamic	Auto, OOS
max. meas. temp	032	42	PARMAXMEASUREDTEMPERATURE	4	FloatingPoint	RO	non-vol.	Auto, OOS
react. high temp	033	43	PARONHIGHTEMPERATURE	1	Unsigned8	RW	static	OOS
defect temp sens	034	44	PARDEFECTTEMPERATURESENSOR	1	Unsigned8	RW	static	OOS

Parameter	Position Indicator	rel. Index	Variable Name	Size [bytes]	Type	Access	Storage Class	Changeable in Mode
level/ullage	040	45	PARLEVELULLAGEMODE	1	Unsigned8	RW	static	OOS
linearisation	041	46	PARLINEARISATION	1	Unsigned8	RW	static	OOS
customer unit	042	47	PARCUSTOMERUNIT	2	Unsigned16	RW	static	OOS
table no.	043	48	PARTABLENUMBER	1	Unsigned8	RW	non-vol.	Auto, OOS
input level	044	49	PARINPUTLEVELHALFAUTOMATIC	4	FloatingPoint	RO	dynamic	Auto, OOS
input level	044	50	PARINPUTLEVELMANUAL	4	FloatingPoint	RW	dynamic	OOS
input volume	045	51	PARINPUTVOLUME	4	FloatingPoint	RW	dynamic	OOS
max. scale	046	52	PARMAXVOLUME	4	FloatingPoint	RW	static	OOS
diameter vessel	047	53	PARCYLINDERVESSEL	4	FloatingPoint	RW	static	OOS
simulation	065	54	PARSIMULATION	1	Unsigned8	RW	dynamic	OOS
simulation value	066	55	PARSIMULATIONVALUELEVEL	4	FloatingPoint	RW	dynamic	Auto, OOS
simulation value	066	56	PARSIMULATIONVALUEVOLUME	4	FloatingPoint	RW	dynamic	Auto, OOS
unlock parameter	0A4	57	PAROPERATIONCODE	2	Unsigned16	RW	non-vol.	OOS
measured dist.	0A5	58	PARMEASUREDDISTANCE	4	FloatingPoint	RO	dynamic	Auto, OOS
measured level	0A6	59	PARMEASUREDLEVEL	4	FloatingPoint	RO	dynamic	Auto, OOS
detection window	0A7	60	PARDETECTIONWINDOW	1	Unsigned8	RW	dynamic	OOS
application par.	0A8	61	PARAPPLICATIONPARAMETER	1	Unsigned8	RO	dynamic	Auto, OOS
distance unit	0C5	62	PARDISTANCEUNIT	2	Unsigned16	RW	static	OOS
temperature unit	0C6	63	PARTEMPERATUREUNIT	2	Unsigned16	RW	static	OOS
download mode	0C8	64	PARDOWNLOADMODE	1	Unsigned8	RW	static	OOS
max meas dist	0D84	65	PARABSMAXMESSDIST	4	FloatingPoint	RO	dynamic	Auto, OOS
max sample dist.	0D88	66	PAREDITRANGEMAXSAMPLEDIST	4	FloatingPoint	RO	dynamic	Auto, OOS
present error	0A0	67	PARACTUALERROR	2	Unsigned16	RO	dynamic	Auto, OOS

11.5 Diagnostic Block

11.5.1 Operation

The diagnostic block contains the error messages of the instrument. These parameters can also be addressed by using the VU331 display module.

The diagnostic block is opened by clicking on the "diagnostic" line.

Parameter changes from the tool are made off-line while the device is operating. The changes are downloaded by first setting MODE_BLK = OOS then pressing the WRITE CHANGES button. Press the READ ALL button to check the values stored in the device. In order to resume operation, change MODE_BLK to AUTO⁵⁾.

11.5.2 Block administration parameters

Parameter	Description
MODE_BLK	See description in Resource block. The possible operating modes of the Sensor block are: – AUTO: the block is operating as normal. – OOS: the block is out of service.
TAG_DESC	User description of the intended application of the block.
BLOCK_ERROR	Shows the error status associated with the block components – Out-of-Service: the block is in OOS mode.

11.5.3 Methods

The FOUNDATION Fieldbus specification provides for the use of so-called methods to simplify the operation of the device. A method is an interactive sequence of steps that must be followed in order to obtain a particular function from the device.

The Prosonic M has got the following methods:

- Set to customer default
- Diagnostics

Most of these methods are identical to the respective function group in the operating menu. A detailed description of them can be found in the "Description of Instrument functions", BA240F.

11.5.4 Instrument specific parameters

Parameter	Position Indicator	rel. Index	Variable Name	Size [bytes]	Type	Access	Storage Class	Changeable in Mode
present error	0A0	13	PARACTUALERROR	2	Unsigned16	RO	dynamic	Auto, OOS
previous error	0A1	14	PARLASTERROR	2	Unsigned16	RO	non-vol.	Auto, OOS
clear last error	0A2	15	PARCLEARLASTERROR	1	Unsigned8	RW	dynamic	Auto, OOS
reset	0A3	16	PARRESET	2	Unsigned16	RW	dynamic	OOS
unlock parameter	0A4	17	PAROPERATIONCODE	2	Unsigned16	RW	non-vol.	OOS
protocol+sw-no.	0C2	18	PARPROTOSFTVERSIONSTRING	16	VisibleString	RO	const	Auto, OOS

5) If MODE_BLK refuses to be changed to AUTO, an error is present. Control all parameters, perform the required changes and try again to change MODE_BLK to AUTO.

11.6 Display Block

11.6.1 Operation

The display block contains the parameters required to parametrise the display module VU331 (which is contained in the remote display and operating unit FHX40). These parameters can also be addressed by using the VU331 display module.

The display block is opened by clicking on the "display" line.

Parameter changes from the tool are made off-line while the device is operating. The changes are downloaded by first setting MODE_BLK = OOS then pressing the WRITE CHANGES button. Press the READ ALL button to check the values stored in the device. In order to resume operation, change MODE_BLK to AUTO⁶⁾.

11.6.2 Block administration parameters

Parameter	Description
MODE_BLK	See description in Resource block. The possible operating modes of the sensor block are: – AUTO: the block is operating as normal. – OOS: the block is out of service.
TAG_DESC	User description of the intended application of the block.
BLOCK_ERROR	Shows the error status associated with the block components – Out-of-Service: the block is in OOS mode.

11.6.3 Methods

The FOUNDATION Fieldbus specification provides for the use of so-called methods to simplify the operation of the device. A method is an interactive sequence of steps that must be followed in order to obtain a particular function from the device.

The Prosonic M has got the following methods:

- Display

Most of these methods are identical to the respective function group in the operating menu. A detailed description of them can be found in the "Description of Instrument functions", BA240F.


11.6.4 Instrument specific parameters

Parameter	Position Indicator	rel. Index	Variable Name	Size [bytes]	Type	Access	Storage Class	Changeable in Mode
language	092	13	PARLANGUAGE	1	Unsigned8	RW	non-vol.	Auto, OOS
back to home	093	14	PARBACKTOHOME	2	Integer16	RW	non-vol.	Auto, OOS
format display	094	15	PARFORMATDISPLAY_FT	1	Unsigned8	RW	non-vol.	Auto, OOS
no.of decimals	095	16	PARNOOFDECIMALS	1	Unsigned8	RW	non-vol.	Auto, OOS
sep. character	096	17	PARSEPARATIONCHARACTER	1	Unsigned8	RW	non-vol.	Auto, OOS
unlock parameter	0A4	18	PAROPERATIONCODE	2	Unsigned16	RW	non-vol.	OOS

6) If MODE_BLK refuses to be changed to AUTO, an error is present. Control all parameters, perform the required changes and try again to change MODE_BLK to AUTO.

11.7 Analog input block

The analog input block conditions the signal output by the Sensor block and outputs signal to the PCL or other function blocks.



11.7.1 Operation

The resource block is opened by a click on the resource line. Parameter changes from the tool are made off-line while the device is operating. The changes are downloaded by first setting `MODE_BLK = OOS` then pressing the `WRITE CHANGES` button. Press the `READ ALL` button to check the values stored in the device. Normally operation is resumed as soon as `MODE-BLK` is set to `AUTO`.

11.7.2 Block administration parameters

Parameter	Description
MODE_BLK	See description in Resource block. The possible operating modes of the Sensor block are: – AUTO: the block is operating as normal – MAN: the block is operated with a manually entered primary value. – OOS: the block is out of service.
TAG_DESC	User description of the intended application of the block.
BLOCK_ERROR	Shows error status of software and hardware components – Out-of-Service: the block is in OOS mode – Simulation active: shows the setting of DIP-switch SIM. Input failure/process variable has BAD status. – configuration error

11.7.3 Output values

Parameter	Description
PV	Either the primary/secondary Sensor block value used to execute the block or a process value associated with it. Comprises value and status.
OUT	The primary value output as a result of executing the analog input block. Comprises value and status.
FIELD_VALUE	Raw value of field device in % of PV range with a status reflecting the Sensor condition before signal characterisation L_Type or filtering V_TIME. Comprises value and status.

11.7.4 Scaling parameters

Parameter	Description
CHANNEL	Selects the measured value to be input to the analogue input block – 0 = no channel defined – 1 = primary value: measured level/volume – 2 = secondary value: measured distance
XD_SCALE	Scales the Sensor block value in the required engineering units (EU).
OUT_SCALE	Scales the output value in the required engineering units (EU).
L_TYPE	Sets the linearization type: – DIRECT: the Sensor block value bypasses the scaling functions – INDIRECT: the Sensor block value is fed through the linear scaling functions – INDIRECT SORT: the Sensor block value is fed through the square root scaling functions

The relationship between the output values and scaling parameters is as follows:

$$\text{FIELD_VAL} = 100 \times \frac{\text{CHANNEL_VALUE} - \text{XD_SCALE_MIN}}{\text{XD_SCALE_MAX} - \text{XD_SCALE_MIN}}$$

The L_TYPE parameter influences the signal conversion:

■ Direct:

$$\text{PV} = \text{CHANNEL_VALUE}$$

■ Indirect:

$$\text{PV} = \frac{\text{FIELD_VALUE}}{100} \times (\text{OUT_SCALE_MAX} - \text{OUT_SCALE_MIN}) + \text{OUT_SCALE_MIN}$$

■ Indirect square root:

$$\text{PV} = \sqrt{\frac{\text{FIELD_VALUE}}{100}} \times (\text{OUT_SCALE_MAX} - \text{OUT_SCALE_MIN}) + \text{OUT_SCALE_MIN}$$

11.7.5 Output response parameters

Parameter	Description
LOW_CUT	Not relevant to level measurement! Determines a threshold for square root linearization below which the output value is set to zero.
PV_FTIME	Sets the time constant for the output value.

11.7.6 Alarm parameters

Parameter	Description
ACK_OPTION	Sets the way in which alarms and warnings are to be acknowledged.
ALARM_HYS	Sets the hysteresis (in output engineering units) for all configured alarms. A hysteresis of e.g. 2% on a HI_HI_LIMIT of 95% would cause the alarm to activate when the level reaches 95% and to deactivate when the level drops below 93%. A hysteresis of e.g. 2% on a LO_LO_LIMIT of 5% would cause the alarm to activate when the level drops below 5% and to deactivate when the level rises to 7%.
HI_HI_PRI	The priority (1 – 15) of the HI_HI alarm
HI_HI_LIM	Sets the HI_HI alarm limit in output engineering units
HI_PRI	The priority (1 – 15) of the HI alarm
HI_LIM	Sets the HI warning limit in output engineering units
LO_PRI	The priority (1 – 15) of the LO alarm
LO_LIM	Sets the LO warning limit in output engineering units
LO_LO_PRI	The priority (1 – 15) of the LO_LO alarm
LO_LO_LIM	Sets the LO_LO alarm limit in output engineering units

11.7.7 Alarm priorities

Parameter	Description
0	Alarm is suppressed
1	Recognised by the system but not reported
2	Reported to the operator, but does not require his attention
3 – 7	Advisory alarms of increasing priority
8 – 15	Critical alarms of increasing priority

11.7.8 Alarm status

Parameter	Description
HI_HI_ALM	The status of the HI_HI alarm
HI_ALM	The status of the HI alarm
LO_ALM	The status of the LO alarm
LO_LO_ALM	The status of the LO_LO alarm

11.7.9 Simulation

The SIMULATE parameter allows the Sensor block output value to be simulated, provided simulation has also been enabled at the device DIP switch. The simulation must be enabled, a value and/or status entered and the block must be in AUTO mode. During simulation the Sensor output value is substituted by the simulated value.

A simulation is also possible by switching MODE_BLK to "MAN" and entering a value for OUT.

Parameter	Description
SIMULATE	Enables, sets and displays a simulated value, options: – enable/disable – simulated value – output value

11.8 List of start indices


The following list indicates the start indices for all blocks and objects:

Object	Start Index
Object Dictionary	298

Object	Start Index
Resource Block	400
Analog Input 1 Function Block	500
Analog Input 2 Function Block	600
PID Function Block	700
Arithmetic Function Block	800
Input Selector Function Block	900
Signal Characterizer Function Block	1000
Integrator Function Block	1100
Sensor Block	2000
Diagnostic Block	2200
Display Block	2400

Object	Start Index
View Objects Resource Block	3000
View Objects Analog Input 1 Function Block	3010
View Objects Analog Input 2 Function Block	3020
View Objects PID Function Block	3030
View Objects Arithmetic Function Block	3040
View Objects Input Selector Function Block	3050
View Objects Signal Characterizer Function Block	3060
View Objects Integrator Function Block	3070
View Objects Sensor Block	4000
View Object Diagnostic Block	4100
View Object Display Block	4200

11.9 Measuring principle



E: Empty distance; F: Span (full distance); D: Distance from sensor membrane - product surface; L: Level; BD: Blocking distance

Sensor	BD	Max. range fluids	Max. range bulk materials
FMU40	0.25 m	5 m	2 m
FMU41	0.35 m	8 m	3.5 m
FMU42	0.4 m	10 m	5 m
FMU43	0.6 m	15 m	7 m
FMU44	0.5 m	20 m	10 m

11.9.1 Time-of-flight method

The sensor of the Prosonic M transmits ultrasonic pulses in the direction of the product surface. There, they are reflected back and received by the sensor. The Prosonic M measures the time *t* between pulse transmission and reception. The instrument uses the time *t* (and the velocity of sound *c*) to calculate the distance *D* between the sensor membrane and the product surface:

$D = c \cdot t / 2$

As the device knows the empty distance *E* from a user entry, it can calculate the level as follows:

$L = E - D$

An integrated temperature sensor compensates for changes in the velocity of sound caused by temperature changes.

11.9.2 Interference echo suppression

The interference echo suppression feature on the Prosonic M ensures that interference echos (e.g. from edges, welded joints and installations) are not interpreted as a level echo.

11.9.3 Calibration

Enter the empty distance *E* and the span *F* to calibrate the device.

11.9.4 Blocking distance

Span F may not extend into the blocking distance BD. Level echos from the blocking distance cannot be evaluated due to the transient characteristics of the sensor.

Index

A

alarm 69
application errors 72

B

basic setup 58
blocking distance 23, 52

C

cantilever 85
CE mark 14
cleaning 74
connection 26

D

declaration of conformity 14
declaration of contamination 81
display appearance 32
display symbols 33

E

empty calibration 59
envelope curve 60
error codes 69
error messages 68

F

FHX40 88
flow measurements 21
full calibration 52, 59

H

hazardous area 4

I

installation bracket 83
interference echo suppression 53

K

key assignment 33
Khafagi-Venturi flume 21

L

level measurements 20

M

mapping 60
measuring principle 108
Measuring range 23
medium property 59

N

nozzle 23

O

on-site display 35
operating menu 94

P

process conditions 50

R

range 24
repairs to Ex-approved devices 74
return 81

S

Service Interface FXA291 87
shafts 20

T

ToF Tool 58
turn housing 25

V

vessel / silo 59

W

warning 69
weather protection cover 83

Declaration of Hazardous Material and De-Contamination *Erklärung zur Kontamination und Reinigung*

RA No.

Please reference the Return Authorization Number (RA#), obtained from Endress+Hauser, on all paperwork and mark the RA# clearly on the outside of the box. If this procedure is not followed, it may result in the refusal of the package at our facility.

Bitte geben Sie die von E+H mitgeteilte Rücklieferungsnummer (RA#) auf allen Lieferpapieren an und vermerken Sie diese auch außen auf der Verpackung. Nichtbeachtung dieser Anweisung führt zur Ablehnung ihrer Lieferung.

Because of legal regulations and for the safety of our employees and operating equipment, we need the "Declaration of Hazardous Material and De-Contamination", with your signature, before your order can be handled. Please make absolutely sure to attach it to the outside of the packaging.

Aufgrund der gesetzlichen Vorschriften und zum Schutz unserer Mitarbeiter und Betriebseinrichtungen, benötigen wir die unterschriebene "Erklärung zur Kontamination und Reinigung", bevor Ihr Auftrag bearbeitet werden kann. Bringen Sie diese unbedingt außen an der Verpackung an.

Type of instrument / sensor

Geräte-/Sensortyp _____

Serial number

Seriennummer _____

☐ **Used as SIL device in a Safety Instrumented System / Einsatz als SIL Gerät in Schutzzeineinrichtungen**

Process data / Prozessdaten

Temperature / Temperatur _____ [°F] _____ [°C]

Pressure / Druck _____ [psi] _____ [Pa]

Conductivity / Leitfähigkeit _____ [µS/cm]

Viscosity / Viskosität _____ [cp] _____ [mm²/s]

Medium and warnings

Warnhinweise zum Medium



	Medium / concentration Medium / Konzentration	Identification CAS No.	flammable entzündlich	toxic giftig	corrosive ätzend	harmful/ irritant gesundheitsschädlich/ reizend	other * sonstiges*	harmless unbedenklich
Process medium Medium im Prozess								
Medium for process cleaning Medium zur Prozessreinigung								
Returned part cleaned with Medium zur Endreinigung								

* explosive; oxidising; dangerous for the environment; biological risk; radioactive

* explosiv; brandfördernd; umweltgefährlich; biogefährlich; radioaktiv

Please tick should one of the above be applicable, include safety data sheet and, if necessary, special handling instructions.

Zutreffendes ankreuzen; trifft einer der Warnhinweise zu, Sicherheitsdatenblatt und ggf. spezielle Handhabungsvorschriften beilegen.

Description of failure / Fehlerbeschreibung _____

Company data / Angaben zum Absender

Company / Firma _____	Phone number of contact person / Telefon-Nr. Ansprechpartner: _____
Address / Adresse _____	Fax / E-Mail _____
_____	Your order No. / Ihre Auftragsnr. _____

"We hereby certify that this declaration is filled out truthfully and completely to the best of our knowledge. We further certify that the returned parts have been carefully cleaned. To the best of our knowledge they are free of any residues in dangerous quantities."

"Wir bestätigen, die vorliegende Erklärung nach unserem besten Wissen wahrheitsgetreu und vollständig ausgefüllt zu haben. Wir bestätigen weiter, dass die zurückgesandten Teile sorgfältig gereinigt wurden und nach unserem besten Wissen frei von Rückständen in gefahrbringender Menge sind."

(place, date / Ort, Datum)

Name, dept./Abt. (please print / bitte Druckschrift)

Signature / Unterschrift

For more Endress+Hauser product please visit: www.ainstru.com
Mail: Sales@ainstru.com

www.endress.com/worldwide

Endress+Hauser 
People for Process Automation

