

iTEMP® Pt TMT 180 **Temperature head transmitter**

Operating instructions



Safety message

Instructions and procedures in the operating instructions may require special precautions to ensure the safety of the personnel performing the operations. Information that potentially raises safety issues is indicated by safety pictograms and symbols. Please refer to the safety messages before performing an operation preceded by pictograms and symbols, see chapter 1.5.

Though the information provided herein is believed to be accurate, be advised that the information contained herein is NOT a guarantee of satisfactory results. Specifically, this information is neither a warranty nor guarantee, expressed or implied, regarding performance; merchantability, fitness, or other matter with respect to the products; and recommendation for the use of the product / process information in conflict with any patent. Please note that the manufacturer reserves the right to change and / or improve the product design and specifications without notice.



Warning!

Failure to follow these installation guidelines could result in death or serious injury.

- Make sure only qualified personnel perform the installation.

Process leaks could result in death or serious injury.

- Do not remove the thermowell while in operation.
- Install and tighten thermowells and sensors before applying pressure.

Electrical shock could cause death or serious injury.

- Use extreme caution when making contact with the leads and terminals.

Brief overview

Using the following short form instructions you can commission your system easily and swiftly:

Safety notes	Page 4
↓	
Installation	Page 7
↓	
Wiring	Page 10
↓	
Display and operating elements Preparing the communication with PC configuration software	Page 12
↓	
Instrument configuration (including a description of the unit functions) A complete description of all the functions as well as a detailed overview of the functionality can be found in this chapter.	Page 13

Table of contents

1	Safety notes	4
1.1	Designated use	4
1.2	Installation, commissioning and operation	4
1.3	Operational safety	5
1.4	Returns	5
1.5	Safety pictograms and symbols	5
2	Identification	6
2.1	Unit identification	6
2.2	Delivery contents	7
2.3	Registered trademarks	7
3	Installation	7
3.1	Installation conditions	7
3.2	Installation	8
4	Wiring	10
4.1	Overview	10
4.2	Measurement unit connection	10
4.3	Potential grounding	11
4.4	Ground the Transmitter	11
5	Operation	12
5.1	Communication	12
6	Commissioning	13
6.1	Installation and function check	13
6.2	Switch on the device	13
6.3	Configuration	13
7	Maintenance	15
8	Accessories	15
9	Trouble-shooting	16
9.1	Trouble-shooting instructions	16
9.2	Application errors without messages	16
9.3	Spare parts	17
9.4	Returns	17
9.5	Disposal	17
9.6	Software history	17
10	Technical Data	18
	Index	23

1 Safety notes

Safe and secure operation of the head transmitter can only be guaranteed if the operating instructions and all safety notes are read, understood and followed.

1.1 Designated use

- The unit is a universal, presettable temperature head transmitter for resistance thermometer (RTD). The unit is constructed for mounting in a connection head (DIN form B) or field housing.
- The manufacturer cannot be held responsible for damage caused by misuse of the unit.

1.2 Installation, commissioning and operation

The unit is constructed using the most up-to-date production equipment and complies to the safety requirements of the local guidelines. The temperature transmitter is fully factory tested according to the specifications indicated on the order. However, if it is installed incorrectly or is misused, certain application dangers can occur. Installation, wiring and maintenance of the unit must only be done by trained, skilled personnel who are authorized to do so by the plant operator. This skilled staff must have read and understood these instructions and must follow them to the letter. The plant operator must make sure that the measurement system has been correctly wired to the connection schematics.

Electrical temperature sensors such as RTD's produce low-level signals proportional to their sensed temperature. The temperature transmitter converts the low-level sensor signal to a standard 4 to 20 mA DC signal that is relatively insensitive to lead length and electrical noise. This current signal is then transmitted to the control room via two wires.

The transmitter electronics module is permanently sealed within the housing, resisting moisture and corrosive damage. Verify that the operating atmosphere of the transmitter is consistent with the appropriate hazardous locations certifications.



Warning!

Electrical shock could cause death or serious injury. If the sensor is installed in a high voltage environment and a fault or installation error occurs, high voltage may be present on the transmitter leads and terminals.

Temperature Effects

The transmitter will operate within specifications for ambient temperatures between -40 and 185 °F (-40 and 85 °C). Heat from the process is transferred from the thermowell to the transmitter housing. If the expected process temperature is near or beyond specification limits, consider the use of additional thermowell lagging, and extension nipple, or a remote mounting configuration to isolate the transmitter from the process.

1.3 Operational safety

The measuring device complies with the general safety requirements in accordance with IEC61010, the EMC requirements of IEC61326 and NAMUR recommendation NE21 and NE43.

Technical advancement

The manufacturer reserves the right to modify technical data without prior notice. Your distributor can supply you with current information and updates to these Operating Instructions.

1.4 Returns

Please follow the Return Authorization Policy at the end of these instructions.

1.5 Safety pictograms and symbols

Safe and reliable operation of this unit can only be guaranteed if the safety notes and warnings in these operating instructions are followed. The safety notes in these instructions are highlighted using the following symbols.



Note!

This icon indicates activities and actions that, if not followed correctly, could have an indirect influence on the unit operation or could lead to an unforeseen unit reaction.



Caution!

This icon indicates activities and actions that, if not followed correctly, could lead to faulty device operation or even damage to the unit.



Warning!

This icon indicates activities and actions that, if not followed correctly, could lead to personal injury, a safety risk or even total damage to the unit.



Explosion protected, type examined operating equipment!

If one of these icons is on the device's nameplate, the device can be used in hazardous areas.



Hazardous area!

This symbol identifies the hazardous area in the diagrams in these Operating Instructions.

– Devices that are used in hazardous areas or cables for such devices must have the corresponding type of protection.



Safe area (non-hazardous areas)!

This symbol identifies the non-hazardous area in the diagrams in these Operating Instructions.

– Devices in non-hazardous areas must also be certified if connection cables run through a hazardous area.

2 Identification

2.1 Unit identification

2.1.1 Legend plate

Compare the legend plates on the head transmitter with the following figures:



Fig. 1: Example: Head transmitter legend plate




Fig. 2: Order code with configuration (example) - K = Standard model, North America region

CE Mark, declaration of conformity

The devices are designed to meet state-of-the-art safety requirements, have been tested, and left the factory in a condition in which they are safe to operate. The devices comply with the applicable standards and regulations in accordance with IEC61010 "Protection Measures for Electrical Equipment for Measurement, Control, Regulation and Laboratory Procedures" and with the EMC requirements of IEC61326. The measuring system described in these Operating Instructions thus complies with the statutory requirements of the EC Directives. The manufacturer confirms successful testing of the device by affixing to it the CE mark.

UL recognized component to UL 3111-1

GL German Lloyd marine approval

GL Type Approval for temperature measurements in hazardous locations on GL Classed Vessels, Marine and Offshore Installations.

2.2 Delivery contents

The delivery contents of the temperature head transmitter are as follows:

- Temperature head transmitter
- Installation screws, installation springs and E-rings
- Operating instructions



Note!

Please take note of the head transmitter accessories in chapter 8 "Accessories".

2.3 Registered trademarks

- iTEMP® and ReadWin® 2000
are registered trademarks of Endress+Hauser Wetzler GmbH + Co. KG, Nesselwang, Germany

3 Installation

3.1 Installation conditions

- When installing and operating the unit, please take note of the allowable ambient temperature (see chapter 10 "Technical Data").

3.1.1 Dimensions

The head transmitter dimensions can be found in chapter 10 "Technical data".

3.1.2 Installation point

- Sensor connection head to DIN 43 729 Form B
- Field housing

3.1.3 Installation angle

There are no limits as to the angle of installation.

3.2 Installation

3.2.1 Typical European installation

For installation, proceed as follows:

Installing in a sensor connection head to DIN 43 729 Form B (see Fig. 3)

- Feed the sensor inset cables (Pos. 5) through the central hole in the head transmitter (Pos. 4).
- Place the installation springs (Pos. 3) onto the screws (Pos. 2).
- Feed the installation screws (Pos. 2) through the holes in the head transmitter and the holes in the sensor inset (Pos. 5). Fix both screws using the E-rings (Pos. 6).
- Position the head transmitter in the connection head in such a way that the current output terminals (terminal 1 and 2) are towards the cable entry gland (Pos. 7).
- Fix the head transmitter (Pos. 4) and sensor inset (Pos. 5) into the connection head.

Installation in a field housing (see Fig. 4)

- Feed the installation screws (Pos. 2) with installation springs (Pos. 3) through the holes in the head transmitter (Pos. 4). Fix these using the E-rings (Pos. 5).
- Screw the head transmitter into the field housing using a screwdriver.



Caution!

In order to avoid damaging the head transmitter, do not over-tighten the installation screws.




Fig. 3: Installation of head transmitter into a Form B sensor connection head.




Fig. 4: Installation of head transmitter into field housing.

3.2.2 Typical North American installation

Industrial thermocouple or RTD assembly with head transmitter (see Fig. 5)

- Attach the thermowell (Pos. 1) to the pipe or process container wall. Install and tighten thermowells before applying process pressure.
- Attach necessary extension nipples and adapters (Pos. 3) to the thermowell. Seal the nipple and adapter threads with silicone tape.
- Install drain seals if required for severe environments or to satisfy code requirements.
- Feed the installation screws (Pos. 6) with installation springs (Pos. 7) through the holes in the head transmitter (Pos. 8). Fix these using the E-rings (Pos. 9).
- Position the head transmitter assembly in the transmitter housing (Pos. 4) in such a way that the current output terminals (terminal 1 and 2) are towards the conduit.
- Screw the head transmitter assembly (Pos. 5) into the transmitter housing (Pos. 4) using a screwdriver.
- Feed the sensor inset cables through the conduit of the transmitter housing and the central hole in the head transmitter.
- Attach the transmitter housing (Pos. 4) with built-in head transmitter assembly to the nipples and adapters (Pos. 3). Seal adapter threads with silicone tape.



Caution!

In order to avoid damaging the head transmitter, do not over-tighten the installation screws.



Caution!

Pull the field wiring leads through the conduit into the transmitter housing. Attach the sensor and power leads to the head transmitter. Avoid contact with other terminals.



Caution!

Install and tighten the transmitter housing cover. Enclosure covers must be fully engaged to meet explosion-proof requirements.




Fig. 5: Installing the head transmitter - Head transmitter assembly

- Pos. 1: Thermowell
 Pos. 2: Measuring inset
 Pos. 3: Extension neck
 Pos. 4: Transmitter housing
 Pos. 5: Head transmitter assembly
 Pos. 6: Installation screws
 Pos. 7: Installation springs
 Pos. 8: Head transmitter
 Pos. 9: E-rings

4 Wiring

4.1 Overview

Terminal layout




Fig. 6: Head transmitter wiring

4.2 Measurement unit connection



Caution!

- Switch off power supply before opening the housing cover. Do not install or connect the unit to power supply. If this is not followed parts of the electronic circuit will be damaged.
- If the device has not been grounded as a result of the housing being installed, we recommended grounding it via one of the ground screws.

• Sensors:

Connect the sensor cables to the respective head transmitter terminals (Terminals 3 to 6) by following the wiring diagram (see Fig. 6).

• Output signal and power supply:

Open the cable gland on the sensor head or field housing. Feed the cable through the opening in the cable gland and then connect the cable cores to terminals 1 and 2 according to the wiring diagram (see Fig. 6).

• PC configuration (SETUP socket):

Open the flap on the SETUP socket (see Fig. 6) and connect the SETUP connection cable.




Fig. 7: Connection to PC for configuration

**Note!**

The screws on the terminals must be screwed in tightly. Head transmitter configuration during measurement operation is possible. There is no need to disconnect cables!

4.3 Potential grounding

**Note!**

Please take note of the following when remotely installing the head transmitter in a field housing. The shield on the output (output signal 4 to 20 mA) must be at the same potential as the shield at the sensor connection. For an effective shielding the cable shield must be solidly connected to the field housing. This can be achieved by connecting the cable shield to the special EMC cable gland.




Fig. 8: Shielding on remote installation

Open the field housing cable gland and connect the shield of the output and sensor connection according to the figure opposite (see Fig. 8). In plants with strong EMC problems shielding of all cables with a low ohm connection to the transmitter housing is recommended.

4.4 Ground the Transmitter

The transmitter will operate with the current signal loop either floating or grounded. However, the extra noise in floating systems affects many types of readout devices. If the signal appears noisy or erratic, grounding the current signal loop at a single point may solve the problem. The best place to ground the loop is at the negative terminal of the power supply. Do not ground the current signal loop at more than one point.

5 Operation

5.1 Communication

The head transmitter must be set up using a PC and configuration set. The following points must be taken into account if trouble-free setup is to be achieved:

- Configuration software installation
More details and download see:
www.readwin2000.com
- Connect the head transmitter to the PC using the connection cable from the configuration set (TMT180A-VM).

5.1.1 Configuration software installation (ReadWin® 2000)

System conditions	– IBM PC or compatible computer (min. Pentium 166 MHz) – Windows 95/98/ME/NT4.0/2000/XP – 64 MB RAM – Mouse – CD-ROM drive – Screen resolution 800 x 600 Pixel – free serial interface
Recommended minimum configuration	– Pentium 400 MHz – 128 MB main RAM – 120 MB free hard drive memory – Screen resolution 1024 x 768 Pixel
Installation start	Start Windows®: 1. Place installations-CD in the respective drive 2. Generally, the 'Autorun'-file starts. If not, start "Setup.exe "and follow the installation instructions 3. If required the help/operating manual can be printed out once the software has been successfully installed.

5.1.2 Connecting the head transmitter to the PC using the configuration kit connection cable

1. Connect the SETUP connector of the interface connecting cable to the SETUP socket in the head transmitter (see 'Fig. 7' in Chapter 4.2).
2. Connect the RS232C connector to a free serial interface socket on the PC. In order to achieve optimum connection, tighten the RS232C connector screws to the PC.
3. If the PC does not have a RS232 serial interface, use a USB (UNIVERSAL SERIAL BUS) converter. Full compliance with the USB specifications Version 1.0.11.1 and USB CDC Version 1.1 are required to support the RS232 serial interface.

6 Commissioning

6.1 Installation and function check

Installation check

Monitor all connections making sure they are tight. In order to guarantee fault-free operation, the terminal screws must be screwed tightly onto the connection cables.

Function check

Measuring the analog 4 to 20 mA output signal or following failure signals:

Measurement range undercut	linear fall to 3.8 mA
Measurement range excess	linear rise to 20.5 mA
Sensor break; sensor short circuit	≤ 3.6 mA or ≥ 21.5 mA

6.2 Switch on the device

Once the power supply has been connected, the head transmitter is operational.

6.3 Configuration

6.3.1 Setting up using the PC configuration software

The operating and readout software is an universally applicable service and configuration software. The operating software offers the user the following possibilities:

- Set-up device functions
- Measured value visualization
- Device parameter data storage
- Measuring point documentation

The head transmitter left the factory with a default parameter configuration. If no customer specific configuration was mentioned on the order then the default parameter configuration is constructed as follows:

Sensor	Pt100 (RTD)
Connection mode	3-wire
Measuring range and units	0 to +100 °C



Note!

If a change has been made to the measurement point then, head transmitter can be re-configured. In order to re-configure the parameters follow these instructions:

- Install the configuration software and make connection to the PC (see Chap. 5, 'Operation').
- For detailed operating instructions for the PC configuration software please read the online documentation (**BA137R/09/ae**) contained in the PC operation and readout software (see folder '**Doc**').

This software can be downloaded free of charge from the Internet at the following address:

www.readwin2000.com

6.3.2 Description of device functions

All parameters that can be read out and set-up for the configuration of the temperature transmitter are listed and described in the following table. Also the menu structure in the PC configuration software is shown in the following table.

Configurable parameters (Default settings in bold)				
Standard settings				
Sensor type	Sensor type Pt100 (TMT180-**1) Pt100 (TMT180-**2) Polynom RTD (TMT180-**1) Polynom RTD (TMT180-**2)	Range start value -328 °F (-200 °C) -58 °F (-50 °C) -328 °F (-200 °C) -58 °F (-50 °C)	Range end value 1202 °F (650 °C) 482 °F (250 °C) 1202 °F (650 °C) 482 °F (250 °C)	min. range 18 °F (10 °C) 18 °F (10 °C) 18 °F (10 °C) 18 °F (10 °C)
Connection mode	Input of RTD connection mode. Input: • 2-wire • 3-wire • 4-wire			
Unit	Input for unit Input: ° C or °F			
Measurement range start value	Input of 4 mA value. Input: Limitation values see ' Sensor type ' 0 °C			
Measurement range end value	Input of 20 mA value. Input: Limitation values see ' Sensor type ' 100 °C			
Coefficient X0 to X4	On sensor type polynom RTD, see description ' Customer specific linearization '			
Expanded settings				
Cable resistance	Input of cable resistance compensation on a 2-wire RTD connection. Input: 0.00 to 20.00 Ω  Note! Function is only active when a 2-wire RTD connection has been selected, see ' Sensor type '.			
Fault condition	Input of the output signal on sensor rupture or short circuit. Input: • max (≥ 21.5 mA) • min (≤ 3.6 mA)			
Output	Input of the standard (4 to 20 mA) or inverse (20 to 4 mA) current output signal. Input: • 4 to 20 mA • 20 to 4 mA			
Filter	Selection of the digital filter 1. order (filter time constant). Input: 0 to 8 s			
Offset	Input of the zero point correction (offset). Input: -10.00 to 10.00 °C (-18.00 to 18.00 °F) 0.00 °C			
Measuring point ident	Measuring point description Input: 8 characters			

Configurable parameters (Default settings in bold)	
Service functions	
Output simulation	Activate simulation mode. Input: • OFF • ON Input of the simulation value (current). Input: 3.8 to 20.5 mA

Customer-specific linearization

Customer-specific linearization and sensor matching are activated after the **POLYNOM RTD** sensor type is selected. Please find detailed information about linearization in the PC configuration software.

7 Maintenance

The temperature head transmitter has no moving parts and requires minimal scheduled maintenance.

Sensor Checkout

To determine whether the sensor is at fault, replace it with another sensor or connect a test sensor locally at the transmitter to test remote sensor wiring. Select any standard, off-the-shelf sensor for use with a temperature head transmitter, or consult the factory for a replacement special sensor or transmitter combination.

8 Accessories



Configuration set for PC SETUP (SETUP program and PC serial interface cable (TTL/RS 232C):
→ Order No.: TMT180A-VM.

ReadWin® 2000, DIN rail clip (SONDTT-AF) according to EN 50022 for E+H temperature head transmitters, Field housing TAF 10 suitable for E+H temperature head transmitters.

PC SETUP program can be downloaded free of charge from the internet from the following address:
www.readwin2000.com

Please contact your supplier when ordering (e.g. spare parts)!

9 Trouble-shooting

9.1 Trouble-shooting instructions

If faults occur after commissioning or during measurement always start any fault finding sequence using the following checklists. The user is guided to the possible fault cause and its removal by question and answer.

9.2 Application errors without messages

9.2.1 General application errors


Error	Cause	Action/cure
No communication	2 wire connection incorrect	Re-connect correctly (see connection diagram)
	No power supply on the 2-wire connection	Check the current loop
	Power supply too low (< 10 V)	Check power supply
	Defective interface cable	Check interface cable
	Defective interface	Check PC interface
	Defective device	Replace device

9.2.2 Application errors for RTD connection (Pt100)

Error	Cause	Action/cure
Fault current (≤ 3.6 mA or ≥ 21.5 mA)	Defective sensor	Check sensor
	Incorrect connection of RTD	Connect cables correctly to terminal schematic
	Incorrect connection of the 2-wire cable	Connect cables correctly to terminal schematic (polarity)
	No power supply on the 2-wire connection	Check current loop; the supply should be > 10 V
	Incorrect transmitter programming (number of wires)	Change device function 'Connection mode' (see chap. 'Commissioning')
	Defective device	Replace device

Error	Cause	Action/cure
Measured value incorrect/ inaccurate	Faulty sensor installation	Install sensor correctly
	Heat conducted by sensor	Take note of sensor installation point
	Transmitter setup faulty (number of wires)	Change device function 'Connection mode'
	Transmitter setup faulty (scale)	Change scale
	Incorrect RTD setup	Change device function 'Sensor type'
	Sensor connection (2-wire)	Check sensor connection
	Sensor cable resistance (2-wire) not compensated	Compensate cable resistance
	Offset incorrectly set	Check offset

9.3 Spare parts



Head transmitter installation set (4 screws, 6 springs, 10 E-rings)
→ Order No.: TMT180A-KA

9.4 Returns

Please follow the return Authorization Policy at the end of these instructions.

9.5 Disposal

Due to its construction, the head transmitter cannot be repaired. When disposing of the head transmitter please take note of the local disposal regulations.

9.6 Software history

Software version / date	Changes to software	Changes to documentation
1.00.00 / 10.2001	Original firmware compatible with: • ReadWin® 2000 1.2.2 and higher	

10 Technical Data

10.0.1 Function and system design

Measuring principle	Electronic monitoring and conversion of input signals in industrial temperature measurement.
Measuring system	The temperature head transmitter is a two wire transmitter with an analog output. It has measurement input for resistance thermometers (RTD) in 2-, 3- or 4-wire connection. Setting up of the unit is done using the configuration set for PC.

10.0.2 Input

Measured variable	Temperature (temperature linear transmission behavior)
Measuring range	The transmitter monitors different measuring ranges depending on the sensor connection and input signals.
Type of input	


Input	Designation	Measuring range limits	Min. span
Resistance thermometer (RTD) to IEC 751 ($\alpha = 0.00385$)	Pt100 (TMT180-**1) Pt100 (TMT180-**2)	-328 to 1202 °F (-200 to 650 °C) -58 to 482 °F (-50 to 250 °C)	18 °F (10 °C) 18 °F (10 °C)
	• Connection type: 2-, 3- or 4-wire connection • Software compensation of cable resistance possible in the 2 wire system (0 to 20 Ω) • Sensor cable resistance max. 11 Ω per cable in the 3 and 4 wire system • Sensor current: ≤ 0.6 mA		

10.0.3 Output

Output signal	Analog 4 to 20 mA, 20 to 4 mA
Breakdown information	Breakdown information to NAMUR NE 43 Breakdown information is created when the measuring information is invalid or not present anymore and gives a complete listing of all errors occurring in the measuring system.

		Signal (mA)
Under ranging	Standard	3.8
Over ranging	Standard	20.5
Sensor break; sensor short circuit low	To NAMUR NE 43	≤ 3.6
Sensor break; sensor short circuit high	To NAMUR NE 43	≥ 21.5

Source impedance max. $(V_{\text{Power supply}} - 10 \text{ V}) / 0.022 \text{ A}$ (current output)
 e.g. $(24 \text{ V} - 10 \text{ V}) / 0.022 \text{ A} = 636.4 \Omega$



Transmission behavior Temperature linear

Filter 1st order digital filter: 0 to 8 s

Input current required $\leq 3.5 \text{ mA}$

Current limit $\leq 23 \text{ mA}$

Switch on delay 4 s (during power up $I_a \leq 3.8 \text{ mA}$)

Response time 1 s

10.0.4 Power supply

Electrical connection See 'Terminal layout' in Chapter 'Wiring'.

Supply voltage $U_b = 10 \text{ to } 35 \text{ V}$, polarity protected

Residual ripple Allowable ripple $U_{ss} \leq 3 \text{ V}$ at $U_b \geq 13 \text{ V}$, $f_{\text{max.}} = 1 \text{ kHz}$

10.0.5 Performance characteristics

Reference operating conditions Calibration temperature: $73.4 \text{ °F} \pm 9 \text{ °F}$ ($+23 \text{ °C} \pm 5 \text{ °C}$)

Maximum measured error

	Type	Measurement accuracy ¹
Resistance thermometer RTD	Pt100 -328 to 1202 °F (-200 to 650 °C)	0.36 °F (0.2 °C) or 0.08%
	Pt100 -58 to 482 °F (-50 to 250 °C)	0.18 °F (0.1 °C) or 0.08%

1) % is related to the adjusted measurement range. The value to be applied is the greater.

Influence of supply voltage • $\leq \pm 0.01\%/V$ deviation from 24 V
 Percentages refer to the full scale value.

Influence of ambient temperature (Temperature drift)	Resistance thermometer Pt100: $T_d = \pm(8.3 \text{ ppm/}^\circ\text{F} * (\text{range end value} + 328) + 27.8 \text{ ppm/}^\circ\text{F} * \text{preset meas. range}) * \Delta \vartheta$ $\Delta \vartheta$ = Deviation of the ambient temperature according to the reference condition (73.4 °F ± 9 °F).
--	--

Influence of load	± 0.02%/100 Ω Percentages refer to the full scale value
-------------------	---

Long-term stability	≤ 0.18 °F/year (≤ 0.1 °C/year) or ≤ 0.05%/year Values under reference operating conditions. % refer to the set span. The highest value is valid.
---------------------	--

10.0.6 Installation conditions

Installation conditions	- Installation angle: no limit - Installation area: Connection head accord. to DIN 43 729 Form B; field housing TAF 10
-------------------------	---

10.0.7 Environmental conditions

Ambient temperature limits	-40 to 185 °F (-40 to +85 °C)
----------------------------	-------------------------------

Storage temperature	-40 to 212 °F (-40 to +100 °C)
---------------------	--------------------------------

Climate class	as per IEC 60654-1, class C
---------------	-----------------------------

Condensation	allowed
--------------	---------

Degree of protection	IP 00, NEMA 4 (IP 66) installed in field housing TAF 10
----------------------	---

Shock and vibration resistance	4g / 2 to 150 Hz as per IEC 60 068-2-6
--------------------------------	--

Electromagnetic compatibility (EMC)

CE Electromagnetic Compatibility Compliance

The device meets all requirements listed under IEC 61326 Amendment 1, 1998

This recommendation is a uniform and practical way of determining whether the devices used in laboratory and process control are immune to interference with an objective to increase its functional safety.

Discharge of static electricity	IEC 61000-4-2	6 kV cont., 8 kV air	
Electromagnetic fields	IEC 61000-4-3	80 to 2000 Hz	10 V/m
Burst (signal)	IEC 61000-4-4	1 kV 2 kV (B) ¹	
Transient voltage	IEC 61000-4-5	1 kV unsym. / 0.5 kV sym.	
HF coupling	IEC 61000-4-6	0.15 to 80 MHz	10 V

1) self recovery

10.0.8 Mechanical construction

Design, dimensions




Fig. 9: Dimensions of the head transmitter in inches (mm)

Weight

approx. 1.4 oz (40 g)

Material

- Housing: PC
- Potting: PUR

Terminals

Cable up to max. 16 AWG (secure screws)

10.0.9 Human interface

Display elements

No display elements are present directly on the temperature transmitter. The measured value display can be called up using the PC configuration software ReadWin® 2000.

Operating elements	No operating elements are present directly on the transmitter to prevent from manipulation. The device parameters of the head transmitter are configured using the PC operating software ReadWin® 2000.
--------------------	---

Remote operation	Configuration set Configuration kit TMT 180A-VM, configurable on PC software program ReadWin® 2000. Starting from version R2.00.00 of the TMT 180A the temperature head transmitter is configurable without voltage supply. Interface PC interface connection cable TTL -/- RS232 with plug. Configurable parameters Sensor type and connection type Pt100, engineering units (°C/°F), measurement range, cable resistance compensation on 2 wire connection, fault conditioning, output signal (4 to 20 mA/20 to 4 mA), offset, measurement point identification (8 characters), output simulation
------------------	---

10.0.10 Certificates and approvals

CE-Mark	The measurement system fulfils the requirements demanded by the EU regulations. Endress+Hauser acknowledges successful unit testing by adding the CE mark.
---------	--

UL	Recognized component to UL 3111-1
----	-----------------------------------

GL	Ship building approval (Germanischer Lloyd)
----	---

Other standards and guidelines	• IEC 60529: Degrees of protection by housing (IP-Code) • IEC 61010: Safety requirements for electrical measurement, control and laboratory instrumentation • IEC 61326: Electromagnetic compatibility (EMC requirements) • NAMUR Standardization association for measurement and control in chemical and pharmaceutical industries. (www.namur.de) • NEMA Standardization association for the electrical industry
--------------------------------	--

Index

B

Brief overview 2

C

CE mark 6
 Configuration software installation
 Installation start 12
 Recommended minimum configuration. 12
 System conditions 12
 Customer-specific linearization. 15

D

Default parameter configuration 13
 Device functions
 Expanded settings. 14
 Service functions 15
 standard settings. 14
 Dimensions 7

E

E-rings. 9

F

Fault checklists 16
 Function check
 Measurement range excess 13
 Measurement range undercut 13
 Sensor short circuit 13
 Function group 14–15

G

GL approval 6

I

Installation angle. 7
 Installation check 13
 Installation point
 Field housing 7
 Form B Sensor connection head 7
 Installation screws. 8–9
 Installation springs 8–9

L

Legend plate. 6

M

Measurement unit connection
 Output signal and power supply 10
 PC setup socket. 10
 Sensors 10

O

Online documentation. 13

R

Returns 17

S

Safety message 2
 Sensor Checkout 15

T

Technical advancement. 5
 Terminal layout. 10
 Thermowell. 9

U

UL recognized component 6

IMPORTANT NOTICE RETURN AUTHORIZATION POLICY

Endress+Hauser must pre-approve and assign a Return Authorization number to any instrument you plan to return. Please identify the Return Authorization number clearly on all shipping cartons and paperwork.

Please note that the issuance of a Return Authorization number does not automatically mean that credit will be issued, or that the return is covered by our warranty. An Endress+Hauser associate will contact you regarding the disposition of your returned equipment.

In order to serve you better, and to protect our employees from any potentially hazardous contaminants, Endress+Hauser must return unopened, at the sender's expense, all items that do not have a Return Authorization number.

To get a Return Authorization number for **credit**, call **888-ENDRESS**

To get a Return Authorization number for **calibration or repair**, call **800-642-8737**

To get a Return Authorization number **in Canada**, call **800-668-3199**

Please be sure to include the following information when requesting a Return Authorization number. This information will help us speed up the repair and return process.

Customer name:

Customer address:

Customer phone number:

Customer contact:

Equipment type:

Original sales order or purchase order number:

Reason for return:

Failure description, if applicable:

Process material(s) to which the equipment has been exposed:

OSHA Hazard Communication Standard 29CFR 1910.1200 mandates that we take specific steps to protect our employees from exposure to potentially hazardous materials. Therefore, all equipment so exposed must be accompanied by a letter certifying that the equipment has been decontaminated prior to its acceptance by Endress+Hauser.

The employees of Endress+Hauser sincerely appreciate your cooperation in following this policy.

Address your equipment to:

Endress+Hauser
2350 Endress Place
Greenwood, IN 46143
Return Authorization number:

In Canada:

Endress+Hauser
1440 Graham's Lane, #1, Burlington
Ont. Canada L7S 1W3
Return Authorization number:

Effective November 1987

For application and selection assistance,
in the U.S. call 888-ENDRESS

For total support of your installed base, 24 hours a day, in the U.S. call 800-642-8737

Visit us on our web site, www.us.endress.com

Endress+Hauser



FLOW

- Electromagnetic
- Vortex Shedding
- Coriolis Mass Flow
- Ultrasonic



LEVEL

- Capacitance (RF)
- Mechanical
- Vibration
- Ultrasonic
- Radar
- Guided Radar (TDR)
- Hydrostatic

PRESSURE

- Gauge/Absolute
- Differential Pressure
- Hydrostatic

RECORDERS

- Paperless Recorders
- Visual Data Managers
- Safety Data Managers

ANALYSIS

- Conductivity
- pH/ORP
- Chlorine
- Dissolved Oxygen
- Turbidity
- Chemical Analyzers
- Nitrate Sensors
- Sludge Level

TEMPERATURE

- Temperature Transmitters
- RTDs / Thermocouples

COMPONENTS

- Displays
- Active Barriers
- Process Transmitters
- Power Supplies

SERVICE

- Total support for you and your instruments

E-direct

- www.us.endress.com/e-direct
- Shop on-line for low-cost instruments, devices and components

For more Endress+Hauser product please visit: www.ainstru.com
Mail: Sales@ainstru.com



For application and selection assistance,
in the U.S. call 888-ENDRESS

For total support of your installed base, 24 hours
a day, in the U.S. call 800-642-8737

Visit us on our web site, www.us.endress.com

Endress+Hauser, Inc.
2350 Endress Place
Greenwood, IN 46143
Phone: (317) 535-7138
888-ENDRESS
FAX: (317) 535-8498

Endress+Hauser
Canada Ltd.
1440 Graham's Lane
Unit 1, Burlington
ON, L7S 1W3
Phone: (905) 681-9292
800-668-3199
FAX: (905) 681-9444

Endress+Hauser
Paseo del Pedregal No. 610
Col. Jardines del Pedregal
01900, Mexico D. F.
Mexico
Phone: (525) 568-2405
FAX: (525) 568-7459

Endress + Hauser
The Power of Know How

