


MANUAL

WHA-GW-F2D2-0-A*-Z2-ETH

***WirelessHART®* Gateway**



***Wireless*HART®**



With regard to the supply of products, the current issue of the following document is applicable: The General Terms of Delivery for Products and Services of the Electrical Industry, published by the Central Association of the Electrical Industry (Zentralverband Elektrotechnik und Elektroindustrie (ZVEI) e.V.) in its most recent version as well as the supplementary clause: "Expanded reservation of proprietorship"

1	Safety	7
1.1	Validity.....	7
1.2	Used Symbols	7
1.3	Target Group, Personnel.....	7
1.4	Reference to Further Documentation.....	7
1.5	Marking	8
1.6	Intended Use	8
1.7	Improper Use.....	8
1.8	Mounting and Installation.....	8
1.9	Housing.....	9
1.10	Operation, Maintenance, Repair	9
1.11	Delivery, Transport, Disposal	9
2	Product Specifications.....	10
2.1	Functional Overview	10
2.1.1	Network Management.....	10
2.1.2	Security Management.....	11
2.1.3	Virtual Remote I/O system	11
2.1.4	Gateway Cache Management	13
2.2	Scope of Delivery	13
2.3	Operating Elements and Indicators	14
2.3.1	LEDs.....	14
2.3.2	Buttons and DIP Switches.....	15
3	Installation.....	19
3.1	Mounting Considerations.....	19
3.1.1	Positioning the <i>WirelessHART</i> Gateway	19
3.1.2	Antenna Characteristics.....	19
3.1.3	Examples for Good and Poor Positioning.....	21
3.2	Installing the Antenna.....	22
3.3	Installing a Remote Antenna	23
3.4	Mounting the Gateway	26

3.5	Preparing Ethernet Connection	26
3.6	Preparing RS-485 Connection.....	29
3.7	Connecting to Power Supply and Grounding	30
4	Commissioning	32
4.1	Connecting via Ethernet	32
4.2	Connecting via RS-485	34
5	Configuration via Web Interface	35
5.1	Identification Parameters.....	36
5.2	Wireless Communication Parameters	37
5.2.1	Setup.....	37
5.2.2	Operating Modes.....	40
5.3	Wired Communication Parameters.....	43
5.3.1	Serial Interface	43
5.3.2	Ethernet Interface	44
5.3.3	HART Protocol	45
5.3.4	MODBUS Protocol	46
5.3.5	Emerson AMS Integration	47
5.4	Diagnostics	47
5.4.1	Identification	48
5.4.2	Wireless Communication.....	49
5.4.3	Wired Communication	56
5.5	Engineering.....	60
5.5.1	Instrument List.....	61
5.5.2	MODBUS Settings	64
5.5.3	Automatic MODBUS Mapping.....	65
5.5.4	Manual MODBUS Mapping for Input Status and Input Register.....	68
5.5.5	Topology View	75

5.6	Additional Functions.....	76
5.6.1	Reset	76
5.6.2	Self Test.....	77
5.6.3	Set DTM Address.....	77
5.6.4	Set Device Address	78
5.6.5	About	78
5.6.6	Firmware Upgrade	78
5.6.7	Change Password.....	79
5.6.8	Upload Certificate for HTTPS Connection.....	79
5.7	Measurement.....	81
6	Configuration via DTM and PACTware	83
6.1	Adding Ethernet Communication DTM	83
6.2	Adding RS-485 Communication DTM.....	85
6.3	Adding Device DTM.....	86
6.4	Online and Offline Parameterization (DTM).....	86
7	Configuration via DD file and Emerson AMS Suite	88
7.1	Integration.....	88
7.2	Configuration.....	91
8	Operation.....	94
8.1	MODBUS and HART Status Information on Lost Connection	94
8.2	Network Enhancement	97
9	Maintenance and Repair	99
9.1	WHA-GW*	99
10	Troubleshooting.....	100
10.1	Faults Indicated by LEDs of the <i>WirelessHART</i> Gateway	100
10.2	Wired Communication Faults.....	100
10.3	Wireless Communication Faults.....	101



11	Technical Specifications	102
11.1	WHA-GW-F2D2-0-* -Z2-ETH	102
11.2	Telecommunication Compliance.....	104
12	Appendix	105
12.1	HART Status Information	105
12.2	MODBUS Status Information	107
12.3	CSV File Structure	108
12.4	Supported Commands.....	111
12.4.1	Universal Commands	111
12.4.2	Common Practice Commands	111
12.4.3	Wireless Commands	112
12.4.4	Device Commands.....	113
12.5	Software License	113

1 Safety

1.1 Validity

The chapter "Safety" is valid as instruction manual.

Specific processes and instructions in this instruction manual require special provisions to guarantee the safety of the operating personnel.

1.2 Used Symbols

This document contains information that you must read for your own personal safety and to avoid property damage. Depending on the risk level, the warning messages are displayed in descending order as follows:

Safety-Relevant Symbols



Danger!

This symbol indicates an imminent danger.

Non-observance will result in personal injury or death.



Warning!

This symbol indicates a possible fault or danger.

Non-observance may cause personal injury or serious property damage.



Caution!

This symbol indicates a possible fault.

Non-observance could interrupt the device and any connected systems and plants, or result in their complete failure.

Informative Symbols



Note!

This symbol brings important information to your attention.



Action

This symbol indicates a paragraph with instructions.

1.3 Target Group, Personnel

Responsibility for planning, assembly, commissioning, operation, maintenance, and dismantling lies with the plant operator.

Mounting, installation, commissioning, operation, maintenance and dismantling of the device may only be carried out by appropriate trained and qualified personnel. The instruction manual must be read and understood.

1.4 Reference to Further Documentation

Observe laws, standards, and directives applicable to the intended use and the operating location. Observe Directive 1999/92/EC in relation to hazardous areas.

The corresponding datasheets, declarations of conformity, EC-type-examination certificates, certificates and control drawings if applicable (see datasheet) are an integral part of this document. You can find this information under www.pepperl-fuchs.com.

Due to constant revisions, documentation is subject to permanent change. Please refer only to the most up-to-date version, which can be found under www.pepperl-fuchs.com.

1.5 Marking

WirelessHART® Gateway

WHA-GW-F2D2-0-AB-Z2-ETH, WHA-GW-F2D2-0-AP-Z2-ETH, WHA-GW-F2D2-0-AS-Z2-ETH

Pepperl+Fuchs GmbH

Lilienthalstraße 200, 68307 Mannheim, Germany

EC-Type Examination Certificate: FM 12 ATEX 0061 , for additional certificates see

www.pepperl-fuchs.com

 II 3 G Ex nA nC IIC T4 Gc

1.6 Intended Use

The device is only approved for appropriate and intended use. Ignoring these instructions will void any warranty and absolve the manufacturer from any liability.

The device must only be operated in the specified ambient temperature range and at the specified relative humidity without condensation.

The device is used in control and instrumentation technology (C&I technology) for wireless data transfer from HART devices.

Take the intended use of the connected devices from the corresponding documentation.

1.7 Improper Use

Protection of the personnel and the plant is not ensured if the device is not being used according to its intended use.

1.8 Mounting and Installation

Prior to mounting, installation, and commissioning of the device you should make yourself familiar with the device and carefully read the instruction manual.

Do not mount the device at locations where an aggressive atmosphere may be present.

Do not mount a damaged or polluted device.

Only use accessories specified by the manufacturer.

All circuits connected to the device must comply with the overvoltage category II (or better) according to IEC/EN 60664-1.

Observe the installation instructions according to IEC/EN 60079-14.

Connection or disconnection of energized non-intrinsically safe circuits is only permitted in the absence of a potentially explosive atmosphere.

The device must be disconnected from the power supply prior to installation and maintenance. The power supply may be activated only after all the circuits required for operation have been fully assembled and connected.

The usage of 2400 MHz equipment is bound to local restrictions. Ensure that local restrictions allow usage of this device before commissioning.

Country	Guideline
Bulgaria	General authorization required for outdoor use and public service.
Italy	If used outside of own premises, general authorization is required.
Japan	The device is granted pursuant to the Japanese Radio Law and the Japanese Telecommunications Business Law. The device must not be modified (otherwise the granted designation number will become invalid).
Latvia	The outdoor usage of the 2.4 GHz band requires an authorization from the Electronic Communications Office.
Norway	May be restricted in the geographical area within a radius of 20 km from the center of Ny-Alesund.
Rumania	Use on a secondary basis. Individual license required.

1.9 Housing

To ensure the degree of protection:

- The housing must not be damaged, distorted or corroded.
- All seals must be undamaged and correctly fitted.
- All screws of the housing/housing cover must be tightened with the appropriate torque.
- Only cable of the appropriate size must be used in the cable glands.
- All cable glands must be tightened with the appropriate torque.
- All unused cable glands must be sealed or plugged with corresponding stopping plugs

1.10 Operation, Maintenance, Repair

The device must not be repaired, changed or manipulated.

If there is a defect, always replace the device with an original device from Pepperl+Fuchs.

Only use operating elements in the absence of a potentially explosive atmosphere.

When the device is in operation, maintain at all times a distance of at least 20 cm to the device antenna. This also applies to any other person in the vicinity of the device.

1.11 Delivery, Transport, Disposal

Check the packaging and contents for damage.

Check if you have received every item and if the items received are the ones you ordered.

Keep the original packaging. Always store and transport the device in the original packaging.

Store the device in a clean and dry environment. The permitted ambient conditions (see datasheet) must be considered.

Disposing of device, packaging, and possibly contained batteries must be in compliance with the applicable laws and guidelines of the respective country.

2 Product Specifications

2.1 Functional Overview

The *WirelessHART* gateway is the interface between the *WirelessHART* network and the process control system. It supports *WirelessHART* networks with up to 250 network participants and provides an RS-485 interface as well as an Ethernet interface. Both interfaces transmit the HART or MODBUS protocol. OPC connectivity can be realized via the HART OPC server. It can be configured via the device type manager (DTM) or device description (DD) in connection with a configuration software. Furthermore, it provides a web interface for direct access via a web browser.

Key Features

- Graphical network analysis
- Simple and automatic configuration options
- Ethernet and RS-485 interface
- HART and MODBUS protocol via both interfaces
- Input *WirelessHART* wireless interface
- 24 V DC supply
- Redundant power supply connections

2.1.1 Network Management

The *WirelessHART* gateway contains a network manager. The network manager takes care of the wireless communication between the *WirelessHART* field devices. The network manager takes care of the creation and maintenance of the wireless mesh network to ensure proper communication between the *WirelessHART* field devices.




Figure 2.1 Network management

1. Step 1: advertising
2. Step 2: joining
3. Step 3: scheduling
4. *WirelessHART* gateway
5. *WirelessHART* field device

First, the network manager sends advertising messages to announce the network's existence. When a *WirelessHART* field device receives such an advertising message, it tries to join the network. If the *WirelessHART* field device can identify itself with the same network ID and join key as stored in the *WirelessHART* gateway, the field device is allowed to join the network. Otherwise, the field device will be rejected.

The network manager can also instruct already joined devices to advertise on its behalf.

In the next step, the network manager sends scheduling information to the field device. The field device is told how to participate in the network and receives various information from the *WirelessHART* gateway:

- Number and identity of neighboring *WirelessHART* field devices,
- When to send messages and which channels to use,
- When to repeat messages for other *WirelessHART* field devices,
- The optimal communication path for messages as well as alternative communication paths in case of failure.

During this process, the field device may also apply to send messages in certain intervals and ask the network manager for the appropriate resources. The network manager then takes care that these resources are available. For example, the network manager informs other *WirelessHART* field devices when to repeat messages.

2.1.2 Security Management

The security manager is part of the *WirelessHART* gateway. To make communication safe, all messages are encrypted with industry-standard AES-128 block ciphers with symmetric keys. Therefore, messages are unreadable for external listeners.

The security manager distributes the encryption keys and changes them in certain (random) intervals, as an option.

2.1.3 Virtual Remote I/O system

The *WirelessHART* gateway makes wireless communication accessible to host systems capable of HART technology through the following principles.

WirelessHART devices and wired devices connected to a *WirelessHART* adapter are made available to host systems via a virtual HART I/O system. This I/O system contains one or multiple I/O cards. Each I/O card has up to 2 channels. To each channel, up to 6 wired field devices may be connected in multi-drop mode. → see Figure 2.2 on page 12

The *WirelessHART* gateway assigns a virtual I/O card to each *WirelessHART* device and stores card and channel values in a list. The I/O cards are assigned to the *WirelessHART* devices in chronological order (0 ... 249). New *WirelessHART* devices in the network are assigned to the next available I/O card.

WirelessHART devices are always assigned to channel 0 of an I/O card. All wired devices connected to a *WirelessHART* adapter are always assigned to channel 1 of the same I/O card as the adapter (multi-drop mode).




Figure 2.2 Network structure and corresponding I/O structure

1. Host application
2. *WirelessHART* gateway
3. *WirelessHART* field device (joined first): I/O card 0, channel 0
4. *WirelessHART* adapter (joined second): I/O card 1, channel 0
5. Wired devices 1...3 connected to *WirelessHART* adapter: I/O card 1, channel 1

If a *WirelessHART* device loses its connection to the *WirelessHART* gateway, it keeps its position in the list and stays assigned to the respective I/O card. If the connection to the *WirelessHART* gateway is re-established, the *WirelessHART* device has the same channel/card values that it had before.

The same principle applies to the field devices connected to the *WirelessHART* adapter. After communication to the *WirelessHART* gateway was lost, the field devices regain their previous position as soon as the connection is re-established.



Note!

This list is stored in a non-volatile memory of the *WirelessHART* gateway. The card and channel number assignment will remain the same after a restart of the *WirelessHART* gateway or software.

Long Tag Emulation

The *WirelessHART* communication protocol uses the long tag to address devices. However, long tags are only supported by HART 6 devices and newer devices (HART 6 = version 6 of the HART communication protocol; current version: HART 7). Older devices, for example HART 5 devices, have to be addressed by the "Message" field. If a HART 5 device is connected to the *WirelessHART* network using a *WirelessHART* adapter, the *WirelessHART* gateway emulates the long tag with the "Message" field.

2015-07

2.1.4 Gateway Cache Management

The *WirelessHART* gateway caches parameters and dynamic values of the wireless and wired subdevices and makes them available to the host. Some commands are automatically cached by the *WirelessHART* gateway (upon read). Other commands, for example dynamic values, are only cached if the respective field device publishes them (upon publishing). See chapter 5.4.2 Burst Lists

The responses to the commands listed in the following table are cached in the *WirelessHART* gateway. Commands in the same row have an identical response frame and share the same cache memory. The write commands (17, 18, 22, 51) will never get an immediate answer, but their response will be cached (caching upon write-confirmation).

Information Cached by *WirelessHART* Gateway

Cache	Command	Description
Static configuration commands, cached upon read or upon write confirmation	0, 11, 21	Read unique identifier (associated with tag or long tag)
	12, (17)	Read (Write) Message
	13, (18)	Read (Write) Short Tag, Descriptor, Date
	20, (22)	Read (Write) Long Tag
	50, (51)	Read (Write) Dynamic Variable Assignments
Dynamic value commands, cached upon publishing only	1	Read Primary Variable
	2	Read Current and Percentage
	3	Read All Variables
	9	Read Device Variables and Status
	33	Read Device Variables
	93	Read Trend
	48	Read Additional Device Status

Status Information Caching

The *WirelessHART* gateway caches the device status byte separately for each wireless or wired device. The device status will be cached from any type of received message, no matter if from a wired or wireless device, or if it is a "published" or "normal" response.

The extended device status byte is cached in a similar way, but is available only for wireless devices.

2.2 Scope of Delivery

The scope of delivery comprises the following components

- Device WHA-GW-*
- Antenna W-ANT-2400-2DB-ROD (Part. No. 215520)
- 3 stopping plugs for unused cable glands
- Product documentation

2.3 Operating Elements and Indicators

Inside the enclosure of the *WirelessHART* gateway there are LED indicators, DIP switches and buttons. The operating elements and indicators can be accessed when the enclosure is open.




Figure 2.3 WHA-GW with open enclosure

1. LEDs
2. Button A
3. Button B
4. DIP switches

2.3.1 LEDs




Figure 2.4 LED indicators

1. RS-485 communication status (yellow LED)
2. Power supply (green LED)
3. *WirelessHART* communication status (yellow LED)
4. Fault (red LED)
5. Ethernet communication status (yellow LED)

LED Indicators

LED indicators	
RS-485 communication status (yellow LED)	
LED flashes	A message is received by the <i>WirelessHART</i> gateway via the serial interface. The LED does not flash if the message is not addressed to the <i>WirelessHART</i> gateway or if a communication error was detected within the message.
LED off	No serial communication at present.
Power supply (green LED)	
LED on	Power connected. The <i>WirelessHART</i> gateway ready.
LED flashes	Power connected, but the <i>WirelessHART</i> gateway is not yet ready to send wireless commands, for example, right after power-up or after a device reset.
LED off	Power disconnected. The LED may remain off for up to 40 seconds after connection to power (system boot-up).
WirelessHART communication status (yellow LED)	
LED flashes	A <i>WirelessHART</i> message is received by the <i>WirelessHART</i> gateway via the wireless interface (including published commands and excluding published events and notifications).
LED off	No wireless communication at present.
Fault (red LED)	
LED on	Hardware fault which makes normal operation of the <i>WirelessHART</i> gateway impossible.
LED flashes	Under certain conditions the LED flashes while the <i>WirelessHART</i> gateway application tries to eliminate the fault.
LED off	No hardware fault.
Ethernet communication status (yellow LED)	
LED flashes	A message is received by the <i>WirelessHART</i> gateway via the Ethernet interface. The LED does not flash if the message is not addressed to the <i>WirelessHART</i> gateway or if a communication error was detected within the message.
LED off	No Ethernet communication at present.

2.3.2 Buttons and DIP Switches




Figure 2.5 Buttons inside the enclosure of the *WirelessHART* gateway

1. Button A
2. Button B

Time pressed	Function
Function of button A	
> 3 seconds	Configuration reset: This button resets all parameters to the factory default values, except the parameters set by button B and button A + B. After 3 seconds, all LEDs light up to confirm the reset.
Function of button B	
> 3 seconds	Communication reset: This button resets all parameters related to the wired communication channels to the factory default values. After 3 seconds, all LEDs light up to confirm the reset.
Function of button [A + B] (security mode disabled)	
> 3 seconds	Password reset: When pressed while the Security Mode is disabled (→ see Figure 2.6 on page 16), the buttons reset the password of the web interface (HTTPS password) to the factory default value. The factory default password for the web interface (HTTPS) is "admin". After 3 seconds, all LEDs light up to confirm the reset.
Function of button [A + B] (security mode enabled)	
> 3 seconds	Network manager reset: When pressed while the Security Mode is enabled (→ see Figure 2.6 on page 16), the buttons reset the join key, network ID, radio power and access mode to the factory default values. After 3 seconds, all LEDs light up to confirm the reset.




Figure 2.6 DIP switches

- 1 Switches 1 - 4: Polling address
- 2 Switches 5 - 6: Baud rate
- 3 Switch 7: RS-485 termination
- 4 Switch 8: Security mode



Note!

When using the DIP switches 1 ... 4 for setting the polling address of the *WirelessHART* gateway, you can set addresses ranging from 0 ... 15 only. Alternatively you can set the polling address using the configuration software. See chapter 5.3.3 see chapter 5.3.4
If using the configuration software, you can set addresses ranging from 0 ... 63 (HART) or 0 ... 247 (MODBUS).

DIP switches 1 ... 4				
SW1	SW2	SW3	SW4	Polling address
OFF	OFF	OFF	OFF	0
ON	OFF	OFF	OFF	1
OFF	ON	OFF	OFF	2
ON	ON	OFF	OFF	3
OFF	OFF	ON	OFF	4
ON	OFF	ON	OFF	5
OFF	ON	ON	OFF	6
ON	ON	ON	OFF	7
OFF	OFF	OFF	ON	8
ON	OFF	OFF	ON	9
OFF	ON	OFF	ON	10
ON	ON	OFF	ON	11
OFF	OFF	ON	ON	12
ON	OFF	ON	ON	13
OFF	ON	ON	ON	14
ON	ON	ON	ON	15



Note!

When using the DIP switches 5 ... 6 for setting the baud rate, this baud rate applies for the HART protocol as well as the MODBUS protocol. Alternatively you can set the baud rate using the configuration software. See chapter 5.3.3 see chapter 5.3.4

If using the configuration software you can set individual baud rates for the HART protocol and the MODBUS protocol.

DIP switches 5 ... 6		
SW5	SW6	Baud rate
OFF	OFF	9600
ON	OFF	19200
OFF	ON	38400
ON	ON	57600



Note!

The security mode has to be enabled (DIP switch 8) to change the join key using the DTM or web interface or to reset the join key and network ID using the buttons inside the enclosure of the *WirelessHART* gateway.



Caution!

Network security risk

Do not to use the security mode connection as a normal communication channel.
After the join key has been changed, disable the security mode (DIP switch 8 = OFF).



DIP switches 7 + 8			
SW7	RS-485 termination	SW8	Security mode
ON	Connected	ON	Enabled
OFF	Disconnected	OFF	Disabled

3 Installation

3.1 Mounting Considerations

3.1.1 Positioning the *WirelessHART* Gateway

Install the *WirelessHART* gateway first, before installing other *WirelessHART* devices. This way you can check for proper operation of new devices as they are installed. Nevertheless, consider the location of future *WirelessHART* devices that will be routed through the *WirelessHART* gateway to ensure good connectivity.

Guidelines for Planning a *WirelessHART* Network

- A line-of-sight between communication partners always is desirable. If a line-of-sight is not possible, the obstacles should not be massive and the partners should be more to the edge of an obstacle to allow the wave to "bend" around it (diffraction effect).
- Consider moving objects that could affect the device's antenna range.
- Install wireless devices at least 1 m above the ground.
- Make sure that the device's antenna is aligned vertically for best results.
- Make sure that a minimum of 2 other *WirelessHART* devices are well within the antenna range of the device.
- Do not position *WirelessHART* devices directly below or above each other. They would be outside each other's antenna range.
- Install *WirelessHART* devices at least 1 m away from each other.
- Antennas must be at least 6 cm away from any wall or any metallic material running parallel to it.
- Position the device as far away as possible from metal surfaces or walls containing metal. There should be as little metal close to the device as possible.
- Do not position other 2.4 GHz devices like cordless phone bases or WLAN routers near *WirelessHART* devices. Keep in mind other wireless networks using the same frequency spectrum (WLAN, Bluetooth, etc.). Wireless technologies used in an industrial environment must be able to coexist without disrupting each other. If multiple networks operate in one plant, a frequency management should be applied as part of administration.

If it is not possible to mount the *WirelessHART* gateway outdoors, you can also connect a remote antenna to the *WirelessHART* gateway and mount the remote antenna outdoors.

3.1.2 Antenna Characteristics

The included antenna W-ANT-2400-2DB-ROD (Part. No. 215520) is an omnidirectional dipole antenna. If you point the antenna upwards, the signal radiates horizontally with an angle of approx. 45 degrees above and below the horizontal (donut shaped). Almost no signal will be radiated directly above and below the antenna. Consider this when planning a *WirelessHART* network. The height differences between wireless devices in a network should not be too big.

This is valid only for an antenna, which is placed outdoors with no metal surfaces in immediate vicinity. The radiation pattern changes significantly when metal surfaces are close to the antenna.



The following diagrams show the antenna gain in two different planes.




Figure 3.1 Antenna gain (side view, 2450 MHz, dBi)




Figure 3.2 Antenna gain (top view, 2450 MHz, dBi)

3.1.3 Examples for Good and Poor Positioning




Figure 3.3 Wave propagation, schematic representation (alpha = approx. 45°, may vary considerably)

- 1 Weaker signal above and below; almost no signal directly above and below
- 2 Stronger signal sideways




Figure 3.4 Good positioning: Devices are within each other's antenna range




Figure 3.5 Poor positioning: Devices are not within each other's antenna range

3.2 Installing the Antenna



Danger!

Explosion hazard

Connection and disconnection of cables or antennas may cause a spark that can ignite a potentially explosive atmosphere.

Connect or disconnect cables or antennas only in the absence of a potentially explosive atmosphere.



Connecting the Standard Antenna (W-ANT-2400-2-ROD)

Firmly screw the antenna to the antenna terminal of the *WirelessHART* gateway.

3.3 Installing a Remote Antenna

If the *WirelessHART* gateway is mounted indoors, or if there are many metal obstacles in the immediate surroundings, you can also connect a remote antenna to the *WirelessHART* gateway. Note that the use of a different antenna or the use of an antenna with a different antenna gain is subject to legal restrictions.

Installation Diagram




Figure 3.6 Installation diagram

1. External antenna (omnidirectional or directional antenna)
2. Coaxial adapter
3. Coaxial cable
4. $\lambda/4$ surge protector
5. Coaxial cable
6. Coaxial adapter
7. *WirelessHART* gateway

Connection Diagram




Figure 3.7 Connection diagram for standard and non-standard antennas

Installation Examples

Antenna	WirelessHART gateway radio power ¹	Cable configurations for coaxial cable W-ACC-CA-NM-NM-*	
		EU	US & Canada
W-ANT-2400-2-ROD Omnidirectional rod antenna 2 dBi	10 dBm	1 m 1 m + 1 m 2 m	1 m 1 m + 1 m 2 m
W-ANT-2400-6dB-ROD-NF Omnidirectional rod antenna 6 dBi	10 dBm	2 m + 2 m 5 m 5 m + 1 m 5 m + 2 m	The use of alternative antennas is not allowed.
W-ANT-2400-8dB-PAN-NF Directional panel antenna 8.5 dBi	10 dBm	5 m + 2 m 5 m + 5 m 10 m	The use of alternative antennas is not allowed.
W-ANT-2400-14dB-PAN-NF Directional panel antenna 14 dBi	10 dBm	5 m + 10 m	The use of alternative antennas is not allowed.
	0 dBm	1 m 1 m + 1 m 2 m 2 m + 1 m 2 m + 2 m	

¹ The power level of the *WirelessHART* gateway can be configured using the **Wireless Communication Parameters**. See chapter 5.2



Danger!

Loss of radio approval and/or device certification

The use of unqualified accessories may void the radio approval and/or Ex certification of the device. In this case, the device must no longer be used.

Use only qualified remote antennas and accessories that are listed in the installation examples or that respect the limits mentioned below. If in doubt, consult your national regulations expert.

Remote antennas and accessories must respect the following limits:

- Antenna must comply with the laws for usage of 2400 MHz equipment of the country of installation.
- Radio frequency $\leq 50 \mu\text{J}$
- Radio frequency power $\leq 2 \text{ W}$
- Antenna gain $\leq 20 \text{ dBi}$
Furthermore, the allowed antenna gain depends on the laws for usage of 2400 MHz equipment of the country of installation.
- Maximum gain for EU $\leq 4 \text{ dBi}$
Maximum gain for US & Canada $\leq 2 \text{ dBi}$
The maximum gain consists of the antenna gain minus the loss of all other components, such as, cables, adapters, etc.



Danger!

Transients and damage by lightning

Outdoor installations can be subject to lightning.

- Keep back from installation and maintenance during thunderstorms.
- Install a surge protector, to protect the installation against transients or damage caused by lightning.



Danger!

Explosion hazard

Connection and disconnection of cables or antennas may cause a spark that can ignite a potentially explosive atmosphere.

Connect or disconnect cables or antennas only in the absence of a potentially explosive atmosphere.



Warning!

Danger of improper installation

An improper installation may impair the function of the *WirelessHART* network or cause damage to the *WirelessHART* gateway.

Mounting and installation of the remote antenna and the related accessories such as cables, surge protectors, and adapters may only be carried out by trained, qualified personnel.



Connecting a Remote Antenna

1. Select an installation example that meets the legal requirements and restrictions of the country of installation. See table "Installation Examples" on page 24
2. Install the components according to the installation diagram. → see Figure 3.6 on page 23
3. Install the surge protector according to the instructions given by the manufacturer. If possible, the surge protector should be grounded directly to keep the ground connection as short as possible. Note that only a complete protection system according to IEC 62305-1 can protect your equipment and personnel.
4. Protect outdoor connections with weatherproof sealing tape to minimize corrosion and to improve long-term durability.

3.4 Mounting the Gateway

The mounting location should be well accessible for mounting and electrical installation. Make sure that there is enough space to open the enclosure cover and to access the terminals, switches, and cable glands. Choose a mounting location that meets the requirements of the climatic limits specified in the technical data.

The enclosure has a degree of protection of IP65 and is designed for wall mounting (mounting accessories and tools not included). See table "Installation torque for cable glands and enclosure cover" on page 31

Required tools:

- 2 screws (M6)
- Drill
- Screwdriver

Depending on the mounting surface, you may need additional mounting material.




Figure 3.8 Mounting holes and enclosure screws

- 1 Mounting holes for M6 screws
- 2 Enclosure screws

Mounting the Gateway

1. Drill 2 holes into the mounting surface so that they match the holes of the enclosure.
2. Screw the device to the mounting surface using M6 screws.

3.5 Preparing Ethernet Connection

The *WirelessHART* gateway is equipped with a galvanically isolated Ethernet interface. Note that the maximum length of the cable running from the *WirelessHART* gateway to the Ethernet access point is 100 m or less, depending on the cable type and transfer rate. Ensure sufficient relief of tension on the cables during installation and note the minimum bending radii of the cables.



Danger!

Explosion hazard


Connection and disconnection of cables or antennas may cause a spark that can ignite a potentially explosive atmosphere.

Connect or disconnect cables or antennas only in the absence of a potentially explosive atmosphere.



Wiring the Ethernet Interface

1. Unscrew the 4 screws of the enclosure cover and remove the cover.
2. Route the Ethernet cable through the cable gland in the middle of the enclosure of the *WirelessHART* gateway. The permissible cable diameter lies between 6 ... 10 mm.
3. Connect the Ethernet cable to the Ethernet terminal block. Depending on the Ethernet access point, use straight-through or crossover wiring.




↳ The *WirelessHART* gateway is now connected to the Ethernet network. The yellow Ethernet communication status LED starts flashing when a correct HART or MODBUS protocol message is received.

4. Tighten the cable glands with appropriate torque. See table "Installation torque for cable glands and enclosure cover" on page 31
5. Seal empty cable glands with the provided plugs.
6. Tighten the enclosure cover with appropriate torque. See table "Installation torque for cable glands and enclosure cover" on page 31

You do not need a RJ45 plug to connect the Ethernet cable to the *WirelessHART* gateway. However, you need a RJ45 plug at the other end of the cable to connect the cable to an Ethernet hub, switch, router, or PC.

Pinout of the RJ45 Plug

There are different standards for the RJ45 plug: **T568A** and **T568B**. The difference between both standards is that some wires are connected to different pins of the plug.



Signal	Pins	Wire color of T568A plug	Wire color of T568B plug
TX+	1	White/green stripe	White/orange stripe
TX-	2	Green	Orange
RX+	3	White/orange stripe	White/green stripe
	4	Blue	Blue
	5	White/blue stripe	White/blue stripe
RX-	6	Orange	Green
	7	White/brown stripe	White/brown stripe
	8	Brown	Brown

Straight-Through or Crossover Wiring

Depending on the network topology, use straight-through or crossover wiring to connect the *WirelessHART* gateway to an Ethernet access point. Note that newer Ethernet hubs, switches, and routers are able to detect whether straight-through wiring or crossover wiring has been used and adjust the pinout automatically if necessary.

Wiring with a T568A Plug

Terminal block an <i>WirelessHART</i> gateway	Straight-through	Crossover
T1	Brown	Brown
	White/brown stripe	White/brown stripe
T2	Blue	Blue
	White/blue stripe	White/blue stripe
RX-	Orange	Green
RX+	White/orange stripe	White/green stripe
TX-	Green	Orange
TX+	White/green stripe	White/orange stripe
SHD	Cable shield	Cable shield

Witing with a T568B Plug

Terminal block an <i>WirelessHART</i> gateway	Straight-through	Crossover
T1	Brown	Brown
	White/brown stripe	White/brown stripe
T2	Blue	Blue
	White/blue stripe	White/blue stripe
RX-	Green	Orange
RX+	White/green stripe	White/orange stripe
TX-	Orange	Green
TX+	White/orange stripe	White/green stripe
SHD	Cable shield	Cable shield

3.6 Preparing RS-485 Connection

The *WirelessHART* gateway is equipped with a fully galvanic isolated RS-485 interface. Note that the maximum length of the cable running from the *WirelessHART* gateway to the process control system is 1200 m or less, depending on the cable type and transfer rate. Use shielded twisted pair (STP) cables only. Ensure sufficient relief of tension on the cables during installation and note the minimum bending radii of the cables.



Note!

Terminator

The interface is daisy-chain capable through its duplicated RS-485 terminal block. If the RS-485 cable ends at the *WirelessHART* gateway and is not routed to other devices (no daisy-chain connection), activate the integrated terminator to ensure reliable RS-485 communication. The terminator can be switched on or off using the operating elements and indicators inside the enclosure (see chapter 2.3) or using the serial interface (see chapter 5.3.1).




Figure 3.9 RS-485 interfaces

1. First RS-485 interface
2. Second RS-485 interface



Note!

Grounding

If the cable shield is grounded, the grounding should only be connected to one end of the cable, in order to avoid equipotential bonding currents.



Wiring the RS-485 Interfaces

1. Unscrew the 4 screws of the enclosure cover and remove the enclosure cover.
2. Route a shielded twisted pair cable through the first cable gland from the left on the bottom of the enclosure. The permissible cable diameter lies between 6 ... 10 mm.
3. Connect the shielded twisted pair cable to the first RS-485 terminal block.
4. For a daisy-chain connection, route the second shielded twisted pair cable through the second cable gland from the left on the bottom of the enclosure. Connect the second shielded twisted pair cable to the second RS-485 terminal block.
5. If the RS-485 bus ends at the *WirelessHART* gateway, set DIP switch number 7 to "ON" to activate the terminator. See chapter 2.3.2
 - ↳ The *WirelessHART* gateway is now connected to the RS-485 network. The yellow RS-485 communication status LED starts flashing when a message is received.
6. Tighten the cable glands with appropriate torque. See table "Installation torque for cable glands and enclosure cover" on page 31
7. Seal empty cable glands with the provided plugs.
8. Tighten the enclosure cover with appropriate torque. See table "Installation torque for cable glands and enclosure cover" on page 31

Gateway Wiring (RS-485 Connection)

Wire RS-485 cable	Terminal WHA-GW	Meaning
RxD/TxD - (RS-485 A)	A	RS-485 differential signal
RxD/TxD + (RS-485 B)	B	
Shield	SHD	Cable shielding

3.7

Connecting to Power Supply and Grounding

There are two 24 V DC power supply terminal blocks located inside the *WirelessHART* gateway, allowing for redundant power supply. Open the enclosure cover to access the terminal blocks.



Note!

Ensure sufficient relief of tension on the cables during installation and note the minimum bending radii of the cables.




Figure 3.10 Power supply

1. First power supply connection
2. Second (redundant) power supply connection
3. Ground connection

Connecting to Power Supply and Grounding

1. Connect one of the grounding terminals to a ground wire. → see Figure 3.10 on page 30
2. Unscrew the 4 screws of the enclosure cover. → see Figure 3.8 on page 26
3. Remove the enclosure cover.
4. Ensure that appropriate power is supplied.
5. Draw the power cable through the second cable gland from right.
The permissible cable diameter lies between 6 ... 10 mm.
6. Connect the power cable to the first power supply connection "Line 1" observing polarity.
→ see Figure 3.10 on page 30
7. If you want to connect a redundant power supply (optional), draw the second power cable through the cable gland on the far right of the enclosure.
8. Connect the second power cable to the second power supply connection "Line 2" observing polarity.
↳ The *WirelessHART* gateway is connected to power supply.
9. Tighten the cable glands with appropriate torque. See table "Installation torque for cable glands and enclosure cover" on page 31
10. Seal empty cable glands with the provided plugs.

11. Tighten the enclosure cover with appropriate torque. See table "Installation torque for cable glands and enclosure cover" on page 31



Note!

The tightening torques of cable glands depend on what type of cable is used and must therefore be determined by the user. The cap nuts must be securely tightened. Tightening the cap nuts too tight can have a negative effect on the protection class. The following figures should be taken as rough guides only.

Installation torque for cable glands and enclosure cover

Installation torque cable glands	Type of cable glands
2.5 Nm	Plastic
4.11 Nm	Nickel plated brass
4.11 Nm	Stainless steel
Installation torque enclosure cover	
2.5 Nm	

Table 3.1 Installation torque for cable glands and enclosure cover

4 Commissioning

4.1 Connecting via Ethernet

Once the *WirelessHART* gateway is connected to the Ethernet jack of your PC, update the local network settings of your PC to communicate with the *WirelessHART* gateway.

Update Network Settings (Windows 7)

1. Connect the Ethernet cable to the Ethernet jack of your PC.
2. Choose **Windows Icon > Control Panel > Network and Sharing Center**.
3. In the **View your active networks** section, click **Local Area Connection** and then click **Properties**.

↳ The **Local Area Connection Properties** window opens.




Figure 4.1 Local Area Connection Properties window

4. Select the list entry **Internet Protocol (TCP/IP)**.

5. Press **Properties**.

↳ The **Internet Protocol (TCP/IP) Properties** window opens.




Figure 4.2 Entering IP address and subnet mask

6. Choose **Use the following IP address** and type 192.168.1.100 into the field **IP address**.

7. Type **255.255.255.0** into the field **Subnet mask**.

8. Press **OK**.

↳ Your PC is now ready to communicate with the *WirelessHART* gateway.

4.2 Connecting via RS-485

Once the *WirelessHART* gateway has been connected to the RS-485 bus, you can connect the RS-485 bus to your PC. This can be done by using an RS-485 to RS-232 converter or using an RS-485 to USB converter.



Note!

The usage of an approved RS-485 converter is recommended for faster configuration and more reliable high-speed operation. In addition, the usage of a galvanically isolated RS-485 converter is strongly recommended for permanent installations.



Connect the RS-485 Bus to your PC

1. Connect the RS-485 to RS-232 converter or the RS-485 to USB converter to your PC.
2. To find out to which COM port the converter is connected, open the Windows® device manager. Click **Windows Icon > Control Panel > System > Device Manager**.
3. Under **Ports (COM & LPT)** you see the converter and its COM port. Make a note of the COM port number. You will need the COM port number when setting up the communication DTM for the RS-485 connection.




Figure 4.3 USB converter in device manager

5 Configuration via Web Interface

When configuring the *WirelessHART* gateway via the web interface, the *WirelessHART* gateway must be connected to your PC via Ethernet.



Log in to the Web Interface

1. Start your web browser.
2. If your web browser uses a proxy, deactivate the proxy.
3. Type the IP address of the *WirelessHART* gateway into the address field. The default IP address is 192.168.001.001. If you changed the IP address of the *WirelessHART* gateway, type in the new IP address.

↳ Depending on the security settings of your web browser, you may see a security warning. In this case, click OK and proceed to the login screen.



Figure 5.1 Entering login data for secure connection

4. Enter your user name and password. The default user is admin and the default password is admin.
5. Click **OK**.

5.1 Identification Parameters

The identification parameters provide various information about the device and identify the device within the network.



Parameter	Device Long Tag: wirelessGateway
Identification	Device Tag: WHA_GW
Wireless Communication	Descriptor: DESC
Wired Communication	Date: 2/7/2012
Diagnostics	Message: NOMESSAGE
Engineering	Country Code: Germany
Additional Functions	
Measurement	

Figure 5.2 Parameter > Identification

Identification Parameters


Parameter	Description	Default
Device Long Tag	Identifies the device in a <i>WirelessHART</i> network. Enter up to 32 characters.	–
Device Tag	Identifies the field device within the process plant. Enter up to 8 characters.	–
Descriptor	Further description of the device. Enter up to 16 characters.	–
Date	User-defined date (e.g. last parameter change). Format: DD.MM.YYYY The Date parameter is not modified by the <i>WirelessHART</i> gateway. It must be set by the user or a host application.	–
Message	User-defined message. Enter up to 32 characters.	–
Country Code	Select the country code of the country in which the device is operated from this drop-down list.	–

Table 5.1 Identification Parameters

5.2 Wireless Communication Parameters

5.2.1 Setup

The setup parameters contain the necessary information for establishing and maintaining a *WirelessHART* network.



Parameter	Network Tag:	demowand
Identification	Network ID:	1491
Wireless Communication	Join Key part 1 of 4 (HEX):	*****
Setup	Join Key part 2 of 4 (HEX):	*****
Operating Modes	Join Key part 3 of 4 (HEX):	*****
Wired Communication	Join Key part 4 of 4 (HEX):	*****
Diagnostics	Write Join Information:	>>
Engineering	Real Time Clock Date:	8/6/2012
Additional Functions	Real Time Clock Time:	07:44:00.237
Measurement	Network start date:	7/13/2012
	Network start time:	12:28:54
	Allow new Devices:	all
	Radio Power:	10dBm
	Bandwidth Profile:	Normal Bandwidth Profile
	Global Advertising Timeout:	
	Activate Global Advertising:	>>

Figure 5.3 Parameter > Wireless Communication > Setup



Note!

Join Key

The **Join Key** parameter can only be edited when the security mode is activated by means of a DIP switch inside the enclosure of the *WirelessHART* gateway. To activate the security mode, set DIP switch 8 to ON. → see Figure 2.6 on page 16

In the security mode it is possible to use CMD 768 HART command to set the join key of the *WirelessHART* gateway as required.



Caution!

Network security risk

For security reasons do not use the security mode connection as a normal communication channel. After having changed the join key, disable the security mode using the DIP switch (DIP switch 8 = OFF).



Caution!

Possible loss of connection when changing **Network ID**

If you change the **Network ID** parameter of an already operating *WirelessHART* network, the *WirelessHART* gateway stores the new network ID and applies the network ID the next time the network is reformed (note that reforming the network can take a long time). When the new network ID becomes active, the connection to other *WirelessHART* devices can get lost.

When changing the network ID in the *WirelessHART* gateway, write the new network ID to each wireless device in the network using either the wired or the wireless connection. Again, the new network ID will be stored in the device and will be applied the next time the network is reformed.

Setup Parameters

Parameter	Description	Default
Network Tag	Identifies the device in a <i>WirelessHART</i> network. Enter up to 32 characters.	–
Network ID	Each wireless device needs to store a network ID to identify the <i>WirelessHART</i> gateway it is expected to connect to. Enter up to 5 digits. The network ID may range from 0 ... 65535. Press Write Join Information to store the new network ID to the <i>WirelessHART</i> gateway. Remember to change the network ID of the other wireless devices in the network, too. The network has to be reformed before the new network ID takes effect. To reform the network, choose Reform Network in the Additional Functions > Reset menu.	1945
Join Key Part 1 ... 4	The join key is a common network password. Each wireless device needs this join key to be allowed to join the network. The join key consists of up to 32 hexadecimal characters (0 ... 9, a ... f). There are four text fields. Enter up to 8 hexadecimal characters into each text field. Each text field must contain the same number of characters (e.g. 5 each). Press Write Join Information to store the new join key to the <i>WirelessHART</i> gateway. This parameter can only be edited if the security mode is activated by means of a DIP switch. → see Figure 2.6 on page 16 The network has to be restarted for the new join key to become active. Reform the network by pressing Device Reset in the Additional Functions > Reset menu. If the join key is changed, the currently joined wireless devices will remain connected with the network. However, no device will be allowed to join unless it stores the new join key. Available only online .	E090D6E2 DADECE94 C7E9C8D1 E781D5ED
Write Join Information	Stores the Network ID and Join Key to the <i>WirelessHART</i> gateway. Please read the information related to the network ID and join key in this section including the security notes. Available only online .	
RTC Date	Real-time clock (RTC) date setting for the network. Enter a date in the following format: DD:MM:YYYY. Available only online .	–
RTC Time	Real-time clock (RTC) time setting for the network. Enter a time in the following format: hh:mm:ss. Available only online .	–
Network start date	Shows the date at which the network was (re)started. Available only online .	–
Network start time	Shows the time at which the network was (re)started. Available only online .	–
Allow new Devices	Specify if new devices are allowed to join the <i>WirelessHART</i> network.	all

2015-07

Parameter	Description	Default
Radio Power	Power level of the radio transmitter of the <i>WirelessHART</i> gateway, which should normally be set to 10 dBm. Observe local restrictions for 2400 MHz equipment.	10 dBm
Bandwidth Profile	This option allows you to increase network performance by reducing the latency, which increases the energy consumption and reduces battery life of the network components. We recommend that you use the medium and high performance profiles if latency reduction is more important than battery life. The network has to be reformed for the new bandwidth profile to become active. To reform the network, choose Reform Network in the Additional Functions > Reset menu.	Normal Bandwidth Profile
Global Advertising Timeout	If Global Advertising is activated, the <i>WirelessHART</i> gateway and the network components will send a series of identification messages at a frequency higher than normal to identify new wireless devices and to reduce the network join time. The messages are sent until the Global Advertising Timeout is reached. Enter the timeout in minutes. The timeout may range from 1 ... 255 minutes.	—
Activate Global Advertising	If activated, the network manager sends advertising messages to announce the network's existence. When a <i>WirelessHART</i> field device receives such an advertising message, it tries to join the network. Enabling Global Advertising increases energy consumption of the network components. Therefore we recommend that you use this features only if needed, for example if you expect new devices to join the network. Note that you can activate Global Advertising without reforming the network.	

Table 5.2 Setup Parameters

You can use the **Channel Blacklist** to disable selected channels. If there are other wireless networks in the area where the *WirelessHART* network is located, you can make sure that channels are not used by multiple networks at a time.

Channel Blacklist

2.405 GHz
2.430 GHz
2.455 GHz
2.475 GHz

CH1 CH2 CH3 CH4 CH5 CH6 CH7 CH8 CH9 CH10 CH11 CH12 CH13 CH14 CH15

Active
After restart

Selection okay
Send to Device

Figure 5.4 Channel Blacklist



Create Channel Blacklist

1. To disable a channel, deactivate its check box in the **Channel Blacklist** area. Note that at least 5 channels must remain active.
2. Click **Send to Device** to transfer the updated blacklist settings to the *WirelessHART* gateway. Note that the *WirelessHART* gateway stores the updated blacklist but does not apply the updated settings unless the network is reformed.
3. Go to **Additional Functions > Reset** and click **Reform Network** to apply the updated channel blacklist.



Example!

Note that a WLAN channel based on the IEEE 802.11 standard is wider than a *WirelessHART* channel based on the IEEE 802.15.4 standard. If running a *WirelessHART* network in such an area, we recommend that you also disable adjacent channels. For example, if channel 5 is already occupied by a wireless network based on the IEEE 802.11 standard, we recommend that you disable the *WirelessHART* channels 4, 5, and 6.



Note!

In addition to the manual channel selection, the *WirelessHART* network adapts the channel usage dynamically to new situations, for example if a new wireless network is installed in the area where the *WirelessHART* network is located.

5.2.2

Operating Modes

The **Operating Modes** table displays all devices of the *WirelessHART* network and their operation modes. It represents the virtual I/O system of the *WirelessHART* gateway. See chapter 2.1.3

Whenever a wireless device joins the network, it is automatically inserted into the **Operating Modes** list if it is not already existing. Wired devices connected to a *WirelessHART* adapter will also be inserted.

Operating Modes										
Refresh										
Long Tag	IO-Card	Channel	Device Type	Status	Dev. Status	Routing Device...	Fast Pipe	Enforce Identificat...	Flush Cache	
WirelessGateway	251	1	WHA-GW							
T209innen	1	0	WHA-UT							
Test_Dev_574	3	0	WHA-ADP							
SDOE	3	1	SDOE							
Test_Dev_598	4	0	WHA-ADP							
62E6	4	1	62E6							
T209ausen	5	0	WHA-UT							
Test_Device_604	6	0	WHA-ADP							
-/-	6	1	EJA							
Test_Dev_576	7	0	WHA-ADP							
NEW_VEGA	7	1	62E2							
EH_SWA70_AN_FMR...	8	0	SWA70							
WHA_ADP_AN_Postli...	9	0	WHA-ADP							
SAMSON3730	9	1	373X-3							
WHA-ADP-CorrTran	10	0	WHA-ADP							
CorrTran_LongTa...	10	1	CorrTran MV							
MULTIDROP	11	0	WHA-ADP							
40000003410057	2	0	WHA-UT							
40000003410029	12	0	WHA-UT							
40000003410027	13	0	WHA-UT							

Figure 5.5 Parameter > Wireless Communication > Operating Modes

If required, click **Refresh** to reload the operation mode parameters of all devices.



Caution!

System failure

If you click **Refresh** right after the device was switched on or reset, the system may stop responding.

If the device was switched on or reset, wait about 1 minute until the boot process is complete before you click **Refresh**.



Note!

If using the DTM and PACTware to configure the *WirelessHART* gateway, the following data is available only during online parameterization.

General Data

Displayed Information	Description
Long Tag	Displays the long tag of the device. HART 5 devices and older devices do not support long tags. For those devices, the <i>WirelessHART</i> adapter uses the content of the Message field which will be displayed here instead.
I/O Card	Indicates the virtual I/O card number to which the device is mapped to. See chapter 2.1.3
Channel	Indicates the channel of the virtual I/O card that the device is mapped to. See chapter 2.1.3 The value 0 identifies a <i>WirelessHART</i> device or a <i>WirelessHART</i> adapter, while the value 1 identifies a wired device connected to a <i>WirelessHART</i> adapter.
Device Type	Displays the device type as registered at the HCF.
Status	The following communication statuses exist:  communication not possible  communication possible, device not identified  (flashing) communication possible, identification ongoing  device connected and identified
Dev. Status	Note that the device status displayed in the list may differ from the actual device status because the HART status bits may be interpreted differently. The following device statuses exist:  maintenance required  out of specification  check function  failure

Operating Mode Parameters

Parameter	Description
Routing Device	Indicates whether the device is allowed to act a routing device. This option enables you to set up a star network, or to increase the battery life of certain devices. To deactivate the routing functionality, deactivate the corresponding check box in the Routing Device column. The network has to be reformed before the activated/deactivated routing functionality takes effect. To reform the network, choose Reform Network in the Additional Functions > Reset menu.
Fast Pipe	This option establishes a direct connection to a selected device. The fast pipe connection is about 4 times faster than a regular connection, which enables you to perform fast updates. To establish a direct connection to a selected device, activate the Fast Pipe check box. Note that you can activate the Fast Pipe option only for one device at a time.
Flush Cache	This option deletes the cache of the received HART commands. Note that the measured values will not be deleted to allow host applications to work with the last measured values.
Force Identification	This option forces a device to resend its identification, for example if a communication failure occurred. Note that this option is available only for devices that have not been identified yet.
Delete Device	To remove a device from the list, click the  X-sign at the end of the row. Note that this option is available only for devices that have no connection to the network.

Table 5.3 Operating Mode Parameters

5.3 Wired Communication Parameters



Note!

If you are connected to the *WirelessHART* gateway via Ethernet using the HART IP communication DTM, make sure to update the parameters of the HART IP communication DTM when changing the following parameters of the *WirelessHART* gateway.

- **Parameterization > Wired Communication > Interfaces > Ethernet > IP Address**
- **Parameterization > Wired Communication > Protocols > HART > Bus Address**
- **Parameterization > Wired Communication > Protocols > HART > Port Number**

5.3.1 Serial Interface

The *WirelessHART* gateway can connect to the host system via an Ethernet interface or a serial interface. This section describes the parameters for the serial interface.

Figure 5.6 Parameter > Wired Communication > Interfaces > Serial

Serial Interface Parameters

Parameter	Description	Default
Termination Resistor Selection	Select if you prefer to activate the termination resistor of the <i>WirelessHART</i> gateway via the DIP switches inside the enclosure (see chapter 2.3) or via software.	DIP switches
Termination Resistor	Connect or disconnect the termination resistor of the <i>WirelessHART</i> gateway. This drop-down list depends on the value of Termination Resistor Selection . If the value of Termination Resistor Selection is "DIP switches", this checkbox is read only.	Disconnected
Protocol Selection	Select whether you want to use HART or MODBUS RTU for serial communication.	HART

Table 5.4 Serial Interface Parameters

5.3.2 Ethernet Interface

The *WirelessHART* gateway can connect to the host system via an Ethernet interface or a serial interface. This section describes the parameters for the Ethernet interface.

Parameter

- Identification
- Wireless Communication
- Wired Communication
 - Interfaces
 - Serial
 - Ethernet**
 - Protocols
- Diagnostics
- Engineering
- Additional Functions
- Measurement

IP configuration mode (DHCP, DNS):

IP Address:

Netmask:

Gateway address:

DNS 1:

DNS 2:

MAC Address:

Write Ethernet Information:

Figure 5.7 Parameter > Wired Communication > Interfaces > Ethernet



Caution!

Possible loss of Ethernet connection

After enabling DHCP using the **IP address assignment (DHCP)** parameter, the host can lose the Ethernet connection due to the new, automatically assigned IP address.

Ethernet Interface Parameters

Parameter	Description	Default
IP configuration mode (DHCP, DNS)	Select Manually to configure the IP address, gateway address, and Domain Name Server (DNS) manually, or select Automatic to enable automatic configuration via the Dynamic Host Configuration Protocol (DHCP) server. If you choose Automatic , all other input fields in the window will be grayed out (read only).	Manually
IP Address	If using manual configuration, enter the IP address of the <i>WirelessHART</i> gateway.	192.168.1.1
Netmask	If using manual configuration, enter the subnet mask.	255.255.255.0
Gateway address	If using manual configuration and if necessary, specify the IP address of the <i>WirelessHART</i> gateway in the IP network. Note that this is not the IP address of the <i>WirelessHART</i> gateway. If changing the gateway address , it can take up to 10 seconds for the changes to take effect.	0.0.0.0
DNS 1	If using manual configuration, enter the address of the first Domain Name Server (DNS 1).	0.0.0.0
DNS 2	If using manual configuration, enter the address of the second Domain Name Server (DNS 2).	0.0.0.0
MAC Address	Displays the MAC address of the <i>WirelessHART</i> gateway. Note that the MAC address is a characteristic of the device itself and cannot be changed. Each device has a unique MAC address.	
Write Ethernet Information	Applies the current Ethernet settings from above to the <i>WirelessHART</i> gateway.	

Table 5.5 Ethernet Interface Parameters

2015-07

5.3.3 HART Protocol

The protocol parameters configure the protocols that run over the serial interface or the Ethernet interface (HART or MODBUS).

When using the serial interface, only one protocol can be active at a time (either HART or MODBUS), depending on the value of the serial interface parameter **Protocol Selection**. See chapter 5.3.1

When using the Ethernet interface, there is no need to select a protocol. Both protocols run parallel using different port numbers.

Figure 5.8 Parameter > Wired Communication > Protocols > HART

HART Parameters

Parameter	Description	Default
Serial		
Bus Address Selection	Select DIP switches to specify the polling address of the <i>WirelessHART</i> gateway using the DIP switches inside the enclosure (see chapter 2.3) or select Software to specify the polling address in the following field.	DIP switches
Bus Address	■ If Bus Address Selection is set to DIP switches, this is a read-only field. ■ If using the DTM and PACTware® for specifying the polling address, this field is a read-only field and you must enter the polling address in the HART IP Communication DTM. See chapter 6.1 ■ If using the web interface for specifying the polling address, enter the polling address for the <i>WirelessHART</i> gateway.	0
Baud Rate Selection	Select DIP switches to specify the baud rate of the <i>WirelessHART</i> gateway using the DIP switches inside the enclosure (see chapter 2.3) or select Software to specify the baud rate in the following field.	DIP switches
Baud Rate	If using the DTM or web interface for specifying the baud rate, select the baud rate for the <i>WirelessHART</i> gateway from the drop-down list. If Baud Rate Selection is set to DIP switches , this parameter is read only.	19200

Parameter	Description	Default
Ethernet		
Port Number	Enter the port number of the <i>WirelessHART</i> gateway (HART over UDP, Ethernet Interface).	5094



Tip

If you change the Ethernet port for the HART protocol, the default port remains open and active. Thus, you can communicate with the *WirelessHART* gateway over the default port (5094) and a user-defined port in parallel. Note that this behavior applies only for the HART protocol (not for the MODBUS protocol).

5.3.4 MODBUS Protocol

The protocol parameters configure the protocols that run over the serial interface or the Ethernet interface (HART or MODBUS).

When using the serial interface, only one protocol can be active at a time (either HART or MODBUS), depending on the value of the serial interface parameter **Protocol Selection**. See chapter 5.3.1

When using the Ethernet interface, there is no need to select a protocol. Both protocols run parallel using different port numbers.

Figure 5.9 Parameter > Wired Communication > Protocols > Modbus

MODBUS Parameters

Parameter	Description	Default
Serial		
Bus Address Selection	Select DIP switches to specify the polling address of the <i>WirelessHART</i> gateway using the DIP switches inside the enclosure (see chapter 2.3) or select Software to specify the polling address in the following field.	DIP switches
Bus Address	If using the software for specifying the polling address, enter the polling address for the <i>WirelessHART</i> gateway. If Bus Address Selection is set to DIP switches , this parameter is read only.	1

2015-07

Parameter	Description	Default
Baud Rate Selection	Select DIP switches to specify the baud rate of the <i>WirelessHART</i> gateway using the DIP switches inside the enclosure (see chapter 2.3) or select Software to specify the baud rate in the following field.	DIP switches
Baud Rate	If using the software for specifying the baud rate, select the baud rate for the <i>WirelessHART</i> gateway from the drop-down list. If Baud Rate Selection is set to DIP switches , this parameter is read only.	19200
Parity Bit	Select the type of parity bit (odd, even or none) that you wish to use over the asynchronous serial protocol.	None
Stop Bit	Select the number of stop bits (1, 1.5 or 2) that you wish to use over the asynchronous serial protocol.	1
Ethernet		
Port number	Enter the port number for MODBUS TCP.	502

Table 5.6 MODBUS Parameters

5.3.5 Emerson AMS Integration

Integration in the Emerson AMS Suite is performed via Ethernet.




Figure 5.10 Parameter > Wired Communication > Protocols > AMS

AMS Parameters

Parameter	Description	Default
Port number	Enter the port number under which the AMS will address the <i>WirelessHART</i> gateway.	33333

5.4 Diagnostics

The **Diagnostics** function provides detailed information about the device, wireless/wired communication and health status.



Note!

Available Only Online (DTM)

If using the configuration via DTM and PACTware the **Diagnostics** function is available only online. See chapter 6.4



Accessing the Diagnostics Window

1. If using the DTM and PACTware, right-click the device in the project tree and select **Diagnostics**.
2. If using the web interface, select **Diagnostics** in the navigation area on the left.

5.4.1

Identification

Here you find information about the *WirelessHART* gateway.

- Parameter - Diagnostics Identification - Wireless Communication - Wired Communication - Engineering - Additional Functions - Measurement	<table><tr><td>Device Long Tag:</td><td>wirelessGateway</td></tr><tr><td>Device Tag:</td><td>WHA_GW</td></tr><tr><td>Descriptor:</td><td>DESC</td></tr><tr><td>Date:</td><td>2/7/2012</td></tr><tr><td>Message:</td><td>NOMESSAGE</td></tr><tr><td>Universal Command Revision:</td><td>7</td></tr><tr><td>Device Revision:</td><td>1</td></tr><tr><td>Software Revision:</td><td>25</td></tr><tr><td>Country Code:</td><td>Germany</td></tr><tr><td>Assembly Number:</td><td>4144959</td></tr></table>	Device Long Tag:	wirelessGateway	Device Tag:	WHA_GW	Descriptor:	DESC	Date:	2/7/2012	Message:	NOMESSAGE	Universal Command Revision:	7	Device Revision:	1	Software Revision:	25	Country Code:	Germany	Assembly Number:	4144959
Device Long Tag:	wirelessGateway																				
Device Tag:	WHA_GW																				
Descriptor:	DESC																				
Date:	2/7/2012																				
Message:	NOMESSAGE																				
Universal Command Revision:	7																				
Device Revision:	1																				
Software Revision:	25																				
Country Code:	Germany																				
Assembly Number:	4144959																				

Figure 5.11 Diagnostics > Identification

Identification Information

Parameter	Description
Device Long Tag	Identifies the device in a <i>WirelessHART</i> network.
Device Tag	Identifies the field device within the process plant.
Descriptor	Further description of the device.
Date	User-defined date (e.g. last parameter change). Format: DD.MM.YYYY The Date parameter is not modified by the <i>WirelessHART</i> gateway. It must be set by the user or a host application.
Message	User-defined message.
Universal command revision	Revision of the universal commands of the device. Only available online .
Device Revision	Revision of the device-specific commands. Only available online .
Software Revision	Software revision of the device. Only available online .
Country Code	Country code of the country in which the device is operated (user-defined).
Assembly Number	The assembly number of the <i>WirelessHART</i> gateway. Only available online .

Table 5.7 Identification Information

5.4.2 Wireless Communication

Overview

The overview screen provides information about the I/O interfaces of the wireless network as well as network statistics.

I/O System Capabilities	
Max. Card Number:	250
Max. Channel Number:	2
Max. Sub Dev. Number:	6
Number of Devices:	15

Lifetime Network Statistics	
Reliability:	100.000000 %
Stability:	93.834000 %
Latency:	1915 ms
Lost upstream packages:	0

Figure 5.12 Diagnostics > Wireless Communication > Overview

Overview Information

Displayed Information	Description
I/O System Capabilities	
Max. Card Number	Displays maximum number of cards in the I/O system. This corresponds to the maximum number of wireless devices that can be connected to the <i>WirelessHART</i> gateway.
Max. Channel Number	Displays maximum number of channels. The <i>WirelessHART</i> gateway always returns the value 2.
Max. Sub Dev. Number	Displays maximum number of sub devices that can be connected to a specific <i>WirelessHART</i> adapter.
Number of Devices	Displays current number of sub devices. Every device counts as a sub device, no matter if it is a wireless device or a wired device connected to a <i>WirelessHART</i> adapter.
Lifetime Network Statistics	
Reliability	Percentage of data packets generated by wireless devices that were correctly received by the <i>WirelessHART</i> gateway.
Stability	Ratio of successful data packet transfers to the total number of data packet transfers on all wireless paths in the network.
Latency	Average time taken for data packets generated by the wireless devices to reach the <i>WirelessHART</i> gateway.
Lost upstream packages	Total number of data packets generated by the wireless devices that were lost when transferred over the network.

Table 5.8 Overview Information



Details

The **Details** table displays all devices of the *WirelessHART* network including their diagnostic information of the last 15 minutes.



Note!

Diagnostic information is available only after a cycle of 15 minutes has been completed. During this time, some information is set to 0 or replaced by wildcard characters.

The diagnostic information represents the last 15 minutes only. Note that for connection paths with very low traffic, the validity of the diagnostic information can be poor.

Long Tag	IO-Card	Channel	Device Type	Status	Dev. Status	Number of Joins	Join Time	Reliability	Latency	Neighbors	RSSI	Stability
wirelessGateway	251	1	WHA-GW	✓	✓					40000003410057	-60 dBm	77.776927...
				✓	✓					40000003410029	-67 dBm	100
				✓	✓					40000003410027	-68 dBm	100
				✓	✓					WHA_ADP_AN_P...	-44 dBm	100
				✓	✓					MULTICROP	-61 dBm	60.549626...
				✓	✓					EH_SNA70_AN_F...	-47 dBm	100
				✓	✓					Test_Device_804	-62 dBm	93.5479888...
				✓	✓					Test_Dev_576	-60 dBm	32
				✓	✓					T209aussein	-40 dBm	100
				✓	✓					Test_Dev_574	-65 dBm	67.6779907...
				✓	✓					T209innen	-44 dBm	96.675
T209innen	1	0	WHA-UT	✓	✓	1	7/13/2012 14:36...	0	0			
Test_Dev_574	3	0	WHA-ADP	✓	✓	1	7/13/2012 14:34...	0	0			
Test_Dev_580	4	0	WHA-ADP	✗	✓							
T209aussein	5	0	WHA-UT	✓	✓	1	7/13/2012 14:36...	0	0			
Test_Device_804	6	0	WHA-ADP	✓	✓	1	7/13/2012 14:35...	0	0			
Test_Dev_576	7	0	WHA-ADP	✓	✓	1	7/13/2012 14:35...	0	0			
EH_SNA70_AN_FMIQ221	8	0	SNA70	✓	✓	1	7/13/2012 14:34...	100 %	1.298 s			
WHA_ADP_AN_Posio...	9	0	WHA-ADP	✗	✓	1	7/13/2012 14:35:5	0	0			
WHA_ADP-ConnTran	10	0	WHA-ADP	✗	✓							
MULTICROP	11	0	WHA-ADP	✓	✓	1	7/13/2012 14:35...	0	0			
40000003410057	2	0	WHA-UT	✓	✓	1	7/13/2012 14:35:3	0	0			
40000003410029	12	0	WHA-UT	✓	✓	1	7/13/2012 14:36...	0	0			
40000003410027	13	0	WHA-UT	✓	✓	1	7/13/2012 14:36:9	0	0			

Figure 5.13 Diagnostics > Wireless Communication > Details

To show/hide the index number of a device in the structure, deactivate/activate **Tree-View**. If **Tree-View** is deactivated, the devices are shown in the order they were added to the instrument list.

If required, click **Refresh** to reload the diagnostic details of all devices.



Caution!

System failure

If you click **Refresh** right after the device was switched on or reset, the system may stop responding.

If the device was switched on or reset, wait about 1 minute until the boot process is complete before you click **Refresh**.



Note!

If using the DTM and PACTware to configure the *WirelessHART* gateway, the following data is available only during online parameterization.

General Data

Displayed Information	Description
Long Tag	Displays the long tag of the device. HART 5 devices and older devices do not support long tags. For those devices, the <i>WirelessHART</i> adapter uses the content of the Message field which will be displayed here instead.
I/O Card	Indicates the virtual I/O card number to which the device is mapped to. See chapter 2.1.3
Channel	Indicates the channel of the virtual I/O card that the device is mapped to. See chapter 2.1.3 The value 0 identifies a <i>WirelessHART</i> device or a <i>WirelessHART</i> adapter, while the value 1 identifies a wired device connected to a <i>WirelessHART</i> adapter.
Device Type	Displays the device type as registered at the HCF.
Status	The following communication statuses exist:  communication not possible  communication possible, device not identified  (flashing) communication possible, identification ongoing  device connected and identified
Dev. Status	Note that the device status displayed in the list may differ from the actual device status because the HART status bits may be interpreted differently. The following device statuses exist:  maintenance required  out of specification  check function  failure

Diagnostic Information

Parameter	Description
Number of Joins	Number of times the device has joined the network.
Join Time	Date and time of the most recent join.
Reliability	Percentage of the data packets generated by the wireless devices that were correctly received by the <i>WirelessHART</i> gateway.
Latency	Average time taken for data packets generated by the wireless devices to reach the <i>WirelessHART</i> gateway.
+	To show/hide the list of neighboring devices, click the + sign in the + column.
Neighbors	Lists the neighboring <i>WirelessHART</i> devices in reach of the selected device.
RSSI	The RSSI (Received Signal Strength Indicator) indicates the power of the received signal for each neighboring device. Note that you must expand the list of neighboring devices in order to see the RSSI value for each device.
Stability	Ratio of successful data packet transfers to the total number of data packet transfers on all wireless paths in the network.

Table 5.9 Diagnostic Information

To export the diagnostic details to a CSV file, click **Export** (web interface) resp. **Export CSV** (DTM).

For more information on the structure of the CSV file, see chapter 12.

Burst Lists

Normally, a HART slave device only responds when being polled by the host. Burst mode is a special communication mode in which a HART slave device sends data to a particular HART command without being polled by the host. When burst mode is used, a HART slave device can publish data (for example process values) autonomously to another device in regular intervals. Alternatively, data can be published if the value has changed by a significant amount, has reached a certain threshold level, or has not been updated within a default reporting time.

The *WirelessHART* gateway maintains a burst message list, which lists the specific commands that are being published by each device in the *WirelessHART* network. Note that the burst list is reset after power-up or network restart.



Note!

The *WirelessHART* gateway is able to cache up-to-date device status information only if at least one command is published in each wireless device. Up-to-date data is important for efficient device status monitoring. You can find the publishing parameters of most *WirelessHART* devices in the **Burst Mode** menu of the DTM.

Device Publishing Guidelines

- We recommended that you always publish **command 48** to ensure caching of the related status information. A publishing interval of approx. 1 minute is generally the best choice for wireless devices (not for wired devices).
For example, when configuring *WirelessHART* adapters, **command 48** allows proper identification and management of changes in the sub-device list without intervention of the host.
- Publishing of at least one command on the wireless device level enables detection of configuration changes and automatic device cache invalidation without intervention of the host.
- Publishing of at least one command also ensures that the cached status information is updated for cached configuration commands.
- Short publishing intervals may impair battery life of wireless devices.

Burst Lists									
Refresh									
Long Tag	IO-Card	Channel	Device Type	Status	Dev. Status		Burst command	Num Packets	
WirelessGateway	251	1	WHA-GW						
• T209Innen	1	0	WHA-UT	✓	⚠		Cmd 3 Read Dynamic Variables and Loop ...	2404	
				✓	✓		Cmd 48 Read Additional Device Status	601	
Test_Dev_574	3	0	WHA-ADP	✓	✓				
• SDOE	3	1	SDOE	✓	✓				
Test_Dev_598	4	0	WHA-ADP	✗	✓				
• 62E6	4	1	62E6	✗	✓				
• T209aussen	5	0	WHA-UT	✓	⚠		Cmd 3 Read Dynamic Variables and Loop ...	1202	
				✓	✓		Cmd 48 Read Additional Device Status	1803	
				✓	✓		Cmd 178	601	
				✓	✓		Cmd 9 Read Device Variables with Status	601	
Test_Device_604	6	0	WHA-ADP	✓	✓		Cmd 48 Read Additional Device Status	601	
				✓	✓		Cmd 77	121	
• -/-	6	1	EJA	✓	✓				
Test_Dev_576	7	0	WHA-ADP	✓	✓				
• NEW_VEGA	7	1	62E2	✓	✓				
• EH_SWIA70_AN_FMR231	8	0	SWIA70	✓	⚠		Cmd 48 Read Additional Device Status	1201	
WHA_ADP_AN_Positioner	9	0	WHA-ADP	✓	✓		Cmd 77	51	
				✓	✓		Cmd 48 Read Additional Device Status	25	
WHA-ADP-CorrTran	10	0	WHA-ADP	✗	✓				
MULTIDROP	11	0	WHA-ADP	✓	⚠		Cmd 48 Read Additional Device Status	601	
• 40000003410057	2	0	WHA-UT	✓	⚠				
• 40000003410029	12	0	WHA-UT	✓	⚠		Cmd 1 Read Primary Variable	1202	
• 40000003410027	13	0	WHA-UT	✓	⚠				

Figure 5.14 Diagnostics > Wireless Communication > Burst Lists

To show/hide the index number of a device in the structure, deactivate/activate **Tree-View**. If **Tree-View** is deactivated, the devices are shown in the order they were added to the instrument list.

If required, click **Refresh** to reload the burst parameters of all devices.



Caution!

System failure

If you click **Refresh** right after the device was switched on or reset, the system may stop responding.

If the device was switched on or reset, wait about 1 minute until the boot process is complete before you click **Refresh**.



Note!

If using the DTM and PACTware to configure the *WirelessHART* gateway, the following data is available only during online parameterization.

General Data

Displayed Information	Description
Long Tag	Displays the long tag of the device. HART 5 devices and older devices do not support long tags. For those devices, the <i>WirelessHART</i> adapter uses the content of the Message field which will be displayed here instead.
I/O Card	Indicates the virtual I/O card number to which the device is mapped to. See chapter 2.1.3
Channel	Indicates the channel of the virtual I/O card that the device is mapped to. See chapter 2.1.3 The value 0 identifies a <i>WirelessHART</i> device or a <i>WirelessHART</i> adapter, while the value 1 identifies a wired device connected to a <i>WirelessHART</i> adapter.
Device Type	Displays the device type as registered at the HCF.
Status	The following communication statuses exist:  communication not possible  communication possible, device not identified  (flashing) communication possible, identification ongoing  device connected and identified
Dev. Status	Note that the device status displayed in the list may differ from the actual device status because the HART status bits may be interpreted differently. The following device statuses exist:  maintenance required  out of specification  check function  failure

Burst Parameters

Parameter	Description
+	To show/hide the list of burst messages for a device, click the + sign in the + column.
Burst Command	Displays the HART command number and its description.
Num. Packets	Number of burst messages the device has sent.

Table 5.10 Burst Parameters

Topology View

The topology view is a graphical overview of all wireless devices within your network, including their connection status and connection paths. To set up the topology view, go to **Engineering > Topology View**. See chapter 5.5.5

The lines between the devices represent the connection paths. The thickness of a connection path indicates the traffic for this path compared to the total traffic. The color of the connection path indicates the stability of the connection for this path.



Note!

Traffic and stability data is available only after a statistics cycle of 15 minutes has been completed.

Note that the data that is displayed in the topology view represents a single cycle of 15 minutes only.

Traffic

Line Style	Description
-----	Dotted lines represent unused paths.
—	Thin lines represent paths with poor traffic (compared to the total traffic).
—	Medium lines represent paths with medium traffic (compared to the total traffic).
—	Thick lines represent important connection paths with heavy traffic (compared to the total traffic).

Stability

Color	Successfully received messages in %
	0 - 10
	10 - 20
	20 - 30
	30 - 40
	40 - 50
	50 - 60
	60 - 70
	70 - 80

2015-07

Color	Successfully received messages in %
	80 - 90
	90 - 100



Note!

For paths indicated in black, there is no statistic information available.



Example!

In the following example you can see that the devices **WHA-ADP-CorrTran** and **Test_Dev_598** have no network connection (red status icon and no connection paths) and thus they are unavailable. Apart from these devices, all other devices are linked with unused connections (dotted lines), which means that if the main connection fails, the communication can easily be switched to an alternative, unused connection path.




Figure 5.15 Diagnostics > Wireless Communication > Topology View

Use the slider to zoom in or out of the topology view. To reset the zoom to its default value, click **Reset Zoom**.

Click the devices in the topology view for more information on the device.

If required, click **Refresh** to reload the device information and rebuild the topology view. Note that rebuilding the topology view takes some time.



Caution!

System failure

If you click **Refresh** right after the device was switched on or reset, the system may stop responding.

If the device was switched on or reset, wait about 1 minute until the boot process is complete before you click **Refresh**.

Topology View Parameters

Parameter	Description
Horizontal image origin	Displays the horizontal respectively vertical alignment of the background image. See chapter 5.5.5
Vertical image origin	
Resolution	Displays the resolution of the background image. See chapter 5.5.5
Paths shown	Enables you to select the connection paths that are displayed in the topology view.

Table 5.11 Topology View Parameters

Display connection paths for a single device

1. Select **Selected** in the **Paths shown** drop-down list.
2. Move the cursor over a device in the topology view.
↳ The connection paths are displayed for the select device.

5.4.3

Wired Communication

The overview screen provides information the host connection of the *WirelessHART* gateway. The information is only available when online.




Figure 5.16 Diagnostics > Wired Communication > Overview

Overview Information

Displayed Information	Description
Messages received through HOST	Total bytes received by the host system.
Messages returned to HOST	Total bytes transmitted to the host system.
Number of Requests forwarded to the I/O system	
Number of responses returned from the I/O system	

Table 5.12 Overview Information



Device Name: WHA-GW

Device Long Tag: wirelessGateway

NE107 Status: ■ Good

Device Revision: 1

Descriptor: DESC

Timestamp of Status: 10:53:48



- ⊕ Parameter
- ⊖ Diagnostics
 - ⊖ Identification
 - ⊕ Wireless Communication
 - ⊖ Wired Communication
 - Overview
 - HART**
- ⊕ Engineering
- ⊕ Additional Functions
 - Measurement

Extended Device Malfunction: ■

- ☐ Manager fault
- ☐ Non-Volatile Memory Defect
- ☐ Volatile Memory Defect
- ☐ Ethernet communication fault
- ☐ Electronic defect
- ☐ RS-485 communication fault

Gateway Operation in Progress: ■

- ☐ Block transfer
- ☐ Delayed answer
- ☐ Self-test
- ☐ File update
- ☐ Start-up phase

Extended List changes: ■

- ☐ Instrument List Changed
- ☒ Active Device List changed

Cumulative Device Status: ■

- ☐ Primary Variable Out of Limits
- ☐ Non-Primary Variable Out of Limits
- ☐ Loop Current Saturated
- ☐ Loop Current Fixed
- ☒ More Status Available
- ☐ Cold Start
- ☒ Configuration Changed
- ☒ Device malfunction

Cumulative Extended Device Status: ■

- ☐ Maintenance Required
- ☐ Device Variable Alert
- ☒ Critical Power Failure

Device Operation in Progress: ■

- ☐ "Configuration Changed bit reset" procedure
- ☐ "Sub-Device update" procedure
- ☐ "Device update" procedure

Figure 5.17 Diagnostics > Wired Communication > HART



Note!

Not all parameters from the **Diagnostics > Wired Communication > HART** window are used by the *WirelessHART* gateway. In the following table, only the relevant parameters are described.

Most parameters are transient parameters, which means that they are automatically reset if the status does no longer apply. The following exceptions have to be reset by pressing **Reset Diagnostic Bits** in the **Additional Functions > Reset** menu.

- Active Device List changed
- More Status Available
- Configuration Changed

HART Parameters

Parameter	Description
Extended Device Malfunction	
Manager fault	Non-recoverable hardware fault within the manager section of the <i>WirelessHART</i> gateway.
Non-Volatile Memory Defect	Non-recoverable hardware fault within a non-volatile memory area.
Volatile Memory Defect	Non-recoverable hardware fault within a volatile memory area.
Ethernet Communication Fault	Non-recoverable hardware fault within the communication controller associated with the Ethernet interface.
Electronic Defect	Non-recoverable hardware fault within the <i>WirelessHART</i> gateway different from the other faults in the "Extended Device Malfunction" category.
RS-485 Communication Fault	Non-recoverable hardware fault within the communication controller associated with the RS-485 interface.
Gateway Operation in Progress	
Block transfer	When the checkbox is activated, this shows that block-transfer activity is going on in the <i>WirelessHART</i> gateway.
Delayed answer	When the checkbox is activated, this shows that delayed-answer activity is going on in the <i>WirelessHART</i> gateway, which can be related either to a buffer of the <i>WirelessHART</i> gateway or to a buffer of a connected device.
Self-test	This bit is associated with a self-test activity triggered by CMD 41. The checkbox remains activated until the activity has been completed.
File update	If required, the <i>WirelessHART</i> gateway can write persistent (i.e. non-volatile) information to its local file system. The checkbox remains activated as long as information is being written to the file system.
Start-up phase	At each power-up or software restart / reset (triggered by CMD 42 & 141), the <i>WirelessHART</i> gateway polls all devices within the Instrument List to check their communication statuses and to update their identity information. The checkbox remains activated until the start-up phase has been completed.
Extended List Changes	
Instrument List changed	This checkbox is activated whenever the Instrument List content is changing.
Active Device List changed	This checkbox is activated whenever the "Active Device list" content is changing. This is the case when a "communication loss" or a "communication recovered" event takes place for a device.
Cumulative Device Status These bits are set to 1 whenever the related status applies to one or more devices (or sub-devices) connected to the <i>WirelessHART</i> gateway.	
Primary Variable out of Limits	The PV is beyond its operating limits.
Non-Primary Variable out of Limits	A device variable not mapped to the PV is beyond its operating limits.
Loop Current Saturated	The loop current has reached its upper (or lower) endpoint limit and cannot increase (or decrease) any further.

2015-07

Parameter	Description
Loop Current Fixed	The loop current is being held at a fixed value and is not responding to process variations.
More status available	More status information is available via Command 48 (Read Additional Status Information).
Cold Start	A power failure or device reset has occurred.
Configuration Changed	An operation was performed that changed the device's configuration.
Device Malfunction	The device detected a serious error or failure that compromises device operation.
Cumulative Extended Device Status These bits are set to 1 whenever the related status applies to one or more devices (or sub-devices) connected to the <i>WirelessHART</i> gateway.	
Maintenance Required	One or more wireless devices require maintenance.
Device Variable Alert	One or more wireless devices have a device variable alert. This bit is set if any device variable is in alarm or warning state.
Critical Power Failure	One or more wireless devices have a power failure (e.g. battery low).
Device Operation in Progress These bits are set to 1 whenever the related procedure is ongoing in one or more devices (or sub-devices) connected to the <i>WirelessHART</i> gateway. When an operation is ongoing, the <i>WirelessHART</i> gateway will return a "Busy" response code to any HART message of the host directed to the relevant device (or sub-device). These bits are not latched and simply reflect the current operation status.	
"Configuration Changed bit reset" procedure	The "Configuration Changed bit" procedure is being performed at one or more devices.
"Sub-Device update" procedure	One or more sub-devices of <i>WirelessHART</i> adapters are being updated.
"Device update" procedure	One or more wireless devices are being updated.

Table 5.13 HART Parameters

5.5

Engineering

The **Engineering** section consists of the following sections:

■ Instrument List

You can freely define an instrument list of all network components before the devices actually join the network. Hereby you can make sure that a device is associated with the predefined I/O card number when the network is reformed or the *WirelessHART* gateway is reset.

■ MODBUS Mapping

You can create the mapping table for the MODBUS input registers manually, semi-automatically, or automatically.

Note that the instrument list must be available before you create the mapping table, because the values for the mapping table are device-related.

■ Topology View

You can upload a background image and arrange the *WirelessHART* devices in the image to set up the topology view.

Note that the instrument list must be available before you set up the topology view, because the set of *WirelessHART* devices is derived from the instrument list.




Figure 5.18 Relationship between the configuration options in the DTM or web interface and the data in the *WirelessHART* gateway

1. The **Instrument List** you set up via the DTM or the web interface is not necessarily identical to the **Operating Modes** list of the *WirelessHART* gateway.
You can set up the **Instrument List** manually, import an existing list from a CSV file, import the devices from the PACTware® project tree, or import the devices from the **Operating Modes** list of the *WirelessHART* gateway. You can freely edit the **Instrument List** in the DTM or web interface. Once the list of devices and their IO card and channel association is complete, you can write this information back to the **Operating Modes** list of the *WirelessHART* gateway.
The **Operating Modes** list contains all devices of the *WirelessHART* network and is constantly updated.
If a new device joins the network, it is automatically inserted into the **Operating Modes** list. If the long tag or address of the new device matches an entry from the list, for example, an entry that you predefined using the **Instrument List**, the device is associated with the predefined values. If not, it is automatically associated with the next free IO card number and it will not appear in the **Instrument List** unless you import the device list from the **Operating Modes** list.
2. Before you create the **MODBUS Mapping**, you must select whether you want to create the mapping manually, semi-automatically, or automatically:
 - If you select **automatic addressing**, the mapping is created automatically for all devices of the **Operating Modes** list. If new *WirelessHART* devices appear in the *WirelessHART* network, they are automatically added to the **Operating Modes** list, and the mapping will also be added automatically.
 - If you select **manual addressing**, you can set up the MODBUS mapping manually or semi-automatically for all devices of the **Instrument List**. Note that if a new *WirelessHART* device joins the *WirelessHART* network, it is added to the **Operating Modes** list only. Because you selected manual addressing, the automatic addressing for the devices in the **Operating Modes** list is disabled and the device does not automatically appear in the **MODBUS Mapping** of the *WirelessHART* gateway. To set up the mapping for the new device, you must import the new device into the **Instrument List** first. After the mapping is complete, you can write the **MODBUS Mapping** from the DTM or web interface to the *WirelessHART* gateway.
3. In the DTM or web interface you can upload a background image and arrange the positions for all devices of the **Instrument List**. After you set up the topology view, you can write the information back to the *WirelessHART* gateway.
If a new *WirelessHART* device joins the *WirelessHART* network, it is inserted at a default position by the *WirelessHART* gateway. To rearrange new devices in the DTM or web interface, you can import the new device into the **Instrument List** or import the device list from the *WirelessHART* gateway.

5.5.1 Instrument List

The instrument list is a copy of the **Operating Modes** list, which is currently active in the *WirelessHART* gateway and represents the virtual I/O system of the *WirelessHART* gateway. See chapter 2.1.3

Thus, unless the **Instrument List** is reloaded from the *WirelessHART* gateway, it may not necessarily be identical to the **Operating Modes** list that is currently active in the *WirelessHART* gateway.

By creating an instrument list before the devices actually join the network, you can make sure that a device is associated with a predefined I/O card number when the network is reformed or the *WirelessHART* gateway is reset. Note that the instrument list is used for editing the devices and that the cached values of the devices are located under **Measurement**. See chapter 5.7

For a detailed overview of the relationship between the configuration options in the DTM or web interface and the data in the *WirelessHART* gateway, → see Figure 5.18 on page 60.



Note!

This list is stored in a non-volatile memory of the *WirelessHART* gateway. The card and channel number assignment will remain the same after a restart of the *WirelessHART* gateway or software.

Parameter

Diagnostics

Engineering

Instrument List

Modbus Mapping

Topology View

Additional Functions

Measurement

Instrument List

Export

Import

Refresh

Apply

Index	Long Tag	I/O-Card	Channel	Device ID	Extended Device Type Code	
0	T209Innen	1	0	00047B	5DE2	✗
1	Test_Dev_574	3	0	658064	5DE1	✗
2	Test_Dev_598	4	0	65806C	5DE1	✗
3	T209aussen	5	0	0003D1	5DE2	✗
4	Test_Device_604	6	0	6580A0	5DE1	✗
5	-/-	6	1	1FCC5C	3704	✗
6	Test_Dev_576	7	0	658048	5DE1	✗
7	EH_SWA70_AN_FMR231	8	0	012345	11F0	✗
8	WHA_ADP_AN_Positioner	9	0	61001D	5DE1	✗
9	WHA-ADP-CorrTran	10	0	5C8030	5DE1	✗
10	NEW_VEGA	7	1	F97A0B	62E2	✗
11	CorrTran_Long_Tag_2	10	1	000000	5DE4	✗
12	SAMSON3730	9	1	6BB623	42EF	✗
13	MULTIDROP	11	0	610010	5DE1	✗
14	5D0E	3	1	5E320A	5D0E	✗
15	62E6	4	1	D1A240	62E6	✗
16	40000003410057	2	0	00045A	5DE2	✗
17	40000003410029	12	0	000443	5DE2	✗
18	40000003410027	13	0	00044C	5DE2	✗

Info

Figure 5.19 Engineering > Instrument List

Instrument List

Displayed Information	Description
Long Tag	Long tag of the device HART 5 devices and older devices do not support long tags. For those devices, the <i>WirelessHART</i> adapter uses the content of the Message field, which will be displayed here instead.
I/O-Card	Virtual I/O card number to which the device is mapped to. See chapter 2.1.3
Channel	Channel of the virtual I/O card the device is mapped to. The value 0 identifies a <i>WirelessHART</i> device or a <i>WirelessHART</i> adapter, while the value 1 identifies a wired device connected to a <i>WirelessHART</i> adapter.
Device ID	HART serial number that is assigned at manufacturing time and that differs for each HART device of a given type. The Device ID is used to build the HART long frame address.
Ext. Device Code	Extended device type code of the device Identifies the HART product family. Each product family is identified by a unique code.

Table 5.14 Instrument List



Caution!

System failure

If you click **Refresh** right after the device was switched on or reset, the system may stop responding.

If the device was switched on or reset, wait about 1 minute until the boot process is complete before you click **Refresh**.

2015-07



Editing the Instrument List



Note!

When editing the instrument list, incomplete entries are highlighted in red. These errors must be corrected before you can apply the instrument list. Warnings are highlighted in yellow.

1. To read the **Operating Modes** list from the *WirelessHART* gateway using the web interface, click **Refresh**. If using the DTM to configure the *WirelessHART* gateway, select the *WirelessHART* gateway in the project tree and choose **Device > Load from device**. If using the DTM to configure the *WirelessHART* gateway, you can also import the devices of the project tree by clicking **Import Project Tree** (DTM).
2. To add a device, click into the last row of the instrument list and specify the device parameters. Press **Enter** to confirm your entries.
You can also edit existing entries by clicking into the corresponding cells of the instrument list.
3. To remove a device from the instrument list, click the  X-sign at the end of the row. The respective I/O card becomes vacant again.
4. To write the current instrument list to the *WirelessHART* gateway using the web interface, click **Apply**. If using the DTM to configure the *WirelessHART* gateway, select the *WirelessHART* gateway in the project tree and choose **Device > Store to device**.
Note that the consistency of the instrument list is not checked before it is applied.

To export the current instrument list to a CSV file, click **Export** (web interface) resp. **Export CSV** (DTM).

To load the instrument list from a CSV file, click **Import** (web interface) resp. **Import CSV** (DTM).

For more information on the structure of the CSV file, see chapter 12.



Tip

If a *WirelessHART* gateway is replaced with a new one, we recommend that you use the export/import functionality to transfer the settings from the old *WirelessHART* gateway to the new one. Otherwise, the new *WirelessHART* gateway rebuilds the *WirelessHART* network from scratch by default, which means that the virtual HART I/O structure in the instrument list and the MODBUS addresses of the devices will differ from the positions and addresses that have been defined in the old *WirelessHART* gateway.

Furthermore, if using the DTM to configure the *WirelessHART* gateway, you can prepare the instrument list and the MODBUS mapping tables offline and export the configuration into a CSV file. Once the *WirelessHART* gateway is available on site, you can import the prepared configuration via the CSV file.

5.5.2 MODBUS Settings

Here you can define several MODBUS settings and choose between automatic or manual MODBUS mapping.




Figure 5.20 Engineering > Modbus Mapping > Modbus Settings

MODBUS Parameters

Parameter	Description
Swap Option	Enables you to select the Big Endian or Little Endian swap option. Note that this setting affects both automatic and manual addressing of the MODBUS registers. In the following examples a word32 [0xABCD] is stored into MODBUS registers using different swap options. Big Endian: no register swap Registers: Big Endian Source bytes: [0xABCD] Target bytes: reg_0: [0xAB] reg_1: [0xCD] Little Endian: register swap Registers: Little Endian Source bytes: [0xABCD] Target bytes: reg_0: [0xCD] reg_1: [0xAB]
Addressing Method	Enables you to select Auto or Manual addressing of the MODBUS registers. Note that the Manual option also includes semi-automatic addressing. ■ If Auto addressing is enabled, the submenus Input Status and Input Register are disabled and you cannot edit the MODBUS mapping manually. The mapping is created automatically for all devices of the Operating Modes list. If new <i>WirelessHART</i> devices appear in the <i>WirelessHART</i> network, they are automatically added to the Operating Modes list, and the mapping will also be added automatically. See chapter 5.5.3. ■ If Manual addressing is enabled, you can use the submenus Input Status and Input Register to set up the MODBUS mapping manually or semi-automatically for all devices of the Instrument List. If a new <i>WirelessHART</i> device joins the <i>WirelessHART</i> network, it is added to the Operating Modes list only. The new device will not appear in the Instrument List unless you import the device list from the Operating Modes list. See chapter 5.5.4.
Read Modbus Registers Mode	Enables you to define the read mode for the MODBUS master. You can select between Input and Holding and Input Registers only. If you select Input and Holding, MODBUS masters that do not support the reading of input registers can read through the holding registers.

Table 5.15 MODBUS Parameters

For a detailed overview of the relationship between the configuration options in the DTM or web interface and the data in the *WirelessHART* gateway, → see Figure 5.18 on page 60.

2015-07



Tip

If you replace a *WirelessHART* gateway with firmware version 2.4 or older, we recommend that you select **Auto** from the **Addressing Method** drop-down list.

5.5.3 Automatic MODBUS Mapping

The MODBUS implementation maps HART dynamic input variables to MODBUS input registers and uses input registers to provide device-related status information. The MODBUS implementation is based on the following assumptions:

- The HART CMD 3 dynamic variables are used for MODBUS mapping.
- For MODBUS access, CMD 3 publishing must be enabled for all relevant devices.
- The *WirelessHART* gateway caches the relevant CMD 3 information. MODBUS commands will therefore access the internal memory of the *WirelessHART* gateway.
- MODBUS input registers are only supported if they are associated with HART dynamic input variables.
- A device can either be a *WirelessHART* device or a wired HART device connected to a *WirelessHART* adapter.
- *WirelessHART* and wired HART devices are mapped independently within the MODBUS input registers. Wired devices are not necessarily mapped consecutive with the associated *WirelessHART* adapter.

Standard Compliance	MODBUS RTU	MODBUS TCP
Physical layer	RS-485	Ethernet
Data transfer mode	RTU (binary mode)	–
Baud rates	1200 bps, 2400 bps, 4800 bps, 9600 bps, 19200 bps, 38400 bps, 57600 bps, 115200 bps	–
Parity	Odd, Even, None	–
Stop bits	1; 1.5; 2	–
Polling address	1 ... 247	–
Capabilities	■ Input registers starting at MODBUS address 30001 ■ HART CMD 3 dynamic variables mapped into input registers ■ 2 input registers map a single HART dynamic variable ■ 32-bit HART floating point format used ■ Status information mapped on dedicated input registers	

You can define the parameters for the MODBUS protocol under **Parameter > Wired Communication > Protocols > Modbus**. For more information, see chapter 5.3.4.

Automatic Mapping of MODBUS Input Registers

Each HART device is mapped on 12 consecutive MODBUS input registers. The input registers can be read using MODBUS function code 04 (Read Input Registers). In general, the information about the *WirelessHART* gateway is mapped on registers 30001 to 30012. The first device is mapped on register 30013, the second starting at register 30025, and so on.

The order of the HART device mapping starting from register 30001, is the same as the order of the HART devices returned by the command 84 (HART CMD 84, Read Sub-Device Identity Summary). For example, the HART device that you can read by using CMD 84 with the sub-device index = 1 is mapped starting at register 30013. The device that you can read by using CMD 84 with the sub-device index = 2 is mapped starting at register 30025 and so on.

To find out the starting register of a certain sub-device, use the following formula:
 $SIR = 30001 + 12 \cdot (SDI)$ where SIR is the starting input register of the associated HART device and SDI is the CMD 84 sub-device index value.

The following table shows the exemplary mapping of the first two HART devices, for example the ones associated with SDI = 1 and SDI = 2.

MODBUS Register		Value	Description	Format	Sub-Device Index (CMD 84)
30013	30014	AI	Primary Variable (loop current, mA unit)	32-bit floating point	1
30015	30016	PV	Primary Variable (device-specific unit, see the manual of the sub-device for more information on the device-specific unit codes)		
30017	30018	SV	Secondary Variable (device-specific unit, see the manual of the sub-device for more information on the device-specific unit codes)		
30019	30020	TV	Tertiary Variable (device-specific unit, see the manual of the sub-device for more information on the device-specific unit codes)		
30021	30022	QV	Quaternary Variable (device-specific unit, see the manual of the sub-device for more information on the device-specific unit codes)		
30023	–	ModStat	MODBUS-Specific Status See chapter 12.2	16-bit unsigned integer	
30024	–	DevStat	HART Device Status See chapter 12.1		

MODBUS Register		Value	Description	Format	Sub-Device Index (CMD 84)
30025	30026	AI	Primary Variable (loop current, mA unit)	32-bit floating point	2
30027	30028	PV	Primary Variable (device-specific unit, see the manual of the sub-device for more information on the device-specific unit codes)		
30029	30030	SV	Secondary Variable (device-specific unit, see the manual of the sub-device for more information on the device-specific unit codes)		
30031	30032	TV	Tertiary Variable (device-specific unit, see the manual of the sub-device for more information on the device-specific unit codes)		
30033	30034	QV	Quaternary Variable (device-specific unit, see the manual of the sub-device for more information on the device-specific unit codes)		
30035	–	ModStat	MODBUS-Specific Status See chapter 12.2	16-bit unsigned integer	
30036	–	DevStat	HART Device Status See chapter 12.1		

Mapping Format of HART Dynamic Variables

For each HART device, the 5 possible CMD 3 floating-point dynamic variables are sequentially mapped (the CMD 3 units code values are not mapped). If a device does not support a specific dynamic value, a **NaN** (Not a Number) floating-point value is returned (namely 0x7F, 0xA0, 0x00, 0x00).

The CMD 3 dynamic variables follow the IEEE-754 (IEC 559) single-precision floating-point format:

Sign of the Fraction	8-bit Exponent	23-bit Fraction
----------------------	----------------	-----------------

The same format is also used for the MODBUS 32-bit floating point values.

The MODBUS protocol does not explicitly specify any 32-bit data element. However, the usage of 2 consecutive 16-bit registers is the de-facto standard way to map a single-precision IEEE-754 floating-point value. Note that the MODBUS floating value will be transmitted in **Big Endian** style. For example, the number 123456.00 as defined in the IEEE-754 standard appears as follows:

Byte 0	Byte 1	Byte 2	Byte 3
0x00	0x20	0xF1	0x47

This number will be transmitted from the *WirelessHART* gateway to the MODBUS master in the following sequence: 47 F1 20 00 where 00 is the less significant byte, which is transmitted in first place.

5.5.4 Manual MODBUS Mapping for Input Status and Input Register



Note!

Manual or semi-automatic creation of the mapping table for the MODBUS input registers is available only if the **Addressing Method** under **Engineering > Modbus Mapping > Modbus Settings** is set to **Manual**. See chapter 5.5.2

The **Instrument List** must be available before you create the mapping table, because the values for the mapping table are retrieved from the **Instrument List**.

For a detailed overview of the relationship between the configuration options in the DTM or web interface and the data in the *WirelessHART* gateway, → see Figure 5.18 on page 60.

The **Input Status** submenu enables you to map discrete variables on the MODBUS input registers.

The **Input Register** submenu enables you to map HART variables and device-specific status information on the MODBUS input registers.

In both submenus, you have the following options:

- You can create the mapping table manually.
For more information, see the subsection Create MODBUS Mapping Manually.
- You can create the mapping table semi-automatically, which means that the mapping table is generated automatically according to your specifications.
For more information, see the subsection Create MODBUS Mapping Semi-Automatically.

Create MODBUS Mapping Manually

The **Table** tab enables you to create or edit the MODBUS mapping table manually.



Note!

The **Instrument List** must be available before you create the mapping table, because the values for the mapping table are retrieved from the **Instrument List**.

For a detailed overview of the relationship between the configuration options in the DTM or web interface and the data in the *WirelessHART* gateway, → see Figure 5.18 on page 60.

Register	Endregister	Long Tag	IO-Card	Channel	Value	
1	2999					☐
3000	3001	T209Innen	1	0	PV	☒
3002	3003	T209Innen	1	0	SV	☒
3004	3005	T209Innen	1	0	TV	☒
3006	3007	T209Innen	1	0	QV	☒
3008	3009	T209Innen	1	0	Battery Life	☒
3010	3010	T209Innen	1	0	Device Status	☒
3011	3012	Test_Dev_574	3	0	PV	☒
3013	3014	Test_Dev_574	3	0	SV	☒
3015	3016	Test_Dev_574	3	0	TV	☒
3017	3018	Test_Dev_574	3	0	QV	☒
3019	3020	Test_Dev_574	3	0	Battery Life	☒
3021	3021	Test_Dev_574	3	0	Device Status	☒
3022	3023	Test_Dev_598	4	0	PV	☒
3024	3025	Test_Dev_598	4	0	SV	☒
3026	3027	Test_Dev_598	4	0	TV	☒
3028	3029	Test_Dev_598	4	0	QV	☒

Figure 5.21 Engineering > Modbus Mapping > Input Status/Input Register: Manual Editing Table

2015-07

Table Parameters

Parameter	Description
Register/End register	MODBUS registers into which the value is mapped.
Long Tag	Long Tag of the device HART 5 devices and older devices do not support long tags. For those devices, the <i>WirelessHART</i> adapter uses the content of the Message field, which will be displayed here instead.
Card	Virtual I/O card number to which the device is mapped to. For more information, see chapter 2.1.3.
Channel	Channel of the virtual I/O card the device is mapped to. The value 0 identifies a <i>WirelessHART</i> device or a <i>WirelessHART</i> adapter, while the value 1 identifies a wired device connected to a <i>WirelessHART</i> adapter. For more information, see chapter 2.1.3.
Value	Indicates the value that is read from the device and mapped to the MODBUS registers. The Input Status submenu enables you to map the following values: ■ Lower Significant Byte: If you select Lower Significant Byte, enter a response byte as well. ■ Most Significant Byte: If you select Most Significant Byte, enter a response byte as well. The Input Register submenu enables you to map the following values: ■ Loop Current ■ Percent Range ■ PV: HART primary variable ■ SV: HART secondary variable ■ TV: HART tertiary variable ■ QV: HART quaternary variable ■ Device Variable: The device variable provides device-specific information. This information is displayed using a device-specific unit code. For more information on what device-specific information is available and on the device-specific unit codes, see the manual of the sub-device. ■ Battery Life ■ Device Status For more information, see chapter 12.1. ■ Ext. Device Status For more information, see chapter 12.1. ■ Device Status & Extended Device Status ■ CMD 48 Device Status If you select CMD 48 Device Status, specify a response byte as well. For more information, see chapter 12.1. ■ All CMD 48 Device States ■ Modbus Status For more information, see chapter 12.2.

Table 5.16 Table Parameters



Caution!

System failure

If you click **Refresh** right after the device was switched on or reset, the system may stop responding.

If the device was switched on or reset, wait about 1 minute until the boot process is complete before you click **Refresh**.



Create MODBUS Mapping Manually



Note!

When editing the mapping table, mapping errors or duplicate address allocations are highlighted in red. These errors must be corrected before you can apply the MODBUS mapping.

Warnings are highlighted in yellow.

1. To read the current mapping from the *WirelessHART* gateway using the web interface, click **Refresh**. If using the DTM to configure the *WirelessHART* gateway, select the *WirelessHART* gateway in the project tree and choose **Device > Load from device**.
2. On the **Table** tab, go to the row in the mapping table that contains free input registers that have not been mapped yet.
3. Click into the **Long Tag** cell and select a device from the drop-down list.
We recommend that you map the values of the *WirelessHART* gateway on the first registers.
4. Click into the **Value** cell and select a value you want to read.
Note that if you select **CMD 48 Device Status**, **Lower Significant Byte**, or **Most Significant Byte**, you must enter a response byte as well.
5. After you selected the device and value, press **Enter** to confirm.
↳ The **Register**, **Endregister**, **Card**, and **Channel** values are updated automatically and a new line for the remaining registers is inserted automatically.
6. Repeat these steps to complete the mapping table.
7. To write the current mapping table to the *WirelessHART* gateway using the web interface, click **Apply**. If using the DTM to configure the *WirelessHART* gateway, select the *WirelessHART* gateway in the project tree and choose **Device > Store to device**.
Note that the new mapping is applied immediately and the consistency of the mapping table is not checked before it is applied.

To export the current mapping table to a CSV file, click **Export** (web interface) resp. **Export CSV** (DTM).

To load the mapping table from a CSV file, click **Import** (web interface) resp. **Import CSV** (DTM).

For more information on the structure of the CSV file, see chapter 12.3.

To delete a mapping entry, click the  X-sign at the end of line. To delete the entire mapping table, click the  X-sign in the table header.



Tip

If a *WirelessHART* gateway is replaced with a new one, we recommend that you use the export/import functionality to transfer the settings from the old *WirelessHART* gateway to the new one. Otherwise, the new *WirelessHART* gateway rebuilds the *WirelessHART* network from scratch by default, which means that the virtual HART I/O structure in the instrument list and the MODBUS addresses of the devices will differ from the positions and addresses that have been defined in the old *WirelessHART* gateway.

Furthermore, if using the DTM to configure the *WirelessHART* gateway, you can prepare the instrument list and the MODBUS mapping tables offline and export the configuration into a CSV file. Once the *WirelessHART* gateway is available on site, you can import the prepared configuration via the CSV file.

Create MODBUS Mapping Semi-Automatically

The **Generate** tab enables you to generate the mapping table automatically according to your specifications. You only need to select the values you want to read from the devices. After this selection has been completed, you can generate the mapping table for all devices automatically.



Note!

The **Instrument List** must be available before you create the mapping table, because the values for the mapping table are retrieved from the **Instrument List**.

For a detailed overview of the relationship between the configuration options in the DTM or web interface and the data in the *WirelessHART* gateway, → see Figure 5.18 on page 60.




Figure 5.22 Engineering > Modbus Mapping > Input Status/Register: Semi-Automatic Generation

Generation Parameters

Parameter	Description
Start Register	The first MODBUS register into which the first value is mapped.
Generation order	The generation order defines the order in which the HART devices will be mapped on the MODBUS input registers. ■ Index The devices are mapped according to the index number. To look up the index numbers, you can deactivate the Tree-View check box under Diagnostics > Wireless Communication > Details. ■ Alphabetical The devices are mapped in alphabetical order, according to the Long Tag of the wireless device. ■ Alphabetical (sub-device) The devices are mapped in alphabetical order, according to the Long Tag of the sub-device. ■ IO card & channel The devices are mapped according to the IO card & channel number of the wireless device. ■ IO card & channel (sub-device) The devices are mapped according to the IO card & channel number of the sub-device.

Parameter	Description
Value	Enables you to define the values you want to read as well as their sequence. Click into the Value column to select a value from the drop-down list. The Input Status submenu enables you to map the following values: ■ Lower Significant Byte: If you select Lower Significant Byte, enter a response byte as well. ■ Most Significant Byte: If you select Most Significant Byte, enter a response byte as well. The Input Register submenu enables you to map the following values: ■ Loop Current ■ Percent Range ■ PV: HART primary variable ■ SV: HART secondary variable ■ TV: HART tertiary variable ■ QV: HART quaternary variable ■ Device Variable: The device variable provides device-specific information. This information is displayed using a device-specific unit code. For more information on what device-specific information is available and on the device-specific unit codes, see the manual of the sub-device. ■ Battery Life ■ Device Status For more information, see chapter 12.1. ■ Ext. Device Status For more information, see chapter 12.1. ■ Device Status & Extended Device Status ■ CMD 48 Device Status If you select CMD 48 Device Status, specify a response byte as well. For more information, see chapter 12.1. ■ All CMD 48 Device States ■ Modbus Status For more information, see chapter 12.2.
Default settings	Generates a default mapping table that corresponds to the Automatic mapping. For more information on the automatic mapping rules, see chapter 5.5.3.
Generate	Writes the mapping to the table on the Table tab, according to your selections on the Generate tab.
Delete all Mappings	If activated, the mapping you generate overwrites all existing mappings on the Table tab. If deactivated, the mapping you generate is added to existing mappings on the Table tab.

Table 5.17 Generation Parameters



Generate MODBUS Mapping

1. On the **Generate** tab, enter the start register for the MODBUS mapping in the **Start register** field.
2. Select the order in which the devices are mapped on the MODBUS registers in the **Generation order** drop-down list.
3. Select the values you want to read for each device in the **Value** column.
Note that if you select **CMD 48 Device Status**, **Lower Significant Byte**, or **Most Significant Byte**, you must enter a response byte as well.
4. If required, activate the **Delete all Mappings** check box to overwrite any existing mappings on the **Table** tab. If deactivated, the mapping you generate is added to existing mappings on the **Table** tab.
5. Click **Generate** to write the mapping to the table on the **Table** tab.
6. Click **Table**.
↳ The mapping table on the **Table** tab displays the generated mappings.
7. If required, you can manually edit the generated mapping table.
For more information, see [Create MODBUS Mapping Manually](#).
8. To write the current instrument list to the *WirelessHART* gateway using the web interface, click **Apply**. If using the DTM to configure the *WirelessHART* gateway, select the *WirelessHART* gateway in the project tree and choose **Device > Store to device**.
Note that the consistency of the instrument list is not checked before it is applied.

To export the current mapping table to a CSV file, click **Export** (web interface) resp. **Export CSV** (DTM).

To load the mapping table from a CSV file, click **Import** (web interface) resp. **Import CSV** (DTM).

For more information on the structure of the CSV file, see chapter 12.3.

To delete a mapping entry, click the X-sign at the end of line. To delete the entire mapping table, click the X-sign in the table header.



Tip

If a *WirelessHART* gateway is replaced with a new one, we recommend that you use the export/import functionality to transfer the settings from the old *WirelessHART* gateway to the new one. Otherwise, the new *WirelessHART* gateway rebuilds the *WirelessHART* network from scratch by default, which means that the virtual HART I/O structure in the instrument list and the MODBUS addresses of the devices will differ from the positions and addresses that have been defined in the old *WirelessHART* gateway.

Furthermore, if using the DTM to configure the *WirelessHART* gateway, you can prepare the instrument list and the MODBUS mapping tables offline and export the configuration into a CSV file. Once the *WirelessHART* gateway is available on site, you can import the prepared configuration via the CSV file.

5.5.5 Topology View

Here you can set up the topology view that is displayed under **Diagnostics > Wireless Communication > Topology View**. You can upload background images in any common graphic format, such as JPG or GIF. For example, you can use a satellite photo, a floor plan, or a diagram in which you want to group the devices



Note!

The **Instrument List** must be available before you set up the topology view, because the set of *WirelessHART* devices is derived from the **Instrument List**. See chapter 5.5.1

For a detailed overview of the relationship between the configuration options in the DTM or web interface and the data in the *WirelessHART* gateway, → see Figure 5.18 on page 60.




Figure 5.23 Engineering > Topology View



Caution!

System failure

If you click **Refresh** right after the device was switched on or reset, the system may stop responding.

If the device was switched on or reset, wait about 1 minute until the boot process is complete before you click **Refresh**.



Set Up the Topology View

1. To retrieve the devices from the **Operating Modes** list of the *WirelessHART* gateway using the web interface, click **Refresh**. If using the DTM to configure the *WirelessHART* gateway, select the *WirelessHART* gateway in the project tree and choose **Device > Load from device**. Note that reloading the device information takes some time.
2. Click **Select Map** to select a background image for the topology view.
3. Click **Browse** to select the background image.
4. Click **Upload Map** to upload the background image.

5. If required, edit the coordinates of the image origin in the **Horizontal image origin** and **Vertical image origin** boxes.
6. Enter a value in the **Resolution** box to scale the background image, for example 1 m/pixel. Note that you can set the resolution only after you have uploaded an image.
7. Arrange the *WirelessHART* devices in the topology view by dragging and dropping the devices to a selected position. Note that for a more accurate positioning you can use the slider to zoom in or out of the topology view. To reset the zoom to its default value, click **Reset Zoom**.
8. To write the current topology view to the *WirelessHART* gateway using the web interface, click **Apply**. If using the DTM to configure the *WirelessHART* gateway, select the *WirelessHART* gateway in the project tree and choose **Device > Store to device**.

To export the current devices and their positions to a CSV file, click **Export** (web interface) resp. **Export CSV** (DTM).

To load a list of devices and their positions from a CSV file, click **Import** (web interface) resp. **Import CSV** (DTM).

For more information on the structure of the CSV file, see chapter 12.

5.6

Additional Functions

Accessing the Additional Functions Window

1. If using the DTM and PACTware, right-click the device in the project tree, select **Additional functions** and choose the desired function.
2. If using the web interface, select **Additional Functions** in the navigation area on the left.

5.6.1

Reset




Figure 5.24 Additional Functions > Reset

Reset Options

Parameter	Description
Device Reset	Restarts the software of the <i>WirelessHART</i> gateway without any impact on the established network (which is not reformed). This function does not set the parameters of the <i>WirelessHART</i> gateway back to their default values. It restarts the <i>WirelessHART</i> gateway software only.
Rebuild Instrument List	Regenerates the instrument list from scratch. The existing instrument list is overwritten. Note that the MODBUS addresses of the devices in the network will be changed by resetting the instrument list. We recommend that you create a backup of the current instrument list before rebuilding a new instrument list. See chapter 5.5.1

Parameter	Description
Reform Network	Restarts and re-establishes the network. For example, this function is needed to activate a new network ID. See chapter 5.2.1 Depending on the size of the network, this process may take several minutes. This function does not set the parameters of the <i>WirelessHART</i> gateway back to their default values. It restarts the network only.
Reset Diagnostic Bits	Resets the HART parameters under Diagnostics > Wired Communication > HART to its default values.

Table 5.18 Reset Options

5.6.2 Self Test

After pressing the **Perform Self-Test** button in the **Additional Functions > Self Test** menu the device carries out a self test.

The results of the self test can be seen in the **Diagnostics** menu. See chapter 5.4

5.6.3 Set DTM Address

The table in the **Set DTM address** window shows the *WirelessHART* devices configured in the PACTware project and their DTM addresses. The DTM address is the device long tag as specified in the DTM of the device (offline data record). The DTM address is also displayed in the project tree structure of the PACTware project.



Note!

The **Long Tag** parameterized in the **Set DTM Address** window must be identical with the **Long Tag** of the same device parameterized in the **Set device address** window. See chapter 5.6.4

Otherwise the DTM is not able to establish a connection to the device.




Figure 5.25 Additional Functions > Set DTM address



Changing the DTM address

1. Place the cursor inside a cell of the **Long Tag** column.
2. Change the device long tag as required. You may change the long tags of several devices at once, if needed.
3. Close the DTM dialogs of the devices whose long tags are to be changed.
4. To apply the new DTM address(es) press **Update changed tags**.
↳ The new DTM addresses are displayed in the project view of PACTware.



5.6.4 Set Device Address

The table in the **Set device address** window shows the *WirelessHART* devices in the network. The device address is the device long tag stored in the device.



Note!

Additional functions > Set device address is available only online, while the connection to the *WirelessHART* gateway and the *WirelessHART* device(s) is active.



Note!

The **Long Tag** parameterized in the **Set Device Address** window must be identical with the **Long Tag** of the same device parameterized in the **Set DTM address** window. See chapter 5.6.3

Otherwise the DTM is not able to establish a connection to the device.



Figure 5.26 Additional Functions > Set device address



Changing the device address

1. Place the cursor inside a cell of the **Long Tag** column.
2. Change the device long tag as required. You may change the long tags of several devices at once, if needed.
3. To apply the new DTM address(es) press **Update changed tags**.
↳ The new DTM addresses are stored to the devices.

5.6.5 About

Additional Functions > About displays information about the device, its manufacturer, and its firmware version.

5.6.6 Firmware Upgrade



Note!

This configuration option is only available in the web interface.




Figure 5.27 Additional Functions > Firmware upgrade

2015-07



Upgrading the Firmware

1. Choose **Additional Functions > Firmware Upgrade**.
2. Click **Browse** to choose the firmware upgrade package (*.ipk) from your hard drive.
3. Click **Upload the Package**.
4. To install the firmware upgrade, press **Install the Package**. You can also abort the upgrade process by clicking **Discard Upgrade**.
↳ The installation process may take a while. When the installation is finished, **Installation Successfully Completed** is displayed.

5.6.7

Change Password



Note!

This configuration option is only available in the web interface.

The screenshot shows a web interface with a left sidebar containing a tree view of navigation options: Parameter, Diagnostics, Engineering, Additional Functions, Reset, Self Test, About, Firmware upgrade, Change Password (highlighted), Upload Certificate, and Measurement. The main content area on the right has a light beige background and contains the following fields and buttons:

- Type a new password: [text input field]
- Type the new password again to confirm: [text input field]
- Change Password: [button with '>>' symbol]
- Discard Operation: [button with '>>' symbol]

Figure 5.28 Additional Functions > Change Password

The connection to the web interface is made using a secure connection (HTTPS) which requires a user name and a password. The factory default settings are:

User name: admin

Password: admin

You can change both user name and password in the web interface.



Changing the Password

1. Log on to the web interface of the *WirelessHART* gateway using the user name for which you want to change the password.
2. Choose **Additional Functions > Change Password**.
3. Enter a new password into the corresponding fields.
4. To apply the new password, click **Change Password**. You can also abort the operation by clicking **Discard Operation**.

↳ The password for the current user has been changed.

5.6.8

Upload Certificate for HTTPS Connection

You can install a trusted certificate issued by a certification authority, such as TC TrustCenter, Thawte, or VeriSign.

A digital certificate is an electronic document that binds a public key with an identity, for example, an organization or an user. The binding between a public key and the identity is done by a signature. This signature can be self-signed or authenticated by a certification authority. The *WirelessHART* gateway is delivered with a self-signed certificate for the HTTPS connection. Because the web browser cannot verify the authenticity of a self-signed certificate, some web browsers display the following (or a similar) warning message in the address bar:





Note!

This configuration option is only available in the web interface.




Figure 5.29 Additional Functions > Upload Certificate



Install a Trusted Certificate



Note!

Prerequisites:

- You need a certificate and a private key from a trusted authority, such as TC TrustCenter, Thawte, or VeriSign.
- Both files must comply with the following standard: X.509 Ver. 3

1. Click **Browse** and select the certificate file from the certification authority.
2. Click >> to upload the certificate.
 - ↳ The **Upload Private Key** option appears.
3. Click **Browse** and select the private key from the certification authority.
4. Click >> to upload the private key.
 - ↳ The **Change Certificate and Private Key** option appears.
5. Click >> to install the certificate and private key.

The new certificate and private key have been successfully installed

Please, reboot the gateway for the change to take effect!

Figure 5.30 Installation confirmation

6. Go to **Additional Functions > Device Reset** and perform a device reset for the changes to take effect.

If the trusted certificate has been installed successfully, the address bar in the web browser displays a padlock icon:



This indicates that the web interface of the *WirelessHART* gateway is a trusted site.

5.7 Measurement

The measurement list displays a comprehensive overview of all cached parameters and values of all sub devices.



Note!

This list is stored in a non-volatile memory of the *WirelessHART* gateway. The card and channel number assignment will remain the same after a restart of the *WirelessHART* gateway or software.



Note!

Please keep in mind that the dynamic values of each sub device (analogue value, PV, SV, TV, QV) are cached by the *WirelessHART* gateway only if the respective sub device publishes those values. See chapter 2.1.4

After a network restart, the **Operating Modes** list needs time to rebuild. During this time, some information is set to 0 or replaced by wildcard characters.

Measurement										
Long Tag	IO-Card	Channel	Device Type	Status	Dev. Status	Loop Curr...	PV	SV	TV	QV
[-] wirelessGateway	251	1	WHA-GW							
[-] T209Innen	1	0	WHA-UT	✓	⚠	7.472000 ...	21.70000 ...	-/-	23.37500 ...	4026.000000 d
[-] Test_Dev_574	3	0	WHA-ADP	✓	✓	-/-	-/-	-/-	-/-	-/-
[-] 5D0E	3	1	5D0E	✓	✓	-/-	-/-	-/-	-/-	-/-
[-] Test_Dev_590	4	0	WHA-ADP	✗	✓	-/-	-/-	-/-	-/-	-/-
[-] 62E6	4	1	62E6	✗	✓	-/-	-/-	-/-	-/-	-/-
[-] T209aussen	5	0	WHA-UT	✓	⚠	7.664000 ...	22.90000 ...	-/-	24.37500 ...	3988.000000 d
[-] Test_Device_504	6	0	WHA-ADP	✓	✓	-/-	-/-	-/-	-/-	-/-
[-] -/-	6	1	EJA	✓	✓	12.06541 ...	1.008176 ...	23.02945 ...	0.000000 ...	-/-
[-] Test_Dev_576	7	0	WHA-ADP	✓	✓	-/-	-/-	-/-	-/-	-/-
[-] NEW_VEGA	7	1	62E2	✓	✓	-/-	-/-	-/-	-/-	-/-
[-] EH_SWA70_AIN_FWR231	8	0	SWA70	✓	⚠	-/-	-/-	-/-	-/-	-/-
[-] WHA_ADP_AIN_Positioner	9	0	WHA-ADP	✓	✓	-/-	-/-	-/-	-/-	-/-
[-] SAMSON3730	9	1	373X-3	✓	✗	4.000000 ...	0.100000 %	0.000000 %	-/-	0.000000 In...
[-] WHA-ADP-CorrTran	10	0	WHA-ADP	✗	✓	-/-	-/-	-/-	-/-	-/-
[-] CorrTran_Long_Tag_2	10	1	CorrTran MV	✗	✓	-/-	-/-	-/-	-/-	-/-
[-] MULTIDROP	11	0	WHA-ADP	✓	⚠	-/-	-/-	-/-	-/-	-/-
[-] 40000003410057	2	0	WHA-UT	✓	⚠	16.33600 ...	77.09999 ...	76.59999 ...	24.43750 ...	4109.000000 d
[-] 40000003410029	12	0	WHA-UT	✓	⚠	-/-	77.00000 ...	-/-	-/-	-/-
[-] 40000003410027	13	0	WHA-UT	✓	⚠	16.36800 ...	-/-	-/-	-/-	-/-

Figure 5.31 Measurement List

If required, click **Refresh** to reload the values of all sub devices.



Caution!

System failure

If you click **Refresh** right after the device was switched on or reset, the system may stop responding.

If the device was switched on or reset, wait about 1 minute until the boot process is complete before you click **Refresh**.



Note!

If using the DTM and PACTware to configure the *WirelessHART* gateway, the following data is available only during online parameterization.

General Data

Displayed Information	Description
Long Tag	Displays the long tag of the device. HART 5 devices and older devices do not support long tags. For those devices, the <i>WirelessHART</i> adapter uses the content of the Message field which will be displayed here instead.
I/O Card	Indicates the virtual I/O card number to which the device is mapped to. See chapter 2.1.3
Channel	Indicates the channel of the virtual I/O card that the device is mapped to. See chapter 2.1.3 The value 0 identifies a <i>WirelessHART</i> device or a <i>WirelessHART</i> adapter, while the value 1 identifies a wired device connected to a <i>WirelessHART</i> adapter.
Device Type	Displays the device type as registered at the HCF.
Status	The following communication statuses exist:  communication not possible  communication possible, device not identified  (flashing) communication possible, identification ongoing  device connected and identified
Dev. Status	Note that the device status displayed in the list may differ from the actual device status because the HART status bits may be interpreted differently. The following device statuses exist:  maintenance required  out of specification  check function  failure

Measured Values

Displayed information	Description
Loop Current	Analogue value of the primary variable
PV	Value of the primary variable
SV	Value of the secondary variable
TV	Value of the tertiary variable
QV	Value of the quaternary variable

Table 5.19 Measured Values

6 Configuration via DTM and PACTware

If using the DTM and PACTware to configure the *WirelessHART* gateway, the *WirelessHART* gateway must be connected via Ethernet or RS-485.

Configuration via DTM is identical to the configuration via web interface with the exception of a few options that are pointed out in the relevant sections. Thus, after you have added the communication DTM and device DTM in PACTware, you can follow the instructions for configuration via web interface.

You can download PACTware, the *WirelessHART* DTM, and the HART Communication DTM from www.pepperl-fuchs.com.

Creating a New Project?

Select **File > New** or click  **Create New Project**.

↳ A new, unnamed project appears in the main window. The project initially consists of the entry **HOST PC**.

Update the Device Catalog

1. Start PACTware.
2. Select **View > Device Catalog**.
↳ The **Device Catalog** window opens.
3. Click **Update Device Catalog** to update the device catalog.
4. Click **Yes** to continue.
↳ The updated device catalog appears.

6.1 Adding Ethernet Communication DTM

Adding Ethernet Communication DTM

1. Select **HOST PC** in the project view.
2. Choose **Device > Add device** or click  **Add device**.
3. Select the entry **HART IP Communication**.
4. Click **OK**.
↳ The Ethernet communication DTM is added to the project.



Figure 6.1 Ethernet communication DTM in project view

5. To edit the parameters, right-click **HART IP Communication** and select **Properties**.
6. Set the parameters according to your preferences. In most cases, the default values should be fine.
7. Click **OK** to save the changes and to close the **Properties** window.

The IP address, bus address and UDP port of the communication DTM must match the parameters of the *WirelessHART* gateway. In some cases, for example, if the *WirelessHART* gateway has already been used in another project, you may have to edit these parameters. When using a new *WirelessHART* gateway, there is no need to change these parameters, because the default settings of the *WirelessHART* gateway already match the default settings of the Ethernet Communication DTM.



Edit DTM Addresses of the Ethernet Communication DTM

1. Right-click **HART IP Communication**.
2. Choose **Additional Functions > Set DTM addresses**.

↳ The **Set DTM addresses** window is displayed.




Figure 6.2 Set DTM address window

3. Change the parameters as required (see following table).
4. Click **Update changed data** to apply the new settings.
5. Disconnect and re-establish the connection between the DTM and the *WirelessHART* gateway to activate the new settings.

HART IP communication DTM			WirelessHART gateway	
Parameter	Explanation	Default	Parameter	Default
Tag	Gateway name in the Project view of PACTware. Any name may be entered (not relevant for connection to the <i>WirelessHART</i> gateway)	WHA-GW	—	—
Bus Address	Gateway polling address Must match the settings of the <i>WirelessHART</i> gateway.	1	Parameterization > Wired Communication > Protocols > HART > Bus Address	1
UDP Address	Gateway IP address Must match the settings of the <i>WirelessHART</i> gateway.	192.168.001.001	Parameterization > Wired Communication > Interfaces > Ethernet > IP Address	192.168.001.001
UDP Port	Gateway port number (HART over UDP) Must match the settings of the <i>WirelessHART</i> gateway.	5094	Parameterization > Wired Communication > Protocols > HART > Port Number	5094

6.2 Adding RS-485 Communication DTM



Adding RS-485 Communication DTM



Note!

The HART Communication DTM is not included in the *WirelessHART* DTM Collection. It can be downloaded separately from www.pepperl-fuchs.com.

1. Select **HOST PC** in the project view.

2. Choose **Device > Add device** or click **Add device** .

3. Select the entry **HART Communication** and click **OK**.

↳ The HART communication DTM is added to the project.




Figure 6.3 HART communication DTM in project view

4. To edit the parameters, right-click the HART communication DTM and select **Properties**.

5. Set the parameters according to the following table.

6. Click **OK** to save the changes and to close the parameter window.

Parameter	Description	Default
Communication interface	Select HART multiplexer .	HART modem
Port	Select the COM port of the RS-485 to RS-232 converter or of the RS-485 to USB converter.	COM1
Baudrate	Select the baud rate of the <i>WirelessHART</i> gateway.	19200
RTS Control	Depending on the RS-485 to RS-232 converter used, it may be necessary to switch the request-to-send control on or off, in order to switch correctly between reception and transmitting mode.	Toggle
Master	Specify if you want the <i>WirelessHART</i> gateway to be the primary or the secondary master. If there is already a primary master, define the <i>WirelessHART</i> gateway as secondary master.	Primary Master
Preamble	Select the number of preambles for HART communication.	5
Number of communication retries	Select the number of retries for HART communication in case of an error.	3
Start address	Select the address range in which the HART Communication DTM searches for HART multiplexers.	0
End address		15

6.3 Adding Device DTM

After you have added a communication DTM, add the device DTM for the *WirelessHART* gateway.



Adding the Device DTM

1. In the project view, right-click on the entry of the communication DTM.
2. To add the device DTM, choose **Add device**.
3. Select the entry **WHA-GW**.
4. Click **OK**.

↳ The DTM for the *WirelessHART* gateway is added to the project.




Figure 6.4 Device DTM in project view



Tip

After you have added the DTM for the *WirelessHART* gateway, you can easily add other *WirelessHART* devices by performing a topology scan. To do so, right-click the *WirelessHART* gateway and select **Connect**. When you have an active connection to the *WirelessHART* gateway, right-click the *WirelessHART* gateway and select **Topology Scan**.

6.4 Online and Offline Parameterization (DTM)

The concept of online and offline parameterization applies only to configuration via DTM and PACTware.

■ Offline Parameterization (not connected to device)

If there is no active connection to the device, you can edit and save the data that is stored locally in PACTware. You can transfer the local data to the device, as soon as a connection to the device has been established.

■ Online Parameterization (connected to device)

If there is an active connection to the device, you can directly edit the data that is stored on the device. Parameter changes are immediately stored on the device.



Note!

Data that is edited and stored on the device during online parameterization is **not** automatically synchronized with the offline data in the PACTware project. If you change device parameters in online mode, the data in PACTware differs from the data on the device. To make sure the data in PACTware matches the data on the device after online parameterization, load the data from the device into the PACTware project.



Offline Parameterization

1. Right-click the device entry in the PACTware project.
2. Choose **Parameter > Offline Parameterization**.
 - ↳ The window containing the offline data record appears.
3. Modify a parameter by typing in a new value or choosing a new value from the drop-down list.
4. To accept the new value, press **Enter**.
5. After all parameter changes have been made, save your project by choosing **File > Save**.
6. To write the new offline configuration to the device, right-click the device entry in the project view and choose **Connect**.
 - ↳ A connection to the device is established.
7. Right-click the device entry again and choose **Store to device**.
 - ↳ The new configuration is stored in the device.



Online Parameterization



Note!

Some options are only available during online parameterization. These options are pointed out in the relevant sections

1. Right-click the device entry in the PACTware project.
2. Select **Connect**.
 - ↳ A connection to the device is established.
3. Right-click the device entry in the PACTware project.
4. Select **Parameter > Online Parameterization**.
 - ↳ The window containing the online data opens and the data is read from the device.
5. Modify a parameter by typing in a new value or choosing a new value from the drop-down list.
6. To accept the new value, press **Enter**.
 - ↳ The new value is stored in the device immediately.
7. After all parameter changes have been made, you can load the online configuration into the PACTware project. To do this, right-click on the device entry in the project view and choose **Load from device**.
8. Save your project by choosing **File > Save**.

7 Configuration via DD file and Emerson AMS Suite

You can also configure the *WirelessHART* gateway by integrating it into a process control system. The exact procedure how to integrate a device depends on the process control system. Please refer to the documentation of your process control system manufacturer.

You can download the device description for the *WirelessHART* gateway from www.pepperl-fuchs.com. Install the DD file according to the instructions from the documentation of your process control system manufacturer.

This manual describes the integration into a process control system using the example of the Emerson AMS Suite. When integrating the *WirelessHART* gateway into the Emerson AMS Suite, the *WirelessHART* gateway must be connected to your PC via Ethernet.

7.1 Integration

The *WirelessHART* gateway is integrated into the Emerson AMS Suite by creating a new wireless network that is established by the *WirelessHART* gateway.

Create New Wireless Network

1. Make sure the AMS Device Manager is not running.
2. Choose **Start > Programs > AMS Device Manager > Network Configuration** to start **Network Configuration**.

↳ The **Network Configuration** window appears.




Figure 7.1 **Network Configuration** window

3. Click **Add**.

4. Select **Wireless Network** and click **Install**.

↳ The **Add Wireless Network Wizard** window appears.




Figure 7.2 **Add Wireless Network Wizard** window

5. Click **Next**.
6. Enter a name for the network in the **Network Name** field and click **Next**.

7. Enter the IP address of the *WirelessHART* gateway in the **Smart Wireless Gateway Name or IP Address** field and click **Add**. The default IP address is 192.168.001.001. If you changed the IP address of the *WirelessHART* gateway, type in the new IP address.




Figure 7.3 **Connection** window

↳ The IP address is displayed in the upper area under **Wireless Network Parameters**.

8. Click **Finish** to close the **Add Wireless Network Wizard**.

↳ The name of the new wireless network is displayed in the **Network Configuration** window.

9. Click **Close** to exit **Network Configuration**.

7.2

Configuration

The **Device Connection View** is a graphical representation of the *WirelessHART* gateway and the connected wireless and wired subdevices. From this view you can directly open the configuration window for each device.

Display Network Participants

1. Start the AMS Device Manager as administrator. To do so, right-click the program icon and select **Run as administrator**.




Figure 7.4 Run as administrator

2. Log in to the AMS Device Manager using your user name, password, and the **Standard** login type.
3. To establish a connection to your devices, choose **View > Device Connection View**.

↳ The **Device Connection View** window displays the networks from the **Network Configuration** window. In this example, **Wireless Network 1** represents the *WirelessHART* network that is established by the *WirelessHART* gateway.




Figure 7.5 Device Connection View window

- Right-click the network that is created by the *WirelessHART* gateway and select **Rebuild and Identify Hierarchy**.

↳ The *WirelessHART* gateway is displayed underneath the network. Note that if the device description has been installed, the *WirelessHART* gateway is displayed with a device-specific icon. Otherwise the system uses a generic icon.




Figure 7.6 *WirelessHART* gateway in **Device Connection View**

- To view the wireless and wired subdevices of the *WirelessHART* gateway, click the + symbol in front of the device icon.

↳ The AMS Device Manager checks the HART loops and adds the field devices to the network tree. Depending on the number of network participants and the network topology, this process can take up to a few minutes.

Configure *WirelessHART* Gateway

Note!

Unless the device description has been installed, you can only configure basic options. The device description adds device-specific options to the configuration window.

- To open the configuration window, double-click the *WirelessHART* gateway in the **Device Connection View**.

↳ The configuration window of the selected device appears.




Figure 7.7 Configuration window

- If you change the value of a field, the background color of this field turns yellow. To apply the changes, click **Send**.




Figure 7.8 Changes are highlighted in yellow

→ The system displays a warning message, asking you to provide an update reason and to confirm that you want to change the values.




Figure 7.9 Confirm Device Configuration Change window

- To confirm the configuration change, click **Yes**.

8 Operation

8.1 MODBUS and HART Status Information on Lost Connection

While you can easily retrieve the status information in the **Measurement** overview (see chapter 5.7), this chapter describes how to read the MODBUS and HART status information by means of some examples.

Field Device Loses Connection to *WirelessHART* Adapter

In this example there are 3 field devices that are connected to the *WirelessHART* network via a *WirelessHART* adapter. Now the field devices have been disconnected from the *WirelessHART* adapter.

In the **Measurement** window the red icon in the **Com. Status** column indicates that the connection has been lost.

Measurement										
										Refresh
Long Tag	IO-Card	Channel	Device Type	Com. Status	Dev. Status	Loop Curr...	PV	SV	TV	QV
[-] wirelessGateway	251	1	WHA-GW							
[-] MULTIDROP	11	0	WHA-ADP	✓	✓	-/-	-/-	-/-	-/-	-/-
▪ PRESSURE	11	1	3095MV	✗	✓	-/-	-/-	-/-	-/-	-/-
▪ BARCON	11	1	5D0E	✗	✓	-/-	-/-	-/-	-/-	-/-
▪ 2010D	11	1	263/265 2000T	✗	✓	-/-	-/-	-/-	-/-	-/-

Figure 8.1 Measurement window

The MODBUS mapping of the device with long tag **BARCON** looks as follows.

Excerpt from MODBUS Mapping Table

Register	Endregister	Long Tag	IO-Card	Channel	Value
...					
241	242	BARCON	11	1	Loop Current
243	244	BARCON	11	1	PV
245	246	BARCON	11	1	SV
247	248	BARCON	11	1	TV
249	250	BARCON	11	1	QV
251	251	BARCON	11	1	MODBUS Status
252	252	BARCON	11	1	Device Status
...					

Loop Current and Variables

30241:	?????
30242:	
30243:	?????
30244:	
30245:	?????
30246:	
30247:	?????
30248:	
30249:	?????
30250:	

Figure 8.2 MODBUS readout of register 30241 ... 30250

The MODBUS readout of registers 30241 ... 30250 results **?????** respectively **NaN** because no field device is available and therefore no values are available.

Status Information

```
30251: <0000000000000101>
30252: <0000000010000000>
```

Figure 8.3 MODBUS readout of register 30251 ... 30252

The MODBUS status information in register 30251 returns 0000000000000101. This indicates that the cache for command 3 is empty (as there is no device). See chapter 12.2

The HART status information in register 30252 returns 0000000010000000 that corresponds to the hexadecimal value 0x80. This indicates a device malfunction. See chapter 12.1

WirelessHART Device Loses Connection to Network

In this example there are 4 *WirelessHART* temperature converters. The device with long tag **40000003410027** lost connection to the *WirelessHART* network, while the device with long tag **T209innen** is still connected.

Measurement										
Long Tag	IO-Card	Channel	Device Type	Com. Status	Dev. Status	Loop Curr...	PV	SV	TV	QV
[-] wirelessGateway	251	1	WHA-GW							
▪ T209innen	1	0	WHA-UT	✓	✓	7.776 mA	23.6 °C	-/-	23.625 °C	3815 d
▪ 40000003410057	2	0	WHA-UT	✓	✓	16.336 mA	77.09999...	76.59999...	22.8125 °C	3737 d
▪ 40000003410029	12	0	WHA-UT	✓	✓	-/-	77.09999...	-/-	-/-	-/-
▪ 40000003410027	13	0	WHA-UT	✗	✓	-/-	-/-	-/-	-/-	-/-

Figure 8.4 Measurement window

The MODBUS mapping of the device with long tag **T209innen** looks as follows.

Excerpt from MODBUS Mapping Table for T209innen

Register	Endregister	Long Tag	IO-Card	Channel	Value
...					
11	11	T209innen	1	0	MODBUS Status
12	12	T209innen	1	0	Device Status
...					

Status Information for T209innen

```
30011: <0000000000000000>
30012: <0000000000010000>
```

Figure 8.5 MODBUS readout of register 30011 ... 30012

The MODBUS status information in register 30011 returns 0000000000000000. This indicates that everything is ok. See chapter 12.2

The HART status information in register 30012 returns 0000000000010000 that corresponds to the hexadecimal value 0x10. This indicates that more status information is available via command 48. See chapter 12.1

This information is also displayed in the **Measurement** window when hovering over the icon in the **Com. Status** column.

T209innen	1	0	WHA-UT	✓	7.792 mA	23.7000	-/-
Test_Dev_574	3	0	WHA-ADP	✓	More Status Available		

Figure 8.6 Measurement window

The MODBUS mapping of the device with long tag **40000003410027** looks as follows.

Excerpt from MODBUS Mapping Table for 40000003410027

Register	Endregister	Long Tag	IO-Card	Channel	Value
...					
217	218	40000003410027	13	0	Loop Current
219	220	40000003410027	13	0	PV
221	222	40000003410027	13	0	SV
223	224	40000003410027	13	0	TV
225	226	40000003410027	13	0	QV
227	227	40000003410027	13	0	MODBUS Status
228	228	40000003410027	13	0	Device Status
...					

Loop Current and Variables for 40000003410027

30217:	?????
30218:	
30219:	?????
30220:	
30221:	?????
30222:	
30223:	?????
30224:	
30225:	?????
30226:	

Figure 8.7 MODBUS readout of register 30217 ... 30226

The MODBUS readout of registers 30217 ... 30226 results **?????** respectively **NaN** because no field device is available and therefore no values are available.

Status Information for 40000003410027

30227:	<00000000000000101>
30228:	<0000000010110000>

Figure 8.8 MODBUS readout of register 30227 ... 30228

The MODBUS status information in register 30227 returns 00000000000000101. This indicates that the cache for command 3 is empty (as there is no device). See chapter 12.2

The HART status information in register 30228 returns 0000000010110000 that corresponds to the hexadecimal value 0xB0 with $0xB0 = 0x80 + 0x20 + 0x10$. See chapter 12.1

- 0x80: device malfunction
- 0x20: cold start
- 0x10: more status available

This information is also displayed in the **Measurement** window when hovering over the icon in the **Com. Status** column.

▪ 40000003410029	12	0	WHA-UT	✓	✓	More Status Available Cold Start There is no device communication at the moment. The displayed data is outdated.
▪ 40000003410027	13	0	WHA-UT	✗	✓	

Figure 8.9 Measurement window

8.2 Network Enhancement

After having installed and set up a wireless network, give the network a couple of hours to stabilize itself before taking the following steps.

Once the *WirelessHART* network is running, there are some simple measures that will help enhancing network performance and reliability. Those measures are described in the following.

Verify Connections

Check that each device has joined the network and is communicating properly. See chapter 5.4.2 Details

If you cannot establish a connection to a device, the device is probably too far away or an obstacle blocks the radio waves. In this case, add an additional device to bridge the gap.

Eliminate Bottlenecks

If the messages of several devices all have to pass through one single device to get to the *WirelessHART* gateway, the network has a bottleneck. If the device at the bottleneck fails, whole parts of the network get cut off from communication because there are no alternative paths to route messages.

To eliminate bottlenecks in a wireless network, add at least one device near the bottleneck to provide redundant communication paths.

There should always be at least two communication paths from one device to another.




Figure 8.10 Eliminating a bottleneck

1. Bottleneck
2. *WirelessHART* gateway
3. Possible position of an additional *WirelessHART* device eliminating the bottleneck



Expand the Network

In an industrial environment, there are several potential obstacles for radio waves, for example buildings, walls, pipes, or even moving obstacles like trucks. Those obstacles can reflect, bend, diffuse or block radio waves. The effects of reflection, bending and diffusion create new waves which interact with the original ones and with each other. They can amplify or nullify each other.

Due to the interference of reflections, moving the antenna a few centimeters can help. If there are obstacles blocking data transfers between wireless devices, add additional devices to provide alternative communication paths. The more devices exist in a *WirelessHART* network, the more reliable it gets.

Optimize Coexistence with other Wireless Networks

WirelessHART networks use the frequency spectrum between 2400 ... 2483.5 MHz according to IEEE 802.15.4. Various other wireless technologies also use this frequency spectrum, for example WLAN (IEEE 802.11) and Bluetooth (IEEE 802.15.1). Measures must be taken to ensure that the various wireless technologies do not affect each other.

If there are problems with other wireless technologies disrupting the *WirelessHART* network, create a channel blacklist that makes the *WirelessHART* gateway skip certain channels known to provide persistent interference. See chapter 5.2.1

If possible, you can also manage the frequencies used by other networks and block the usage of channels already used by the *WirelessHART* network (frequency management).



9 Maintenance and Repair

9.1 WHA-GW*

The national requirements apply to maintenance, servicing, and inspection of associated apparatus.

No maintenance is necessary if the devices are operated properly, observing the mounting instructions and ambient conditions.

The devices must not be repaired, changed or manipulated. If there is a defect, the product must always be replaced with an original device.

10 Troubleshooting

10.1 Faults Indicated by LEDs of the *WirelessHART* Gateway

Indication	Possible cause	Corrective action
Red LED is on	Hardware fault that makes normal operation of the <i>WirelessHART</i> gateway impossible.	Try powering the <i>WirelessHART</i> gateway down and up again. If the problem persists, please return the <i>WirelessHART</i> gateway to Pepperl+Fuchs for repair.
Red LED flashes	Under certain conditions the LED flashes while the <i>WirelessHART</i> gateway tries to eliminate the fault.	If the problem persists, please contact Pepperl+Fuchs customer service.

10.2 Wired Communication Faults

Fault	Possible cause	Corrective action
The host is not able to establish an Ethernet connection to the <i>WirelessHART</i> gateway.	The <i>WirelessHART</i> gateway is connected to the Ethernet with a straight through connection although a crossover connection is necessary (or vice versa).	Access the Ethernet interface of the <i>WirelessHART</i> gateway. Interchange the green wire with the orange one, and the white/orange wire with the white/green one. This action changes a crossover connection into a straight-through connection and vice versa.
	The Ethernet parameters of the <i>WirelessHART</i> gateway are incorrect.	Check the Ethernet parameters of the <i>WirelessHART</i> gateway. See chapter 5.3.2
	The Local Area Connection Properties of your PC are not configured correctly.	Configure the Local Area Connection according to the instructions given. See chapter 4.1
	If you are parameterizing via the web interface: Maybe your web browser uses proxies.	Deactivate proxies in your browser.
The host is not able to establish a serial connection to the <i>WirelessHART</i> gateway.	Wrong parameters (e.g. COM port, address range) are set in the communication DTM.	Check the parameters in the communication DTM. See chapter 6.2 Also check the baud rate/polling address configured via the DIP switches inside the enclosure. See chapter 2.3.2
The host is not able to establish a serial connection to the <i>WirelessHART</i> gateway, or the signal quality is poor.	The terminator is not activated.	If the RS-485 bus ends at the <i>WirelessHART</i> gateway, activate the terminator by setting DIP switch number 7 to ON (see chapter 2.3.2) or by using the serial interface (see chapter 5.3.1).

10.3 Wireless Communication Faults

Fault	Possible cause	Corrective action
The <i>WirelessHART</i> gateway cannot find a <i>WirelessHART</i> device in the network.	The device has not yet joined the network.	The joining process may take a while. Check the join status in the instrument list of the <i>WirelessHART</i> gateway. Alternatively, check the wireless communication parameters (join status) of the device via a HART modem connected to the device.
	The device carries the wrong network ID and/or the wrong join key.	Check the wireless communication parameters of the device via a HART modem connected to the device. The device and the <i>WirelessHART</i> gateway must have the same network ID and join key.
	There are not enough neighboring <i>WirelessHART</i> devices within the device's antenna range.	Check the number of neighbors (Diagnosis > Wireless Communication). There should be at least 2 neighbors.
The wireless connection to a <i>WirelessHART</i> device is poor and disappears from time to time	There are not enough neighboring <i>WirelessHART</i> devices within the device's antenna range.	Check the number of neighbors (Diagnosis > Wireless Communication). There should be at least 2 neighbors.
	Walls or other static/moving objects block the radio signals, or the antenna is not aligned vertically.	Check the position of the <i>WirelessHART</i> gateway or use an external antenna. See chapter 3.1

11 Technical Specifications

11.1 WHA-GW-F2D2-0-*-Z2-ETH

Supply	
Rated voltage	20 ... 30 V DC SELV/PELV
Power consumption	< 5 W
External bus	
Connection	screw terminals for - 0.2 ... 4 mm ² (rigid wire) - 0.2 ... 2.5 mm ² (flexible wire)
Interface 1	Ethernet 10 BASE-T/100 BASE-TX , full galvanic isolation
Protocol	HART UDP, MODBUS TCP
Cable length	max. 100 m , depending on cables and transfer rate
Connection	UTP, STP or FTP
Interface 2	RS-485
Protocol	HART, MODBUS RTU
Daisy-chain capability	supported by duplicated connection terminals
Transfer rate	max. 115 kBit/s
Cable length	max. 1200 m , depending on cables and transfer rate
Bus termination	integrated termination resistor , adjustable via DIP switch and software
Input	
Number of channels	250
Interface	omnidirectional dipole antenna, removable
Communication	<i>WirelessHART</i> specifications - physical layer: IEEE 802.15.4.2006 - frequency band: 2.4 GHz (ISM band, licence free) - transmission rate: 250 kBit/s - max. transmit power: +10 dBm (EIRP) - transmission range: outdoor 250 m, indoor 50 m (under reference conditions) - communication standard: <i>WirelessHART</i>
Electrical isolation	
Interface/power supply	basic insulation according to IEC 61140, rated insulation voltage 50 V _{eff}
Interface/interface	basic insulation according to IEC 61140, rated insulation voltage 50 V _{eff}
Indicators/settings	
Display elements	LED PWR (power supply status), one green LED LED COM (communication status), three yellow LEDs LED FLT (fault signal), one green LED
Control elements	2 push buttons: - restore HART configuration - restore communication configuration DIP switches: - baud rate - RS-485 address - RS-485 termination - security mode

2015-07

Directive conformity	
Electromagnetic compatibility	
Directive 2004/108/EC	EN 61326-1:2006
Radio and telecommunication terminal equipment	The usage of 2.4 GHz equipment is bound to local restrictions. Ensure that restrictions allow usage of this product before commissioning.
Directive 99/5/EC	EN 300328: V1.7.1 EN 301489-17: V1.3.2
FCC CFR47 Part 15 B and C	ANSI C63.4-2003
Conformity	
Degree of protection	IEC 60529
Shock resistance	EN 60068-2-27
Vibration resistance	EN 60068-2-6
Ambient conditions	
Ambient temperature	-20 ... 60 °C (-4 ... 140 °F)
Storage temperature	-40 ... 85 °C (-40 ... 185 °F)
Relative humidity	5 ... 95 %, noncondensing
Corrosion resistance	acc. to ISA-S71.04-1985, severity level G3 test setup and execution acc. to EN 60068-2-60
Mechanical specifications	
Degree of protection	IP66/IP67
Mass	approx. 1 kg
Dimensions	258 mm x 114 mm x 84 mm without antenna and cable glands
Mounting	panel mounting
Data for application in connection with Ex-areas	
EC-Type Examination Certificate	FM 12 ATEX 0061 , for additional certificates see www.pepperl-fuchs.com
Group, category, type of protection, temperature class	 II 3 G Ex nA nC IIC T4 Gc
Directive conformity	
Directive 94/9/EC	EN 60079-0:2012 EN 60079-15:2010
General information	
Supplementary information	EC-Type Examination Certificate, Statement of Conformity, Declaration of Conformity, Attestation of Conformity and instructions have to be observed where applicable. For information see www.pepperl-fuchs.com .



11.2 Telecommunication Compliance

- ETSI (R&TTE)
- FCC Part 15.247 for wireless applications in the area of 2.4 GHz
- EN 300 328

The usage of 2400 MHz equipment is bound to local restrictions. Ensure that local restrictions allow usage of this device before commissioning.

Country	Guideline
Bulgaria	General authorization required for outdoor use and public service.
Italy	If used outside of own premises, general authorization is required.
Japan	The device is granted pursuant to the Japanese Radio Law and the Japanese Telecommunications Business Law. The device must not be modified (otherwise the granted designation number will become invalid).
Latvia	The outdoor usage of the 2.4 GHz band requires an authorization from the Electronic Communications Office.
Norway	May be restricted in the geographical area within a radius of 20 km from the center of Ny-Alesund.
Rumania	Use on a secondary basis. Individual license required.

12

Appendix

12.1

HART Status Information

HART Device Status

The HART device status or field device status indicates the current operating status of the field device.

Code	Parameter	Description
0x01	Primary Variable Out Of Limits	The PV is beyond its operating limits.
0x02	Non-Primary Variable Out Of Limits	A device variable not mapped on the PV is beyond its operating limits.
0x04	Loop Current Saturated	The loop current has reached its upper (or lower) endpoint limit and cannot increase (or decrease) any further.
0x08	Loop Current Fixed	The loop current is being held at a fixed value and is not responding to process variations.
0x10	More Status Available	More status information is available via command 48.
0x20	Cold Start	A power failure or device reset has occurred.
0x40	Configuration Changed	An operation was performed that changed the configuration of the device.
0x80	Device Malfunction	The device detected a serious error or failure that compromises device operation.

HART Extended Device Status

Code	Parameter	Description
0x01	Maintenance Required	This bit is set to indicate that, while the device has not malfunctioned, the field device requires maintenance.
0x02	Device Variable Alert	This bit is set if any device variable is in an alarm or warning state. The host should identify the device variable(s) causing this to be set using the device variable status indicators.
0x04	Critical Power Failure	For battery powered devices. This bit is set when the power is becoming critically low. Devices must be able to sustain their network connection for at least 15 minutes from when this bit is set.
0x08	Failure	When this bit is set, one or more device variables (for example, measurement or control values) are invalid due to a malfunction of the field device or its peripherals.
0x10	Out Of Specification	When set, this bit indicates deviations from the permissible ambient or process conditions have been detected that may compromise measurement or control accuracy (for example, device performance may be degraded given current operating conditions).
0x20	Function Check	This bit is set if one or more device variables are temporarily invalid (for example, frozen) due to ongoing work on the device.

Command 48

Command 48 returns additional status information that is not included in the HART device status response code.

All field devices must support at least bytes 0 ... 8. Thus, the minimum response length of command 48 is 9 bytes. If a field device supports more than one analog channel, bytes 9 ... 13 must be supported as well. In this case, the minimum response length of command 48 is 14 bytes.

Response Data Bytes

Byte	Parameter	Description
0	Device-Specific Status 0 Extended Device Malfunction	■ 0x01 Manager Fault ■ 0x02 Non-Volatile Memory Defect ■ 0x04 Volatile Memory Defect ■ 0x08 Ethernet Communication Fault ■ 0x10 Wired Device Duplicated ■ 0x20 Long Tag Duplicated ■ 0x40 Electronic Defect ■ 0x80 RS-485 Communication Fault
1	Device-Specific Status 1 Gateway Operation in Progress	■ 0x02 Block Transfer (not supported) ■ 0x04 Delayed Answer ■ 0x08 Self-Test (not supported) ■ 0x20 Device List Update ■ 0x40 Network Manager Reset In Progress ■ 0x80 Start-Up Phase
2	Device-Specific Status 2 Extended Lists Changes	■ 0x01 Instrument List Changed ■ 0x04 Active Device List Changed
3	Device-Specific Status 3 Cumulative Device Status	■ 0x01 Primary Variable Out Of Limits ■ 0x02 Non-Primary Variable Out Of Limits ■ 0x04 Loop Current Saturated ■ 0x08 Loop Current Fixed ■ 0x10 More Status Available ■ 0x20 Cold Start ■ 0x40 Configuration Changed ■ 0x80 Device Malfunction
4	Device-Specific Status 4 Device Operation in Progress	■ 0x01 Maintenance Required ■ 0x02 Device Variable Alert ■ 0x04 Critical Power Failure
5	Device-Specific Status 5 Device Operation in Progress	■ 0x02 "Configuration Changed Bit Reset" Procedure ■ 0x04 "Sub-Device Update" Procedure ■ 0x08 "Device Update" Procedure
6	Extended Device Status	Not available

2015-07

Byte	Parameter	Description
7	Device Operating Mode	Not available
8	Standardized Status 0 Standardized Device Malfunction	■ 0x01 Simulation Active The device is in simulation mode and one or more of its device variables are not representative of the process. ■ 0x02 Non-Volatile Memory Defect The non-volatile memory check is invalid or corrupt, or the battery of a battery-powered memory is defective. ■ 0x04 Volatile Memory Defect The RAM memory check is invalid or corrupt. ■ 0x08 Watchdog Reset Executed A watchdog reset has been executed. ■ 0x10 Environmental Conditions Out Of Range An internal or environmental condition is beyond acceptable limits. ■ 0x20 Power Supply Conditions Out Of Range The power supply is outside its allowable range. ■ 0x40 Electronic Defect A hardware problem has been detected.
9	Standardized Status 1	Not available
10	Analog Channel Saturated	Not available
11	Standardized Status 2 Standardized Lists Changes	■ 0x01 Instrument List Changed When set, the gateway has lost communication with one of its sub-devices or discovered a new sub-device. This bit is reset if command 74 is issued. The current sub-device list is read using command 84. ■ 0x02 Duplicate Master Detected The adapter has discovered another master with the same address connected to its token-passing interface.
12	Standardized Status 3	Not available
13	Analog Channel Fixed	Not available
14 ... 24	Device-Specific Status Information	Not available

12.2 MODBUS Status Information

MODBUS-Specific Status

Code	Parameter	Description
0x01 (LSB)	Cache Validity	Set to 1 when the cache of the device for HART command 3 is empty.
0x02 (LSB)	Identification Ongoing	Set to 1 when the gateway is performing a device identification procedure.
LSB: lower significant byte		

12.3 CSV File Structure

Use a semicolon ; as separator for the values in the CSV file. If a value already contains a semicolon you must put the value into quote signs ". If the value already contains quote signs, put the entire value into quote signs " and replace the original quote signs with two quote signs "".



Example!

The value **this is a "long tag" that contains quote signs** must be entered like this:
"this is a ""long tag"" that contains quote signs"

Avoid special characters. They can easily be corrupted or they can cause the whole data row to be skipped during the import of the CSV file.

Avoid leading blanks, trailing blanks, and tabs, especially for integer or hexadecimal values.

Respect the data type of each column.

If a mandatory column is missing, the whole file is rejected and nothing is imported.

If a mandatory value is missing, the corresponding data row is skipped.

MODBUS Mapping

The files for the MODBUS mapping contain the following columns.

File Structure

Expanded Device Type Code	Device Id	IO-Card	Channel	Long Tag	Register	Register Type	Information Code	Mapping Code
4 digits hex	6 digits hex	int decimal	int decimal	string[32]	int decimal	int decimal	int decimal	int decimal
				mandatory	mandatory	mandatory	mandatory	mandatory

The data in the **RegisterType**, **InformationCode**, and **MappingCode** columns is encoded as described in the tables below.

RegisterType Codes

Value	Description
1	Discrete Input
3	Input Register

InformationCode Codes

Value	Description
0	HART Status (RegisterType Code = 3)
1	CMD 48 Status (RegisterType Code = 3)
2	Device Variables (RegisterType Code = 3)
3	MODBUS Status (RegisterType Code = 3)
4	Discrete Variables (RegisterType Code = 3)

Note that the **MappingCode** codes depend on the **InformationCode** code.

MappingCode Codes

Information Code	Value	Description
0 (HART Status)	0	Device Status
	1	Extended Device Status
	2	Device Status & Extended Device Status
1 (CMD 48 Status)	0 ... 12	CMD 48 status word to be mapped 0 maps CMD 48 bytes 0&1 1 maps CMD 48 bytes 2&3 and so on Note: 12 maps CMD 48 byte 24 only
2 (Device Variable)	0 ... 242	Device Variables For more information on what device-specific information is available and on the device-specific unit codes, see the manual of the sub-device.
	243	Battery Life
	244	Percent Range
	245	Loop Current
	246	Primary Variable
	247	Secondary Variable
	248	Tertiary Variable
	249	Quaternary Variable
	255	Slot 0 data time stamp
3 (MODBUS Status)	0	"Mod Stat" information
4 (Discrete Variable - LSB)	0 ... 255	Discrete Variable Index The less significant byte of the variable is mapped.
5 (Discrete Variable - MSB)	0 ... 255	Discrete Variable Index The most significant byte of the variable is mapped.
6 (Network Statistic)	0	Reliability
	1	Stability
	2	Latency
	3	Lost Upstream Packets
LSB: least significant byte MSB: most significant byte		

Instrument List

The files for the instrument list contain the following columns.

File Structure

Expanded Device Type Code	Device Id	IO-Card	Channel	Long Tag
4 digits hex	6 digits hex	int decimal	int decimal	string[32]
				mandatory

Topology View

The files for the topology view contain the following columns.

Note that the X- and Y-origins of the background image are not part of the CSV file, as these coordinates are related to the background image.

File Structure

Expanded Device Type Code	Device Id	IO-Card	Channel	Long Tag	Units Code	Range	X-Coordinate	Y-Coordinate	Z-Coordinate
4 digits hex	6 digits hex	int decimal	int decimal	string[32]	int decimal	float decimal	float decimal	float decimal	float decimal
				mandatory			mandatory	mandatory	

Diagnostic Details

The files you can export under **Diagnostics > Wireless Communication > Details** contain the following columns. There are no mandatory columns as there is no import function. Nevertheless, you can export the data in CSV format for documentation.

File Structure

Expanded Device Type Code	Device Id	IO-Card	Channel	Long Tag	Status	Device Status	Number Of Joins	Recent Join Date	Reliability	Latency	Neighbors	RSSI	Stability
4 digits hex	6 digits hex	int decimal	int decimal	string[32]	2 digits hex	2 digits hex	int decimal	yyyy: mm: hh: m: ss	float	float	string[32]	int decimal	float

12.4 Supported Commands

The following tables show the HART commands supported by the device.



Note!

Unlike a HART multiplexer the *WirelessHART* gateway only accepts commands directly addressed to its HART slave address.

12.4.1 Universal Commands

Command	Action	Description	
Identity Commands			
0		Read unique identifier	12 Bytes device identifier are given in the response
11		Read unique identifier using tag	12 Bytes device identifier are given in the response, if the given tag complies to the tag of the gateway
21		Read unique identifier using long tag	12 Bytes device identifier are given in the response, if the given long tag complies to the long tag of the gateway
Static Parameter Commands			
13		Read tag, descriptor, date	Read the 8 digit tag, the 16 digit description and the date.
18		Write tag, descriptor, date	Write the 8 digit tag, the 16 digit description and the date
12		Read message	Read the 32 digit message
17		Write message	Write the 32 digit message
20		Read long tag	Read the 32 digit long tag
22		Write long tag	Write the 32 digit long tag
16		Read final assembly number	
19		Write final assembly number	
Status Commands			
38		Reset configuration changed flag	Reset the "Configuration changed" response code
48		Read additional status	

12.4.2 Common Practice Commands

Command		Action	Description
Device Management Commands			
41		Perform device self test	Initiates the self test function in the device
42		Perform device reset	Immediately after the response the microprocessor of the device will be reset.
89		Set real-time clock	12 Bytes device identifier are given in the response, if the given long tag complies to the long tag of the gateway.
90		Read real-time clock	
512		Read country code	

Command	Action	Description
513		Write country code
Data Link Layer Commands		
59		Write number of response preambles
		The number of preambles insert in response telegrams can vary from 2 to 20. Default setting is 4.
106		Flush delayed response buffers
		Flush all gateway DR buffers.
I/O System Commands		
74		Read I/O system capabilities
		Also returns number of detected devices.
77		Send command to sub-device using card/channel
		Request embeds full Hart command.
85		Read I/O channel statistics using card/channel
		Read channel communication statistics.
86		Read sub-device statistics using list index
		Read device communication statistics.
84		Read sub-device identity summary using list index
		Allows to read the Instrument list (a single item at a time).
I/O System (HOST I/F) Commands		
88		Write I/O system retry count
94		Read I/O system host statistics
		Read host I/F communication statistics.

12.4.3 Wireless Commands

Command	Action	Description
Network information commands		
768		Write join key
		Write the network's unique join key. Only possible in (see chapter 5.2.1).
773		Write network ID
		Write the unique network ID.
774		Read network ID
		Read the unique network ID.
775		Write network tag
		Write the network tag. The network tag identifies the device in the <i>WirelessHART</i> network.
776		Read network tag
		Read the network tag.
794		Read UTC time mapping
		Read the time setting for the network.
797		Write Radio Power
798		Read Radio Power
840		Read Network Device's Statistics
Active / White / Black lists commands		
814		Read Device List entries using list index
816		Delete device List table entry using unique ID
821		Write network access mode
822		Read network access mode

12.4.4 Device Commands

Command		Action	Description
835		Read network device burst mode list using unique ID	Read the device burst message list.
836		Flush device cached responses using unique ID	Instructs the gateway to flush all cached responses for the relevant device.

12.5 Software License

Open Source Software Information

The product you have bought uses open source software. According to the open source license terms and conditions for the use of the open source software we provide you with the following information:

1. Under the program source code you will find a list of the different open source software embedded in the product. The program source code is available under www.pepperl-fuchs.com.
2. In the list the copyright owners of the respective open source software are named.
3. Under the program source code the license terms and conditions for the use of the different open source software are available.
4. The sublicense for the use of the open source software embedded in the product is granted to you under the same license terms and conditions as required by the copyright owners (see Nr. 3 above).
5. We expressly point out that the license terms and conditions contain extensive limitations of liability.

PROCESS AUTOMATION – PROTECTING YOUR PROCESS



For more VEGA product please visit: www.ainstru.com
Mail: Sales@ainstru.com

Worldwide Headquarters

Pepperl+Fuchs GmbH
68307 Mannheim · Germany
Tel. +49 621 776-0
E-mail: info@de.pepperl-fuchs.com

For the Pepperl+Fuchs representative
closest to you check www.pepperl-fuchs.com/contact

www.pepperl-fuchs.com

Subject to modifications
Copyright PEPPERL+FUCHS • Printed in Germany

 **PEPPERL+FUCHS**
PROTECTING YOUR PROCESS

/ TDOCT-1898HENG
07/2015